


Fuel Tank Filler Door Lock Actuator Replacement



Callout	Component Name
<b>Preliminary Procedure</b> Remove the fuel tank filler housing. Refer to <a href="#">Fuel Tank Filler Pipe Housing Replacement</a> .	
1	Fuel Tank Filler Door Lock Actuator Rod
2	Fuel Tank Filler Door Lock Actuator