

OWNER'S MANUAL

TE 125 EU

TE 250 EU

TE 250 AUS

TE 250 USA

TE 300 EU

TE 300 AUS

TE 300 USA

2013

Art. no. 3802032en



HUSABERG
PURE ENDURO

Congratulations on your decision to purchase a HUSABERG motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it accordingly.

We wish you a lot of enjoyment in riding this vehicle.

Enter the serial numbers of your vehicle below.

Chassis number (☛ p. 12)	Dealer's stamp
Engine number (☛ p. 12)	
Key number (TE EU/AUS) (☛ p. 12)	

The Owner's Manual contained the latest information for this model at the time of going to print. Slight deviations resulting from continuing development and design can, however, not be completely excluded.

All specifications are non-binding. HUSABERG, a division of KTM Sportmotorcycle AG (referred to below as HUSABERG) specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. HUSABERG accepts no liability for delivery options, deviations from illustrations and descriptions or misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2012 KTM-Sportmotorcycle AG / Division HUSABERG, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

Within the meaning of the international quality management standard ISO 9001, HUSABERG uses quality assurance processes that lead to the maximum possible quality of the products.




Issued by: TÜV Management Service













































REG.NO. 12 100 6061

KTM-Sportmotorcycle AG / Division HUSABERG
5230 Mattighofen, Austria

TABLE OF CONTENTS

2

1	MEANS OF REPRESENTATION	5	6.14.17	Display mode SPEED/S1 (stop watch 1).....	21
1.1	Symbols used	5	6.14.18	Display mode SPEED/S2 (stop watch 2).....	21
1.2	Formats used.....	5	6.14.19	Table of functions.....	22
2	SAFETY ADVICE.....	6	6.14.20	Table of conditions and menu activation	22
2.1	Use definition - intended use	6	6.15	Opening the filler cap.....	22
2.2	Safety advice.....	6	6.16	Closing the filler cap	23
2.3	Degrees of risk and symbols	6	6.17	Fuel tap	23
2.4	Tampering warning.....	6	6.18	Choke	23
2.5	Safe operation	7	6.19	Shift lever	24
2.6	Protective clothing	7	6.20	Kick starter	24
2.7	Work rules.....	7	6.21	Foot brake lever.....	24
2.8	Environment.....	7	6.22	Side stand.....	24
2.9	Owner's Manual	8	6.23	Steering lock (TE EU/AUS).....	25
3	IMPORTANT NOTES.....	9	6.24	Locking the steering (TE EU/AUS)	25
3.1	Warranty	9	6.25	Unlocking the steering (TE EU/AUS)	25
3.2	Operating and auxiliary substances	9	7	PREPARING FOR USE.....	26
3.3	Spare parts, accessories	9	7.1	Advice on first use	26
3.4	Service	9	7.2	Running in the engine.....	27
3.5	Figures	9	7.3	Preparing the vehicle for difficult riding conditions	27
3.6	Customer service.....	9	7.4	Preparing for rides on dry sand	28
4	VIEW OF VEHICLE	10	7.5	Preparing for rides on wet sand	28
4.1	View of vehicle, front left (example)	10	7.6	Preparing for rides on wet and muddy surfaces	29
4.2	View of vehicle, rear right (example)	11	7.7	Preparing for rides at high temperature and slow speed	29
5	SERIAL NUMBERS	12	7.8	Preparing for rides at low temperature and in snow.....	30
5.1	Chassis number	12	8	RIDING INSTRUCTIONS	31
5.2	Type label	12	8.1	Checks and maintenance steps when preparing for use	31
5.3	Key number (TE EU/AUS)	12	8.2	Starting.....	31
5.4	Engine number	12	8.3	Starting off.....	32
5.5	Fork part number	12	8.4	Shifting, riding	32
5.6	Shock absorber part number	13	8.5	Braking.....	32
6	CONTROLS.....	14	8.6	Stopping, parking.....	33
6.1	Clutch lever.....	14	8.7	Transport	33
6.2	Hand brake lever.....	14	8.8	Refueling	34
6.3	Throttle grip	14	9	SERVICE SCHEDULE	35
6.4	Kill switch (TE EU/AUS)	14	9.1	Service schedule.....	35
6.5	Kill switch (TE USA)	14	9.2	Service work (as additional order)	36
6.6	Horn button (TE EU/AUS)	15	10	TUNING THE CHASSIS	37
6.7	Light switch (TE EU/AUS).....	15	10.1	Checking the basic chassis setting with the rider's weight.....	37
6.8	Light switch (TE USA)	15	10.2	Compression damping of shock absorber	37
6.9	Turn signal switch (TE EU/AUS)	15	10.3	Adjusting the low-speed compression damping of the shock absorber	37
6.10	Emergency OFF switch (TE AUS).....	15	10.4	Adjusting the high-speed compression damping of the shock absorber.....	38
6.11	Electric starter button (TE 250/300 EU/USA)	16	10.5	Adjusting the rebound damping of the shock absorber.....	38
6.12	Electric starter button (TE AUS)	16	10.6	Measuring the sag of the unloaded rear wheel....	39
6.13	Overview of indicator lamps (TE EU/AUS).....	16	10.7	Checking the static sag of the shock absorber	39
6.14	Speedometer	16	10.8	Checking the riding sag of the shock absorber....	40
6.14.1	Speedometer overview	16	10.9	Adjusting the spring preload of the shock absorber 	40
6.14.2	Activation and test.....	16	10.10	Adjusting the riding sag 	41
6.14.3	Tripmaster switch	17	10.11	Checking the basic setting of the fork	41
6.14.4	Setting kilometers or miles	17	10.12	Adjusting the compression damping of the fork	42
6.14.5	Adjusting the speedometer functions	17	10.13	Adjusting the rebound damping of the fork	42
6.14.6	Setting the clock	18	10.14	Handlebar position.....	43
6.14.7	Querying lap time	18	10.15	Adjusting the handlebar position 	43
6.14.8	Display mode SPEED (speed).....	19			
6.14.9	Display mode SPEED/H (operating hours).....	19			
6.14.10	Display mode SPEED/CLK (clock).....	19			
6.14.11	Display mode SPEED/LAP (lap time).....	19			
6.14.12	Display mode SPEED/ODO (odometer)	20			
6.14.13	Display mode SPEED/TR1 (trip master 1).....	20			
6.14.14	Display mode SPEED/TR2 (trip master 2).....	20			
6.14.15	Display mode SPEED/A1 (average speed 1) ...	21			
6.14.16	Display mode SPEED/A2 (average speed 2) ...	21			

11	SERVICE WORK ON THE CHASSIS.....	44	12.3	Adjusting the basic position of the hand brake lever (TE USA).....	69
11.1	Raising the motorcycle with the lift stand.....	44	12.4	Checking the brake discs.....	70
11.2	Removing the motorcycle from the lift stand.....	44	12.5	Checking the front brake fluid level.....	70
11.3	Bleeding the fork legs.....	44	12.6	Adding front brake fluid 	70
11.4	Cleaning the dust boots of the fork legs.....	45	12.7	Checking the front brake linings.....	71
11.5	Loosening the fork protection.....	45	12.8	Changing the front brake linings 	72
11.6	Positioning the fork protection.....	45	12.9	Checking the free travel of the foot brake lever.....	73
11.7	Removing the fork legs 	46	12.10	Adjusting the basic position of the foot brake lever 	73
11.8	Installing the fork legs 	46	12.11	Checking the rear brake fluid level.....	74
11.9	Removing the fork protector 	47	12.12	Adding rear brake fluid 	74
11.10	Installing the fork protector 	47	12.13	Checking the rear brake linings.....	75
11.11	Removing the lower triple clamp 	47	12.14	Changing the rear brake linings 	75
11.12	Installing the lower triple clamp 	48	13	WHEELS, TIRES.....	77
11.13	Checking the play of the steering head bearing.....	49	13.1	Removing the front wheel 	77
11.14	Adjusting the play of the steering head bearing 	50	13.2	Installing the front wheel 	77
11.15	Greasing the steering head bearing 	50	13.3	Removing the rear wheel 	78
11.16	Removing the front fender.....	51	13.4	Installing the rear wheel 	78
11.17	Installing the front fender.....	51	13.5	Checking the tire condition.....	79
11.18	Removing the shock absorber 	51	13.6	Checking the tire air pressure.....	80
11.19	Installing the shock absorber 	52	13.7	Checking the spoke tension.....	80
11.20	Removing the seat.....	53	14	ELECTRICAL SYSTEM.....	82
11.21	Mounting the seat.....	53	14.1	Removing the battery  (TE 250/300).....	82
11.22	Removing the air filter box lid.....	53	14.2	Installing the battery  (TE 250/300).....	82
11.23	Installing the air filter box lid.....	53	14.3	Recharging the battery  (TE 250/300).....	82
11.24	Removing the air filter 	53	14.4	Changing the main fuse (TE 250/300).....	83
11.25	Installing the air filter 	54	14.5	Removing the headlight mask with the headlight.....	84
11.26	Cleaning the air filter and air filter box 	54	14.6	Installing the headlight mask with the headlight.....	84
11.27	Sealing the air filter box 	55	14.7	Changing the headlight bulb.....	85
11.28	Removing the main silencer.....	55	14.8	Changing the turn signal bulb (TE EU/AUS).....	85
11.29	Installing the main silencer.....	55	14.9	Checking the headlight setting.....	86
11.30	Changing the glass fiber yarn filling of the main silencer 	56	14.10	Adjusting the headlight range.....	86
11.31	Removing the right side cover.....	56	14.11	Changing the speedometer battery.....	86
11.32	Installing the right side cover.....	57	15	COOLING SYSTEM.....	88
11.33	Removing the fuel tank 	57	15.1	Cooling system.....	88
11.34	Installing the fuel tank 	58	15.2	Checking the antifreeze and coolant level.....	88
11.35	Checking the chain for dirt.....	59	15.3	Checking the coolant level.....	89
11.36	Cleaning the chain.....	59	15.4	Draining the coolant 	89
11.37	Checking the chain tension.....	59	15.5	Refilling with coolant 	90
11.38	Adjusting the chain tension.....	60	16	TUNING THE ENGINE.....	92
11.39	Checking the chain, rear sprocket, engine sprocket, and chain guide.....	61	16.1	Checking the play in the throttle cable.....	92
11.40	Adjusting the chain guide 	63	16.2	Adjusting the play in the throttle cable 	92
11.41	Checking the frame 	63	16.3	Carburetor.....	92
11.42	Checking the swingarm 	63	16.4	Carburetor - adjusting the idle speed 	93
11.43	Checking the throttle cable routing.....	64	16.5	Emptying the carburetor float chamber 	94
11.44	Checking the rubber grip.....	64	16.6	Checking the basic position of the shift lever.....	95
11.45	Additionally securing the rubber grip.....	65	16.7	Adjusting the basic position of the shift lever 	95
11.46	Adjusting the basic position of the clutch lever.....	65	16.8	Engine characteristic - auxiliary spring (TE 250/300).....	95
11.47	Checking/rectifying the fluid level of the hydraulic clutch.....	65	16.9	Engine characteristic - setting the auxiliary spring  (TE 250/300).....	95
11.48	Changing the hydraulic clutch fluid 	66	17	SERVICE WORK ON THE ENGINE.....	97
11.49	Removing the engine guard.....	67	17.1	Checking the gear oil level.....	97
11.50	Installing the engine guard.....	67	17.2	Changing the gear oil 	97
12	BRAKE SYSTEM.....	69	17.3	Draining the gear oil 	98
12.1	Checking the free travel of the hand brake lever.....	69	17.4	Refilling with gear oil 	98
12.2	Adjusting free travel of hand brake lever (TE EU/AUS).....	69	17.5	Adding gear oil 	99

18	CLEANING, CARE	101
18.1	Cleaning the motorcycle	101
18.2	Checks and maintenance steps for winter operation.....	102
19	STORAGE	103
19.1	Storage	103
19.2	Preparing for use after storage.....	103
20	TROUBLESHOOTING	104
21	TECHNICAL DATA.....	106
21.1	Engine	106
21.1.1	TE 125.....	106
21.1.2	All TE 250	106
21.1.3	All TE 300	107
21.2	Engine tightening torques	108
21.2.1	TE 125.....	108
21.2.2	TE 250/300.....	108
21.3	Capacities	109
21.3.1	Gear oil.....	109
21.3.2	Coolant.....	109
21.3.3	Fuel	109
21.4	Chassis	110
21.5	Electrical system.....	110
21.6	Tires.....	111
21.7	Fork.....	111
21.7.1	TE 125.....	111
21.7.2	TE 250/300.....	111
21.8	Shock absorber.....	112
21.8.1	TE 125.....	112
21.8.2	TE 250/300.....	112
21.9	Chassis tightening torques	113
21.10	Carburetor	114
21.10.1	TE 125.....	114
21.10.2	TE 250 EU	114
21.10.3	TE AUS	114
21.10.4	TE 250 USA	114
21.10.5	TE 300 EU	115
21.10.6	TE 300 USA	115
21.10.7	Carburetor tuning (TE 125) 🏍.....	115
21.10.8	Carburetor tuning (All TE 250) 🏍.....	116
21.10.9	Carburetor tuning (All TE 300) 🏍.....	117
21.10.10	General carburetor tuning 🏍.....	118
22	SUBSTANCES	119
23	AUXILIARY SUBSTANCES	121
24	STANDARDS	123
	INDEX	124

1.1 Symbols used

The symbols used are explained below.



Indicates an expected reaction (e.g., to a work step or a function).



Indicates an unexpected reaction (e.g., to a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. In the interest of your own safety, have these jobs performed by an authorized HUSABERG workshop. There, your motorcycle will be optimally maintained by specially trained experts using the specialist tools required.



Indicates a page reference (more information is provided on the specified page).

1.2 Formats used

The following typographical formats are used.

Specific name	Identifies a proprietary name.
----------------------	--------------------------------

Name®	Identifies a protected name.
--------------	------------------------------

Brand™	Identifies a brand available on the open market.
---------------	--

2.1 Use definition - intended use

(TE EU/AUS)

HUSABERG sport motorcycles are designed and built to withstand the normal stresses and strains of competitive use. The motorcycles comply with currently valid regulations and categories of the top international motorsport organizations.



Info

The vehicle should only be used by trained persons. The motorcycle is authorized for public road traffic in the homologated (reduced) version only.

In the derestricted version, the motorcycle must be used only on closed off properties remote from public road traffic.

This motorcycle is designed for use in offroad endurance competition and not primarily for use in motocross.

(TE USA)

HUSABERG sport motorcycles are designed and built to withstand the normal stresses and strains of competitive use. The motorcycles comply with currently valid regulations and categories of the top international motorsport organizations.



Info

The motorcycle may only be used in closed off areas remote from public road traffic.

This motorcycle is designed for use in offroad endurance competition and not primarily for use in motocross.

2.2 Safety advice

A number of safety instructions need to be followed to operate the vehicle safely. Therefore, read this manual carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



Info

The vehicle has various information and warning labels at prominent locations. Do not remove information/warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.3 Degrees of risk and symbols



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Warning

Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

2.4 Tampering warning




Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencer, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of any part of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing any moving part of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

2.5 Safe operation

-  **Danger**
Danger of accidents Danger arising from the rider's judgement being impaired.
- Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.
-  **Danger**
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.
- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
-  **Warning**
Danger of burns Some vehicle components become very hot when the vehicle is operated.
- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.


Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

The vehicle should only be used by trained persons. An appropriate driver's license is needed to ride the vehicle on public roads.

Have malfunctions that impair safety promptly eliminated by an authorized HUSABERG workshop.

Adhere to the information and warning labels on the vehicle.

2.6 Protective clothing

-  **Warning**
Risk of injury Missing or poor protective clothing presents an increased safety risk.
- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.

In the interest of your own safety, HUSABERG recommends that you only operate the vehicle while wearing protective clothing.

2.7 Work rules

Special tools are needed for certain tasks. They are not included with the vehicle but can be ordered under the number in parentheses. E.g.: bearing puller (15112017000)

When the vehicle is assembled, non-reusable parts (e.g., self-locking screws and nuts, gaskets, seal rings, O-rings, splints, lock washers) must be replaced with new parts.

Where thread lockers are used on screw connections (e.g., **Loctite®**), follow the instructions for use from the manufacturer.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Replace damaged or worn parts.

After you complete the repair or maintenance work, check the roadworthiness of the vehicle.

2.8 Environment

Motorcycling is a wonderful sport and we naturally hope that you can enjoy it to the full. However, it is a potential problem for the environment and can lead to conflicts with other persons. But if you use your motorcycle responsibly, you can ensure that such problems and conflicts do not have to occur. To protect the future of motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

2.9 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and maintain your motorcycle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury.

Keep the Owner's Manual in an accessible place to enable you to refer to it as needed.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized HUSABERG dealer.

The Owner's Manual is an important component of the vehicle and should be handed over to the new owner if the vehicle is sold.

3.1 Warranty

The work prescribed in the service schedule must be carried out by an authorized HUSABERG workshop only and confirmed in the customer's service booklet and in the **HUSABERG dealer.net**; otherwise, all manufacturer warranty claims shall be void. No manufacturer warranty claims can be considered for damage resulting from manipulations and/or alterations to the vehicle.

3.2 Operating and auxiliary substances



Warning

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.

Use operating and auxiliary substances (such as fuel and lubricants) as specified in the Owner's Manual.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by HUSABERG and have them installed by an authorized HUSABERG workshop. HUSABERG accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessories are specified in parentheses in the descriptions. Your HUSABERG dealer will be glad to advise you.

The current **HUSABERG Pure Tech** parts for your vehicle can be found on the HUSABERG website.
International HUSABERG website: www.husaberg.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. Incorrect adjustment and tuning of the engine and chassis can lead to damage and breakage of components.

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

3.6 Customer service

Your authorized HUSABERG dealer will be happy to answer any questions you may have on your vehicle and HUSABERG.


A list of authorized HUSABERG dealers can be found on the HUSABERG website.
International HUSABERG website: www.husaberg.com

4.1 View of vehicle, front left (example)



1	Filler cap
2	Air filter box lid
3	Fuel tap (☛ p. 23)
4	Choke (☛ p. 23)
5	Shift lever (☛ p. 24)
6	Side stand (☛ p. 24)


4.2 View of vehicle, rear right (example)



L00312-10


1	Fork compression adjustment
2	Clutch lever (☛ p. 14)
3	Kill switch (☛ p. 14)
3	Horn button (☛ p. 15)
3	Light switch (☛ p. 15)
3	Turn signal switch (☛ p. 15)
4	Speedometer overview (☛ p. 16)
5	Emergency OFF switch (☛ p. 15)
5	Electric starter button (☛ p. 16)
6	Throttle grip (☛ p. 14)
7	Hand brake lever (☛ p. 14)
8	Fork rebound adjustment
9	Shock absorber rebound adjustment
10	Level viewer for brake fluid, rear
11	Shock absorber compression adjustment
12	Foot brake lever (☛ p. 24)
13	Kick starter (☛ p. 24)

5.1 Chassis number




The chassis number ❶ is stamped on the right side of the steering head.

5.2 Type label




The type label ❶ is fixed to the front of the steering head.

5.3 Key number (TE EU/AUS)




The key number ❶ is stamped on the key strap.

5.4 Engine number




The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

5.5 Fork part number




The fork part number ❶ is stamped on the inner side of the fork stub.

5.6 Shock absorber part number



The shock absorber part number ❶ is stamped on the upper part of the shock absorber above the adjusting ring.

6.1 Clutch lever




The clutch lever ❶ is fitted on the left side of the handlebar. The clutch is hydraulically operated and self-adjusting.

6.2 Hand brake lever



The hand brake lever ❶ is located on the right side of the handlebar. The hand brake lever is used to activate the front brake.

6.3 Throttle grip



The throttle grip ❶ is fitted on the right side of the handlebar.

6.4 Kill switch (TE EU/AUS)



The kill switch ❶ is fitted on the left side of the handlebar.

Possible states

- Kill switch ☒ in basic position – In this position, the ignition circuit is closed, and the engine can be started.
- Kill switch ☒ pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.5 Kill switch (TE USA)



The kill switch ❶ is fitted on the left side of the handlebar.

Possible states

- Kill switch ☒ in basic position – In this position, the ignition circuit is closed and the engine can be started.
- Kill switch ☒ is pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.6 Horn button (TE EU/AUS)



The horn button ❶ is fitted on the left side of the handlebar.

Possible states

- Horn button ❶ in neutral position
- Horn button ❶ pressed – The horn is operated in this position.

6.7 Light switch (TE EU/AUS)



The light switch ❶ is fitted on the left side of the handlebar.

Possible states

●	Light off – The light switch is turned to the right. In this position, the light is switched off.
☞	Low beam on – The light switch is in the central position. In this position, the low beam and tail light are switched on.
☜	High beam on – The light switch is turned to the left. In this position, the high beam and the tail light are switched on.

6.8 Light switch (TE USA)




The light switch ❶ is on the right of the speedometer.

Possible states

- Light off – Light switch is pressed in up to the stop. In this position, the light is switched off.
- Light on – Light switch is pulled out to the stop. In this position, the low beam and tail light are switched on.

6.9 Turn signal switch (TE EU/AUS)



The turn signal switch ❶ is fitted on the left side of the handlebar.

Possible states

	Turn signal light off – The turn signal switch is in the central position.
☞	Left turn signal on – The turn signal switch is turned to the left.
☜	Right turn signal on – The turn signal switch is turned to the right.

6.10 Emergency OFF switch (TE AUS)




The emergency OFF switch ❶ is fitted on the right side of the handlebar.

Possible states

⊗	Ignition off – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.
⊙	Ignition on – In this position, the ignition circuit is closed, and the engine can be started.

6.11 Electric starter button (TE 250/300 EU/USA)



The electric starter button ❶ is fitted on the right side of the handlebar.

Possible states

- Electric starter button ❶ in the basic position
- Electric starter button ❶ pressed – The electric starter is actuated in this position.

6.12 Electric starter button (TE AUS)



Electric starter button ❶ is fitted on the right side of the handlebar.

Possible states

- Electric starter button ❶ in basic position
- Electric starter button ❶ pressed – In this position, the electric starter is actuated.

6.13 Overview of indicator lamps (TE EU/AUS)




Possible states

	The high beam indicator light lights up blue – The high beam is switched on.
	The turn signal indicator light flashes green – The turn signal is switched on.

6.14 Speedometer


6.14.1 Speedometer overview



- Press the button ❶ to change the display mode or change to one of the Setup menus.
- Press the button ❷ to control different functions.
- Press the button ❸ to control different functions.

i Info
When the vehicle is delivered, only the **SPEED/H** and **SPEED/ODO** display modes are activated.

6.14.2 Activation and test




Activating the speedometer

The speedometer is activated when one of the buttons is pressed or an impulse comes from the wheel speed sensor.

Display test

To enable you to check that the display is functioning properly, all display segments light up briefly.

**WS (wheel size)**

After the display function check, the wheel size **WS** is displayed briefly.

**Info**

The number 2205 equals the circumference of the 21" front wheel with standard tires.

The display then changes to the last selected mode.

6.14.3 Tripmaster switch**(Option: Tripmaster switch)**

The tripmaster switch is used to control the functions of the speedometer from the handlebar.


**Info**

The trip master is an optional accessory.




6.14.4 Setting kilometers or miles**Info**

If you change the unit of measure, the **ODO** value is retained and converted accordingly.


The values **TR1**, **TR2**, **A1**, **A2** and **S1** are cleared when the unit of measure is changed.

**Condition**



The motorcycle is stationary.

- Press the button  briefly and repeatedly until **H** appears at the bottom right of the display.
- Press the button  for 3 - 5 seconds.
 - ✓ The Setup menu is displayed and the active functions are shown.
- Press the button  repeatedly until the **Km/h/Mph** display flashes.

Adjusting Km/h

- Press the button .

Adjusting Mph


- Press the button .
- Press the button  for 3 - 5 seconds.
 - ✓ The settings are stored and the Setup menu is closed.

**Info**




If no button is pressed for 20 seconds, or if no impulse comes from the wheel speed sensor, the settings are automatically saved and the Setup menu is closed.

6.14.5 Adjusting the speedometer functions**Info**


When the vehicle is delivered, only the **SPEED/H** and **SPEED/ODO** display modes are activated.

**Condition**



The motorcycle is stationary.

- Press the button  briefly and repeatedly until **H** appears at the bottom right of the display.
- Press the button  for 3 - 5 seconds.
 - ✓ The Setup menu is displayed and the activated functions are shown.
- Change to the desired function by pressing the button  briefly.
 - ✓ The selected function flashes.

Activating a function


- Press the button .
- ✓ The symbol remains on the screen and the display changes to the next function.

Deactivating the function








- Press the button .
 - ✓ The symbol on the screen goes out and the display changes to the next function.
- All desired functions are activated or deactivated accordingly.
- Press the button  for 3 - 5 seconds.
 - ✓ The settings are stored and the Setup menu is closed.

**Info**

If no button is pressed for 20 seconds, or if no impulse comes from the wheel speed sensor, the settings are automatically saved and the Setup menu is closed.


6.14.6 Setting the clock**Condition**

The motorcycle is stationary.

- Press the button  briefly and repeatedly until **CLK** appears at the bottom right of the display.
- Press the button  for 3 - 5 seconds.
 - ✓ The hour display flashes.
- Set the hour display with the button  and/or button .
- Press the button  briefly.
 - ✓ The next segment of the display flashes and can be set.
- You can set the following segments in the same way as the hours by pressing the button  and the button .

**Info**

The seconds can only be set to zero.


- Press the button  for 3 - 5 seconds.
 - ✓ The settings are stored and the Setup menu is closed.

**Info**






If no button is pressed for 20 seconds, or if no impulse comes from the wheel speed sensor, the settings are automatically saved and the Setup menu is closed.

6.14.7 Querying lap time**Info**

This function can be called up only if lap times are measured.

**Condition**


The motorcycle is stationary.


- Press the button  briefly and repeatedly until **LAP** appears at the bottom right of the display.
- Press the button  briefly.
 - ✓ **LAP 1** appears on the left side of the display.
- Laps 1-10 can be displayed by pressing the button .
- The button  has no function.
- Press the button  briefly.
 - ✓ Next display mode

**Info**

If an impulse is received from the wheel speed sensor, the left side of the display changes back to the **SPEED** mode.

6.14.8 Display mode SPEED (speed)



- Press the button  briefly and repeatedly until **SPEED** appears on the left side of the display.

The current speed is displayed in the **SPEED** display mode.

The current speed can be displayed in **Km/h** or **Mph**.

Info

Making the setting according to the country.


When an impulse comes from the front wheel, the left side of the speedometer display changes to the **SPEED** mode and the current speed is shown.

6.14.9 Display mode SPEED/H (operating hours)



Condition

- The motorcycle is stationary.

- Press the button  briefly and repeatedly until **H** appears at the bottom right of the display.

In display mode **H**, the operating hours of the engine are displayed.





The operating hours counter stores the total traveling time.

Info

The operating hour counter is necessary for ensuring that service work is carried out at the right intervals.


If the speedometer is in **H** display mode at the start of the journey, it automatically changes to the **ODO** display mode.

The **H** display mode is suppressed during the journey.





Press the button  .	No function
Press the button  .	No function
Press the button  for 3 - 5 seconds.	The display changes to the Setup menu of the speedometer functions.
Press the button  briefly.	Next display mode

6.14.10 Display mode SPEED/CLK (clock)





- Press the button  briefly and repeatedly until **CLK** appears at the bottom right of the display.

The time is displayed in **CLK** display mode.

Press the button  .	No function
Press the button  .	No function
Press the button  for 3 - 5 seconds.	The display changes to the Setup menu of the clock.
Press the button  briefly.	Next display mode


6.14.11 Display mode SPEED/LAP (lap time)






- Press the button  briefly and repeatedly until **LAP** appears at the bottom right of the display.


In the **LAP** display mode, up to 10 lap times can be timed with the stop watch.

Info

If the lap time continues after you press the button , 9 memory locations are already occupied.


Lap 10 must be timed with the button .





Press the button  .	Starts or stops the clock.
Press the button  .	Stops the current lap time and saves it, and the stop watch starts the next lap.
Press the button  for 3 - 5 seconds.	The stop watch and the lap time are reset.

Press the button  briefly.	Next display mode
---	-------------------


6.14.12 Display mode SPEED/ODO (odometer)





- Press the button  briefly and repeatedly until **ODO** appears at the bottom right of the display.
- The total distance traveled is displayed in the **ODO** display mode.

Press the button  .	No function
Press the button  .	No function
Press the button  for 3 - 5 seconds.	–
Press the button  briefly.	Next display mode





6.14.13 Display mode SPEED/TR1 (trip master 1)




- Press the button  briefly and repeatedly until **TR1** appears at the top right of the display.
- TR1** (trip master 1) runs constantly and counts to 999.9.
You can use it to measure trips or the distance between refueling stops.
TR1 is coupled with **A1** (average speed 1) and **S1** (stop watch 1).




 **Info**


If 999.9 is exceeded, the values of **TR1**, **A1** and **S1** are automatically reset to 0.0.



Press the button  .	No function
Press the button  .	No function
Press the button  for 3 - 5 seconds.	The TR1 , A1 and S1 displays are reset to 0.0.
Press the button  briefly.	Next display mode





6.14.14 Display mode SPEED/TR2 (trip master 2)




- Press the button  briefly and repeatedly until **TR2** appears at the top right of the display.
- TR2** (trip master 2) runs constantly and counts up to 999.9.
The displayed value can be set manually with the button  and the button . This is a very practical function when riding using the road book.

 **Info**

The **TR2** value can also be corrected manually during the journey with the button  and the button .
If 999.9 is exceeded, the value of **TR2** is automatically reset to 0.0.

Press the button  .	Increases value of TR2 .
Press the button  .	Reduces value of TR2 .
Press the button  for 3 - 5 seconds.	Deletes value of TR2 .
Press the button  briefly.	Next display mode

6.14.15 Display mode SPEED/A1 (average speed 1)



- Press the button briefly and repeatedly until **A1** appears at the top right of the display.

A1 (average speed 1) shows the average speed calculated on the basis of **TR1** (trip master 1) and **S1** (stop watch 1).

The calculation of this value is activated by the first impulse of the wheel speed sensor and ends 3 seconds after the last impulse.

Press the button .	No function
Press the button .	No function
Press the button for 3 - 5 seconds.	The TR1 , A1 and S1 displays are reset to 0.0.
Press the button briefly.	Next display mode

6.14.16 Display mode SPEED/A2 (average speed 2)



- Press the button briefly and repeatedly until **A2** appears at the top right of the display.

A2 (average speed 2) shows the average speed on the basis of the current speed if the stop watch **S2** (stop watch 2) is running.

Info The displayed value can differ from the actual average speed if **S2** is not stopped after the ride.

Press the button .	No function
Press the button .	No function
Press the button for 3 - 5 seconds.	–
Press the button briefly.	Next display mode

6.14.17 Display mode SPEED/S1 (stop watch 1)




- Press the button briefly and repeatedly until **S1** appears at the top right of the display.

S1 (stop watch 1) displays the journey time on the basis of **TR1** and continues when an impulse is received from the wheel speed sensor.

The calculation of this value starts with the first impulse of the wheel speed sensor and ends 3 seconds after the last impulse.

Press the button .	No function
Press the button .	No function
Press the button for 3 - 5 seconds.	Displays of TR1 , A1 and S1 are reset to 0.0.
Press the button briefly.	Next display mode

6.14.18 Display mode SPEED/S2 (stop watch 2)







- Press the button briefly and repeatedly until **S2** appears at the top right of the display.

S2 (stop watch 2) is a manual stop watch.

If **S2** is running in the background, the **S2** display flashes in the speedometer display.

Press the button .	Starts or stops S2 .
Press the button .	No function
Press the button for 3 - 5 seconds.	Displays of S2 and A2 are reset to 0.0.
Press the button briefly.	Next display mode

6.14.19 Table of functions

Display	Press the button  .	Press the button  .	Press the button  for 3 - 5 seconds.	Press the button  briefly.
Display mode SPEED/H (operating hours)	No function	No function	The display changes to the Setup menu of the speedometer functions.	Next display mode
Display mode SPEED/CLK (clock)	No function	No function	The display changes to the Setup menu of the clock.	Next display mode
Display mode SPEED/LAP (lap time)	Starts or stops the clock.	Stops the current lap time and saves it, and the stop watch starts the next lap.	The stop watch and the lap time are reset.	Next display mode
Display mode SPEED/ODO (odometer)	No function	No function	–	Next display mode
Display mode SPEED/TR1 (trip master 1)	No function	No function	The TR1 , A1 and S1 displays are reset to 0.0.	Next display mode
Display mode SPEED/TR2 (trip master 2)	Increases value of TR2 .	Reduces value of TR2 .	Deletes value of TR2 .	Next display mode
Display mode SPEED/A1 (average speed 1)	No function	No function	The TR1 , A1 and S1 displays are reset to 0.0.	Next display mode
Display mode SPEED/A2 (average speed 2)	No function	No function	–	Next display mode
Display mode SPEED/S1 (stop watch 1)	No function	No function	Displays of TR1 , A1 and S1 are reset to 0.0.	Next display mode
Display mode SPEED/S2 (stop watch 2)	Starts or stops S2 .	No function	Displays of S2 and A2 are reset to 0.0.	Next display mode

6.14.20 Table of conditions and menu activation

Display	The motorcycle is stationary.	Menu can be activated
Display mode SPEED/H (operating hours)	•	
Display mode SPEED/CLK (clock)		•
Display mode SPEED/LAP (lap time)		•
Display mode SPEED/TR1 (trip master 1)		•
Display mode SPEED/TR2 (trip master 2)		•
Display mode SPEED/A1 (average speed 1)		•
Display mode SPEED/A2 (average speed 2)		•
Display mode SPEED/S1 (stop watch 1)		•
Display mode SPEED/S2 (stop watch 2)		•

6.15 Opening the filler cap

**Danger****Fire hazard** Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.

**Warning****Danger of poisoning** Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.



Warning


Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Press release button ❶, turn the filler cap counterclockwise, and lift it free.

6.16 Closing the filler cap




- Replace the filler cap and turn clockwise until release button ❶ locks in place.

Info

Run the fuel tank breather hose ❷ without kinks.

6.17 Fuel tap




The fuel tap is found on the left side of the fuel tank.


Tap handle ❶ on the fuel tap can be used to open or close the fuel supply to the carburetor.

Possible states

- Fuel supply closed **OFF** – Fuel cannot flow from the fuel tank to the carburetor.
- Fuel supply open **ON** – Fuel can flow from the fuel tank to the carburetor. The fuel tank empties to the point of reserve capacity.
- Open the fuel reserve supply **RES** – Fuel can flow from the fuel tank to the carburetor. The fuel tank empties fully.



6.18 Choke



The choke knob ❶ is fitted on the left side of the carburetor.

Activating the choke function frees an opening through which the engine can draw extra fuel. This gives a richer fuel-air mixture, which is needed for a cold start.


Info

If the engine is warm, the choke function must be deactivated.


Possible states

- Choke function activated – The choke knob is pulled out all the way.
- Choke function deactivated – The choke knob is pushed in all the way.

6.19 Shift lever



Shift lever ❶ is mounted on the left side of the engine.




The gear positions can be seen in the photograph.
The neutral or idle position is between the first and second gears.

6.20 Kick starter




The kick starter ❶ is fitted on the right side of the engine. The top part can be swiveled.

6.21 Foot brake lever




The foot brake lever ❶ is located in front of the right footrest.
The foot brake lever is used to activate the rear brake.

6.22 Side stand



The side stand ❶ is on the left side of the vehicle.




The side stand is used to park the motorcycle.



Info

When you are riding, side stand **1** must be folded up and secured with rubber band **2**.

6.23 Steering lock (TE EU/AUS)




The steering lock **1** is fitted on the left side of the steering head. The steering lock is used to lock the steering. Steering, and therefore riding, is no longer possible.

6.24 Locking the steering (TE EU/AUS)

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.




- Park the vehicle.
 - Turn the handlebar as far as possible to the right.
 - Insert the key in the steering lock, turn it to the left, press it in, and turn it to the right. Remove the key.
- ✓ Steering is no longer possible.



Info

Never leave the key in the steering lock.

6.25 Unlocking the steering (TE EU/AUS)



- Insert the key in the steering lock, turn it to the left, pull it out, and turn it to the right. Remove the key.
- ✓ You can now steer the bike again.



Info

Never leave the key in the steering lock.

7.1 Advice on first use



Danger

Danger of accidents Danger arising from the rider's judgement being impaired.

- Do not operate the vehicle while under the influence of alcohol, drugs and certain medications or physically or mentally impaired.



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear protective clothing (helmet, boots, gloves, pants and jacket with protectors) every time you ride the vehicle. Always wear protective clothing that is in good condition and meets the legal requirements.



Warning

Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



Warning

Danger of accidents Critical riding behavior due to inappropriate riding.

- Adapt your riding speed to the road conditions and your riding ability.



Warning

Danger of accidents Accident risk caused by presence of a passenger.

- Your vehicle is not designed to carry passengers. Do not ride with a passenger.



Warning

Danger of accidents Failure of brake system.

- If the foot brake lever is not released, the brake linings drag continuously. The rear brake may fail due to overheating. Take your foot off the foot brake lever when you are not braking.



Warning

Danger of accidents Unstable riding behavior.

- Do not exceed the maximum permissible weight and axle loads.



Warning

Risk of misappropriation Usage by unauthorized persons.

- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.



Info

When using your motorcycle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized HUSABERG workshop.
 - ✓ You will receive a delivery certificate and the service booklet at vehicle handover.
- Before your first trip, read the entire operating instructions carefully.
- Get to know the controls.
- Adjust the basic position of the clutch lever. (☞ p. 65)

(TE EU/AUS)

- Adjust the free travel of the hand brake lever. (☞ p. 69)

(TE USA)

- Adjust the basic position of the hand brake lever. (☞ p. 69)
- Adjust the basic position of the foot brake lever. ☞ (☞ p. 73)
- Adjust the basic position of the shift lever. ☞ (☞ p. 95)
- Get used to handling the motorcycle on a suitable piece of land before making a longer trip.



Info

Offroad, you should be accompanied by another person on another machine so that you can help each other.

- Try also to ride as slowly as possible and in a standing position to get a better feeling for the vehicle.
- Do not make any trips that exceed your ability and experience.

- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
- If you carry any baggage, make sure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.



Info

Motorcycles react sensitively to any changes in weight distribution.

- Do not exceed the overall maximum permitted weight and the axle loads.

Guideline

Maximum permissible overall weight	335 kg (739 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)

- Check the spoke tension. (🔧 p. 80)



Info

The spoke tension must be checked after half an hour of operation.

- Run the engine in. (🔧 p. 27)

7.2 Running in the engine

- During the running-in phase, do not exceed the specified engine performance.

Guideline

Maximum engine performance	
During the first 3 operating hours	< 70 %
During the first 5 operating hours	< 100 %

- Avoid fully opening the throttle!

7.3 Preparing the vehicle for difficult riding conditions



Info

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

- Seal the air filter box. 🛠️ (🔧 p. 55)
- Clean the air filter and air filter box. 🛠️ (🔧 p. 54)



Info

Check the air filter approx. every 30 minutes.

- Additionally secure the rubber grip. (🔧 p. 65)
- Check the electrical connector for humidity and corrosion and to ensure it is firmly seated.
 - » If humidity, corrosion, or damage is found:
 - Clean and dry the connector, or change it if necessary.

Difficult riding conditions are:

- Rides on dry sand. (🔧 p. 28)
- Rides on wet sand. (🔧 p. 28)
- Riding on wet and muddy surfaces. (🔧 p. 29)
- Rides at high temperature and slow speed. (🔧 p. 29)
- Riding at low temperature and in snow. (🔧 p. 30)

7.4 Preparing for rides on dry sand



- Check the radiator cap.

Value on radiator cap	1.8 bar (26 psi)
-----------------------	------------------

- » If the displayed value does not equal the setpoint value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

- Change the radiator cap.

- Fit a dust cover on the air filter.

Dust cover for air filter (59006019000)



Info

See the **HUSABERG Pure Tech** fitting instructions.



- Fit a sand cover on the air filter.

Sand cover for air filter (59006022000)



Info

See the **HUSABERG Pure Tech** fitting instructions.

- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized HUSABERG workshop.



- Clean the chain.

Chain cleaner (☛ p. 121)

- Mount the steel sprocket.



Tip

Do not grease the chain.

- Clean the radiator fins.
- Straighten bent radiator fins carefully.
- If used in sand regularly, replace the piston every 10 operating hours.

7.5 Preparing for rides on wet sand



- Check the radiator cap.

Value on radiator cap	1.8 bar (26 psi)
-----------------------	------------------

- » If the displayed value does not equal the setpoint value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



- Change the radiator cap.
- Mount a rain cover on the air filter.

Rain cover for air filter (59006021000)



Info

See the **HUSABERG Pure Tech** fitting instructions.

- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized HUSABERG workshop.

- Clean the chain.

Chain cleaner (☛ p. 121)

- Mount the steel sprocket.



Tip

Do not grease the chain.

- Clean the radiator fins.
- Straighten bent radiator fins carefully.



7.6 Preparing for rides on wet and muddy surfaces



- Mount a rain cover on the air filter.

Rain cover for air filter (59006021000)



Info

See the **HUSABERG Pure Tech** parts fitting instructions.

- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized HUSABERG workshop.

- Mount the steel sprocket.
- Clean the motorcycle. (☛ p. 101)
- Straighten bent radiator fins carefully.



7.7 Preparing for rides at high temperature and slow speed



- Check the radiator cap.

Value on radiator cap

1.8 bar (26 psi)

- » If the displayed value does not equal the setpoint value:



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



- Change the radiator cap.
- Adjust the secondary drive to the road conditions.



Info

The transmission oil heats up quickly when the clutch is operated frequently due to an excessively high secondary drive.

- Clean the chain.

Chain cleaner (🔧 p. 121)

- Clean the radiator fins.
- Straighten bent radiator fins carefully.
- Check the coolant level. (🔧 p. 89)

7.8 Preparing for rides at low temperature and in snow



- Mount a rain cover on the air filter.

Rain cover for air filter (59006021000)



Info

See the **HUSABERG Pure Tech** fitting instructions.

- Adjust the carburetor jetting and setting.



Info

The recommended carburetor tuning is available from your authorized HUSABERG workshop.

8.1 Checks and maintenance steps when preparing for use

**Info**

Before riding the vehicle, always check its condition and operating safety.
The vehicle must be in perfect technical condition when used.

- Check the gear oil level. (🔧 p. 97)
- Check the electrical system.
- Check the front brake fluid level. (🔧 p. 70)
- Check the rear brake fluid level. (🔧 p. 74)
- Check the front brake linings. (🔧 p. 71)
- Check the rear brake linings. (🔧 p. 75)
- Check that the brake system is functioning properly.
- Check the coolant level. (🔧 p. 89)
- Check the chain for dirt. (🔧 p. 59)
- Check the chain, rear sprocket, engine sprocket, and chain guide. (🔧 p. 61)
- Check the chain tension. (🔧 p. 59)
- Check the tire condition. (🔧 p. 79)
- Check the tire air pressure. (🔧 p. 80)
- Check the spoke tension. (🔧 p. 80)
- Clean the dust boots of the fork legs. (🔧 p. 45)
- Bleed the fork legs. (🔧 p. 44)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts, and hose clamps regularly for tightness.
- Check the fuel supply.

8.2 Starting

**Danger**

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.

**Info**

If the motorcycle is unwilling to start, the cause can be old fuel in the float chamber. The flammable elements of the fuel evaporate after a long time of standing.
If the float chamber is filled with fresh fuel, the engine starts immediately.

Engine has been out of use for more than one week

- Empty the carburetor float chamber. 🛠️ (🔧 p. 94)
- Turn tap handle ① on the fuel tap to position **ON**. (Figure L00310-10 🔧 p. 23)
✓ Fuel can flow from the fuel tank to the carburetor.
- Remove the motorcycle from the stand.
- Shift gear to neutral.

(TE AUS)

- Turn the emergency OFF switch to the position ○.

The engine is cold

- Pull the choke knob all the way out.
- Press the electric starter button or press the kick starter robustly through its full range.

**Info**

Do not open the throttle.

8.3 Starting off



Info

Switch on the light before riding. This will make it easier for other road users to see you.
When you are riding, the side stand must be folded up and secured with the rubber band.

- Pull the clutch lever, engage 1st gear, release the clutch lever slowly, and simultaneously open the throttle carefully.

8.4 Shifting, riding



Warning

Danger of accidents If you change down at high engine speed, the rear wheel can lock up.

- Do not change into a low gear at high engine speed. The engine races and the rear wheel can lock up.



Info

If you hear unusual noises while riding, stop immediately, switch off the engine, and contact an authorized HUSABERG workshop.
First gear is used for starting off or for steep inclines.

- When conditions allow (incline, road situation, etc.), you can shift into a higher gear. To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch, and open the throttle.
- If the choke function was activated, deactivate it after the engine has warmed up.
- When you reach maximum speed after fully opening the throttle, turn back the throttle to about 3/4 of its range. This barely reduces vehicle speed but lowers fuel consumption considerably.
- Always open the throttle only as much as the engine can handle – abrupt throttle opening increases fuel consumption.
- To shift down, brake and close the throttle at the same time.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and open the throttle or shift again.
- Switch off the engine if you expect to be standing for a long time.

Guideline

≥ 2 min

- Avoid frequent and longer slipping of the clutch. This heats the engine oil, the engine, and the cooling system.
- Ride with a lower engine speed instead of with a high engine speed and a slipping clutch.

8.5 Braking



Warning

Danger of accidents If you brake too hard, the wheels can lock.

- Adapt your braking to the traffic situation and the road conditions.



Warning

Danger of accidents Reduced braking efficiency caused by spongy pressure point of front or rear brake.

- Check the brake system and do not continue riding. (Your authorized HUSABERG workshop would be pleased to help you.)



Warning

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

- Clean or dry a dirty or wet brake system by riding and braking gently.

- On sandy, wet, or slippery surfaces, use the rear brake.
- Braking should always be completed before you go into a bend. Change down to a lower gear appropriate to your road speed.

8.6 Stopping, parking



Warning

Risk of misappropriation Usage by unauthorized persons.

- Never leave the vehicle while the engine is running. Secure the vehicle against use by unauthorized persons.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.

Note


Material damage Damage and destruction of components by excessive load.

- The side stand is designed for the weight of the motorcycle only. Do not sit on the motorcycle when it is supported by the side stand only. The side stand and/or the frame could be damaged and the motorcycle could fall over.




- Brake the motorcycle.

- Shift gear to neutral.

(TE EU/AUS)

- Press and hold the kill switch  while the engine is idling until the engine stops.

(TE USA)

- Press and hold the kill switch  while the engine is idling until the engine stops.
- Turn tap handle  on the fuel tap to position **OFF**. (Figure L00310-10  p. 23)
- Park the motorcycle on firm ground.

8.7 Transport

Note


Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

Note

Fire hazard Some vehicle components become very hot when the vehicle is operated.

- Do not park the vehicle near flammable or explosive substances. Do not place objects on the vehicle while it is still warm from being run. Always let the vehicle cool first.



- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against accidents or falling over.

8.8 Refueling

Danger
Fire hazard Fuel is highly flammable.


- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.

Warning
Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact of the fuel with skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel.

Warning
Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to get into the ground water, the ground, or the sewage system.



- Switch off the engine.
- Open the filler cap. (🔧 p. 22)
- Fill the fuel tank with fuel up to measurement **A**.

Guideline

Measurement of A	35 mm (1.38 in)	
Total fuel tank capacity, approx.	10.7 l (2.83 US gal)	Super unleaded gasoline, mixed with 2-stroke engine oil (1:60) (🔧 p. 120)
2-stroke engine oil (🔧 p. 119)		

- Close the filler cap. (🔧 p. 23)
















9.1 Service schedule

	S20A	S40A
Check that the electrical equipment is functioning properly.	•	•
Check and charge the battery. 🛠️ (TE 250/300)	•	•
Change the gear oil. 🛠️ (🔧 p. 97)	•	•
Check the front brake linings. (🔧 p. 71)	•	•
Check the rear brake linings. (🔧 p. 75)	•	•
Check the brake discs. (🔧 p. 70)	•	•
Check the brake lines for damage and leakage.	•	•
Check the rear brake fluid level. (🔧 p. 74)	•	•
Check the free travel of the foot brake lever. (🔧 p. 73)	•	•
Check the frame and swingarm. 🛠️	•	•
Check the swingarm bearing. 🛠️		•
Check the heim joints at the top and bottom of the shock absorber. 🛠️	•	•
Check the tire condition. (🔧 p. 79)	•	•
Check the tire air pressure. (🔧 p. 80)	•	•
Check the wheel bearing for play. 🛠️	•	•
Check the wheel hubs. 🛠️	•	•
Check the rim run-out. 🛠️	•	•
Check the spoke tension. (🔧 p. 80)	•	•
Check the chain, rear sprocket, engine sprocket, and chain guide. (🔧 p. 61)	•	•
Check the chain tension. (🔧 p. 59)	•	•
Grease all moving parts (e.g. side stand, hand lever, chain, ...) and check for smooth operation. 🛠️	•	•
Check/rectify the fluid level of the hydraulic clutch. (🔧 p. 65)	•	•
Check the front brake fluid level. (🔧 p. 70)	•	•
Check the free travel of the hand brake lever. (🔧 p. 69)	•	•
Check the play of the steering head bearing. (🔧 p. 49)	•	•
Change the spark plug and spark plug connector. 🛠️	•	•
Check the intake diaphragm. 🛠️	•	•
Check the exhaust control to ensure it is functioning properly and operating smoothly. 🛠️		•
Check the clutch. 🛠️		•
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and sleeves for cracking, leaks, and incorrect routing. 🛠️	•	•
Check the antifreeze and coolant level. (🔧 p. 88)	•	•
Check the cables for damage and routing without sharp bends. 🛠️	•	•
Check that the throttle cables are undamaged, routed without sharp bends, and set correctly.	•	•
Clean the air filter and air filter box. 🛠️ (🔧 p. 54)	•	•
Change the glass fiber yarn filling of the main silencer. 🛠️ (🔧 p. 56)	•	•
Check the screws and nuts for tightness. 🛠️	•	•
Check the headlight setting. (🔧 p. 86)	•	•
Check the idle.	•	•
Final check: Check the vehicle for safe operation and take a test ride.	•	•
Make the service entry in HUSABERG DEALER.NET and in the service record. 🛠️	•	•

S20A: Every 20 operating hours

S40A: Every 40 operating hours/after every race

9.2 Service work (as additional order)

	S40A	S80A	J1A
Change the front brake fluid. 			•
Change the rear brake fluid. 			•
Change the hydraulic clutch fluid.  ( p. 66)			•
Grease the steering head bearing.  ( p. 50)			•
Check/set the carburetor components. 		•	•
Perform a fork service. 	•	•	
Service the shock absorber. 	•	•	
Check the starter drive.  (TE 250/300)	•	•	
Change the piston and check the cylinder.  (TE 125)	•	•	
Change the piston and check the cylinder.  (TE 250/300)		•	
Change the connecting rod, conrod bearing, and crank pin. 		•	
Check the transmission and shift mechanism. 		•	
Change all engine bearings. 		•	

S40A: Every 40 operating hours


S80A: Every 80 operating hours/every 40 operating hours when used for motorsports

J1A: Annually

10.1 Checking the basic chassis setting with the rider's weight

**Info**

When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm, and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, HUSABERG motorcycles are adjusted for a standard rider weight (with full protective clothing).

Guideline

Standard rider weight	75... 85 kg (165... 187 lb.)
-----------------------	------------------------------

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

10.2 Compression damping of shock absorber

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed.

High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.

The high-speed setting has an effect on the landing after a jump, for example: the rear wheel suspension compresses more quickly. The low-speed setting has an effect when riding over long ground swells, for example: the rear wheel suspension compresses more slowly.

These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

10.3 Adjusting the low-speed compression damping of the shock absorber


**Caution**

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized HUSABERG workshop would be pleased to help you.)

**Info**

The low-speed setting can be seen during the slow to normal compression of the shock absorber.



- Turn adjusting screw ❶ clockwise with a screwdriver up to the last perceptible click.

**Info**

Do not loosen nut ❷!

- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed (TE 125)	
Comfort	25 clicks
Standard	20 clicks
Sport	15 clicks
Compression damping, low-speed (TE 250/300)	
Comfort	25 clicks
Standard	20 clicks
Sport	15 clicks

i Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.4 Adjusting the high-speed compression damping of the shock absorber

- ! Caution**
Danger of accidents Disassembly of pressurized parts can lead to injury.
- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized HUSABERG workshop would be pleased to help you.)

i Info
The high-speed setting can be seen during the fast compression of the shock absorber.



- Turn adjusting screw ❶ all the way clockwise with a socket wrench.

i Info
Do not loosen nut ❷!

- Turn back counterclockwise by the number of turns corresponding to the shock absorber type.


Guideline

Compression damping, high-speed (TE 125)	
Comfort	2 turns
Standard	1.5 turns
Sport	1.25 turns
Compression damping, high-speed (TE 250/300)	
Comfort	2 turns
Standard	1.5 turns
Sport	1.25 turns

i Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.5 Adjusting the rebound damping of the shock absorber

- ! Caution**
Danger of accidents Disassembly of pressurized parts can lead to injury.
- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized HUSABERG workshop would be pleased to help you.)



- Turn adjusting screw ❶ clockwise up to the last perceptible click.

**Info**

Do not loosen nut ❷!

- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.


Guideline

Rebound damping (TE 125)	
Comfort	28 clicks
Standard	24 clicks
Sport	22 clicks
Rebound damping (TE 250/300)	
Comfort	28 clicks
Standard	24 clicks
Sport	22 clicks

**Info**

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.6 Measuring the sag of the unloaded rear wheel

**Preparatory work**

- Raise the motorcycle with the lift stand. (🔧 p. 44)


Main work

- Measure the distance – as vertical as possible – between the rear axle and a fixed point, for example, a mark on the side cover.
- Note down the value as dimension A.

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 44)

10.7 Checking the static sag of the shock absorber



- Measure distance A of the unloaded rear wheel. (🔧 p. 39)
- Hold the motorcycle upright with the aid of an assistant.
- Measure the distance between the rear axle and the fixed point again.
- Note down the value as dimension B.

**Info**


The static sag is the difference between measurements A and B.

- Check the static sag.

Static sag (TE 125)	33... 35 mm (1.3... 1.38 in)
Static sag (TE 250/300)	33... 35 mm (1.3... 1.38 in)

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber. 🛠️ (🔧 p. 40)

10.8 Checking the riding sag of the shock absorber



- Measure distance **A** of the unloaded rear wheel. (☞ p. 39)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
 - ✓ The rear wheel suspension levels out.
- Another person now measures the distance between the rear axle and a fixed point.
- Note down the value as dimension **C**.

**Info**

The riding sag is the difference between measurements **A** and **C**.

- Check the riding sag.

Guideline

Riding sag (TE 125)	105... 115 mm (4.13... 4.53 in)
Riding sag (TE 250/300)	105... 115 mm (4.13... 4.53 in)

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. ☞ (☞ p. 41)

10.9 Adjusting the spring preload of the shock absorber ☞


**Caution**

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided. (Your authorized HUSABERG workshop would be pleased to help you.)

**Info**

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.

**Preparatory work**

- Raise the motorcycle with the lift stand. (☞ p. 44)
- Remove the shock absorber. ☞ (☞ p. 51)
- After removing the shock absorber, clean it thoroughly.

Main work

- Loosen screw **1**.
- Turn adjusting ring **2** until the spring is no longer under tension.

Combination wrench (50329080000)

Hook wrench (T106S)

- Measure the overall spring length while the spring is not under tension.
- Tighten the spring by turning adjusting ring **2** to measurement **A**.

Guideline

Spring preload (TE 125)	6 mm (0.24 in)
Spring preload (TE 250/300)	7 mm (0.28 in)

**Info**

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten screw **1**.


Guideline

Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)
--------------------------------------	----	-------------------

Finishing work

- Install the shock absorber. ☞ (☞ p. 52)
- Remove the motorcycle from the lift stand. (☞ p. 44)

10.10 Adjusting the riding sag 🛠️



Preparatory work

- Raise the motorcycle with the lift stand. (🔧 p. 44)
- Remove the shock absorber. 🛠️ (🔧 p. 51)
- After removing the shock absorber, clean it thoroughly.

Main work

- Choose and mount a suitable spring.

Guideline

Spring rate (TE 125)	
Weight of rider: 65... 75 kg (143... 165 lb.)	63 N/mm (360 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	66 N/mm (377 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	69 N/mm (394 lb/in)
Spring rate (TE 250/300)	
Weight of rider: 65... 75 kg (143... 165 lb.)	66 N/mm (377 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	69 N/mm (394 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	72 N/mm (411 lb/in)



Info

The spring rate is shown on the outside of the spring.

Finishing work


- Install the shock absorber. 🛠️ (🔧 p. 52)
- Remove the motorcycle from the lift stand. (🔧 p. 44)
- Check the static sag of the shock absorber. (🔧 p. 39)
- Check the riding sag of the shock absorber. (🔧 p. 40)
- Adjust the rebound damping of the shock absorber. (🔧 p. 38)

10.11 Checking the basic setting of the fork



Info

For various reasons, no exact riding sag can be determined for the forks.



- As with the shock absorber, smaller rider weight differences can be compensated by the spring preload.
- However, if the fork is often overloaded (hard end stop on compression), stiffer springs must be fit to avoid damage to the fork and frame.

10.12 Adjusting the compression damping of the fork

i Info
The hydraulic compression damping determines the fork suspension behavior.



- Turn the white adjusting screw ❶ all the way clockwise.

i Info
Adjusting screw ❶ is located at the upper end of the left fork leg. The compression damping is located in the left fork leg **COMP** (white adjusting screw). The rebound damping is located in the right fork leg **REB** (red adjusting screw).

- Turn back counterclockwise by the number of clicks corresponding to the fork type.
- Guideline

Compression damping (TE 125)	
Comfort	24 clicks
Standard	22 clicks
Sport	16 clicks
Compression damping (TE 250/300)	
Comfort	24 clicks
Standard	22 clicks
Sport	16 clicks

i Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.13 Adjusting the rebound damping of the fork

i Info
The hydraulic rebound damping determines the fork suspension behavior.



- Turn the red adjusting screw ❶ all the way clockwise.


i Info
Adjusting screw ❶ is located at the upper end of the right fork leg. The compression damping is located in the left fork leg **COMP** (white adjusting screw). The rebound damping is located in the right fork leg **REB** (red adjusting screw).

- Turn back counterclockwise by the number of clicks corresponding to the fork type.
- Guideline

Rebound damping (TE 125)	
Comfort	23 clicks
Standard	21 clicks
Sport	21 clicks
Rebound damping (TE 250/300)	
Comfort	20 clicks
Standard	18 clicks
Sport	18 clicks

i Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

10.14 Handlebar position



On the upper triple clamp, there are two holes a distance of **A** apart.


Hole distance A	15 mm (0.59 in)
-----------------	-----------------

The holes on the handlebar support are placed at a distance of **B** from the center.

Hole distance B	3.5 mm (0.138 in)
-----------------	-------------------

The handlebar can be mounted in four different positions. In this way, the handlebar can be mounted in the position that is most comfortable for the rider.

10.15 Adjusting the handlebar position



- Remove screws **1**. Remove the handlebar clamp. Remove the handlebar and lay it to one side.

Info

Protect the motorcycle and its attachments against damage by covering them.
Do not bend the cables and lines.

- Remove screws **2**. Remove the handlebar support.
- Place the handlebar support in the required position. Mount and tighten screws **2**.
Guideline

Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	Loctite® 243™
--------------------------	-----	------------------------	---------------

Info

Position the left and right handlebar supports evenly.

- Position the handlebar.


Info

Make sure cables and wiring are positioned correctly.

- Position the handlebar clamp. Mount and tighten screws **1**.

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
------------------------	----	------------------------

11.1 Raising the motorcycle with the lift stand



(TE 125)

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

- Raise the motorcycle at the frame underneath the engine.

Lift stand (81229055100)

- ✓ The wheels must no longer touch the ground.

- Secure the motorcycle against falling over.



(TE 250/300)

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.

- Raise the motorcycle at the frame underneath the engine.

Lift stand (81229055100)

- ✓ The wheels must no longer touch the ground.


- Secure the motorcycle against falling over.

11.2 Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, press side stand ❶ to the ground with your foot and lean the motorcycle on it.



Info

When you are riding, the side stand must be folded up and secured with the rubber band.

11.3 Bleeding the fork legs



Preparatory work

- Raise the motorcycle with the lift stand. (☛ p. 44)

Main work

- Remove bleeder screws ❶ briefly.
- ✓ Any excess pressure escapes from the interior of the fork.
- Mount and tighten the bleeder screws.

Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 44)

11.4 Cleaning the dust boots of the fork legs

**Preparatory work**

- Raise the motorcycle with the lift stand. (☛ p. 44)
- Loosen the fork protection. (☛ p. 45)

Main work

- Push dust boots ❶ of both fork legs downwards.

**Info**

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can penetrate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.

**Warning**

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean and oil the dust boots and inner fork tube of both fork legs.


Universal oil spray (☛ p. 122)

- Press the dust boots back into their normal position.
- Remove excess oil.

Finishing work


- Position the fork protection. (☛ p. 45)
- Remove the motorcycle from the lift stand. (☛ p. 44)

11.5 Loosening the fork protection



- Remove screws ❶ and take off the clamp.
- Remove screws ❷ on the left fork leg. Push the fork protection downwards.
- Remove the screws on the right fork leg. Push the fork protection downwards.

11.6 Positioning the fork protection



- Position the fork protection on the left fork leg. Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the brake line and clamp. Mount and tighten screws ❷.
- Position the fork protection on the right fork leg. Mount and tighten the screws.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------


11.7 Removing the fork legs

Preparatory work


- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (☞ p. 84)
- Raise the motorcycle with the lift stand. (☞ p. 44)
- Remove the front wheel. ☞ (☞ p. 77)

Main work

- Remove screws ❶ and take off the clamp.
- Remove cable binder ❷.
- Remove screws ❸ and take off the brake caliper.
- Hang the brake caliper and the brake line loosely to the side.



L00226-10



L00319-10

- Loosen screws ❹. Remove the fork leg on the left.
- Loosen screws ❺. Remove the fork leg on the right.

11.8 Installing the fork legs

Main work

- Position the fork legs.



Info

The rebound damping is located in the right fork leg (red adjusting screw). The compression damping is located in the left fork leg (white adjusting screw).

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.

Position bleeder screws ❶ toward the front.



L00320-10

- Tighten screws ❷.


Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	------------------------

- Tighten screws ❸.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
----------------------------	----	--------------------




L00319-11

- Position the brake caliper. Mount and tighten screws ❹.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	------------------------	---------------

- Mount cable binder ❺.
- Position the brake line, wiring harness, and clamp. Mount and tighten screws ❻.



L00227-10

Finishing work

- Install the front wheel. ☞ (☞ p. 77)

- Install the headlight mask with the headlight. (🔧 p. 84)


11.9 Removing the fork protector 🛠️

Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (🔧 p. 84)
- Raise the motorcycle with the lift stand. (🔧 p. 44)
- Remove the front wheel. 🛠️ (🔧 p. 77)
- Remove the fork legs. 🛠️ (🔧 p. 46)

Main work

- Remove screws ❶ on the left fork leg. Lift off the fork protector.
- Remove the screws on the right fork leg. Lift off the fork protector.



11.10 Installing the fork protector 🛠️

Main work

- Position the fork protection on the left fork leg. Mount and tighten screws ❶.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the fork protection on the right fork leg. Mount and tighten the screws.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



Finishing work

- Install the fork legs. 🛠️ (🔧 p. 46)
- Install the front wheel. 🛠️ (🔧 p. 77)
- Install the headlight mask with the headlight. (🔧 p. 84)

11.11 Removing the lower triple clamp 🛠️

Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (🔧 p. 84)
- Raise the motorcycle with the lift stand. (🔧 p. 44)
- Remove the front wheel. 🛠️ (🔧 p. 77)
- Remove the fork legs. 🛠️ (🔧 p. 46)
- Remove the front fender. (🔧 p. 51)
- Remove the handlebar cushion.

Main work


- Remove screw ❶. Remove screw ❷, take off the upper triple clamp with the handlebar, and set it aside.




Info

Protect the motorcycle and its attachments against damage by covering them.


Do not bend the cables and lines.





- Remove O-ring ③. Remove protective ring ④.
- Take out the lower triple clamp with the steering stem.
- Take out the upper steering head bearing.

11.12 Installing the lower triple clamp




Main work

- Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (☛ p. 121)

- Insert the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Check whether the top steering head seal ① is correctly positioned.
- Slide on protective ring ② and O-ring ③.



- Position the upper triple clamp with the steering.
- Mount screw ④ but do not tighten yet.
- Mount the clutch line with cable guide ⑤.



- Position the fork legs.

Info

The rebound damping is located in the right fork leg (red adjusting screw). The compression damping is located in the left fork leg (white adjusting screw).

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the top edge of the upper triple clamp.


Position bleeder screws ⑥ toward the front.

- Tighten screws ⑦.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
----------------------------	----	--------------------





- Tighten screw ④.

Guideline


Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
--------------------------	---------	--------------------



- Mount and tighten screw ⑧.

Guideline


Screw, top steering stem	M8	17 Nm (12.5 lbf ft)	Loctite® 243™
--------------------------	----	---------------------	---------------



- Tighten screws ⑨.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------



- Position the brake caliper. Mount and tighten screws ⑩.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	---------------------	---------------

- Mount cable binder ⑪.
- Position the brake line, wiring harness, and clamp. Mount and tighten screws ⑫.
- Install the front fender. (☞ p. 51)
- Install the headlight mask with the headlight. (☞ p. 84)
- Install the front wheel. 🛞 (☞ p. 77)

Finishing work

- Mount the handlebar cushion.
- Check that the wiring harness, throttle cables, and brake and clutch lines can move freely and are routed correctly.
- Check the play of the steering head bearing. (☞ p. 49)
- Remove the motorcycle from the lift stand. (☞ p. 44)

11.13 Checking the play of the steering head bearing



Warning

Danger of accidents Unstable vehicle handling from incorrect steering head bearing play.

- Adjust the steering head bearing play without delay. (Your authorized HUSABERG workshop would be pleased to help you.)




Info

If the bike is ridden with play in the steering head bearing, the bearing, and the bearing seats in the frame can become damaged over time.

Preparatory work

- Raise the motorcycle with the lift stand. (☞ p. 44)



Main work

- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

No play should be noticeable in the steering head bearing.

- » If there is noticeable play present:
 - Adjust the play of the steering head bearing. (p. 50)
- Move the handlebar to and fro over the entire steering range.


The handlebar must be able to move easily over the entire steering range. There should be no perceptible detent positions.

- » If detent positions are noticeable:
 - Adjust the play of the steering head bearing. (p. 50)
 - Check the steering head bearing and change if necessary.

Finishing work

- Remove the motorcycle from the lift stand. (p. 44)

11.14 Adjusting the play of the steering head bearing



Preparatory work

- Raise the motorcycle with the lift stand. (p. 44)

Main work

- Loosen screws 1. Remove screw 2.
- Loosen and retighten screw 3.

Guideline

Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
--------------------------	---------	--------------------

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Tighten screws 1.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	---------------------

- Mount and tighten screw 2.


Guideline

Screw, top steering stem	M8	17 Nm (12.5 lbf ft)	Loctite® 243™
--------------------------	----	---------------------	---------------

Finishing work


- Check the play of the steering head bearing. (p. 49)
- Remove the motorcycle from the lift stand. (p. 44)

11.15 Greasing the steering head bearing



- Remove the lower triple clamp. (p. 47)
- Install the lower triple clamp. (p. 48)

11.16 Removing the front fender




Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (🔧 p. 84)


Main work

- Remove screws ❶.
- Take the brake line and wiring harness out of the brake line guide.
- Disconnect the connectors of the front turn signals.



- Remove screws ❷. Take off the fender.

11.17 Installing the front fender




Main work

- Position the front fender. Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Position the brake line and wiring harness in the brake line guide.
- Connect the connectors of the front turn signals.
- Mount and tighten screws ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------


Finishing work

- Install the headlight mask with the headlight. (🔧 p. 84)

11.18 Removing the shock absorber 🛠

Preparatory work

- Raise the motorcycle with the lift stand. (🔧 p. 44)



Main work (TE 125)


- Remove screw ❶ and lower the rear wheel with the swing arm as far as possible without blocking the rear wheel. Fix the rear wheel in this position.
- Remove screw ❷, push splash protector ❸ to the side, and remove the shock absorber.



(TE 250/300)

- Remove screw ❶ and lower the rear wheel with the swing arm as far as possible without blocking the rear wheel. Fix the rear wheel in this position.
- Remove screw ❷, push splash protector ❸ to the side, and remove the shock absorber.

11.19 Installing the shock absorber



Main work (TE 125)

- Push splash protector ❶ to the side and position the shock absorber. Mount and tighten screw ❷.

Guideline

Screw, top shock absorber	M12	80 Nm (59 lbf ft)	Loctite® 2701
---------------------------	-----	----------------------	---------------

- Mount and tighten screw ❸.


Guideline

Screw, bottom shock absorber	M12	80 Nm (59 lbf ft)	Loctite® 2701
------------------------------	-----	----------------------	---------------



Info

The heim joint for the shock absorber at the swing arm is Teflon coated. It must not be greased with grease or with other lubricants. Lubricants dissolve the Teflon coating, thereby drastically reducing the service life.



(TE 250/300)

- Push splash protector ❶ to the side and position the shock absorber. Mount and tighten screw ❷.

Guideline

Screw, top shock absorber	M12	80 Nm (59 lbf ft)	Loctite® 2701
---------------------------	-----	----------------------	---------------

- Mount and tighten screw ❸.

Guideline

Screw, bottom shock absorber	M12	80 Nm (59 lbf ft)	Loctite® 2701
------------------------------	-----	----------------------	---------------




Info

The heim joint for the shock absorber at the swing arm is Teflon coated. It must not be greased with grease or with other lubricants. Lubricants dissolve the Teflon coating, thereby drastically reducing the service life.

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 44)

11.20 Removing the seat



- Remove screws ❶ in the recessed grips on the left and right.
- Lift up the seat at the rear, pull it back, and then lift it off.

11.21 Mounting the seat




- Attach the front of the seat to the collar bushing of the fuel tank and lower the seat at the rear while pushing forward.
- Make sure that the seat is correctly locked in.
- Mount and tighten the screws for securing the seat.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

11.22 Removing the air filter box lid



- Release catch ❶, pull off the air filter box lid sideways in areas ❶ and ❷ and remove toward the rear.

11.23 Installing the air filter box lid



- Position the air filter box lid and tab ❶. Engage the air filter box lid in areas ❶ and ❷.
- Engage tab ❶.

11.24 Removing the air filter

Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.




Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

Preparatory work


- Remove the air filter box lid. (🔧 p. 53)



Main work

- Push air filter holder ① toward the air filter at position ① and detach it at end ②. Swing the air filter holder to one side and remove the air filter with the air filter support.
- Remove the air filter from the air filter support.


11.25 Installing the air filter



Main work

- Mount the clean air filter on the air filter support.
- Grease the air filter in area ①.

Long-life grease (☛ p. 121)



- Insert both parts together, position them, and fasten them using air filter holder ① in area ①.

✓ The arrow of marking **UP** faces up.



Info

If the air filter is not correctly mounted, dust and dirt can enter the engine and cause damage.

Finishing work

- Install the air filter box lid. (☛ p. 53)

11.26 Cleaning the air filter and air filter box



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.

Preparatory work

- Remove the air filter box lid. (☛ p. 53)
- Remove the air filter. ☛ (☛ p. 53)

Main work

- Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaning agent (☛ p. 121)



Info

Only press the air filter to dry it; never wring it out.

- Oil the dry air filter with a high quality filter oil.

Oil for foam air filter (☛ p. 121)

- Clean the air filter box.




- Check the carburetor connection boot for damage and tightness.

Finishing work

- Install the air filter. (🔧 p. 54)
- Install the air filter box lid. (🔧 p. 53)

11.27 Sealing the air filter box 🔧



- Seal the air filter box in the marked area ❶.

11.28 Removing the main silencer




Warning
Danger of burns The exhaust system gets very hot when the vehicle is driven.
- Allow the exhaust system to cool down. Do not touch hot components.

Preparatory work


- Remove the right side cover. (🔧 p. 56)

Main work

- Remove screws ❶.
- Pull the main silencer off of the manifold at rubber sleeve ❷.



11.29 Installing the main silencer



Main work

- Mount the main silencer with rubber sleeve ❶.
- Mount and tighten screws ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Finishing work

- Install the right side cover. (🔧 p. 57)

11.30 Changing the glass fiber yarn filling of the main silencer



Warning


Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down. Do not touch hot components.



Info

Over time, the fibers of the glass fiber yarn filling escape and the damper "burns" out. Not only is the noise level higher, the performance characteristic changes.



Preparatory work

- Remove the right side cover. (p. 56)
- Remove the main silencer. (p. 55)

Main work

- Remove screws ❶. Pull out inner tube ❷.
- Pull the glass fiber yarn filling ❸ from the inner tube.
- Clean the parts that are to be reinstalled.
- Mount the new glass fiber yarn filling ❹ on the inner tube.
- Slide outer tube ❺ over the inner tube with the new glass fiber yarn filling.
- Mount and tighten all screws ❶.

Finishing work


- Install the main silencer. (p. 55)
- Install the right side cover. (p. 57)

11.31 Removing the right side cover



- Remove screw ❶.
- Pull off the side cover in area A sideways and remove it toward the rear.

11.32 Installing the right side cover



- Position the side cover and engage in area **A**.
- Mount and tighten screw **1**.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

11.33 Removing the fuel tank



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.

Preparatory work

- Remove the seat. (☛ p. 53)

Main work

- Turn tap handle **1** on the fuel tap to position **OFF**. (Figure L00310-10☛ p. 23)
- Pull off the fuel hose.






Info

Remaining fuel may run out of the fuel hose.

- Remove screws **1** with the collar sleeve.

(TE EU/AUS)

- Hang the horn and horn bracket to one side.
- Remove screw **2** with the collar sleeve.
- Remove the tube from the fuel tank vent line.



- Pull both spoilers off of the sides of radiator bracket **3** and lift off the fuel tank.

11.34 Installing the fuel tank

Danger
Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.

Warning
Danger of poisoning Fuel is poisonous and a health hazard.


- Avoid contact of the fuel with skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel.

Preparatory work

- Remove the seat. (p. 53)
- Remove the fuel tank. (p. 57)
- Check the throttle cable routing. (p. 64)

Main work

- Position the fuel tank and fit the two spoilers to the sides of the radiator bracket.
- Make sure that no cables are trapped or damaged.




- Mount the fuel tank vent hose.
- Mount and tighten screw 1 with the collar bushing.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

(TE EU/AUS)

- Position the horn with the horn bracket.



- Mount and tighten screws 2 with the collar sleeve.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Connect the fuel hose.

Finishing work

- Mount the seat. (p. 53)

11.35 Checking the chain for dirt



- Check the chain for heavy soiling.
 - » If the chain is very dirty:
 - Clean the chain. (🔧 p. 59)

11.36 Cleaning the chain



Warning

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

The service life of the chain depends largely on its maintenance.



- Clean the chain regularly and then treat with chain spray.

Chain cleaner (🔧 p. 121)

Chain spray (🔧 p. 121)

11.37 Checking the chain tension




Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.

Preparatory work

- Raise the motorcycle with the lift stand. (🔧 p. 44)

**Main work**

- Press the chain upward at the end of the chain sliding piece and determine chain tension **A**.

 **Info**

The lower chain section **1** must be taut.

When the chain guard is mounted, it must be possible to pull up the chain at least to the point where it makes contact with chain guard **B**.

Because chain wear is not always even, repeat this measurement at different chain positions.

Chain tension	55... 58 mm (2.17... 2.28 in)
---------------	-------------------------------

- » If the chain tension does not meet specifications:
 - Adjust the chain tension. (☛ p. 60)

Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 44)

11.38 Adjusting the chain tension**Warning**

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.

Preparatory work

- Raise the motorcycle with the lift stand. (☛ p. 44)
- Check the chain tension. (☛ p. 59)

Main work

- Loosen nut **1**.
- Loosen nuts **2**.
- Adjust the chain tension by turning the left and right adjusting screws **3**.

Guideline

Chain tension	55... 58 mm (2.17... 2.28 in)
Turn adjusting screws 3 on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks A . The rear wheel is now correctly aligned.	

- Tighten nuts **2**.
- Make sure that chain adjusters **4** are fitted correctly on adjusting screws **3**.
- Tighten nut **1**.

Guideline


Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------

 **Info**


The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters **4** can be turned by 180°.

Finishing work

- Remove the motorcycle from the lift stand. (☛ p. 44)



11.39 Checking the chain, rear sprocket, engine sprocket, and chain guide

**Preparatory work**

- Raise the motorcycle with the lift stand. (🔧 p. 44)

Main work

- Shift gear to neutral.
- Check the rear sprocket and engine sprocket for wear.
 - » If the rear sprocket or engine sprocket is worn:
 - Change the rear sprocket or engine sprocket. 🛠️

**Info**

The engine sprocket, rear sprocket, and chain should always be changed together.

- Pull on the upper part of the chain with the specified weight **A**.

Guideline

Weight, chain wear measurement	10... 15 kg (22... 33 lb.)
--------------------------------	----------------------------

- Measure distance **B** of 18 chain links in the lower chain section.

**Info**



Chain wear is not always even; repeat this measurement at different chain positions.

Maximum distance B at the longest chain section	272 mm (10.71 in)
--	-------------------

- » If distance **B** is greater than the specified measurement:
 - Change the chain. 🛠️

**Info**


When you mount a new chain, you should also change the rear sprocket and engine sprocket.
New chains wear out faster on old, worn sprockets.



- Check the chain sliding guard for wear.
 - » If the lower edge of the chain pins is in line with or below the chain sliding guard:
 - Change the chain sliding guard. 🛠️
- Check the chain sliding guard for tightness.
 - » If the chain sliding guard is loose:
 - Tighten the chain sliding guard.


Guideline


Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
----------------------------	----	----------------------	---------------



- Check the chain sliding piece for wear.
 - » If the lower edge of the chain pins is in line with or below the chain sliding piece:
 - Change the chain sliding piece. 🔧
 - Check the chain sliding piece for tightness.
 - » If the chain sliding piece is loose:
 - Tighten the chain sliding piece.
- Guideline

Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)
----------------------------	----	------------------------



- Check the chain guide for wear.
-
-  **Info**
Wear can be seen on the front of the chain guide.
-
- » If the light part of the chain guide is worn:
 - Change the chain guide. 🔧




- Check the chain guide for tightness.
 - » If the chain guide is loose:
 - Tighten the chain guide.
- Guideline
- | | | |
|---------------------------|----|-----------------------|
| Remaining screws, chassis | M6 | 10 Nm
(7.4 lbf ft) |
| Remaining nuts, chassis | M6 | 10 Nm
(7.4 lbf ft) |

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 44)

11.40 Adjusting the chain guide 🛠️



- Remove the nut of screw ❶.
- Remove screws ❶ and ❷. Take off the chain guide.

Condition

Number of teeth: ≤ 44 teeth

- Insert nut ❸ in hole ❶. Position the chain guide.
- Mount and tighten screws ❶ and ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

- Mount the nut on screw ❶ and tighten.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
-------------------------	----	-----------------------

Condition

Number of teeth: ≥ 45 teeth

- Insert nut ❸ in hole ❷. Position the chain guide.
- Mount and tighten screws ❶ and ❷.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

- Mount the nut on screw ❶ and tighten.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
-------------------------	----	-----------------------

11.41 Checking the frame 🛠️



- Check the frame for cracks and deformation.
 - » If the frame exhibits cracks or deformation due to a mechanical impact:
 - Change the frame. 🛠️

**Info**

A frame that has been damaged due to a mechanical impact must always be changed. Repair of the frame is not authorized by HUSABERG.

11.42 Checking the swingarm 🛠️



- Check the swingarm for damage, cracking, and deformation.
 - » If the swingarm shows signs of damage, cracking, or deformation:
 - Change the swingarm. 🛠️

**Info**

A damaged swingarm must always be changed. Repair of the swingarm is not authorized by HUSABERG.

11.43 Checking the throttle cable routing

Preparatory work

- Remove the seat. (🔧 p. 53)
- Remove the fuel tank. 🛠️ (🔧 p. 57)


Main work

(TE 125)

- Check the throttle cable routing.

The throttle cable must be routed to the carburetor on the left side of the upper frame tube behind the handlebars.

- » If the throttle cable is not routed as specified:
 - Correct the throttle cable routing.



(TE 250/300)

- Check the throttle cable routing.


The throttle cable must be routed to the carburetor on the left side of the upper frame tube behind the handlebars.

- » If the throttle cable is not routed as specified:
 - Correct the throttle cable routing.

Finishing work

- Install the fuel tank. 🛠️ (🔧 p. 58)
- Mount the seat. (🔧 p. 53)

11.44 Checking the rubber grip



- Check the rubber grips on the handlebar for damage, wear, and looseness.
 - » If a rubber grip is damaged, worn, or loose:
 - Change and secure the rubber grip.

Rubber grip adhesive (00062030051) (🔧 p. 122)

11.45 Additionally securing the rubber grip

**Preparatory work**

- Check the rubber grip. (☛ p. 64)

Main work

- Secure the rubber grip at two points using the securing wire.

Securing wire (54812016000)

Wire twister forceps (U6907854)

- ✓ The twisted wire ends face away from the hands and are bent toward the rubber grip.


11.46 Adjusting the basic position of the clutch lever

**(TE 125)**

- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ❶.

**Info**

Turn the adjusting screw counterclockwise to increase the distance between the clutch lever and the handlebar.
Turn the adjusting screw clockwise to decrease the distance between the clutch lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!

**(TE 250/300)**

- Adjust the basic setting of the clutch lever to your hand size by turning adjusting screw ❶.


**Info**

Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handlebar.
Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding!

11.47 Checking/rectifying the fluid level of the hydraulic clutch

**Info**

The fluid level rises with increased wear of the clutch facing discs.

**(TE 125)**

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Check the fluid level.


Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

» If the fluid level does not meet specifications:

- Correct the fluid level of the hydraulic clutch.

Hydraulic oil (15) (☛ p. 120)

- Position the cover with the membrane. Mount and tighten the screws.

**(TE 250/300)**

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Check the fluid level.

Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

» If the fluid level does not meet specifications:

- Correct the fluid level of the hydraulic clutch.


Brake fluid DOT 4 / DOT 5.1 (☛ p. 119)
--

- Position the cover with the membrane. Mount and tighten the screws.

11.48 Changing the hydraulic clutch fluid ☛**Warning**

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**(TE 125)**


- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.

- Fill bleeding syringe ❹ with the appropriate hydraulic fluid.

Bleed syringe (50329050000)

Hydraulic oil (15) (☛ p. 120)

- On the slave cylinder, remove bleeder screw ❺ and mount bleeding syringe ❹.




- Inject the liquid into the system until it escapes from hole ❻ of the master cylinder without bubbles.
- To prevent overflow, drain fluid occasionally from the master cylinder reservoir.
- Remove the bleeding syringe. Mount and tighten the bleeder screw.
- Correct the fluid level of the hydraulic clutch.


Guideline


Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

- Position the cover with the membrane. Mount and tighten the screws.


**(TE 250/300)**

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.





L00323-10



L00217-10

- Fill bleeding syringe ④ with the appropriate hydraulic fluid.

Bleed syringe (50329050000)

Brake fluid DOT 4 / DOT 5.1 (☛ p. 119)
--

- On the slave cylinder, remove bleeder screw ⑤ and mount bleeding syringe ④.

- Inject the liquid into the system until it escapes from hole ⑥ of the master cylinder without bubbles.
- To prevent overflow, drain fluid occasionally from the master cylinder reservoir.
- Remove the bleeding syringe. Mount and tighten the bleeder screw.
- Correct the fluid level of the hydraulic clutch.

Guideline

Fluid level below container rim	4 mm (0.16 in)
---------------------------------	----------------

- Position the cover with the membrane. Mount and tighten the screws.


11.49 Removing the engine guard



L00327-10

(TE 125)

- Turn quick release ① counterclockwise until it disengages. Remove the engine guard.



L00328-10

(TE 250/300)

- Turn quick release ① counterclockwise until it disengages. Remove the engine guard.


11.50 Installing the engine guard



L00327-10

(TE 125)

- Attach the engine guard on the frame at the rear and swing up at the front.
- Turn quick release ① clockwise all the way.




(TE 250/300)

- Turn quick release ❶ clockwise all the way.
- Attach the engine guard on the frame at the rear and swing up at the front.

12.1 Checking the free travel of the hand brake lever

- Warning**
Danger of accidents Brake system failure.
- If there is no free travel on the hand brake lever, pressure builds up on the front brake circuit. The front brake can fail due to overheating. Adjust the free travel on hand brake lever according to specifications.



(TE USA)

- Push the hand brake lever forward and check free travel **A**.

Free travel of hand brake lever	$\geq 3 \text{ mm } (\geq 0.12 \text{ in})$
---------------------------------	---

- » If the free travel does not meet specifications:
 - Adjust the basic position of the hand brake lever. (☛ p. 69)




(TE EU/AUS)

- Push the hand brake to the handlebar and check free travel **A**.

Free travel of hand brake lever	$\geq 3 \text{ mm } (\geq 0.12 \text{ in})$
---------------------------------	---

- » If the free travel does not meet specifications:
 - Adjust the free travel of the hand brake lever. (☛ p. 69)

12.2 Adjusting free travel of hand brake lever (TE EU/AUS)




- Check the free travel of the hand brake lever. (☛ p. 69)
- Adjust the free travel of the hand brake lever with adjusting screw **1**.



Info

Turn the adjusting screw clockwise to reduce free travel. The pressure point moves away from the handlebar.
 Turn the adjusting screw counterclockwise to increase free travel. The pressure point moves towards the handlebar.
 The range of adjustment is limited.
 Turn the adjusting screw by hand only, and do not apply any force.
 Do not make any adjustments while riding!

12.3 Adjusting the basic position of the hand brake lever (TE USA)



- Check the free travel of the hand brake lever. (☛ p. 69)
- Adjust the basic setting of the hand brake lever to your hand size by turning adjusting screw **1**.




Info

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.
 Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.
 The range of adjustment is limited.
 Turn the adjusting screw by hand only, and do not apply any force.
 Do not make any adjustments while riding!

12.4 Checking the brake discs

**Warning****Danger of accidents** Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay. (Your authorized HUSABERG workshop would be pleased to help you.)



400257-10

- Check the thickness of the front and rear brake discs at several places on the disc to see if it conforms to measurement **A**.

**Info**

Wear reduces the thickness of the brake disc around the area used by the brake linings.

Brake discs - wear limit

Front	2.5 mm (0.098 in)
Rear	3.5 mm (0.138 in)

- » If the brake disc thickness is less than the specified value:
 - Change the brake disc.
- Check the front and rear brake discs for damage, cracking, and deformation.
 - » If the brake disc exhibits damage, cracking, or deformation:
 - Change the brake disc.


12.5 Checking the front brake fluid level

**Warning****Danger of accidents** Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized HUSABERG workshop would be pleased to help you.)

**Warning****Danger of accidents** Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized HUSABERG workshop would be pleased to help you.)



602522-10

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the viewer **1**.
 - » If the brake fluid is below the **MIN** marking:
 - Add front brake fluid. 🛠️ (📖 p. 70)


12.6 Adding front brake fluid 🛠️

**Warning****Danger of accidents** Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized HUSABERG workshop would be pleased to help you.)


**Warning****Skin irritation** Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

- 

Warning


Danger of accidents Reduced braking efficiency due to old brake fluid.

 - Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized HUSABERG workshop would be pleased to help you.)
- 

Warning

Environmental hazard Hazardous substances cause environmental damage.

 - Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.





Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.




- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
 - Remove screws ❶.
 - Remove cover ❷ with membrane ❸.
 - Add brake fluid to level A.
- Guideline
- | | |
|---|---------------|
| Dimension A (brake fluid level below top edge of container) | 5 mm (0.2 in) |
|---|---------------|
- | |
|--|
| Brake fluid DOT 4 / DOT 5.1 (🔧 p. 119) |
|--|
- Position the cover with the membrane. Mount and tighten the screws.
- 

Info

Clean up overflowed or spilt brake fluid immediately with water.


12.7 Checking the front brake linings

- 

Warning

Danger of accidents Reduced braking efficiency caused by worn brake linings.

 - Change worn brake linings immediately. (Your authorized HUSABERG workshop would be pleased to help you.)




- Check the brake linings for minimum thickness A.
- | | |
|---------------------|--------------------|
| Minimum thickness A | ≥ 1 mm (≥ 0.04 in) |
|---------------------|--------------------|
- » If the minimum thickness is less than specified:
 - Change the front brake linings. 🛠️ (🔧 p. 72)
 - Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:
 - Change the front brake linings. 🛠️ (🔧 p. 72)

12.8 Changing the front brake linings


- Warning**
Danger of accident Brake system failure.
- Maintenance work and repairs must be carried out professionally. (Your authorized HUSABERG workshop would be pleased to help you.)
- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Danger of accidents Reduced braking efficiency due to old brake fluid.
- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized HUSABERG workshop would be pleased to help you.)
- Warning**
Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.
- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.
- Warning**
Danger of accidents Reduced braking efficiency due to use of non-approved brake linings.
- Brake linings available from accessory suppliers are often not tested and approved for use on HUSABERG vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original HUSABERG brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- i Info**
Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.




- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons. Ensure that brake fluid does not overflow from the brake fluid reservoir, using suction to remove it if it does.


- i Info**
Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.




- Remove cotter pins ④, pull out pin ⑤, and remove the brake linings.
- Clean the brake caliper and brake caliper support.



- Check that leaf spring **6** in the brake caliper and sliding plate **7** in the brake caliper support are seated correctly.



- Insert the brake linings, insert the pin, and mount the cotter pin.
- Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



- Correct the brake fluid quantity to level **A**.

Guideline

Dimension A (brake fluid level below top edge of container)	5 mm (0.2 in)
--	---------------

Brake fluid DOT 4 / DOT 5.1 (↖ p. 119)

- Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilt brake fluid immediately with water.


12.9 Checking the free travel of the foot brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



- Disconnect spring **1**.
- Move the foot brake lever backwards and forwards between the end stop and the foot brake cylinder piston bracket and check free travel **A**.

Guideline

Free travel of foot brake lever	3... 5 mm (0.12... 0.2 in)
---------------------------------	----------------------------

- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. ↗ (↖ p. 73)
- Reconnect spring **1**.


12.10 Adjusting the basic position of the foot brake lever ↗



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust the free travel on foot brake lever according to specifications.



- Disconnect spring ❶.
- Loosen nut ❷ and turn it back with push rod ❺ until you have maximum free travel.
- To adjust the basic position of the foot brake lever individually, loosen nut ❷, and turn screw ❸ accordingly.

**Info**

The range of adjustment is limited.

- Turn push rod ❺ accordingly until you have free travel A. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel of foot brake lever	3... 5 mm (0.12... 0.2 in)
---------------------------------	----------------------------

- Hold screw ❸ and tighten nut ❷.

Guideline

Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)
----------------------------	----	------------------------

- Hold push rod ❺ and tighten nut ❷.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------

- Reconnect spring ❶.

12.11 Checking the rear brake fluid level

**Warning**


Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized HUSABERG workshop would be pleased to help you.)

**Warning**

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized HUSABERG workshop would be pleased to help you.)



- Stand the vehicle upright.
- Check the brake fluid level in viewer ❶.
 - » If an air bubble is visible in viewer ❶:
 - Add rear brake fluid. 🛠️ (p. 74)

12.12 Adding rear brake fluid 🛠️

**Warning**

Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding. (Your authorized HUSABERG workshop would be pleased to help you.)

**Warning**

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized HUSABERG workshop would be pleased to help you.)



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.



- Stand the vehicle upright.
- Remove screw cap ❶ with membrane ❷ and the O-ring.
- Add brake fluid to level A.

Brake fluid DOT 4 / DOT 5.1 (☞ p. 119)

- Mount the screw cap with the membrane and the O-ring.



Info

Clean up overflowed or spilt brake fluid immediately with water.


12.13 Checking the rear brake linings



Warning

Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately. (Your authorized HUSABERG workshop would be pleased to help you.)



- Check the brake linings for minimum thickness A.

Minimum thickness A	≥ 1 mm (≥ 0.04 in)
---------------------	--------------------

- » If the minimum thickness is less than specified:
 - Change the rear brake linings. ☞ (☞ p. 75)
- Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:
 - Change the rear brake linings. ☞ (☞ p. 75)

12.14 Changing the rear brake linings ☞



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking efficiency due to old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule. (Your authorized HUSABERG workshop would be pleased to help you.)



Warning

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

i Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.



- Remove the rear brake linings. 🛠️
- Stand the vehicle upright.
- Remove screw cap ❶ with membrane ❷ and the O-ring.
- Push the brake piston back to its basic position and ensure that brake fluid does not flow out of the brake fluid reservoir, sucking it away if it does.
- Install the rear brake linings. 🛠️
- Add brake fluid to level A.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 119)

- Mount the screw cap with the membrane and the O-ring.

i Info

Clean up overflowed or spilt brake fluid immediately with water.

13.1 Removing the front wheel



Preparatory work

- Raise the motorcycle with the lift stand. (p. 44)


Main work

- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons.




Info

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.



- Remove screw ❶.
- Loosen screws ❷.




- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.



Info

Do not pull the hand brake lever when the front wheel is removed. Always lay the wheel down in such a way that the brake disc is not damaged.



- Remove spacers ❸.


13.2 Installing the front wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the wheel bearing.
- Clean and grease shaft seal rings ❶ and bearing surface A of the spacers.

Long-life grease (p. 121)

- Insert the spacers.



- Lift the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw ②.

Guideline

Screw, front wheel spindle	M24x1.5	45 Nm (33.2 lbf ft)
----------------------------	---------	------------------------

- Operate the hand brake lever several times until the brake linings are lying correctly against on the brake disc.
- Remove the motorcycle from the lift stand. (☛ p. 44)
- Pull the front wheel brake and push down hard on the fork several times to align the fork legs.
- Tighten screws ③.

Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	------------------------

13.3 Removing the rear wheel ☛

Preparatory work

- Raise the motorcycle with the lift stand. (☛ p. 44)

Main work

- Press the brake caliper onto the brake disc by hand in order to push back the brake piston.



Info



Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove nut ①.
- Remove chain adjuster ②. Withdraw wheel spindle ③ only enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.
- Holding the rear wheel, withdraw the wheel spindle. Take the rear wheel out of the swingarm.



Info

Do not operate the foot brake when the rear wheel is removed. Always lay the wheel down in such a way that the brake disc is not damaged.



- Remove spacers ④.




13.4 Installing the rear wheel ☛



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Main work

- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the wheel bearing. 🛠️
- Clean and grease shaft seal rings (1) and bearing surface (A) of the spacers.

Long-life grease (🔧 p. 121)

- Insert the spacers.
- Lift the rear wheel into the swingarm, position it, and insert wheel spindle (2).
- Put the chain on.

- Position chain adjuster (3). Mount nut (4) but do not tighten it yet.
- Make sure that chain adjusters (3) are fitted correctly on adjusting screws (5).
- Check the chain tension. (🔧 p. 59)
- Tighten nut (4).

Guideline

Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)
-------------------------	---------	-------------------



Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length. Chain adjusters (3) can be turned by 180°.

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work

- Remove the motorcycle from the lift stand. (🔧 p. 44)

13.5 Checking the tire condition



Info


Only mount tires approved or recommended by HUSABERG.

Other tires could have a negative effect on handling characteristics.

The type, condition, and air pressure of the tires all have an important impact on the handling characteristics of the motorcycle.

The tires mounted on the front and rear wheels must have a similar profile.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects and other damage.
 - » If the tire exhibits cuts, run-in objects, or other damage:
 - Change the tire.
- Check the depth of the tread.



Info

Note local national regulations concerning the minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	--------------------

- » If the tread depth is less than the minimum permissible depth:
 - Change the tire.
- Check the tire age.

i Info

The tire's date of manufacture is usually part of the tire markings and is indicated by the last four digits of the **DOT** marking. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

HUSABERG recommends replacing the tires after five years at the latest, regardless of the actual wear.


- » If the tire is older than five years:
 - Change the tire.

13.6 Checking the tire air pressure

i Info

Low tire air pressure leads to abnormal wear and overheating of the tire.

Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove the dust cap.
- Check the tire air pressure when the tires are cold.

Tire air pressure, off-road	
Front	1.0 bar (15 psi)
Rear	1.0 bar (15 psi)
Tire air pressure, road	
Front	2 bar (29 psi)
Rear	2 bar (29 psi)

- » If the tire pressure does not meet specifications:
 - Correct the tire pressure.
- Mount the dust cap.

13.7 Checking the spoke tension

! Warning

Danger of accidents Instable handling due to incorrect spoke tension.


- Ensure that the spoke tension is correct. (Your authorized HUSABERG workshop would be pleased to help you.)

i Info

A loose spoke causes wheel imbalance and rapidly leads to more loose spokes.

If the spokes are too tight, they can break due to local overload.

Check the spoke tension regularly, especially on a new motorcycle.




- Briefly strike each spoke with the tip of a screwdriver.

i Info

The tone frequency depends on the length of the spoke and the spoke diameter.

If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.

- » If the spoke tension varies:
 - Correct the spoke tension. 
- Check the spoke torque.


Guideline

Spoke nipple, front wheel	M4.5	5... 6 Nm (3.7... 4.4 lbf ft)
Spoke nipple, rear wheel	M5	5... 6 Nm (3.7... 4.4 lbf ft)

Torque wrench with various accessories in set (58429094000)

14.1 Removing the battery ↻ (TE 250/300)

- Warning**
Risk of injury Battery acid and battery gases cause serious chemical burns.
- Keep batteries out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - Avoid contact with battery acid and battery gases.
 - Keep the battery away from sparks or open flames. Charge only in well-ventilated areas.
 - In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.


**Preparatory work**

- Switch off all power consumers and switch off the engine.
- Remove the seat. (↻ p. 53)

Main work

- Disconnect the negative cable ❶ of the battery.
- Pull back the positive terminal cover ❷ and disconnect the positive cable of the battery.
- Detach rubber band ❸ at the bottom.
- Lift the battery up and out.

14.2 Installing the battery ↻ (TE 250/300)

**Main work**

- Place the battery in the battery holder.

Battery (YTX4L-BS) (↻ p. 110)

- Attach rubber band ❶.
- Attach the positive cable and replace the positive terminal cover ❷.

Guideline

Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)
-------------------------	----	-------------------------

**Info**

Contact disks A must be mounted between battery terminals ❹ and cable sockets ❺ with the claws facing up.



- Attach negative cable ❸.


Finishing work

- Mount the seat. (↻ p. 53)


14.3 Recharging the battery ↻ (TE 250/300)

- Warning**
Risk of injury Battery acid and battery gases cause serious chemical burns.
- Keep batteries out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - Avoid contact with battery acid and battery gases.
 - Keep the battery away from sparks or open flames. Charge only in well-ventilated areas.
 - In the event of skin contact, rinse with large amounts of water. If battery acid gets in the eyes, rinse with water for at least 15 minutes and contact a physician.

- **Warning**
Environmental hazard Battery components and acid are harmful to the environment.
- Do not dispose of batteries with the regular garbage. Dispose of defective batteries in an environmentally responsible manner. Take the batteries to your HUSABERG dealer or to a collection point for old batteries.
- **Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

Even if there is no load on the battery, it loses power every day.
The charging level and type of charge are very important to the battery service life.
Rapid recharging with a high charging current shortens the battery's service life.
If the charging current, charging voltage, and charging time are exceeded, electrolyte escapes through the safety valves. This reduces the battery capacity.
If the battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.
If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfate, destroying the battery.
The battery is maintenance-free, i.e., the acid level does not have to be checked.



Preparatory work


- Switch off all power consumers and switch off the engine.
- Remove the seat. (🔧 p. 53)
- Disconnect the negative cable of the battery to avoid damage to the motorcycle's electronics.

Main work

- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (81229074000)

You can also use the battery charger to check the off load voltage, the starting ability of the battery and the alternator. With this device, you cannot overcharge the battery.

**Info**

Never remove lid ❶.
Charge the battery with a maximum of 10% of the capacity specified on battery housing ❷.

- Switch off the charger after charging. Disconnect the battery.



Guideline

The charge current, charge voltage, and charge time must not be exceeded.	
Charge the battery regularly when the motorcycle is not in use	3 months


Finishing work

- Mount the seat. (🔧 p. 53)

14.4 Changing the main fuse (TE 250/300)

- **Warning**
Fire hazard The electrical system can be overloaded if the wrong fuses are used.
- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.
- **Info**
- The main fuse protects all power consumers of the vehicle. It is located in the starter relay housing under the air filter box lid.

- Preparatory work**
- Switch off all power consumers and switch off the engine.
 - Remove the air filter box lid. (🔧 p. 53)



Main work

- Remove protection caps ❶.
- Remove the faulty main fuse ❷.



Info

A defective fuse can be identified by the burned-out fuse wire ❸. A reserve fuse ❹ is located in the starter relay.

- Install a new main fuse.

Fuse (58011109110)

- Check that the electrical equipment is functioning properly.



Tip


Insert the spare fuse so that it is available if needed.

- Mount the protection caps.
- Mount the starter relay onto the holder and lay the cable.

Finishing work

- Install the air filter box lid. (➔ p. 53)

14.5 Removing the headlight mask with the headlight




Preparatory work

- Switch off all power consumers and switch off the engine.


Main work

- Open rubber bands ❶ on the fork legs.
- Tilt the headlight mask forward and detach at catch ❷.
- Disconnect connector ❸.
- Take off the headlight mask with headlight.

14.6 Installing the headlight mask with the headlight



- Plug in connector ❶.
- Check that the lighting is functioning properly.
- Attach headlight holder ❷ at catch ❸ and position the headlight mask.




- Position rubber bands ❹ around the fork legs and close them.
- ✓ The wiring harness and brake line ❺ are routed in front of the headlight mask.
- Check the headlight setting. (➔ p. 86)

14.7 Changing the headlight bulb


Note

Damage to reflector Reduced luminance.

- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



C00099-10



100463-10

Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (☛ p. 84)

Main work

- Turn protection cap ❶ with the bulb socket beneath it all the way counterclockwise and lift it off.
- Pull bulb socket ❷ of the parking light out of the reflector.

- Press headlight bulb ❸ lightly into the bulb socket, turn it all the way counterclockwise, and pull it out.
- Insert the new headlight bulb.

(TE EU/AUS)

Headlight (S2/socket BA20d) (☛ p. 110)

- Insert the protection cap with the bulb socket into the reflector and turn it all the way clockwise.
- Insert the bulb socket of the parking light into the reflector.

Finishing work



- Install the headlight mask with the headlight. (☛ p. 84)

14.8 Changing the turn signal bulb (TE EU/AUS)

Note

Damage to reflector Reduced luminance.

- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



101722-10

Main work

- Remove the screw on the rear of the turn signal housing.
- Carefully remove turn signal glass ❶.
- Lightly squeeze orange cap ❷ in the area of the holding lugs and take it off.
- Press the turn signal bulb lightly into the socket, turn it counterclockwise by about 30°, and take it out of the socket.



Info

Do not touch the reflector with your fingers, and keep it free from grease.

- Press the new turn signal bulb carefully into the socket and turn it clockwise until it stops.


Turn signal (R10W/socket BA15s) (☛ p. 110)

- Mount the orange cap.
- Position the turn signal glass.
- Insert the screw and first turn it counterclockwise until it engages in the thread with a slight jerk. Tighten the screw slightly.

Finishing work

- Check that the turn signal system is functioning properly.

14.9 Checking the headlight setting



- Position the vehicle upright on a horizontal surface in front of a light wall and make a mark at the height of the center of the low beam headlight.
- Make another mark a distance **B** under the first mark.

Guideline

Distance B	5 cm (2 in)
-------------------	-------------

- Position the vehicle vertically a distance **A** away from the wall.

Guideline


Distance A	5 m (16 ft)
-------------------	-------------

- The rider now sits down on the motorcycle.
- Switch on the low beam.
- Check the headlight setting.

The boundary between light and dark must be exactly on the lower mark for a motorcycle with driver.

- » If the light-dark border does not meet specifications:
 - Adjust the headlight range. (☛ p. 86)

14.10 Adjusting the headlight range



Preparatory work

- Check the headlight setting. (☛ p. 86)

Main work

- Turn adjusting screw **1** to adjust the headlight range.

Guideline

The boundary between light and dark must be exactly on the lower mark for a motorcycle with a rider (instructions on how to apply the mark: Checking the headlight setting).




Info

Turn clockwise to reduce the headlight range; turn counterclockwise to increase the headlight range.

A change in weight on the vehicle may require a correction of the headlight range.

14.11 Changing the speedometer battery




Preparatory work

- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (☛ p. 84)

Main work


- Remove screws **1**.
- Pull the speedometer upward out of the holder.



- Using a coin, turn protection cap ② all the way counterclockwise and remove it.
- Remove speedometer battery ③.
- Insert the new battery with the lettering facing up.

Speedometer battery (CR 2430) (☛ p. 110)

- Check the O-ring of the protection cap for correct seating.




- Position protection cap ② and turn all the way clockwise using a coin.
- Press any button on the speedometer.
✓ The speedometer is activated.
- Position the speedometer in the holder.
- Mount and tighten the screws with the washers.

Finishing work

- Install the headlight mask with the headlight. (☛ p. 84)
- Set kilometers or miles. (☛ p. 17)
- Adjust the speedometer functions. (☛ p. 17)
- Set the clock. (☛ p. 18)

15.1 Cooling system




(TE 125)

Water pump ❶ in the engine circulates the coolant. The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ❷. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.



(TE 250/300)

Water pump ❶ in the engine circulates the coolant. The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ❷. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

15.2 Checking the antifreeze and coolant level

**Warning**


Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

**Warning**

Danger of poisoning Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

**Condition**

The engine is cold.

- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the coolant antifreeze.

-25... -45 °C (-13... -49 °F)

» If the coolant antifreeze does not meet specifications:

- Correct the coolant antifreeze.

- Check the coolant level in the radiator.

Coolant level A above the radiator fins.	10 mm (0.39 in)
--	-----------------

» If the level of the coolant does not meet specifications:

- Correct the coolant level.

Alternative 1



Coolant (☞ p. 119)


Alternative 2

Coolant (mixed ready to use) (☞ p. 119)

- Mount the radiator cap.



15.3 Checking the coolant level


- **Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.




- Condition**
The engine is cold.
- Stand the motorcycle upright on a horizontal surface.
 - Remove the radiator cap.
 - Check the coolant level in the radiator.
- | | |
|---|-----------------|
| Coolant level A above the radiator fins. | 10 mm (0.39 in) |
|---|-----------------|
- » If the level of the coolant does not meet specifications:
- Correct the coolant level.
- Alternative 1**
- | |
|--------------------|
| Coolant (☛ p. 119) |
|--------------------|
- Alternative 2**
- | |
|---|
| Coolant (mixed ready to use) (☛ p. 119) |
|---|
- Mount the radiator cap.

15.4 Draining the coolant ☛

- **Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



- Condition**
The engine is cold.
- Position the motorcycle upright.
 - Place a suitable container under the water pump cover.
- (TE 125)**
- Remove screw **1**. Take off radiator cap **2**.
 - Completely drain the coolant.
 - Mount and tighten screw **1** with a new seal ring.
- Guideline
- | | | |
|------------------------------|-------|------------------------|
| Drain plug, water pump cover | M10x1 | 15 Nm
(11.1 lbf ft) |
|------------------------------|-------|------------------------|



(TE 250/300)

- Remove screw ❶. Take off radiator cap ❷.
- Completely drain the coolant.
- Mount and tighten screw ❶ with a new seal ring.

Guideline

Drain plug, water pump cover	M10x1	15 Nm (11.1 lbf ft)
------------------------------	-------	------------------------

15.5 Refilling with coolant



Warning

Danger of poisoning Coolant is poisonous and a health hazard.


- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



(TE 125)

- Make sure that screw ❶ is tightened.
- Position the motorcycle upright.
- Fill the radiator completely with coolant.


Coolant	1.2 l (1.3 qt.)	Coolant (☛ p. 119)
		Coolant (mixed ready to use) (☛ p. 119)



- Loosen screw ❷ until coolant that does not contain any bubbles escapes. Replace and retighten screw ❷.

Guideline

Bleeder screw, cylinder head	M6	10 Nm (7.4 lbf ft)
------------------------------	----	-----------------------



(TE 250/300)

- Make sure that screw ❶ is tightened.
- Position the motorcycle upright.
- Fill the radiator completely with coolant.

Coolant	1.2 l (1.3 qt.)	Coolant (☛ p. 119)
		Coolant (mixed ready to use) (☛ p. 119)

- Position the vehicle as shown and secure it against rolling away. A height difference of A must be reached.


Guideline

Height difference A	75 cm (29.5 in)
---------------------	-----------------



Info

To ensure that all of the air can escape from the cooling system, the front of the vehicle must be jacked up. A poorly bled cooling system is less effective at cooling and may result in overheating of the engine.




- Place the vehicle back on a level surface.



- Fill the radiator completely with coolant.
- Mount radiator cap ②.
- Run the engine until it is warm.
- Check the coolant level. (➔ p. 89)

16.1 Checking the play in the throttle cable



- Check the throttle grip for smooth operation.
- Move the handlebar to the straight-ahead position. Move the throttle grip backwards and forwards to ascertain the play in the throttle cable.

Play in throttle cable	3... 5 mm (0.12... 0.2 in)
------------------------	----------------------------

- » If the throttle cable play does not meet specifications:
 - Adjust the play in the throttle cable. (p. 92)



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:
 - Adjust the play in the throttle cable. (p. 92)

16.2 Adjusting the play in the throttle cable



Main work

- Move the handlebar to the straight-ahead position.
- Push back sleeve ①.
- Ensure that the throttle cable sleeve is pushed all the way into barrel adjuster ②.
- Loosen nut ③.
- Turn adjusting screw ② in such a way there is throttle cable play A in the throttle grip.

Guideline


Play in throttle cable	3... 5 mm (0.12... 0.2 in)
------------------------	----------------------------

- Tighten nut ③.
- Slide on sleeve ①.

Finishing work

- Check the throttle grip for smooth operation.

16.3 Carburetor



The idle setting of the carburetor has a big influence on the starting behavior, on stable idling, and on the vehicle response when the throttle is opened. This means that an engine with a correctly set idle speed is easier to start than if the idle is set wrongly.




Info

The carburetor and its components are subject to greater wear due to engine vibrations. Wear can lead to malfunctions.

The factory setting for the carburetor is set for the following values.

Altitude above sea level	500 m (1,640 ft)
Ambient temperature	20 °C (68 °F)

Super unleaded gasoline, mixed with 2-stroke engine oil (1:60) (p. 120)



The idle speed is adjusted with adjusting screw ❶.
The idle mixture is adjusted with the idle air adjusting screw ❷.

Idle range A

Operation with the throttle slide closed. This range is influenced by adjusting screw ❶ and the idle air adjusting screw ❷.

Transition range B

Behavior of the engine when the throttle slide is being opened. This range is influenced by the idling jet and by the form of the throttle slide.
If the engine sputters and smokes heavily when it starts despite a good idle and part-load setting, and if it abruptly reaches full power at a high rpm, the carburetor setting is too rich, the float level is too high, or the float needle valve is leaky.


Part-load range C

Operation with the throttle slide partially open. This range is influenced by the jet needle (form and position). The idle setting influences the engine tuning in the lower range, and the main jet influences the engine tuning in the upper range.
If, when accelerating with the throttle slide partially opened, the engine only stutters while running, the jet needle needs to be lowered by one level. If the engine knocks, especially when it reaches the full performance engine speed while accelerating, the jet needle needs to be raised. If the behavior described above occurs while idling or just above idling, the idling system needs to be regulated to a leaner setting if the engine is stuttering and to a richer setting if knocking.

Full-load range D

Operation with the throttle slide open (full throttle). This range is influenced by the main jet and jet needle.
If the insulator of a new spark plug is very light-colored or white after a brief ride at full throttle, or if the engine knocks, a larger main jet needs to be used. If the insulator is dark brown or sooty, a smaller main jet needs to be used.

16.4 Carburetor - adjusting the idle speed 🛠️



- Screw in idle air adjusting screw ❷ all the way and turn it to the specified basic position.

Guideline

Idle air adjusting screw (TE 125)	
Open	2.75 turns
Idle air adjusting screw (TE USA)	
Open	2.0 turns
Idle air adjusting screw (TE AUS)	
Open	3.5 turns
Idle air adjusting screw (TE 250 EU)	
Open	1.5 turns
Idle air adjusting screw (TE 300 EU)	
Open	1.75 turns

- Run the engine until warm.

Guideline

Warm-up time	≥ 5 min
--------------	---------



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.
– When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Adjust the idle speed with adjusting screw ❶.

Guideline

Choke function deactivated – The choke knob is pushed in all the way. (🔧 p. 23)	
Idle speed	1,400... 1,500 rpm

- Turn idle air adjusting screw ❷ slowly in a clockwise direction until the idle speed begins to fall.

- Note the position and turn the idle air adjusting screw slowly counterclockwise until the idle speed falls again.
- Adjust to the point between these two positions with the highest idle speed.

**Info**

If there is a large engine speed rise, reduce the idle speed to a normal level and repeat the above steps.

If the procedure described here does not lead to satisfactory results, the cause may be a wrongly dimensioned idling jet.

If you can turn the idle air adjusting screw to the end without any change of engine speed, you need to install a smaller idling jet.

After changing the idling jet, repeat the adjusting steps from the beginning. Following extreme air temperature or altitude changes, adjust the idle speed again.

16.5 Emptying the carburetor float chamber

**Danger**

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.

**Warning**

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.

**Warning**

Environmental hazard Improper handling of fuel is a danger to the environment.


- Do not allow fuel to get into the ground water, the ground, or the sewage system.

**Info**

Carry out this work with a cold engine.


Water in the float chamber results in malfunctioning.

Preparatory work


- Turn tap handle ❶ on the fuel tap to position **OFF**. (Figure L00310-10  p. 23)
- ✓ Fuel no longer flows from the fuel tank to the carburetor.

Main work

- Place a cloth beneath the carburetor to soak up emerging fuel.
- Remove screw plug ❶.
- Completely drain the fuel.
- Mount and tighten the screw plug.



16.6 Checking the basic position of the shift lever




- Sit on the vehicle in the riding position and determine distance **A** between the upper edge of your boot and the shift lever.


Distance between shift lever and upper edge of boot	10... 20 mm (0.39... 0.79 in)
---	-------------------------------

- » If the distance does not meet specifications:
 - Adjust the basic position of the shift lever. (p. 95)

16.7 Adjusting the basic position of the shift lever



- Remove screw **1** and take off shift lever **2**.



- Clean gear teeth **A** of the shift lever and shift shaft.
- Mount the shift lever on the shift shaft in the required position and engage the gearing.



Info


The range of adjustment is limited.
The shift lever must not come into contact with any other vehicle components during the shift procedure.

- Mount and tighten the screw.

Guideline

Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
--------------------	----	------------------------	---------------

16.8 Engine characteristic - auxiliary spring (TE 250/300)



The auxiliary spring is located on the right side of the engine below the water pump cover.

Possible states

- Auxiliary spring with yellow marking – Auxiliary spring mounted at the factory with medium tuning (standard) for good rideability.
- Auxiliary spring with green marking – Auxiliary spring contained in the separate enclosure for softer performance.
- Auxiliary spring with red marking – Auxiliary spring contained in the separate enclosure for more aggressive performance.

The engine characteristic can be influenced by different spring strengths of auxiliary spring **1**.

16.9 Engine characteristic - setting the auxiliary spring (TE 250/300)




Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.


- Do not touch hot components such as exhaust system, radiator, engine, shock absorber, and the brake system. Allow these components to cool down before starting work on them.

Preparatory work


- Tilt the motorcycle approx. 45° to the left and secure it to prevent it from falling.



- Main work**
- Remove screws ❶.




- Take cap ❷, adjusting spring ❸, auxiliary spring ❹, and spring insert ❺ out of the clutch cover.
- Pull both springs off of the spring insert.



- Mount the required auxiliary spring ❹ and adjusting spring ❸ and slide them into the clutch cover together.

Auxiliary spring with yellow marking (54637072300)
Auxiliary spring with green marking (54837072100)
Auxiliary spring with red marking (54837072000)

✓ The cut-out of spring insert ❺ engages in the angle lever.

 **Info**


Screw ❻ must not be turned as this would worsen the engine characteristic.

- Check the O-ring in the cap.
- Position the cap.
- Mount and tighten the screws.

Guideline		
Screw, exhaust control cover	M5	6 Nm (4.4 lbf ft)

17.1 Checking the gear oil level

i Info
The gear oil level must be checked while the engine is cold.




Preparatory work
– Stand the motorcycle upright on a horizontal surface.

- Main work (TE 125)**
- Remove screw ❶ from the opening used to check the gear oil level.
 - Check the gear oil level.
- A small quantity of gear oil should flow out of the opening.
- » If gear oil does not flow out:
 - Add gear oil. 🛢️ (🔧 p. 99)
 - Mount and tighten the screw in the opening used to check the gear oil level.

Guideline

Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)
-----------------------------	----	-----------------------




- (TE 250/300)**
- Remove screw ❶ from the opening used to check the gear oil level.
 - Check the gear oil level.
- A small quantity of gear oil should flow out of the opening.
- » If gear oil does not flow out:
 - Add gear oil. 🛢️ (🔧 p. 99)
 - Mount and tighten the screw in the opening used to check the gear oil level.


Guideline

Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)
-----------------------------	----	-----------------------

17.2 Changing the gear oil 🛢️




- Drain the gear oil. 🛢️ (🔧 p. 98)




- Refill with gear oil. 🛢️ (🔧 p. 98)

17.3 Draining the gear oil

- 

Warning


Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

 - Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.
- 

Warning

Environmental hazard Hazardous substances cause environmental damage.

 - Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Only drain the gear oil while the engine is warm.

- Preparatory work**
- Park the motorcycle on a level surface.
 - Remove the engine guard. (🔧 p. 67)
 - Place a suitable container under the engine.

- Main work**
(TE 125)
- Remove the gear oil drain plug with magnet ❶.
 - Remove gear oil drain plug ❷.
 - Completely drain the gear oil.
 - Clean the gear oil drain plug thoroughly.
 - Clean the sealing area on the engine.
 - Mount the gear oil drain plug with magnet ❶ and the seal ring and tighten.

Guideline		
Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)

- Mount gear oil drain plug ❷ with the seal ring and tighten.


Guideline		
Gear oil drain plug	M10x1	15 Nm (11.1 lbf ft)

- (TE 250/300)**
- Remove the gear oil drain plug with magnet ❶.
 - Completely drain the gear oil.
 - Clean the gear oil drain plug with the magnet thoroughly.
 - Clean the sealing area on the engine.
 - Mount the gear oil drain plug with magnet ❶ and the seal ring and tighten.

Guideline		
Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)


- Finishing work**
- Install the engine guard. (🔧 p. 67)

17.4 Refilling with gear oil



Info

Too little gear oil or poor-quality oil results in premature wear of the transmission.



Main work

- Remove screw cap ❶ and fill up gear oil.

Gear oil (TE 125)	0.70 l (0.74 qt.)	Engine oil (15W/50) (☞ p. 119)
Gear oil (TE 250/300)	0.80 l (0.85 qt.)	Engine oil (15W/50) (☞ p. 119)

- Mount and tighten the screw cap.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.

Finishing work

- Check the gear oil level. (☞ p. 97)

17.5 Adding gear oil ☞



Info

Too little gear oil or poor-quality gear oil results in premature wear of the transmission. The gear oil must be added while the engine is cold.


Preparatory work

- Park the motorcycle on a level surface.

Main work


(TE 125)

- Remove screw ❶ from the opening used to check the gear oil level.



(TE 250/300)

- Remove screw ❶ from the opening used to check the gear oil level.



- Remove screw cap ❷.

- Add gear oil until it emerges from the opening used to check the gear oil level.

Engine oil (15W/50) (☞ p. 119)

- Mount and tighten the screw in the opening used to check the gear oil level.

Guideline


(TE 125)

Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)
-----------------------------	----	-----------------------

(TE 250/300)

Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)
-----------------------------	----	-----------------------

- Mount and tighten screw cap ❷.



**Danger**

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
-
- Start the engine and check that it is oil-tight.

18.1 Cleaning the motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

- When cleaning the vehicle with a pressure cleaner, do not point the water jet directly onto electrical components, connectors, cables, bearings, etc. Maintain a minimum distance of 60 cm between the nozzle of the pressure cleaner and the component. Excessive pressure can cause malfunctions or destroy these parts.


**Warning**

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period. Avoid direct sunshine on the motorcycle during cleaning.



- Close off the exhaust system to prevent water from entering.
- Remove coarse dirt particles with a gentle spray of water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a paintbrush.

Motorcycle cleaner (☛ p. 121)

**Info**

Use warm water containing normal motorcycle cleaner and a soft sponge. Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the closure of the exhaust system.
- Empty the carburetor float chamber. ☛ (☛ p. 94)

**Warning**

Danger of accidents Reduced braking efficiency due to a wet or dirty brake system.

- Clean or dry a dirty or wet brake system by riding and braking gently.

- After cleaning, ride a short distance until the engine reaches operating temperature.

**Info**

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

- After the motorcycle has cooled off, lubricate all moving parts and bearings.
- Clean the chain. (☛ p. 59)
- Treat bare metal parts (except for brake discs and exhaust system) with anti-corrosion materials.

Cleaning and polishing materials for metal, rubber and plastic (☛ p. 121)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Cleaning and polishing materials for metal, rubber and plastic (☛ p. 121)


(TE EU/AUS)

- Lubricate the steering lock.

Universal oil spray (☛ p. 122)

18.2 Checks and maintenance steps for winter operation

- i Info**
If the motorcycle is used in the winter, salt can be expected on the roads. Precautions need to be taken against road salt corrosion.
If the vehicle was operated in road salt, clean it with cold water after riding. Warm water would enhance the corrosive effects of salt.



- Clean the motorcycle. (🔧 p. 101)
- Clean the brakes.

- i Info**
After **EVERY** trip on salted roads, thoroughly wash the brake calipers and brake linings with cold water and dry carefully. This should be done after the parts are cooled down and while they are installed.
After riding on salted roads, thoroughly wash the motorcycle with cold water and dry it well.

- Treat the engine, swingarm, and all other bright and zinc-plated parts (except for the brake discs) with a wax-based corrosion inhibitor.

- i Info**
Corrosion inhibitor is not permitted to come in contact with the brake discs as this would greatly reduce the braking force.

- Clean the chain. (🔧 p. 59)

19.1 Storage

**Warning**


Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.

**Info**

If you want to garage the motorcycle for a longer period, take the following steps.

Before storing the motorcycle, check all parts for function and wear. If service, repairs or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- Clean the motorcycle. (🔧 p. 101)
- Change the gear oil. 🛢️ (🔧 p. 97)
- Check the antifreeze and coolant level. (🔧 p. 88)
- Drain the fuel from the fuel tank into a suitable container.
- Empty the carburetor float chamber. 🛢️ (🔧 p. 94)
- Check the tire air pressure. (🔧 p. 80)

(TE 250/300)

- Remove the battery. 🛢️ (🔧 p. 82)

(TE 250/300)

- Recharge the battery. 🛢️ (🔧 p. 82)

Guideline

Storage temperature of battery without direct sunlight	0... 35 °C (32... 95 °F)
--	--------------------------

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

**Info**

HUSABERG recommends raising the motorcycle.


- Raise the motorcycle with the lift stand. (🔧 p. 44)
- Cover the vehicle with an air-permeable cover or blanket.

**Info**

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Avoid running the engine for a short time only. Because the engine will not warm up sufficiently, the water vapor produced during combustion will condense, causing engine parts and the exhaust system to rust.

19.2 Preparing for use after storage



- Remove the motorcycle from the lift stand. (🔧 p. 44)

(TE 250/300)

- Install the battery. 🛢️ (🔧 p. 82)
- Refuel. (🔧 p. 34)
- Perform checks and maintenance steps when preparing for use. (🔧 p. 31)
- Make a test ride.

Faults	Possible cause	Action
The engine cannot be cranked (electric starter)	Operating error	– Go through the steps of starting the engine. (☛ p. 31)
	Battery discharged	(TE 250/300) – Recharge the battery. ☛ (☛ p. 82) – Check the charging voltage. ☛ – Check the closed current. ☛
	Main fuse is blown	(TE 250/300) – Remove the main fuse. (TE 250/300) – Install the main fuse.
	Starter relay faulty	– Check the starter relay. ☛
	Starter motor faulty	– Check the starter motor. ☛
Engine turns but does not start	Operating error	– Go through the steps of starting the engine. (☛ p. 31)
	Motorcycle was out of use for a long time and there is old fuel in the float chamber	– Empty the carburetor float chamber. ☛ (☛ p. 94)
	Fuel feed interrupted	– Check the fuel tank breather. – Clean the fuel tap. – Check/set the carburetor components.
	Spark plug oily or wet	– Clean and dry the spark plug, or change it if necessary.
	Electrode distance (plug gap) of spark plug too wide	– Adjust the plug gap. Guideline (TE 125) Spark plug electrode gap 0.60 mm (0.0236 in) (TE 250/300) Spark plug electrode gap 0.60 mm (0.0236 in)
	Fault in ignition system	– Check the ignition system. ☛
	Short circuit cable in wiring harness frayed, kill switch faulty	– Check the kill switch. ☛
	The connector or ignition coil is loose or oxydized	– Clean the connector and treat with contact spray.
Engine has no idle	Water in carburetor or jets blocked	– Check/set the carburetor components.
	Idling jet blocked	– Check/set the carburetor components.
	Adjusting screws on carburetor distorted	– Carburetor - adjust the idle speed. ☛ (☛ p. 93)
	Spark plug defective	– Change the spark plug.
Engine does not speed up	Ignition system defective	– Ignition coil - check the primary winding. ☛ – Ignition coil - check the secondary winding. ☛ – Check the spark plug connector. ☛
	Carburetor running over because float needle dirty or worn	– Check/set the carburetor components.
	Loose carburetor jets	– Check/set the carburetor components.
Engine has too little power	Fault in ignition system	– Check the ignition system. ☛
	Fuel feed interrupted	– Check the fuel tank breather. – Clean the fuel tap. – Check/set the carburetor components.
	Air filter very dirty	– Clean the air filter and air filter box. ☛ (☛ p. 54)
	Exhaust system leaky, deformed or too little glass fiber yarn filling in main silencer	– Check exhaust system for damage. – Change the glass fiber yarn filling of the main silencer. ☛ (☛ p. 56)
	Fault in ignition system	– Check the ignition system. ☛

Faults	Possible cause	Action
Engine has too little power	Diaphragm or reed valve housing damaged	– Check the diaphragm and reed valve housing.
Engine stalls or is popping into the carburetor	Lack of fuel	– Turn tap handle ❶ on the fuel tap to position ON . (Figure L00310-10 p. 23) – Refuel. (p. 34)
	Engine takes in bad air	– Check the intake flange and carburetor for tightness.
	The connector or ignition coil is loose or oxydized	– Clean the connector and treat with contact spray.
Engine overheats	Too little coolant in cooling system	– Check the cooling system for leakage. – Check the coolant level. (p. 89)
	Too little air stream	– Switch off engine when stationary.
	Radiator fins very dirty	– Clean the radiator fins.
	Foam formation in cooling system	– Drain the coolant. (p. 89) – Refill with coolant. (p. 90)
	Damaged cylinder head or cylinder head gasket	– Check the cylinder head or cylinder head gas-ket.
	Bent radiator hose	– Change the radiator hose. (p. 90)
White smoke emission (steam in exhaust gas)	Damaged cylinder head or cylinder head gasket	– Check the cylinder head or cylinder head gas-ket.
Gear oil exits at the vent hose	Too much gear oil added	– Check the gear oil level. (p. 97)
Water in the gear oil	Damaged shaft seal ring or water pump	– Check the shaft seal ring and water pump.

21.1 Engine**21.1.1 TE 125**

Design	1-cylinder 2-stroke engine, water-cooled, with reed intake and exhaust control
Displacement	124.8 cm ³ (7.616 cu in)
Stroke	54.5 mm (2.146 in)
Bore	54 mm (2.13 in)
Crankshaft bearing	1 grooved ball bearing/1 roller bearing
Conrod bearing	Needle bearing
Piston pin bearing	Needle bearing
Pistons	Aluminum cast
Piston rings	2 half keystone rings
X (upper edge of piston to upper edge of cylinder)	0... 0.10 mm (0... 0.0039 in)
Z (height of control flap)	43.7 mm (1.72 in)
Primary transmission	23:73
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	6-gear, claw shifted
Transmission ratio	
1st gear	12:33
2nd gear	15:31
3rd gear	17:28
4th gear	19:26
5th gear	21:25
6th gear	20:20
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment, type Kokusan
Ignition point (BTDC)	1.4 mm (0.055 in)
Spark plug	NGK BR9 ECMVX
Spark plug electrode gap	0.60 mm (0.0236 in)
Starting aid	Kick starter

21.1.2 All TE 250

Design	1-cylinder 2-stroke engine, water-cooled, with reed intake and exhaust control
Displacement	249 cm ³ (15.19 cu in)
Stroke	72 mm (2.83 in)
Bore	66.4 mm (2.614 in)
Exhaust valve - Beginning of adjustment	5,600 rpm
Exhaust valve - end of adjustment with red auxiliary spring	7,200 rpm
Exhaust valve - end of adjustment with yellow auxiliary spring	7,900 rpm
Exhaust valve - end of adjustment with green auxiliary spring	8,400 rpm
Crankshaft bearing	1 grooved ball bearing/1 roller bearing
Conrod bearing	Needle bearing
Piston pin bearing	Needle bearing
Pistons	Aluminum cast
Piston rings	2 half keystone rings
X (upper edge of piston to upper edge of cylinder)	0... 0.10 mm (0... 0.0039 in)
Z (height of control flap)	48 mm (1.89 in)
Primary transmission	26:72
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	6-gear, claw shifted
Transmission ratio	

1st gear	14:32
2nd gear	16:26
3rd gear	20:25
4th gear	22:23
5th gear	25:22
6th gear	26:20
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment, type Kokusan
Ignition point (BTDC)	1.9 mm (0.075 in)
Spark plug	NGK BR 7 ES
Spark plug electrode gap	0.60 mm (0.0236 in)
Starting aid	Kick starter and electric starter

21.1.3 All TE 300

Design	1-cylinder 2-stroke engine, water-cooled, with reed intake and exhaust control
Displacement	293 cm ³ (17.88 cu in)
Stroke	72 mm (2.83 in)
Bore	72 mm (2.83 in)
Exhaust valve - Beginning of adjustment	5,600 rpm
Exhaust valve - end of adjustment with red auxiliary spring	7,200 rpm
Exhaust valve - end of adjustment with yellow auxiliary spring	7,900 rpm
Exhaust valve - end of adjustment with green auxiliary spring	8,400 rpm
Crankshaft bearing	1 grooved ball bearing/1 roller bearing
Conrod bearing	Needle bearing
Piston pin bearing	Needle bearing
Pistons	Aluminum cast
Piston rings	2 rectangular rings
X (upper edge of piston to upper edge of cylinder)	0... 0.10 mm (0... 0.0039 in)
Z (height of control flap)	48.5 mm (1.909 in)
Primary transmission	26:72
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	6-gear, claw shifted
Transmission ratio	
1st gear	14:32
2nd gear	16:26
3rd gear	20:25
4th gear	22:23
5th gear	25:22
6th gear	26:20
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment, type Kokusan
Ignition point (BTDC)	1.9 mm (0.075 in)
Spark plug	NGK BR 7 ES
Spark plug electrode gap	0.60 mm (0.0236 in)
Starting aid	Kick starter and electric starter

21.2 Engine tightening torques

21.2.1 TE 125

Screw, membrane	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Locking screw for bearing	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, alternator cover	M5	5 Nm (3.7 lbf ft)	–
Screw, centrifugal timer	M5	8 Nm (5.9 lbf ft)	Loctite® 243™
Screw, exhaust control cover	M5	5 Nm (3.7 lbf ft)	–
Screw, exhaust flange	M5	6 Nm (4.4 lbf ft)	–
Screw, ignition system/stator	M5	6 Nm (4.4 lbf ft)	Loctite® 222
Screw, lock washer, axle for control flap	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, water pump wheel	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Adjustment cable, exhaust control	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Bleeder screw, cylinder head	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch slave cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch spring	M6	10 Nm (7.4 lbf ft)	–
Screw, engine case	M6	10 Nm (7.4 lbf ft)	–
Screw, exhaust control	M6	10 Nm (7.4 lbf ft)	–
Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)	–
Screw, intake flange/reed valve housing	M6	10 Nm (7.4 lbf ft)	–
Screw, kick starter stop plate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, shifting gate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, cylinder head	M7	18 Nm (13.3 lbf ft)	–
Axle for control flap, exhaust control	M8	Step 1 3 Nm (2.2 lbf ft) Step 2 (loosen, counter-clockwise) 1/4 turn	–
Nut, cylinder base	M8	30 Nm (22.1 lbf ft)	–
Screw, kick starter	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, shift drum locating	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Stud, cylinder base	M8	35 Nm (25.8 lbf ft)	–
Drain plug, water pump cover	M10x1	15 Nm (11.1 lbf ft)	–
Gear oil drain plug	M10x1	15 Nm (11.1 lbf ft)	–
Nut, rotor	M12x1	60 Nm (44.3 lbf ft)	–
Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Spark plug	M14x1.25	25 Nm (18.4 lbf ft)	–
Nut, primary gear	M16LHx1.5	130 Nm (95.9 lbf ft)	Loctite® 243™
Nut, inner clutch hub	M18x1.5	130 Nm (95.9 lbf ft)	Loctite® 243™
Cap nut, exhaust control	M26x1	35 Nm (25.8 lbf ft)	–

21.2.2 TE 250/300

Screw, angle lever, exhaust control	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, exhaust control cover	M5	6 Nm (4.4 lbf ft)	–
Screw, ignition pulse generator	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, locking lever	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, retaining bracket of exhaust control	M5	7 Nm (5.2 lbf ft)	Loctite® 243™

Screw, water pump wheel	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, alternator cover	M6	8 Nm (5.9 lbf ft)	–
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch spring	M6	10 Nm (7.4 lbf ft)	–
Screw, control flap, exhaust control	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, engine case	M6	10 Nm (7.4 lbf ft)	–
Screw, exhaust flange	M6	8 Nm (5.9 lbf ft)	–
Screw, gear oil level check	M6	10 Nm (7.4 lbf ft)	–
Screw, intake flange/reed valve housing	M6	10 Nm (7.4 lbf ft)	–
Screw, intermediate wheel bolt	M6	8 Nm (5.9 lbf ft)	Loctite® 648™
Screw, kick starter spring	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, kick starter stop plate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift drum bearing retainer	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, slave cylinder of the clutch	M6	10 Nm (7.4 lbf ft)	–
Screw, starter motor	M6	8 Nm (5.9 lbf ft)	–
Screw, stator	M6	8 Nm (5.9 lbf ft)	Loctite® 243™
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Screw, cylinder head	M8	27 Nm (19.9 lbf ft)	–
Screw, kick starter	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Nut, cylinder base	M10	35 Nm (25.8 lbf ft)	–
Drain plug, water pump cover	M10x1	15 Nm (11.1 lbf ft)	–
Nut, rotor	M12x1	60 Nm (44.3 lbf ft)	–
Gear oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Spark plug	M14x1.25	25 Nm (18.4 lbf ft)	–
Nut, inner clutch hub	M18x1.5	120 Nm (88.5 lbf ft)	Loctite® 2701
Nut, primary gear	M18LHx1.5	150 Nm (110.6 lbf ft)	Loctite® 648™

21.3 Capacities

21.3.1 Gear oil

Gear oil (TE 125)	0.70 l (0.74 qt.)	Engine oil (15W/50) (☛ p. 119)
Gear oil (TE 250/300)	0.80 l (0.85 qt.)	Engine oil (15W/50) (☛ p. 119)

21.3.2 Coolant

Coolant	1.2 l (1.3 qt.)	Coolant (☛ p. 119)
		Coolant (mixed ready to use) (☛ p. 119)

21.3.3 Fuel

Total fuel tank capacity, approx.	10.7 l (2.83 US gal)	Super unleaded gasoline, mixed with 2-stroke engine oil (1:60) (☛ p. 120)
Fuel reserve, approx.	2 l (2 qt.)	

21.4 Chassis

Frame	Central tube frame made of chrome molybdenum steel tubing	
Fork	WP Suspension Up Side Down 4860 4CS	
Suspension travel		
Front	292 mm (11.5 in)	
Rear	335 mm (13.19 in)	
Fork offset	22 mm (0.87 in)	
Shock absorber	WP Suspension PDS 5018 DCC	
Brake system	Disc brakes, brake calipers on floating bearings	
Brake discs - diameter		
Front	260 mm (10.24 in)	
Rear	220 mm (8.66 in)	
Brake discs - wear limit		
Front	2.5 mm (0.098 in)	
Rear	3.5 mm (0.138 in)	
Tire air pressure, road		
Front	2 bar (29 psi)	
Rear	2 bar (29 psi)	
Tire air pressure, off-road		
Front	1.0 bar (15 psi)	
Rear	1.0 bar (15 psi)	
Secondary ratio (TE 125)	14:50 (13:50)	
Secondary ratio (TE 250/300 EU/AUS)	14:50 (13:50)	
Secondary ratio (TE USA)	13:50	
Chain	5/8 x 1/4"	
Rear sprockets available	38, 40, 42, 45, 48, 49, 50, 51, 52	
Steering head angle	63.5°	
Wheelbase (TE 125)	1,471±10 mm (57.91±0.39 in)	
Wheelbase (TE 250/300)	1,482±10 mm (58.35±0.39 in)	
Seat height unloaded	960 mm (37.8 in)	
Ground clearance unloaded	355 mm (13.98 in)	
Weight without fuel, approx. (TE 125)	95 kg (209 lb.)	
Weight without fuel, approx. (TE 250/300)	104 kg (229 lb.)	
Maximum permissible front axle load	145 kg (320 lb.)	
Maximum permissible rear axle load	190 kg (419 lb.)	
Maximum permissible overall weight	335 kg (739 lb.)	

21.5 Electrical system

Battery (TE 250/300)	YTX4L-BS	Battery voltage: 12 V Nominal capacity: 3 Ah Maintenance-free
Speedometer battery	CR 2430	Battery voltage: 3 V
Headlight (TE EU/AUS)	S2/socket BA20d	12 V 35/35 W
Parking light (TE EU/AUS)	W5W/socket W2.1x9.5d	12 V 5 W
Indicator lamps (TE EU/AUS)	W2.3W/socket W2x4.6d	12 V 2.3 W
Turn signal (TE EU/AUS)	R10W/socket BA15s	12 V 10 W
Brake/tail light (TE EU/AUS)	LED	
License plate lamp (TE EU/AUS)	W5W/socket W2.1x9.5d	12 V 5 W

21.6 Tires

Validity	Front tires	Rear tires
(TE 125)	90/90 - 21 M/C 54R M+S TT Michelin ENDURO COMPETITION	120/90 - 18 65R TT Michelin ENDURO COMPETITION
(TE 250/300 EU/AUS)	90/90 - 21 M/C 54R M+S TT Michelin ENDURO COMPETITION	140/80 - 18 M/C 70R TT Michelin ENDURO COMPETITION
(TE USA)	80/100 - 21 M/C 51M TT Dunlop GEOMAX MX51	110/100 - 18 M/C 64M TT Dunlop GEOMAX MX51
Additional information is available in the Service section under: www.husaberg.com		

21.7 Fork

21.7.1 TE 125

Fork part number	24.18.7M.61
Fork	WP Suspension Up Side Down 4860 4CS
Compression damping	
Comfort	24 clicks
Standard	22 clicks
Sport	16 clicks
Rebound damping	
Comfort	23 clicks
Standard	21 clicks
Sport	21 clicks
Spring length with preload spacer(s)	470 mm (18.5 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	3.8 N/mm (21.7 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	4.0 N/mm (22.8 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	4.2 N/mm (24 lb/in)
Fork length	932 mm (36.69 in)
Air chamber length	110 mm (4.33 in)
Fork oil per fork leg	607 ml (20.52 fl. oz.)
Fork oil (SAE 4) (48601166S1) (☛ p. 119)	

21.7.2 TE 250/300

Fork part number	24.18.7M.63
Fork	WP Suspension Up Side Down 4860 4CS
Compression damping	
Comfort	24 clicks
Standard	22 clicks
Sport	16 clicks
Rebound damping	
Comfort	20 clicks
Standard	18 clicks
Sport	18 clicks
Spring length with preload spacer(s)	470 mm (18.5 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	4.0 N/mm (22.8 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	4.2 N/mm (24 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	4.4 N/mm (25.1 lb/in)
Fork length	932 mm (36.69 in)
Air chamber length	110 mm (4.33 in)
Fork oil per fork leg	607 ml (20.52 fl. oz.)
Fork oil (SAE 4) (48601166S1) (☛ p. 119)	

21.8 Shock absorber**21.8.1 TE 125**

Shock absorber part number	12.45.7M.61
Shock absorber	WP Suspension PDS 5018 DCC
Compression damping, low-speed	
Comfort	25 clicks
Standard	20 clicks
Sport	15 clicks
Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1.25 turns
Rebound damping	
Comfort	28 clicks
Standard	24 clicks
Sport	22 clicks
Spring preload	6 mm (0.24 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	63 N/mm (360 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	66 N/mm (377 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	69 N/mm (394 lb/in)
Spring length	250 mm (9.84 in)
Gas pressure	10 bar (145 psi)
Static sag	33... 35 mm (1.3... 1.38 in)
Riding sag	105... 115 mm (4.13... 4.53 in)
Fitted length	417 mm (16.42 in)
Shock absorber oil (☛ p. 120)	SAE 2.5

21.8.2 TE 250/300

Shock absorber part number	12.45.7M.63
Shock absorber	WP Suspension PDS 5018 DCC
Compression damping, low-speed	
Comfort	25 clicks
Standard	20 clicks
Sport	15 clicks
Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1.25 turns
Rebound damping	
Comfort	28 clicks
Standard	24 clicks
Sport	22 clicks
Spring preload	7 mm (0.28 in)
Spring rate	
Weight of rider: 65... 75 kg (143... 165 lb.)	66 N/mm (377 lb/in)
Weight of rider: 75... 85 kg (165... 187 lb.)	69 N/mm (394 lb/in)
Weight of rider: 85... 95 kg (187... 209 lb.)	72 N/mm (411 lb/in)
Spring length	250 mm (9.84 in)
Gas pressure	10 bar (145 psi)
Static sag	33... 35 mm (1.3... 1.38 in)

Riding sag	105... 115 mm (4.13... 4.53 in)
Fitted length	417 mm (16.42 in)
Shock absorber oil (☛ p. 120)	SAE 2.5

21.9 Chassis tightening torques

Spoke nipple, front wheel	M4.5	5... 6 Nm (3.7... 4.4 lbf ft)	–
Screw, battery terminal (TE 250/300)	M5	2.5 Nm (1.84 lbf ft)	–
Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)	–
Spoke nipple, rear wheel	M5	5... 6 Nm (3.7... 4.4 lbf ft)	–
Nut, starter motor	M6	10 Nm (7.4 lbf ft)	–
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)	–
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)	–
Screw, ball joint of push rod on foot brake cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, throttle grip	M6	3 Nm (2.2 lbf ft)	–
Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)	–
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)	Loctite® 2701
Nut, rim lock	M8	10 Nm (7.4 lbf ft)	–
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)	–
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	–
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)	–
Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)	–
Screw, engine brace	M8	33 Nm (24.3 lbf ft)	–
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	–
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	–
Screw, side stand attachment	M8	45 Nm (33.2 lbf ft)	Loctite® 2701
Screw, subframe	M8x20	35 Nm (25.8 lbf ft)	Loctite® 2701
Screw, subframe	M8x30	30 Nm (22.1 lbf ft)	Loctite® 2701
Screw, top steering stem	M8	17 Nm (12.5 lbf ft)	Loctite® 243™
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)	–
Engine bracket screw	M10	60 Nm (44.3 lbf ft)	–
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)	–
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)	–
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	Loctite® 243™
Screw, bottom shock absorber	M12	80 Nm (59 lbf ft)	Loctite® 2701
Screw, top shock absorber	M12	80 Nm (59 lbf ft)	Loctite® 2701
Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)	–
Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)	–
Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)	–
Screw-in nozzles, cooling system	M20x1.5	12 Nm (8.9 lbf ft)	Loctite® 243™
Screw, front wheel spindle	M24x1.5	45 Nm (33.2 lbf ft)	–

21.10 Carburetor

21.10.1 TE 125

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	FK125
Needle position	4th position from top
Jet needle	N84I (NOZF / NOZG / NOZH)
Main jet	100 (168/170/172)
Idling jet	38X38 (45)
Starting jet	50 (85)
Idle air adjusting screw	
Open	2.75 turns
Throttle slide	7 with cut-out
Slide stop	-

21.10.2 TE 250 EU

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	FK028
Needle position	2nd position from top
Jet needle	N84K (N8RW / N8RJ / N8RK)
Main jet	110 (162 / 165)
Idling jet	38X38 (35)
Starting jet	50 (85)
Idle air adjusting screw	
Open	1.5 turns
Throttle slide	7 with cut-out
Slide stop	Present

21.10.3 TE AUS

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	3600C
Needle position	1. Position from top
Jet needle	N3CJ (N8RW / N8RJ / N8RK / N2ZK / N2ZJ / N2ZL)
Main jet	160 (162/165)
Idling jet	35
Starting jet	85
Idle air adjusting screw	
Open	3.5 turns
Throttle slide	7 with cut-out
Slide stop	Present

21.10.4 TE 250 USA

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	BC4 0
Needle position	4th position from top
Jet needle	N8RJ (N8RW / N8RK)
Main jet	165 (162)
Idling jet	35
Starting jet	85
Idle air adjusting screw	
Open	2.0 turns

Throttle slide	7 with cut-out
Slide stop	-

21.10.5 TE 300 EU

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	FK029
Needle position	2nd position from top
Jet needle	N84K (N2ZJ / N2ZK / N2ZL)
Main jet	115 (162 / 165)
Idling jet	38X38 (35)
Starting jet	50 (85)
Idle air adjusting screw	
Open	1.75 turns
Throttle slide	7 with cut-out
Slide stop	Present

21.10.6 TE 300 USA

Carburetor type	KEIHIN PWK 36S AG
Carburetor identification number	BC5 0
Needle position	4th position from top
Jet needle	N2ZK (N2ZJ / N2ZL)
Main jet	165 (162)
Idling jet	35
Starting jet	85
Idle air adjusting screw	
Open	2.0 turns
Throttle slide	7 with cut-out
Slide stop	-

21.10.7 Carburetor tuning (TE 125) 🏍️**Danger**

Loss of approval for road use and insurance coverage The motorcycle is authorized for public road traffic in the homologous (reduced) version only.

- In the derestricted version, the motorcycle must be used only on closed off property remote from public road traffic.

KEIHIN PWK 36S AG							
M/FT ASL ↓	TEMP →	-20°C ... -7°C -2°F ... 20°F	-6°C ... 5°C 19°F ... 41°F	6°C ... 15°C 42°F ... 60°F	16°C ... 24°C 61°F ... 78°F	25°C ... 36°C 79°F ... 98°F	37°C ... 49°C 99°F ... 120°F
3.000 m 10,000 ft ↑ 2.301 m 7,501 ft	ASO IJ NDL POS MJ	1,5 45 NOZG 3 170	1,5 42 NOZG 3 168	2 42 NOZH 2 165	2,5 40 NOZH 2 162	3 40 NOZI 2 160	
2.300 m 7,500 ft ↑ 1.501 m 5,001 ft	ASO IJ NDL POS MJ	1,5 45 NOZG 4 172	1,5 45 NOZG 3 170	1,5 42 NOZG 3 168	2 42 NOZH 2 165	2,5 40 NOZH 2 162	3 40 NOZI 2 160
1.500 m 5,000 ft ↑ 751 m 2,501 ft	ASO IJ NDL POS MJ	1,5 48 NOZF 4 175	1,5 45 NOZG 4 172	1,5 45 NOZG 3 170	1,5 42 NOZG 3 168	2 42 NOZH 2 165	2,5 40 NOZH 2 162
750 m 2,500 ft ↑ 301 m 1,001 ft	ASO IJ NDL POS MJ	1 48 NOZE 5 178	1,5 48 NOZF 4 175	1,5 45 NOZG 4 172	1,5 45 NOZG 3 170	1,5 42 NOZG 3 168	2 42 NOZH 2 165
300 m 1,000 ft ↑ 0 m 0 ft	ASO IJ NDL POS MJ	1 50 NOZE 5 180	1 48 NOZF 5 178	1,5 48 NOZF 3 175	1,5 45 NOZG 4 172	1,5 45 NOZG 3 170	1,5 42 NOZG 3 168

401348-01

M/FT ASL	Sea level
TEMP	Temperature
ASO	Idle air adjusting screw open
IJ	Idling jet
NDL	Needle
POS	Needle position from above
MJ	Main jet

Does not apply to sand surfaces!

21.10.8 Carburetor tuning (All TE 250) 🏍️**Danger**

Loss of approval for road use and insurance coverage The motorcycle is authorized for public road traffic in the homologous (reduced) version only.

- In the derestricted version, the motorcycle must be used only on closed off property remote from public road traffic.

KEIHIN PWK 36S AG							
M/FT ASL ↓	TEMP →	-20°C ... -7°C -2°F ... 20°F	-6°C ... 5°C 19°F ... 41°F	6°C ... 15°C 42°F ... 60°F	16°C ... 24°C 61°F ... 78°F	25°C ... 36°C 79°F ... 98°F	37°C ... 49°C 99°F ... 120°F
3.000 m 10,000 ft ↑ 2.301 m 7,501 ft	ASO IJ NDL POS MJ	2 35 N8RJ 4 165	2 35 N8RJ 3 165	2,5 35 N8RK 3 162	2,5 35 N8RK 2 160	3 35 N8RL 2 158	
2.300 m 7,500 ft ↑ 1.501 m 5,001 ft	ASO IJ NDL POS MJ	1,5 35 N8RW 4 168	2 35 N8RJ 4 165	2 35 N8RJ 3 165	2,5 35 N8RK 3 162	2,5 35 N8RK 2 160	3 35 N8RL 2 158
1.500 m 5,000 ft ↑ 751 m 2,501 ft	ASO IJ NDL POS MJ	1,5 38 N8RH 4 170	1,5 35 N8RW 4 168	2 35 N8RJ 4 165	2 35 N8RJ 3 165	2,5 35 N8RK 3 162	2,5 35 N8RK 2 160
750 m 2,500 ft ↑ 301 m 1,001 ft	ASO IJ NDL POS MJ	1 40 N8RH 5 172	1,5 38 N8RH 4 170	1,5 35 N8RW 4 168	2 35 N8RJ 4 165	2 35 N8RJ 3 165	2,5 35 N8RK 3 162
300 m 1,000 ft ↑ 0 m 0 ft	ASO IJ NDL POS MJ	1 40 N8RG 5 175	1 40 N8RH 5 172	1,5 38 N8RH 4 170	1,5 35 N8RW 4 168	2 35 N8RJ 4 165	2 35 N8RJ 3 165

401043-01

M/FT ASL	Sea level
TEMP	Temperature
ASO	Idle air adjusting screw open
IJ	Idling jet
NDL	Needle
POS	Needle position from above
MJ	Main jet

Does not apply to sand surfaces!

21.10.9 Carburetor tuning (All TE 300)



Danger

Loss of approval for road use and insurance coverage The motorcycle is authorized for public road traffic in the homologous (reduced) version only.

- In the derestricted version, the motorcycle must be used only on closed off property remote from public road traffic.


KEIHIN PWK 36S AG							
M/FT ASL ↓	TEMP →	-20°C ... -7°C -2°F ... 20°F	-6°C ... 5°C 19°F ... 41°F	6°C ... 15°C 42°F ... 60°F	16°C ... 24°C 61°F ... 78°F	25°C ... 36°C 79°F ... 98°F	37°C ... 49°C 99°F ... 120°F
3.000 m 10,000 ft ↑ 2.301 m 7,501 ft	ASO IJ NDL POS MJ	2 35 N2ZK 4 165	2 35 N2ZK 3 165	2,5 35 N2ZL 3 162	3 35 N2ZL 2 160	3,5 35 N2ZL 2 158	
2.300 m 7,500 ft ↑ 1.501 m 5,001 ft	ASO IJ NDL POS MJ	1,5 35 N2ZJ 4 168	2 35 N2ZK 4 165	2 35 N2ZK 3 165	2,5 35 N2ZL 3 162	3 35 N2ZL 2 160	3,5 35 N2ZL 2 158
1.500 m 5,000 ft ↑ 751 m 2,501 ft	ASO IJ NDL POS MJ	1,5 38 N2ZW 4 170	1,5 35 N2ZJ 4 168	2 35 N2ZK 4 165	2 35 N2ZK 3 165	2,5 35 N2ZL 3 162	3 35 N2ZL 2 160
750 m 2,500 ft ↑ 301 m 1,001 ft	ASO IJ NDL POS MJ	1 40 N2ZW 5 172	1,5 38 N2ZW 4 170	1,5 35 N2ZJ 4 168	2 35 N2ZK 4 165	2 35 N2ZK 3 165	2,5 35 N2ZL 3 162
300 m 1,000 ft ↑ 0 m 0 ft	ASO IJ NDL POS MJ	1 40 N2ZH 5 175	1 40 N2ZW 5 172	1,5 38 N2ZW 4 170	1,5 35 N2ZJ 4 168	2 35 N2ZK 4 165	2 35 N2ZK 3 165

401044-01

M/FT ASL	Sea level
TEMP	Temperature
ASO	Idle air adjusting screw open
IJ	Idling jet
NDL	Needle
POS	Needle position from above
MJ	Main jet

Does not apply to sand surfaces!

21.10.10 General carburetor tuning 🛠️



B00075-10

1... 5

Needle position from above

The five possible needle positions are shown here.

The carburetor tuning depends on the defined ambient and operating conditions.

2-stroke engine oil

According to

- JASO FC (☛ p. 123)

Guideline

- Only use high quality 2-stroke engine oil of a well-known brand. HUSABERG recommends **Motorex®** products.

Fully synthetic

Supplier

Motorex®

- **Cross Power 2T**

Brake fluid DOT 4 / DOT 5.1

According to

- DOT

Guideline

- Use only brake fluid that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. HUSABERG recommends **Castrol** and **Motorex®** products.

Supplier

Castrol

- **RESPONSE BRAKE FLUID SUPER DOT 4**

Motorex®

- **Brake Fluid DOT 5.1**

Coolant

Guideline

- Use only suitable coolant (even in countries with high temperatures). Using inferior antifreeze can result in corrosion and foaming. HUSABERG recommends **Motorex®** products.

Mixture ratio

Antifreeze: -25... -45 °C (-13... -49 °F)	50 % anti-corrosion/antifreeze 50 % distilled water
---	--

Coolant (mixed ready to use)

Antifreeze	-40 °C (-40 °F)
------------	-----------------

Supplier

Motorex®

- **COOLANT G48**

Engine oil (15W/50)

According to

- JASO T903 MA (☛ p. 123)
- SAE (☛ p. 123) (15W/50)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Top Speed 4T**

Fork oil (SAE 4) (48601166S1)

According to

- SAE (☛ p. 123) (SAE 4)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Hydraulic oil (15)

According to

- ISO VG (15)

Guideline

- Use only hydraulic oil that complies with the specified standards (see specifications on the container) and that possesses the corresponding properties. HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- Hydraulic Fluid 75

Shock absorber oil (SAE 2.5) (50180342S1)

According to

- SAE (☛ p. 123) (SAE 2.5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Super unleaded (ROZ 95/RON 95/PON 91)

According to

- DIN EN 228 (ROZ 95/RON 95/PON 91)

Guideline

- Only use unleaded super fuel that matches or is equivalent to the specified fuel grade.
- Fuel with an ethanol content of up to 10 % (E10 fuel) is safe to use.



Info

Do **not** use fuel containing methanol (e. g. M15, M85, M100) or more than 10 % ethanol (e. g. E15, E25, E85, E100).

Super unleaded gasoline, mixed with 2-stroke engine oil (1:60)

According to

- DIN EN 228
- JASO FC (☛ p. 123) (1:60)

Mixture ratio

1:60	2-stroke engine oil (☛ p. 119) Super unleaded (ROZ 95/RON 95/PON 91) (☛ p. 120)
------	--

Supplier

Motorex®

- Cross Power 2T

Air filter cleaning agent

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Twin Air Dirt Bio Remover**

Chain cleaner

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Chain Clean**

Chain spray

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Chainlube Offroad**

Cleaning and polishing materials for metal, rubber and plastic

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Protect & Shine**

High viscosity grease

Guideline

- HUSABERG recommends **SKF®** products.

Supplier

SKF®

- **LGHB 2**

Long-life grease

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Bike Grease 2000**

Motorcycle cleaner

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Moto Clean 900**

Oil for foam air filter

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Twin Air Liquid Bio Power**

Rubber grip adhesive (00062030051)

Supplier

KTM-Sportmotorcycle AG / Division HUSABERG

- **GRIP GLUE**

Universal oil spray

Guideline

- HUSABERG recommends **Motorex®** products.

Supplier

Motorex®

- **Joker 440 Synthetic**

JASO FC

JASO FC is a classification for a 2-stroke engine oil that was specifically developed for the extreme demands of racing. Thanks to first rate synthetic esters and specially designed additives, superb combustion is achieved even under extreme operating conditions.

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles – the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. In most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

A	
Accessories	9
Air filter	
cleaning	54
installing	54
removing	53
Air filter box	
cleaning	54
sealing	55
Air filter box lid	
installing	53
removing	53
Antifreeze	
checking	88
Auxiliary substances	9
B	
Basic chassis setting	
checking with rider's weight	37
Battery	
installing	82
recharging	82
removing	82
Brake discs	
checking	70
Brake fluid	
front brake, adding	70
rear brake, adding	74
Brake fluid level	
front brake, checking	70
rear brake, checking	74
Brake linings	
front brake, changing	72
front brake, checking	71
rear brake, changing	75
rear brake, checking	75
C	
Capacity	
coolant	90, 109
fuel	34, 109
gear oil	99, 109
Carburetor	92
float chamber, emptying	94
idle speed, adjusting	93
Chain	
checking	61
cleaning	59
Chain guide	
adjusting	63
checking	61
Chain tension	
adjusting	60
checking	59
Chassis number	12
Choke	23
Cleaning, care	101-102
Clutch	
fluid level, checking/rectifying	65
fluid, changing	66
Clutch lever	14
basic position, adjusting	65
Compression damping	
fork, adjusting	42
Compression damping, high-speed	
shock absorber, adjusting	38
Compression damping, low-speed	
shock absorber, adjusting	37
Coolant	
draining	89
refilling	90
Coolant level	
checking	88-89
Cooling system	88
Customer service	9
D	
Difficult riding conditions	27
dry sand	28
high temperature	29
low temperature	30
muddy surfaces	29
slow speed	29
snow	30
wet sand	28
wet surfaces	29
E	
Electric starter button	16
Emergency OFF switch	15
Engine	
running in	27
Engine characteristic	
auxiliary spring	95
spring	95
Engine guard	
installing	67
removing	67
Engine number	12
Engine sprocket	
checking	61
Environment	7
F	
Figures	9
Filler cap	
closing	23
opening	22
Filling up	
fuel	34
Foot brake lever	
free travel, checking	73
Foot brake pedal	24
basic position, adjusting	73

Fork	
basic setting, checking	41
Fork legs	
bleeding	44
dust boots, cleaning	45
installing	46
removing	46
Fork protector	
installing	47
removing	47
Frame	
checking	63
Front fender	
installing	51
removing	51
Front wheel	
installing	77
removing	77
Fuel tank	
installing	58
removing	57
Fuel tap	23
Fuse	
main fuse, changing	83
G	
Gear oil	
adding	99
changing	97
draining	98
refilling	98
Gear oil level	
checking	97
H	
Hand brake lever	14
basic position, adjusting	69
free travel, adjusting	69
free travel, checking	69
Handlebar position	43
adjusting	43
Headlight	
headlight range, adjusting	86
Headlight adjustment	
checking	86
Headlight bulb	
changing	85
Headlight mask with headlight	
installing	84
removing	84
Horn button	15
I	
Intended use	6
K	
Key number	12
Kick starter	24
Kill switch	14
L	
Light switch	15
Lower triple clamp	
installing	48
removing	47
M	
Main fuse	
changing	83
Main silencer	
glass fiber yarn filling, changing	56
installing	55
removing	55
Motorcycle	
cleaning	101
raising with lift stand	44
removing from lift stand	44
O	
Operating substances	9
Overview of indicator lamps	16
Owner's Manual	8
P	
Play in throttle cable	
checking	92
Preparing for use	
advice on first use	26
after storage	103
checks and maintenance steps when preparing for use	31
Protective clothing	7
R	
Rear sprocket	
checking	61
Rear wheel	
installing	78
removing	78
Rebound damping	
fork, adjusting	42
shock absorber, adjusting	38
Riding sag	
adjusting	41
Right side cover	
installing	57
removing	56
Rubber grip	
checking	64
securing	65
S	
Safe operation	7
Seat	
mounting	53
remove	53
Service	9
Service schedule	35-36
Shift lever	24
basic position, adjusting	95

basic position, checking	95
Shock absorber	
compression damping, general	37
installing	52
removing	51
riding sag, checking	40
spring preload, adjusting	40
static sag, checking	39
Side stand	24
Spare parts	9
Speedometer	
adjusting	17
battery, changing	86
clock, setting	18
kilometers or miles, setting	17
speedometer overview	16
Spoke tension	
checking	80
Starting	31
Steering	
locking	25
unlocking	25
Steering head bearing	
greasing	50
Steering head bearing play	
adjusting	50
checking	49
Storage	103
Swingarm	
checking	63
T	
Technical data	
capacities	109
carburetor	114
chassis	110
chassis tightening torques	113
electrical system	110
engine	106
engine tightening torques	108
fork	111
shock absorber	112
tires	111
Throttle cable play	
adjusting	92
Throttle cable routing	
checking	64
Throttle grip	14
Tire air pressure	
checking	80
Tire condition	
checking	79
Transport	33
Troubleshooting	104-105
Turn signal bulb	
changing	85
Turn signal switch	15

Type label	12
U	
Use definition	6
V	
View of vehicle	
front left	10
rear right	11
W	
Warranty	9
Winter operation	
checks and maintenance steps	102
Work rules	7

KTM-Sportmotorcycle AG / Division HUSABERG
Stallhofnerstraße 3
5230 Mattighofen, Austria
www.husaberg.com



3802032en

