04 -	DRIVE SYSTEM AND BRAKE	
	DRIVE AND URIVEN FULLETS	
	MELANICAL DRANE	
	HYDRAULIC BRAKE	3
	TRACK	3
	GEARBOX	3
	CHAINCASE	3
05	- ELECTRICAL SYSTEM	3
00-		3
	IGNITION SYSTEM	3
	CHARGING SYSTEM	4
	STARTING SYSTEM	4
	ROTAX ELECTRONIC REVERSE (RER)	4
	LIGHTS, INSTRUMENTS AND ACCESSORIES	4
06 -	- STEERING STSTEM	
	HANDLEBAR	4
	SKI	4
07 -	- SUSPENSION	4
-		
	GINE (443 AND 552)	
01 -	- ENGINE REMOVAL AND INSTALLATION	5
	GENERAL	5
	PROCEDURES.	5
02 -	- ENGINE LEAK TEST	5
	PREPARATION	5
	PROCEDURES	5
	ENGINE LEAK VERIFICATION FLOW CHART	5
03 -	- AIR INTAKE SYSTEM	5
	PROCEDURES	6
	AIR FILTER	6
	AIR INTAKE SILENCER	6
04 -	- EXHAUST SYSTEM	6
	GENERAL	66
	PROCEDURES	6
	TUNED PIPE	6
	MANIFOLD	6
05	- OIL INJECTION SYSTEM	6
	GENERAL	72
	RECOMMENDED OIL TYPE	72
	INSPECTION	72
	OIL SYSTEM LEAK TEST	72
	DECOFFLIEFS	73
	OIL RESERVOIR	
	OIL LEVEL SENSOR	73
	OIL FILTER	74
	OIL PUMP	74
		79
		79
06		81
		83
		83
	STARTER HANDLE	
		83
		86
07	- AXIAI FAN	89
		90
	GENERAL	50

	PROCEDURES	90
	CYLINDER COWL	. 90
	AXIAL FAN	
	FAN BELT	. 91
	AXIAL FAN BEARING	. 93
08 -	MAGNETO SYSTEM	. 95
	GENERAL	
	PROCEDURES	. 97
	MAGNETO FLYWHEEL	. 97
	STATOR	. 99
	TRIGGER COIL	
09 -	- TOP END	101
	GENERAL	105
	PROCEDURES	105
	CYLINDER COWL	105
	CYLINDER HEAD	105
	CYLINDER	106
	PISTON	107
	REED VALVE	111
0 -	BOTTOM END	113
	GENERAL	
	PROCEDURES	116
	CRANKCASE	116
	CRANKSHAFT	117
	CRANKSHAFT BEARINGS	118
1 -	ENGINE MEASUREMENT	123
	CYLINDER HEAD WARPAGE	123
	COMBUSTION CHAMBER VOLUME MEASUREMENT	123
	CYLINDER TAPER	124
	CYLINDER OUT OF ROUND	124
	CYLINDER/PISTON CLEARANCE	125
	RING/PISTON GROOVE CLEARANCE	
	RING END GAP	127
	CRANKSHAFT DEFLECTION	127
	CONNECTING ROD BIG END AXIAL PLAY	127
	CRANKSHAFT ALIGNMENT	127
	CHECKING SURFACE FLATNESS	128
-		
EN	GINE (593) • ENGINE REMOVAL AND INSTALLATION	129
)1 -	ENGINE REMOVAL AND INSTALLATION	
	GENERAL PROCEDURES	132
-	PROCEDURES	137
02 -	ENGINE LEAK TEST	
	GENERAL. PROCEDURES.	137
	PROCEDURES.	140
	ENGINE LEAK VERIFICATION FLOW CHART	141
)3 -	AIR INTAKE SYSTEM	143
	PROCEDURES	
	AIR FILTER	144
	AIR FILLER	145
04 -	EXHAUST SYSTEM	147
	CENEDAL	
	PROCEDURES	
	TUNED PIPE	1.80
	MANIFOLD	1.82
	MANIFOLD	11

	EXHAUST GAS TEMPERATURE SENSOR (EGTS).	
	5 - COOLING SYSTEM	149
05	GENERAL	151
	GENERAL	154
	INSPECTION	154
	COOLING SYSTEM LEAK TEST	154
	MAINTENANCE	154
	COOLANT REPLACEMENT	154
	PROCEDURES	155
	THERMOSTAT	155
	RADIATOR CAP	156
	FRONT RADIATOR	150
	REAR RADIATOR	157
	COOLANT TANK	157
	WATER PUMP	157
	COOLANT TEMPERATURE SENSOR (CTS)	157
06	- OIL INJECTION SYSTEM	10/
	GENERAL	109
	RECOMMENDED OIL TYPE	163
	INSPECTION	163
	OIL SYSTEM LEAK TEST	163
	PROCEDURES	163
	OIL DECEDURED	164
	OIL RESERVOIR	164
	OIL LEVEL SENSOR	165
	OIL FILTER	165
	OIL PUMP	165
-	INJECTION NOZZLE	168
07	- REWIND STARTER	171
	GENERAL	173
	PROCEDURES	173
	STARTER HANDLE	173
	REWIND STARTER	173
	ROPE	176
08 -	- MAGNETO SYSTEM	179
	GENERAL	182
	PROCEDURES	192
	MAGNETO FLYWHEEL	182
	STATOR	102
	TRIGGER COIL	104
	CRANKSHAFT POSITION SENSOR (CPS)	100
09 -	TOP END.	180
	CENEDAL	
	PROCEDURES	190
	REED VALVE	190
	REED VALVE	
	RAVE VALVE	191
		194
	CYLINDER HEAD	195
	CYLINDER	195
10	PISTON.	196
10-	BOTTOM END	
		204
	PROCEDURES	204
	WALER PUMP	204
	BEARING HOUSING	204
	WATER/OIL PUMP SHAFT	208
	CHANKCASE	208
	CRANKSHAFT	209

	CRANKSHAFT BEARINGS	211
	11 - ENGINE MEASUREMENT	
	CYLINDER HEAD WARPAGE	215
	COMBUSTION CHAMBER VOLUME MEASUREMENT	215
	CYLINDER TAPER	
	CYLINDER OUT OF ROUND	216
	PISTON/CYLINDER CLEARANCE	217
	RING/PISTON GROOVE CLEARANCE.	218
	RING END GAP	219
	CRANKSHAFT DEFLECTION	210
	CONNECTING ROD BIG END AXIAL PLAY	210
	CRANKSHAFT ALIGNMENT	
)5	ENGINE (810)	The second
	01 - ENGINE REMOVAL AND INSTALLATION	221
	GENERAL	
	PROCEDURES	
	ENGINE REMOVAL	
	ENGINE INSTALLATION	
	02 - ENGINE LEAK TEST	
	GENERAL	
	PROCEDURES	
	PREPARATION	227
4	LEAK TEST	229
	REASSEMBLY	229
	03 – AIR INTAKE SYSTEM	231
	GENERAL	233
	PROCEDURES	233
	AIR INTAKE SILENCER	233
	INTAKE MANIFOLD	
	04 - EXHAUST SYSTEM	
	GENERAL	237
	PROCEDURES	
	EXHAUST PIPE	
	MUFFLER	
	05 - LUBRICATION SYSTEM	
	ENGINE LUBRICATION	
	GENERAL.	
	MAINTENANCE	
	OIL LEVEL VERIFICATION.	
	OIL CHANGE	
	OIL FILTER	
	INSPECTION	
	ENGINE OIL PRESSURE	243
	PROCEDURES	
	OIL PRESSURE SWITCH	
	ENGINE OIL PRESSURE REGULATOR	
	OIL PUMP	
	ENGINE OIL STRAINER	
	REED VALVE	
	06 - COOLING SYSTEM	
	GENERAL	252
	INSPECTION	
	COOLING SYSTEM LEAK TEST.	252
	MAINTENANCE	
	COOLANT REPLACEMENT	253
		V

PROCEDURES	-
	. 255
COOLANT TANK CAP.	255
FRONT RADIATOR	255
RADIATOR FAN	
RELAY R3	
REAR RADIATOR	
COOLANT TANK	
COOLANT TEMPERATURE SENSOR (CTS)	a second second second
THERMOSTAT	
WATER PUMP HOUSING	
WATER PUMP IMPELLER	200
WATER PUMP SHAFT AND SEALS	
07 - MAGNETO SYSTEM	263
GENERAL	265
PROCEDURES	265
MAGNETO COVER	265
STATOR	266
ROTOR	267
SPRAG CLUTCH.	268
SPRAG CLUTCH GEAR	and the state of the second
STARTER DRIVE GEARS	269
08 - CYLINDER AND HEAD	and the second second
GENERAL	
MAINTENANCE	275
VALVE CLEARANCE ADJUSTMENT	Contraction of the
PROCEDURES	
VALVE COVER	
TIMING CHAIN TENSIONER	
CAMSHAFT TIMING GEAR.	
ROCKER ARM	279
TIMING CHAIN	100 T 100 T
	281
CYLINDER HEAD	
CAMSHAFT	283
VALVE SPRING	287 288
VALVE	
VALVE GUIDE.	291
CYLINDER	292
PISTON.	293
PISTON RINGS	297
09 - BOTTOM END	299 302
GENERAL	
PROCEDURES	302
PTO COVER OIL SEAL.	302
PTO COVER	302
DRIVE GEARS	305
TIMING CHAIN	306 307
TIMING CHAIN GUIDE.	
CRANKCASE	307
CRANKSHAFT	311
FUEL SYSTEM	319
01 - FUEL TANK AND FUEL PUMP (440F, 550F AND 600)	
INSPECTION	322
FUEL SYSTEM LEAK TEST	322
PROCEDURES	322
DIAPHRAGM FUEL PUMP	

	IN-TANK FUEL STRAINER	
	IN-TANK FUEL STRAINER FUEL FILTER FUEL TANK	
	FUEL TANK	
02 -	THE TANK AND FUEL DUMP (AND ADD	
	INCOLOTION	
	THE OLIGITED IN THE WAY	
	PLIEL PRESSURE TEST	
	DECOEDUDEO	
	FUEL TANK	•
	FUEL TANK TROUBLESHOOTING. FUEL DELIVERY SYSTEM DIAGNOSTIC FLOW CHART	4.
	FUEL DELIVERY SYSTEM DIAGNOSTIC FLOW CHART • FUEL TANK AND FUEL PUMP (V800)	•
03 -	FUEL DELIVERY SYSTEM DIAGNOSTIC FLOW CHART FUEL TANK AND FUEL PUMP (V800) INSPECTION	-
	FUEL TANK AND FUEL PUMP (V800) INSPECTION FUEL SYSTEM LEAK TEST.	-
	FUEL SYSTEM LEAK TEST. FUEL PRESSURE TEST.	
	FUEL SYSTEM LEAK TEST. FUEL PRESSURE TEST. TROUBLESHOOTING.	
	FUEL PRESSURE TEST TROUBLESHOOTING FUEL SYSTEM DIAGNOSTIC FLOW CHART	
	FUEL SYSTEM DIAGNOSTIC FLOW CHART	
	PROCEDURES	
	ELIEL ELITED	
	ELEL DUMD	
	FUEL TANK	
04	- VM CARBURETORS (440F, 550F AND 600)	
04 -	CARBONETORS (440F, 550F AND 600)	
	CARBURETOR. THROTTLE CABLE CHOKE CABLE	-
	THROTTLE CABLE	
	CHOKE CARLE	
	CHOKE CABLE	5
		1 1
EN	CINE MANAGEMENT (SDI)	-
EN 01 -	GINE MANAGEMENT (SDI)	and the second
EN 01 -	GINE MANAGEMENT (SDI) • OVERVIEW	and the second
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL. OPERATING PRINCIPLE.	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION.	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM. ENGINE MANAGEMENT SYSTEM (EMS)	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM. ENGINE MANAGEMENT SYSTEM (EMS)	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM. ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION.	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION. IGNITION SYSTEM E-RAVE	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM. ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION. IGNITION SYSTEM. E-RAVE. ENGINE MODES OF OPERATION.	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM. ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION. IGNITION SYSTEM. E-RAVE. ENGINE MODES OF OPERATION. MONITORING SYSTEM	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE	
EN 01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION. FUEL DELIVERY SYSTEM. ELECTRICAL SYSTEM. ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION. IGNITION SYSTEM. E-RAVE. ENGINE MODES OF OPERATION. MONITORING SYSTEM	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC. GENERAL EMS FAULT CODE TABLES	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC. GENERAL EMS FAULT CODE TABLES EMS FAULT CODE SUPPLEMENTAL INFORMATION.	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC GENERAL EMS FAULT CODE TABLES EMS FAULT CODES SUPPLEMENTAL INFORMATION. COMMUNICATION TOOLS	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC. GENERAL EMS FAULT CODE TABLES EMS FAULT CODE SUPPLEMENTAL INFORMATION. COMMUNICATION TOOLS MPI (MULTI-PURPOSE INTERFACE)	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC. GENERAL EMS FAULT CODE TABLES EMS FAULT CODE SUPPLEMENTAL INFORMATION. COMMUNICATION TOOLS MPI (MULTI-PURPOSE INTERFACE) MPL2 (MULTI-PURPOSE INTERFACE)	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC GENERAL EMS FAULT CODE TABLES EMS FAULT CODE SUPPLEMENTAL INFORMATION. COMMUNICATION TOOLS MPI (MULTI-PURPOSE INTERFACE) MPI-2 (MULTI-PURPOSE INTERFACE) MPI-2 (MULTI-PURPOSE INTERFACE)	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION. IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC. GENERAL EMS FAULT CODE TABLES EMS FAULT CODE SUPPLEMENTAL INFORMATION. COMMUNICATION TOOLS MPI (MULTI-PURPOSE INTERFACE) MPI-2 (MULTI-PURPOSE INTERFACE) B.U.D.S. SOFTWARE ADJUSTMENT AND REPAIR PROCEDURES	
01 -	GINE MANAGEMENT (SDI) OVERVIEW GENERAL OPERATING PRINCIPLE AIR INDUCTION FUEL DELIVERY SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ELECTRICAL SYSTEM ENGINE MANAGEMENT SYSTEM (EMS) FUEL INJECTION IGNITION SYSTEM E-RAVE ENGINE MODES OF OPERATION MONITORING SYSTEM DIAGNOSTIC MODE ENGINE MANAGEMENT SYSTEM FUNCTIONS EMS DIAGNOSTIC AND COMMUNICATION TOOLS DIAGNOSTIC. GENERAL EMS FAULT CODE TABLES EMS FAULT CODE SUPPLEMENTAL INFORMATION. COMMUNICATION TOOLS MPI (MULTI-PURPOSE INTERFACE) MPL2 (MULTI-PURPOSE INTERFACE)	

	FUEL SYSTEM	375
	ELECTRICAL SYSTEM	376 380
		380
	IDLE SPEED CLOSED THROTTLE RESET	380
	THROTTLE CABLE	381
	IGNITION TIMING	382
	REPAIR PROCEDURES	382
	FUEL INJECTORS	
	ENGINE CONTROL MODULE (ECM)	
	THROTTLE BODY	
	THROTTLE POSITION SENSOR (TPS)	
	CRANKSHAFT POSITION SENSOR (CPS)	388
	AIR TEMPERATURE SENSOR (ATS)	389
	COOLANT TEMPERATURE SENSOR (CTS)	390
	AIR PRESSURE SENSOR (APS)	391
	EXHAUST GAS TEMPERATURE SENSOR (EGTS)	391
	KNOCK SENSOR (KS)	302
	E-RAVE SOLENOID	393
08		
	01 - OVERVIEW	395
	OPERATING PRINCIPLE	396
	AIR INDUCTION.	206
	FUEL SYSTEM	200
	ELECTRICAL SYSTEM.	207
	ENGINE MANAGEMENT SYSTEM	399
	ELECTRONIC FUEL INJECTION	399
	IGNITION.	399
	ENGINE MODES OF OPERATION	400
	MONITORING SYSTEM	400
	02 - EMS DIAGNOSTIC AND COMMUNICATION TOOLS	403
		403
		403
	MULTI-PURPOSE INTERFACE (MPI)	403
	MULTI-PURPOSE INTERFACE-2 (MPI-2)	405
	B.U.D.S. SOFTWARE	408
		410
	MONITORING SYSTEM	410
	FAULT CODES	410
	FAULT CODE TABLE	411
	ADDOCTIMENT AND REPAIR PROCEDURES	417
		417
	FUEL SYSTEM	417
	ELECTRICAL SYSTEM	418
	IDI E SPEED	420
	IDLE SPEED	420
	THIOTILL CADLE	400
	CLOCED THIOTTLE AND IDLE ACTUATOR RESET	401
		400
	HE ANT NOCEDURES	100
	ENGINE CONTROL MODULE (ECM)	100
		101
	TOLE HAIL ASSOCIATION AND AND AND AND AND AND AND AND AND AN	127
	IT MOTILE BODT	100
-	THROTTLE POSITION SENSOR (TPS)	431

	IDLE BYPASS VALVE	43
	CRANKSHAFT POSITION SENSOR (CPS)	
	CAMSHAFT POSITION SENSOR (CAPS)	
	MANIFOLD AIR PRESSURE AND TEMPERATURE SENSOR (MAPTS)	
	COOLANT TEMPERATURE SENSOR (CTS)	
	OIL PRESSURE SWITCH (OPS)	
ELI	ECTRICAL SYSTEM	
01 -	- COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE (600 MODELS)	
	COMMUNICATION TOOLS	
	MULTI-PURPOSE INTERFACE (MPI)	
	MULTI-PURPOSE INTERFACE MPI-2	
	B.U.D.S. SOFTWARE	
02 -	- IGNITION SYSTEM (440F/550F)	
	GENERAL	
	IGNITION SYSTEM TESTING SEQUENCE	
	PROCEDURES	
	SPARK PLUG	
	IGNITION SWITCH	
	TETHER CUT-OUT SWITCH	
	ENGINE CUT-OUT SWITCH	
	WIRING HARNESS	
	IGNITION COIL	
	IGNITION GENERATOR COIL	
	TRIGGER COIL	
	MPEM	
	ADJUSTMENT	
	IGNITION TIMING	
03 -	IGNITION SYSTEM (600)	
	GENERAL	
	IGNITION SYSTEM TESTING SEQUENCE	
	PROCEDURES	
	SPARK PLUG	
	ELECTRICAL CONNECTOR	
	DESS POST	
	ENGINE CUT-OUT SWITCH	
	WIRING HARNESS	
	IGNITION COIL	
	TRIGGER COIL	4
	MULTI-PURPOSE ELECTRONIC MODULE (MPEM)	
	ADJUSTMENT	
	IGNITION TIMING	
04 -	IGNITION SYSTEM (V800)	48
	GENERAL	
	PROCEDURES	4
	DESS SWITCH.	4
	ENGINE CUT-OUT SWITCH	4
	IGNITION COIL	4
	IGNITION TIMING	4
	SPARK PLUG	4
05 - 0	CHARGING SYSTEM	
	GENERAL	
	PROCEDURES	
	CHARGING FUSE	
	VOLTAGE REGULATOR	
	VERVE REVERTORIER CONTRACTORIER CONTRACTORIE CONTRACTORIE CONTRACTORIER CONTRACTORIE CONT	-
	STATOR	4

1

	BATTERY	476
	BATTERY (VRLA)	480
	06 - STARTING SYSTEM	483
	GENERAL	
	PROCEDURES	
	FUSES	
	BATTERY	490
	REVERSE SWITCH	490
	IGNITION SWITCH	490
	DESS SWITCH.	490
	ENGINE CUT-OUT SWITCH	490
	START SWITCH	490
	STARTING SOLENOID (440F/550F/600).	491
	STARTING SOLENOID (600 HO SDI)	492
	STARTING SOLENOID (V800)	
	ELECTRIC STARTER	
	07 - DIGITALLY ENCODED SECURITY SYSTEM (DESS)	501
	GENERAL	501
	KEY PROGRAMMING	501
	TROUBLESHOOTING.	502
	08 - ROTAX ELECTRONIC REVERSE (440F)	505
	GENERAL	
	TROUBLESHOOTING	
	TESTING PROCEDURES	505
	RER SWITCH	505
	RER TRIGGER COIL	505
	09 - LIGHTS, INSTRUMENTS AND ACCESSORIES.	
	GENERAL	509
		509
	RELAY LOCATION	510
	CURRENT TYPE (AC AND DC)	510
	POWER DISTRIBUTION	
	DIAGNOSTIC.	512
	LIGHTING AND ACCESSORIES SYSTEM TESTING.	512
	PROCEDURES	513
	FUSES	513
	RELAY R1	514
	RELAY R2	515
	RELAY R4	515
	HEADLAMP.	515
	TAILLIGHT	517
	ELECTRONIC SPEEDOMETER	517
	SPEED SENSOR	522
	TACHOMETER	523
	ENGINE TEMPERATURE GAUGE	524
	HEATING ELEMENTS	525
	12-VOLT POWER OUTLET	527
	12-VOLT REAR POWER OUTLET	527
	BEEPER	527
		521
0	DRIVE SYSTEM AND BRAKE	1997
	01 - DRIVE BELT	529
	APPLICATION CHART	529
	DRIVE BELT	529
	02 - DRIVE PULLEY (COMET® 102)	529
	GENERAL	
	PROCEDURES	535
		535

	FIXED AND SLIDING SHEAVES	535
	RAMPS	538
	RING GEAR	539
3 -	DRIVE PULLEY (BOMBARDIER LITE)	541
	GENERAL	
	PROCEDURES	543
	FIXED AND SLIDING SHEAVES	
	GOVERNOR CUP	544
	CENTRIFUGAL WEIGHT	545
	SPRING	
	RING GEAR	
-	DRIVE PULLEY (TRA III)	
	GENERAL	
	PROCEDURES	
	CALIBRATION SCREWS	
	FIXED AND SLIDING SHEAVES	
	GOVERNOR CUP	
	RAMPS.	
	SPRING	
	CENTRIFUGAL LEVERS	
	BUSHINGS	
-	DRIVE PULLEY (TRA IV)	
	GENERAL	_
	PROCEDURES	
	CALIBRATION SCREWS	
	FIXED AND SLIDING SHEAVES	
	GOVERNOR CUP.	
	RAMPS	
	SPRING	
	CENTRIFUGAL LEVERS	
	BUSHINGS	
i	DRIVEN PULLEY(IBC 5100 AND IBC VSA 6000)	
	GENERAL	
	PROCEDURES	
	DRIVEN PULLEY	575
_	DRIVEN PULLEY (LPV 27)	579
	GENERAL	581
	PROCEDURES	581
	DRIVEN PULLEY	581
_	PULLEY ALIGNMENT	587
	GENERAL	587
	PULLEY ALIGNMENT SPECIFICATIONS	587
	PROCEDURES.	588
_	BRAKE (WT/SWT/SUV/TUV)	591
	GENERAL	593
	PROCEDURES	593
	BRAKE FLUID	593
	BRAKE PADS	593
	BRAKE DISC	595
	CALIPER	595
	MASTER CYLINDER	596
	PRAKELICHT SWITCH	596
	COUNTERSHAFT AND BRAKE (LT 440F)	599
-		600
	GENERAL PROCEDURES	600
	BRAKE PADS	600
	BRAKE FAUS	×
		100 million

	CALIPER	- Cr
	GALIFER	60
	BRAKE CABLE	60
	BRAKE DISC.	60
	BRAKE LIGHT SWITCH	60
	COUNTERSHAFT	60
	COUNTERSHAFT BEARING.	60
11 -	CHAINCASE (LT 440F)	60
	GENERAL	60
	MAINTENANCE	60
	CHAINCASE OIL	6
	DRIVE CHAIN ADJUSTMENT	6
	PROCEDURES	
	CHAINCASE	6
	CHAINTENSIONER	
	CHAIN TENSIONER ROLLER BEARING	
	GEARBOX (WT/SWT/SUV/TUV)	-
	GENERAL	
	MAINTENANCE	
	GEARBOX OIL	6
1	PROCEDURES	-
	GEARBOX	_
	DRIVE AXLE	-
	GENERAL	6
in the set	PROCEDURES	6
	DRIVE AXLE	0.000
	DRIVE AXLE BEARING	6
	SPROCKETS.	
14 - '		
14 - 1	SPROCKETS	6
14 -	TRACK	6
SUS	TRACK TRACK PENSION	6
SUS	TRACK TRACK PENSION	6
SUS 01 -	TRACK TRACK PENSION FRONT SUSPENSION (LT/WT/SWT)	6
SUS 01 -	TRACK TRACK PENSION FRONT SUSPENSION (LT/WT/SWT) GENERAL	6 6 6
SUS 01 -	TRACK	6
SUS 01 -	TRACK	6 6 6 6 6 6 6
SUS 01 - 02 -	TRACK	
SUS 01 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	
SUS 01 - 02 - 03 -	TRACK	

	04 – REAR SUSPENSION (SUV/TUV)	
	SUSPENSION REMOVAL	
	SUSPENSION DISASSEMBLY AND ASSEMBLY	
	SUSPENSION INSTALLATION	
	SUSPENSION LUBRICATION	
(05 - SHOCK ABSORBER INSPECTION AND SERVICING	
	SHOCK ABSORBER	
2 5	STEERING	
0	1 - STEERING AND HANDLEBAR	
	GENERAL	
	PROCEDURES	
	HANDLEBAR GRIP.	
	HANDLEBAR	
	HANDLEBAR EXTENSION	
	TIE-ROD	
	STEERING ARM	
	STEERING COLUMN	
02	- SKIS AND STEERING ALIGNMENT	
	GENERAL	
	ADJUSTMENT	
	STEERING ALIGNMENT	
	PROCEDURES	
	SKI BLINNER	
	SKI RUNNER. SKI.	
BC	SKI RUNNER. SKI	
	SKI RUNNER. SKI	
	SKI RUNNER. SKI DDY/FRAME - BODY. PARTS REPLACEMENT	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT	
	SKI RUNNER SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL	
	SKI RUNNER. SKI	
	SKI RUNNER. SKI	
	SKI RUNNER SKI SKI DDY/FRAME - BODY PARTS REPLACEMENT DECAL HOOD FRONT BUMPER BOTTOM PAN	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT DECAL HOOD FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER BOTTOM PAN WINDSHIELD CONSOLE	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE. SEAT.	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT. DECAL HOOD. FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE. SEAT.	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER BOTTOM PAN WINDSHIELD CONSOLE SEAT BACKREST	
	SKI RUNNER SKI DDY/FRAME - BODY PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST CLEANING.	
	SKI RUNNER SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST CLEANING. SEAT.	
	SKI RUNNER SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST CLEANING. SEAT. PLASTIC	
01	SKI RUNNER SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST. CLEANING. SEAT. PLASTIC. REPAIR	
01	SKI RUNNER SKI	
01	SKI RUNNER SKI SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST CLEANING. SEAT. PLASTIC. REPAIR REPAIR PROCEDURE FOR R.R.I.M. FRAME	
01	SKI RUNNER SKI SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST CLEANING. SEAT. PLASTIC. REPAIR REPAIR PROCEDURE FOR R.R.I.M. FRAME. PROCEDURES	
01	SKI RUNNER. SKI	
01	SKI RUNNER SKI SKI DDY/FRAME - BODY. PARTS REPLACEMENT. DECAL HOOD FRONT BUMPER. BOTTOM PAN WINDSHIELD CONSOLE. SEAT. BACKREST CLEANING. SEAT. PLASTIC. REPAIR REPAIR PROCEDURE FOR R.R.I.M. FRAME	

14	TECHNICAL SPECIFICATIONS 01 - 440F AND 550F MODELS. 02 - 600 MODELS. 03 - 600 HO SDI MODELS. 04 - V800 MODELS.	693 697
15	ELECTRICAL CONNECTORS AND WIRING DIAGRAMS	60.4
	01 - ELECTRICAL CONNECTORS	707
	PROCEDURES	709
	SUMITOMO CONNECTOR	
	DEUTSCH CONNECTORS.	710
	PACKARD CONNECTOR	710
	PACKARD 24-CIHCUIT AND 32-CIRCUIT CONNECTOR	711
	AMP MULTILOCK CONNECTOR	
	AMP 5-LIBLUIT LUNNELTUR	
	RODIAL CONTRECTOR A AND B	
	BATTERY CABLE TERMINAL 02 - WIRING DIAGRAMS	717
	WIRE COLORS	719
		719

SAFETY NOTICE

SAFETY NOTICE

This manual has been prepared as a guide to correctly service and repair some 2007 Ski-Doo snowmobiles. See model list on next page.

This edition was primarily published to be used by snowmobile mechanic technicians who are already familiar with all service procedures relating to Bombardier Recreational Products Inc. (BRP) made snow-mobiles. Mechanic technicians should attend continuous training courses given by B.R.P.T.I.

Please note that the instructions will apply only if proper hand tools and special service tools are used.

This manual uses technical terms which may be slightly different from the ones used in the PARTS CAT-ALOG.

It is understood that this manual may be translated into another language. In the event of any discrepancy, the English version shall prevail.

The content depicts parts and/or procedures applicable to the particular product at time of writing. Service and Warranty Bulletins may be published to update the content of this manual. Make sure to read and understand them. It does not included dealer modifications, whether authorized or not by BRP, after manufacturing the product.

In addition, the sole purpose of the illustrations throughout the manual, is to assist identification of the general configuration of the parts. They are not to be interpreted as technical drawings or exact replicas of the parts.

The use of BRP parts is most strongly recommended when considering replacement of any component. Dealer and/or distributor assistance should be sought in case of doubt.

The engines and the corresponding components identified in this document should not be utilized on product(s) other than those mentioned in this document.

Unless otherwise specified, engine should be turned OFF and cold for all maintenance and repair procedures.

This manual emphasizes particular information denoted by the wording and symbols:

Identifies an instruction which, if not followed, could cause serious personal injury including pos sibility of death.

CAUTION: Denotes an instruction which, if not followed, could severely damage vehicle comp nents.

NOTE: Indicates supplementary information needed to fully complete an instruction.

Although the mere reading of such information does not eliminate the hazard, your understanding of information will promote its correct use. Always use common shop safety practice.

This information relates to the preparation and use of BRP snowmobile and has been utilized safely effectively by BRP. However, Bombardier Recreational Products Inc. (BRP) disclaims liability for all c ages and/or injuries resulting from the improper use of the contents. We strongly recommend that services be carried out and/or verified by a highly skilled professional mechanic. It is understood certain modifications may render use of the vehicle illegal under existing federal, provincial and state ulations.

INTRODUCTION

GENERAL INFORMATIONS

This shop manual covers the following BRP made 2007 Skandic and Expedition TUV models:


MODEL	ENGINE TYPE
Expedition TUV 600 HO SDI	593 HO SDI
Expedition TUV V800	V810
Skandic LT 440F	443
Skandic SUV 550F	552
Skandic SUV 600	593
Skandic SWT 550F	552
Skandic SWT V800	V810
Skandic WT 550F	552
Skandic WT 600	593

Skandic Series



TYPICAL

Expedition TUV




The information and component/system descriptions contained in this manual are correct at time of publication. BRP however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on products previously manufactured.

Due to late changes, it may have some differences between the manufactured product and the description and/or specifications in this document.

BRP reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring obligation.

The use of RIGHT and LEFT indications in the text, always refers to driving position (when sitting on vehicle).




TYPICAL 1. Left 2. Right

mmr2007-140

effectives by 342 for every four bettier Reads acres effects the resulting from the manages activities be contex out and or switted by a high contain that high reader ray meder use of the very material


VEHICLE IDENTIFICATION NUMBER

Vehicle Identification Number Location




TYPICAL 1. Vehicle identification number

Identification Number Meaning




ENGINE SERIAL NUMBER

Engine Serial Number Location




TYPICAL — 2-STROKE FAN COOLED ENGINES 1. Engine serial number

mmr2007-140



TYPICAL — 2-STROKE LIQUID COOLED ENGINES 1. Engine serial number



TYPICAL — V800 1. Engine serial number

ARRANGEMENT OF THIS MANUAL, ILLUSTRATIONS AND PROCEDURES

The manual is divided into many major sections as you can see in the main table of contents at the beginning of the manual.

Each section is divided in various subsections, and again, each subsection has one or more division.

Illustrations and photos show the typical construction of the different assemblies and, in all cases, may not reproduce the full detail or exact shape of the parts shown. However, they represent parts which have the same or a similar function.


wen

CAUTION: Most components of those vehicles are built with parts dimensioned in the metric system. Most fasteners are metric and must not be replaced by customary fasteners or vice-versa. Mismatched or incorrect fasteners could cause damage to the vehicle or possible personal injury.

As many of the procedures in this manual are interrelated, we suggest, that before undertaking any task, you read and thoroughly understand the entire section or subsection in which the procedure is contained.

A number of procedures throughout the book require the use of special tools. Before commencing any procedure, be sure that you have on hand all the tools required, or approved equivalents.

VEHICLE IDEN DEICARDIN NUMBER





CAUTION: Most components of those vehicles are built with parts dimensioned in the metric system. Most fasteners are metric and must not be replaced by customary fasteners or vice-versa. Mismatched or incorrect fasteners could cause damage to the vehicle or possible personal injury.

As many of the procedures in this manual are interrelated, we suggest, that before undertaking any task, you read and thoroughly understand the entire section or subsection in which the procedure is contained.

A number of procedures throughout the book require the use of special tools. Before commencing any procedure, be sure that you have on hand all the tools required, or approved equivalents.

VEHICLE IDENTIFICATION NUMBER





ENGINE EMISSIONS INFORMATION

Manufacturer's Responsibility

Manufacturers of engines must determine the exhaust emission levels for each engine horsepower family and certify these engines with the United States of America *ENVIRONMENTAL PROTEC-TION AGENCY (EPA)*. An emissions control information label, showing emission levels and engine specifications, must be placed on each vehicle at the time of manufacture.

Dealer Responsibility

When performing service on snowmobiles that carry an emissions control information label, adjustments must be kept within published factory specifications.

Replacement or repair of any emission related component must be executed in a manner that maintains emission levels within the prescribed certification standards.

Dealers are not to modify the engine in any manner that would alter the horsepower or allow emission levels to exceed their predetermined factory specifications.

Exceptions include manufacturer's prescribed changes, such as altitude adjustments for example.

Owner Responsibility

The owner/operator is required to have engine maintenance performed to maintain emission levels within prescribed certification standards.

The owner/operator is not to, and should not allow anyone to modify the engine in any manner that would alter the horsepower or allow emissions levels to exceed their predetermined factory specifications.

EPA Emission Regulations

mmr2007-140

Some Ski-Doo snowmobiles manufactured by BRP are certified to the EPA as conforming to the requirements of the regulations for the control of air pollution from new snowmobiles engines. This certification is contingent on certain adjustments being set to factory standards. For this reason, the factory procedure for servicing the product must be strictly followed and, whenever practicable, returned to the original intent of the design. The responsibilities listed above are general and in no way a complete listing of the rules and regulations pertaining to the EPA requirements on exhaust emissions for snowmobiles products. For more detailed information on this subject, you may contact the following locations:

FOR ALL COURIER SERVICES:

U.S. Environmental Protection Agency Office of Transportation and Air Quality 1310 L Street NW Washington D.C. 20005

REGULAR US POSTAL MAIL: 1200 Pennsylvania Ave. NW Mail Code 6403J Washington D.C. 20460

INTERNET: http://www.epa.gov/otaq/

E-MAIL: otaqpublicweb@epa.gov

SELF-LOCKING FASTENERS PROCEDURE



TYPICAL - SELF-LOCKING FASTENER

The following describes the most common application procedures when working with self-locking fasteners.

Use a metal brush or a tap to clean the hole properly then use a solvent, let act during 30 minutes and wipe off. The solvent utilization is to ensure the adhesive works properly.


LOCTITE APPLICATION PROCEDURE

The following describes the most common application procedures when working with Loctite products.

NOTE: Always use proper strength Loctite product as recommended in this shop manual.

Threadlocker


Uncovered Holes (bolts and nuts)



1. Apply here 2. Do not apply


- Clean threads (bolt and nut) with solvent.
- Apply Loctite Primer N (P/N 293 800 041) on threads and allow to dry.
- Choose proper strength Loctite threadlocker.
- Fit bolt in the hole.
- Apply a few drops of threadlocker at proposed tightened nut engagement area.
- Position nut and tighten as required.

Blind Holes




- On threads
 On threads and at the bottom of hole
- Clean threads (bolt and hole) with solvent.
- Apply Loctite Primer N (P/N 293 800 041) on threads (bolt and nut) and allow to dry for 30 seconds.
- Choose proper strength Loctite threadlocker.
- Apply several drops along the threaded hole and at the bottom of the hole.
- Apply several drops on bolt threads.
- Tighten as required.

Stud in Blind Holes



- On threads
 On threads and in the hole
 Onto nut threads
- Clean threads (stud and hole) with solvent.
- Apply Loctite Primer N (P/N 293 800 041) on threads and allow to dry.
- Put several drops of proper strength Loctite threadlocker on female threads and in hole.
- Apply several drops of proper strength Loctite on stud threads.
- Install stud.
- Install cover, etc.
- Apply drops of proper strength Loctite on uncovered threads.
- Tighten nuts as required.


Pre-Assembled Parts



- Clean bolts and nuts with solvent.
- Assemble components.
- Tighten nuts.
- Apply drops of proper strength Loctite on bolt/nut contact surfaces.
- Avoid touching metal with tip of flask.

NOTE: For preventive maintenance on existing equipment, retighten nuts and apply proper strength Loctite on bolt/nut contact surfaces.

Adjusting Screw




1. Apply here 2. Plunger

- Adjust screw to proper setting.
- Apply drops of proper strength Loctite thread-
- locker on screw/body contact surfaces.
- Avoid touching metal with tip of flask.

NOTE: if it is difficult to readjust, heat screw with a soldering iron (232°C (450°F)).

Stripped Thread Repair



mmr2007-140

Standard Thread Repair

- Follow instructions on Loctite FORM-A-THREAD 81668 package.
- If a plate is used to align bolt:
- a. Apply release agent on mating surfaces.

- b. Put waxed paper or similar film on the surfaces
- Twist bolt when inserting it to improve thread conformation.
- NOTE: NOT intended for engine stud repairs.

Repair of Small Holes/Fine Threads


Option 1: Enlarge damaged hole, then follow STANDARD THREAD REPAIR procedure.

Option 2: Apply FORM-A-THREAD on the screw and insert in damaged hole.

Permanent Stud Installation (light duty)

- Use a stud or thread on desired length.
- DO NOT apply release agent on stud.
- Do a STANDARD THREAD REPAIR.
- Allow to cure for 30 minutes.
- Assemble.

Gasket Compound



Proper strength Loctite Loctite Primer N (P/N 293 800 041) and Gasket Eliminator 518 (P/N 293 800 038) on both sides of gasket Loctite Primer N only 1.2

- 3
- Remove old gasket and other contaminants with Loctite Chisel remover (P/N 413 708 500). Use a mechanical mean if necessary.

NOTE: Avoid grinding.

- Clean both mating surfaces with solvent.
- Spray Loctite Primer N on both mating surfaces and on both sides of gasket. Allow to dry 1 or 2 minutes
- Apply GASKET ELIMINATOR 518 (P/N 293 800 038) on both sides of gasket, using a clean applicator.

XXIII

Place gasket on mating surfaces and assemble immediately.


NOTE: If the cover is bolted to blind holes (above). apply proper strength Loctite in the hole and on threads. Tighten.

If holes are sunken, apply proper strength Loctite on bolt threads.

- Tighten as usual.

Mounting on Shaft

Mounting with a Press



- Bearing Proper strength Loctite Shaft 23
- Clean shaft external part and element internal part.
- Apply a strip of proper strength Loctite on shaft circumference at insert or engagement point.

NOTE: Retaining compound is always forced out when applied on shaft.

- DO NOT use antiseize Loctite or any similar product.

- No curing period is required.

- Mounting in Tandem
- 1. Apply retaining compound on internal element bore.
- 2. Continue to assemble as shown above.

Case-In Components Metallic Gaskets

ADDATUS

1. Proper strength Loctite

- Clean inner housing diameter and outer gasket diameter.
- Spray housing and gasket with Loctite Primer N (P/N 293 800 041).
- Apply a strip of proper strength Loctite on leading edge of outer metallic gasket diameter.

NOTE: Any Loctite product can be used here. A low strength liquid is recommended as normal strength and gap are required.

- Install according to standard procedure.
- Wipe off surplus.
- Allow it to cure for 30 minutes.

NOTE: Normally used on worn-out housings to prevent leaking or sliding.

It is generally not necessary to remove gasket compound applied on outer gasket diameter.

TIGHTENING TORQUE

Tighten fasteners to torque mentioned in exploded views and/or text, When they are not specified, refer to following table. The table also gives the metric conversion.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones, where specified. If the efficiency of a locking device is impaired, it must be renewed.

In order to avoid a poor assembling, tighten screws, bolts or nuts in accordance with the following procedure:

- Manually screw all screws, bolts and/or nuts.
- Apply the half of the recommended torque value.

CAUTION: Be sure to use proper tightening torque for the proper strength grade.

NOTE: When possible, always apply torque on the nut.

- Torque at the recommended torque value.

NOTE: Always torque screws, bolts and/or nuts in a criss-cross sequence.

Property class and head markings	4.8	8.8 9.8 Q Q Q Q Q Q Q Q	12.9 12.9 12.9 12.9 12.9 12.9
Property class and nut markings	$(O) \square (O)$		

FASTENER		FASTENER G	RADE/TORQUE	
SIZE	5.8 Grade	8.8 Grade	10.9 Grade	12.9 Grade
M4	1.5 – 2 №m (13 – 18 lbf•in)	2.5 – 3 №m (22 – 27 lbf•in)	3.5 - 4 N•m (31 - 35 lbf•in)	4 - 5 N•m (35 - 44 lbf•in)
M5	3 - 3.5 N•m (27 - 31 lbf•in)	4.5 - 5.5 N•m (40 - 47 lbf•in)	7 - 8.5 N•m (62 - 75 lbf•in)	8 – 10 N•m (71 – 89 lbf•in)
M6	6.5 - 8.5 N•m (58 - 75 lbf•in)	8 – 12 N•m (71 – 106 lbf•in)	10.5 - 15 N•m (93 - 133 lbf•in)	16 N•m (142 lbf•in
M8	15 N•m (11 lbf•ft)	24.5 N•m (18 lbf•ft)	31.5 N•m (23 lbf•ft)	40 N•m (30 lbf•ft)
M10	29 N•m (21 lbf•ft)	48 N•m (35 lbf•ft)	61 N•m (45 lbf•ft)	72.5 N•m (53 lbf•ft
M12	52 N•m (38 lbf•ft)	85 N•m (63 lbf•ft)	105 N•m (77 lbf•ft)	127.5 N•m (94 lbf•f
M14	85 N•m (63 lbf•ft)	135 N•m (100 lbf•ft)	170 N•m (125 lbf•ft)	200 N •m (148 lbf•ft

MAINTENANCE C (440F/550F/600)	H	AI	RT	Г						
	10-HOUR OR 500 KM (300 mi) INSPECTION (5)									
A: ADJUST		N	And and	-	-	Y 240	-	and the second		
I: INSPECT L: LUBRICATE			M					-	(500 mi) Y 3200 KM (2000 mi)	
R: REPLACE C: CLEAN	1987			Г	-		-	-	R 6000 KM (3700 mi)	
T: PROCEED WITH TASK					F			AGE		
				-				PRES	EASON PREPARATION	
PART/TASK				-	1				REFER TO SUBSECTION	
ENGINE		-	-	-	-					
Rewind starter	1.2	-			-		C, L,		REWIND STARTER	
Engine support	1			1	-	L			ENGINE REMOVAL AND INSTALLATION	
Exhaust system	1		1			1	1			
Exhaust manifold screws	I						1	1	EXHAUST SYSTEM	
Axial fan condition (440F/550F models)	14						1		AXIAL FAN	
Cooling system cap, hoses and clamps (600 models)	1		-	1			1		COOLING SYSTEM	
Coolant (600 models)	1				R					
Crankshaft PTO seal (2)			-		-	1		-	BOTTOM END	
RAVE valves (2) (600 models)				C				-	TOP END	
RAVE valves solenoid (600 HO SDI models)	-		0	1	-					
Air filter			C				C	-	AIR INTAKE SYSTEM	
Air intake silencer Engine lubrication						Т	١,	6	STORAGE PROCEDURE	
LUBRICATION SYSTEM					2				STURAGE PROCEDURE	
njection oil filter						R	T			
Dil injection pump	A			A	1000	-			OIL INJECTION SYSTEM	
UEL SYSTEM	-		-	-	20.5			-		
dd fuel stabilizer						T	T		STORAGE PROCEDURE	
lel filter	1		-		R	-			STORAGE THOSEDORE	
el lines, fuel rail and connections					n			-	FUEL TANK AND FUEL PUMP	
urburetor (440F/550F/600 models)	A		-	A				AC		
rottle cable	A		-	A			-	A,C	VM CARBURETORS	
rottle body ⁽²⁾ (600 HO SDI models)		-		-				-		
		1000	-	-	-			C	ENGINE MANAGEMENT	
ECTRICAL SYSTEM				1	1			1	ENOUS LINE CONTRACTOR	
S fault codes ⁽²⁾ (600 HO SDI models)	1		-	-		-			ENGINE MANAGEMENT	
rk plugs (2) (4)	1		1					R	IGNITION SYSTEM	
ery (if so equipped)	1		1				I	1	CHARGING SYSTEM	
ng harnesses and cables ⁽²⁾	1		1				1	2	ELECTRICAL CONNECTOR	
ation of lighting system O beam, taillight and brake light)	1	1					1		LIGHTS, INSTRUMENTS	
lamp beam aiming				A					ACCESSORIES	
e cut-out switch and tether cut-out switch operation test	1	1					1		IGNITION SYSTEM	

		10-HOUR OR 500 KM (300 mi) INSPECTION (1) WEEKLY OR EVERY 240 KM (150 mi)											
A: ADJUST													
I: INSPECT		MONTHLY OR EVERY 800 KM (500 mi)											
L: LUBRICATE R: REPLACE				100	ONCE A YEAR OR EVERY 3200 KM (2000 mi)								
C: CLEAN	Sig under					EVER	ARS OR 6000 KM (3700 mi)						
T: PROCEED WITH TASK							STO	RAGE (1)					
Andrew Anna Provide 1	and the							PRESEASON PREPARATION (1)					
PART/TASK				1			-	REFER TO SUBSECTION					
DRIVE SYSTEM		-		1	-	-	1	A STATISTICS AND A STATISTICS					
Drive belt condition					-		1	DRIVE BELT					
Drive belt height adjustment		EV	ERY B	ELT RI	EPLA	CEMEN		DRIVE PULLEY and					
Drive and driven pulley	1		1	С		1	С	DRIVE POLLEY and DRIVEN PULLEY					
Tightening torque of drive pulley screw				1			1						
Driven pulley preload				1		1		DRIVE PULLEY					
Ramp pivot nut tightening			1 This	1				DRIVE PULLEY (COMET 102)					
Ramp bushing				R									
Drive chain tension	the the					1		CHAINCASE or GEARBOX					
Chaincase or gearbox oil	1		1			R	1	CHAINCASE OF DEALDON					
Drive axle end bearing (3)	L		L			L	and and	DRIVE AXLE					
Countershaft lubrication ⁽³⁾	L		L			L		COUNTERSHAFT AND BRAKE					
Track	1		1	1		1		TRACK					
Track tension and alignment	A			AS R	EQUI	RED		INFIOR					
BRAKE SYSTEM		-	-	-	1								
Brake fluid	1	1	. 20		R	1.	1	BRAKE					
Brake hose, pads and disk	1	1		(and			1	Divine					
USPENSION	A start of	-		-	-		-						
ront suspension arms ⁽³⁾	A.		A, 1	L		A, I,L		FRONT SUSPENSION					
ear suspension (3)	1		I,L	-	-	I,L	-						
uspension stopper strap	And and and and		1	1	-	1		REAR SUSPENSION					
TEERING SYSTEM					1		-						
teering ⁽³⁾	1,1		1	L	1	I,L		STEERING AND HANDLEBAR					
/ear and condition of skis and runners	1	1		1	1	1		SKIS AND STEERING ALIGNMEN					
EHICLE				and the second									
ehicle cleaning and protection	T		Т	Contract of	100000	T	strate.	STORAGE PROCEDURE					

(1) To be performed by an authorized Ski-Doo dealer.

(2) Emission-related.

(3) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).

(4) Before installing new spark plugs at preseason preparation, it is suggested to burn excess storage oil by starting the engine with the old spark plugs. Only perform this operation in a well-ventilated area.

3

Subsection 02 (MAINTENANCE CHART (V800))

MAINTENANCE CHART (V800)

	and the second	10-H	OUR	OR 50	O KM	(300	mi) II	ISPECTION (1)							
A: ADJUST			WEE	KLY O	R EV	ERY	240 KI	VI (150 mi)							
I: INSPECT				MON	THLY	OR	EVERY	Y 800 KM (500 mi)							
L: LUBRICATE R: REPLACE						ONCE A YEAR OR EVERY 3200 KM (2000 mi)									
C: CLEAN						EVE	RY 2 Y	EARS OR 6000 KM (3700 mi)							
T: PROCEED WITH TASK							STO	RAGE (1)							
							-	PRESEASON PREPARATION (1)							
PART/TASK	1.1	-						REFER TO SUBSECTION							
ENGINE			11.55			-	-								
Engine and oil filter	R	1.1.4		R			False Sta	LUBRICATION SYSTEM							
Valve adjustment	I, A	S alles	1	I, A		1.17		CYLINDER AND HEAD							
Engine seals		a ser a		Legion.			1	ENGINE							
Engine motor mounts		11.0		1-	1. 1.	1		ENGINE REMOVAL AND INSTALLATION							
Exhaust system			1	1		1		EXHAUST SYSTEM							
Air filter			С		24.5		С	AIR INTAKE SYSTEM							
Air intake silencer						the second	1, C	AIN INTAKE STSTEM							
Cooling system cap, hoses and clamps				L	1		1	COOLING SYSTEM							
Coolant	1		1 10		R			COOLING STSTEM							
Engine lubrication		12	1			T		STORAGE PROCEDURE							
FUEL SYSTEM				-	100		-								
Add fuel stabilizer						T	-	STORAGE PROCEDURE							
Fuel filter					R			FUEL TANK AND FUEL PUMP							
Fuel lines and connections	1						1								
Throttle body				1.4			С	ENGINE MANAGEMENT							
Throttle cable	1			1			1								
ELECTRICAL SYSTEM		1			1										
EMS fault codes	1					1		ENGINE MANAGEMENT							
Spark plugs	- 1	1			R			IGNITION SYSTEM							
Battery	1		1			1	1	CHARGING SYSTEM							
Wiring harnesses and cables	1		I	1	1	1	1000	ELECTRICAL SYSTEM							
Headlamp beam aiming				A											
Operation of lighting system (HI/LO beam, taillight and brake light)	1	1	The second			1		LIGHTS, INSTRUMENTS AND ACCESSORIE							
Engine cut-out switch and tether cut-out switch operation test	1	1				1									

Section 01 MAINTENANCE

Subsection 02 (MAINTENANCE CHART (V800))

1.101213		10-	HOUR	OR 5	00 KN	A (300	mi) IN	SPECTION (1)	
A: ADJUST			WE	EKLY	OR E	VERY	240 KM	(150 mi)	
I: INSPECT				MO	NTHL	YOR	EVERY	800 KM (500 mi)	
L: LUBRICATE R: REPLACE					ON	CEAN	R EVERY 3200 KM (2000 mi)		
C: CLEAN T: PROCEED WITH TASK		-			No al	EVE	RY 2 YE	ARS OR 6000 KM (3700 mi)	
I. PROCEED WITH TASK							STOR	AGE (1)	
							F	PRESEASON PREPARATION (1)	
PART/TASK					0			REFER TO SUBSECTION	
DRIVE SYSTEM		-	_		-		-	Letter the the second	
Drive belt	1	1		1000			1	DRIVE BELT	
Drive belt height adjustment		EACH	H BEL	T REP	LACE	MEN		Dinte deci	
Drive and driven pulley	1		1	С		1	С	DRIVE PULLEY and DRIVEN PULLEY	
Tightening torque of drive pulley screw	1			1	2		1	DRIVE PULLEY	
Driven pulley preload	1			1			1	DRIVEN PULLEY	
Gearbox oil	1		1			R	1	CHAINCASE	
Drive axle end bearing (2)	L	and a	L			L		DRIVE AXLE	
Track	1	1				1		TRACK	
Track tension and alignment	A		A	S REG	DUIRE	ED	the second	MACK	
BRAKE SYSTEM				1					
Brake fluid	1	1		1	R		1	DDAVE	
Brake hose, pads and disk	1	1					1	BRAKE	
SUSPENSION									
Front and rear suspensions	1		I,L		-	I, L		FRONT SUSPENSION and	
Rear suspension stopper strap				1		1		REAR SUSPENSION	
STEERING SYSTEM		- And			a su				
Steering mechanism ⁽²⁾	I,L		1	L		I,L		STEERING AND HANDLEBAR	
Near and condition of skis and runners	1	1		State of the		1		SKIS AND STEERING ALIGNMENT	
/EHICLE		-	1200						
/ehicle cleaning and protection	T		T	1000	1	Т		STORAGE PROCEDURE	

mmr2007-142

(1) To be performed by an authorized Ski-Doo dealer.

4

(2) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).

STORAGE PROCEDURE (440F/550F/600)

SERVICE PRODUCTS

Description	Part Number	Page
fuel stabilizer	413 408 600	
heavy duty cleaner		
plastic & vinyl cleaner	413 711 200	
scratch remover kit	861 774 800	
storage oil (Canada)	413 711 600	6
storage oil (USA)	413 711 900	
suspension grease		
XP-S Lube		

GENERAL

Proper snowmobile storage is a necessity during the summer months or when a vehicle is not being used for more than one month.

Refer to storage column from *MAINTENANCE CHART* jointly with the present storage procedure in order to cover each and every aspect of the snowmobile storage procedure. Any worn, broken or damaged parts must be replaced.

Unless otherwise specified, engine should be turned off for storage procedure.

To facilitate the inspection and ensure adequate lubrication of components, it is recommended to clean the entire vehicle first.

ENGINE SYSTEM

Rewind Starter

For inspection, cleaning and lubrication, refer to REWIND STARTER section.

Engine Support

Check if engine support is cracked, bent or otherwise damaged. Replace if necessary.

Check rubber mounts on engine support. Replace them if brittle, cracked or otherwise damaged.

Exhaust System

Check and replace if necessary:

- Tuned pipe shields and deflectors for damages.
- Tuned pipe ends for cracks or damages.

mmr2007-143

Manifold for cracks or damages.

Engine

PTO Crankshaft Seal

Check PTO crankshaft seal for leak. Replace seals if required.

Engine Lubrication

Engine internal parts must be lubricated to protect them from possible rust formation during the storage period.

NOTE: Be sure to add fuel stabilizer to a full tank of fuel before starting the engine (see details further in *FUEL SYSTEM*).

Proceed as follows:

 Place the vehicle in a well ventilated area and start the engine.

A WARNING

Ensure the track is free of particles which could be thrown out while it is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle.

- Allow engine to run at idle speed until it reached its operating temperature.
- Stop the engine.
- Remove the primary air intake silencer. Refer to AIR INTAKE SYSTEM for the removal proce-
- dure.
- Restart engine and run at idle speed.

Section 01 MAINTENANCE Subsection 03 (STORAGE PROCEDURE (440F/550F/600))

- Inject storage oil into each carburetor/throttle body until the engine stalls or until a sufficient quantity of oil has entered the engine (approximately half a can).
- With the engine stopped, remove the spark plugs and spray storage oil (Canada) (P/N 413 711 600) or storage oil (USA) (P/N 413 711 900) into each cylinder.
- Crank slowly 2 or 3 revolutions to lubricate cylinders.
- Reinstall the spark plugs and primary air intake silencer.

LUBRICATION SYSTEM

Injection Oil Filter

Replace injection oil filter, refer to OIL INJECTION SYSTEM section.

FUEL SYSTEM

Fuel Stabilizer

It is critical to use the fuel stabilizer (P/N 413 408 600) (250 mL) to prevent fuel deterioration, gum formation and fuel system components corrosion. Follow manufacturer's instructions for proper use.

Pour fuel stabilizer in fuel tank prior to starting engine for internal parts lubrication so that stabilizer flows everywhere in fuel system. Fill up fuel tank completely. Ensure there is no water inside fuel tank.

CAUTION: Should any water be trapped inside fuel tank, severe internal damage will occur to the fuel injection system (if so equipped).

Do not drain fuel system.

CAUTION: Fuel stabilizer should be added prior to engine lubrication to ensure carburetor protection against varnish deposit.

▲ WARNING

Fuel is flammable and explosive under certain conditions. Always work in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity. Fuel tank may be pressurized, slowly turn cap when opening. Never use an open flame to check fuel level. When fueling, keep vehicle level. Do not overfill or top off the fuel tank and leave vehicle in the sun. As temperature increases, fuel expands and might overflow. Always wipe off any fuel spillage from the vehicle. Periodically inspect fuel system.

DRIVE SYSTEM

Drive and Driven Pulleys

After inspection and interior cleaning of pulleys, spray XP-S Lube (P/N 293 600 016) on sheaves. Do not reinstall drive belt.

Skandic WT, SWT, SUV and Expedition TUV

Check the driven pulley preload. Refer to DRIVEN PULLEY.

Chaincase

Skandic LT 440F

Check drive chain tension and adjust if necessary. Replace chaincase oil. Refer to CHAINCASE section.

Gearbox Oil

Skandic WT, SWT, SUV and Expedition TUV

Replace gearbox oil, refer to GEARBOX section.

Drive Axle End Bearing

Lubricate end housing bearing with suspension grease (P/N 293 550 033). Continue lubricating until grease flows out of the pilot hole on speedometer sensor.

Track

Visually inspect track for:

- cuts and abnormal wear
- broken rods
- broken or missing track cleats.

Replace damaged or missing cleats by new ones. If track is damaged or rods are broken, replace track.

NOTE: Do not release track tension.

STEERING SYSTEM

Steering Mechanism

Lubricate the steering mechanism if needed. Inspect all components for tightness.

Skis and Runners

Inspect skis and runners for wear, deterioration or damage.

Section 01 MAINTENANCE Subsection 03 (STORAGE PROCEDURE (440F/550F/600))

SUSPENSION

Front Suspension

Inspect the front suspension arms for wear or damages, replace if necessary. Refer to *FRONT SUSPENSION*.

Lubricate front suspension arms.

Rear Suspension

Inspect rear suspension components for wear, deterioration or damage, replace defective parts if necessary.

Inspect strap for wear or cracks, bolt and nut for tightness. If loose, inspect hole for deformation. Replace if necessary.

Lubricate front and rear arms at grease fittings using suspension grease (P/N 293 550 033).

ELECTRICAL SYSTEM

EMS Fault Codes 600 HO SDI Models

Using B.U.D.S., verify if fault codes appear in the EMS. Repair or replace defective parts.

Battery (if so equipped)

Remove battery, clean its tray and surrounding area with water and baking soda.

Visually inspect battery casing for cracks, leaks or other possible damage. Discoloration, warping or raised top, indicates that battery has overheated or been overcharged. If casing is damaged, replace battery.

Charge battery as explained in CHARGING SYS-TEM section.

Wiring Harnesses, Cables and Connectors

Inspect for wear, deterioration or damage, replace defective parts if necessary.

Lighting System and Switches

Check operation of lighting system (HI/LO beam, brake light, etc.).

Check if engine and tether cord cutout switches work properly.

VEHICLE

Vehicle Cleaning

Clean the engine compartment. Remove grass, twigs, cloth, etc. These are combustible under certain conditions.

To clean the entire vehicle, use only flannel cloths or equivalent.

CAUTION: It is necessary to use flannel cloths or equivalent on windshield and hood to avoid further damaging surfaces to clean.

To clean the entire vehicle, including bottom pan and metallic parts use heavy duty cleaner (P/N 293 110 001).

CAUTION: Do not use heavy duty cleaner on decals or vinyl.

For vinyl and plastic parts use plastic & vinyl cleaner (P/N 413 711 200).

To remove scratches on windshield use scratch remover kit (P/N 861 774 800) or any good extrafine rubbing compound and wax product.

CAUTION: Never clean plastic parts or hood with strong detergent, degreasing agent, paint thinner, acetone, products containing chlorine, etc.

Inspect the hood and repair any damage.

Touch up all metal spots with touch-up paint where paint has been scratched or worn off.

Spray all bare metal parts including shock rods with XP-S Lube (P/N 293 600 016).

Wax the hood and the painted portion of the frame for better protection. Use a non-abrasive wax such as silicone wax.

NOTE: Apply non-abrasive wax on glossy finish only.

Vehicle Protection

Block air intake and muffler with clean rags.

Protect the vehicle with an approved cover to prevent dust accumulation during storage.

CAUTION: The snowmobile has to be stored in a cool and dry place and covered with an opaque but ventilated tarpaulin. This will prevent sun rays and grime from affecting plastic components and vehicle finish.

Lift rear of vehicle until track is clear of the ground. Install on a snowmobile mechanical stand.

Section 01 MAINTENANCE Subsection 04 (STORAGE PROCEDURE (V800))

STORAGE PROCEDURE (V800)

SERVICE PRODUCTS

Description	Part Number	Page
BRP fuel stabilizer		
heavy duty cleaner	293 110 001	
plastic & vinyl cleaner		
scratch remover		
suspension grease		
XP-S Lube	293 600 016	
XP-S storage oil (USA)	413 711 900	
XP-S storage oil		9

GENERAL

Proper snowmobile storage is a necessity during the summer months or when a vehicle is not being used for more than one month.

Refer to storage column from *MAINTENANCE CHART* jointly with the present storage procedure in order to cover each and every aspect of the snowmobile storage procedure. Any worn, broken or damaged parts should be replaced.

Unless otherwise specified, engine should be turned off for storage procedure.

To facilitate the inspection and ensure adequate lubrication of components, it is recommended to clean the entire vehicle first.

PROCEDURES

ENGINE

Engine Support

Check if engine support is cracked, bent or otherwise damaged. Replace if necessary.

Check rubber mounts on engine support. Replace them if brittle, cracked or otherwise damaged.

Exhaust System

Check and replace if necessary:

- Tuned pipe shield for damages.
- Tuned pipe ends for cracks or damages.
- Manifold for cracks or damages.

Engine

Engine internal parts must be lubricated to protect them from possible rust formation during the storage period.

NOTE: Be sure to add fuel stabilizer before starting the engine.

Proceed as follows:

Start the engine and allow it to run at idle speed until the engine reaches its operating temperature.

Stop the engine.

Change engine oil and filter. Refer to LUBRICA-TION SYSTEM.

With the engine stopped, remove spark plugs and spray XP-S storage oil (P/N 413 711 600) into each cylinder.

NOTE: For US citizens, use the XP-S storage oil (USA) (P/N 413 711 900) only.

CAUTION: Do not inject storage oil into throttle body bore to avoid blocking idle bypass valve.

Press start button, 1 or 2 seconds maximum, to lubricate cylinder.

Reinstall the spark plugs.

A WARNING

This procedure must only be performed in a well-ventilated area. Do not run engine during storage period.

Section 01 MAINTENANCE

Subsection 04 (STORAGE PROCEDURE (V800))

FUEL SYSTEM

Fuel Stabilizer

It is critical to use the BRP fuel stabilizer (P/N 413 408 600) to prevent fuel deterioration, gum formation and fuel system components corrosion. Follow manufacturer's instructions for proper use.

Pour fuel stabilizer in fuel tank prior to starting engine for internal parts lubrication so that stabilizer flows everywhere in fuel system. Fill up fuel tank completely. Ensure there is no water inside fuel tank.

Do not drain fuel system.

Fuel is flammable and explosive under certain conditions. Always work in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity. Fuel tank may be pressurized, slowly turn cap when opening. When fueling, keep vehicle level. Do not overfill or top off the fuel tank and leave vehicle in the sun. As temperature increases, fuel expands and might overflow. Always wipe off any fuel spillage from the vehicle.

ELECTRICAL SYSTEM

EMS Fault Codes

Using B.U.D.S., verify if fault codes appear in the EMS. Repair or replace defective parts.

Lighting System and Switches

Check operation of lighting system (HI/LO beam, brake light, etc.).

Check if engine cutout switch and tether cord cutout switch work properly.

Battery

Remove battery, clean its tray and close area with water and baking soda.

Inspect, clean and charge battery as explained in CHARGING SYSTEM.

Wiring Harnesses, Cables and Connectors

Inspect for wear, deterioration or damage, replace defective parts if necessary.

DRIVE SYSTEM

Drive and Driven Pulleys

After inspection and interior cleaning of pulleys, spray XP-S Lube (P/N 293 600 016) on sheaves. Do not reinstall drive belt.

Gearbox

Replace gearbox oil, refer to DRIVE SYSTEM section.

Drive Axle End Bearing

Lubricate end housing bearing with suspension grease (P/N 293 550 033). Continue lubricating until grease flows out of the pilot hole on end cap.

Track

Visually inspect track for:

- cuts and abnormal wear
- broken rods
- broken or missing track cleats.

Replace damaged or missing cleats by new ones. If track is damaged or rods are broken, replace track.

NOTE: Do not release track tension.

SUSPENSION

Front Suspension

Inspect front suspension components for tightness, wear, deterioration or damage, replace defective parts if necessary.

Lubricate ski legs if needed with suspension grease (P/N 293 550 033).

Rear Suspension

Inspect rear suspension components for wear, deterioration or damage, replace defective parts if necessary.

Lubricate front and rear arms at grease fittings using suspension grease (P/N 293 550 033).

Suspension Stopper Strap

Inspect strap for wear or cracks, bolt and nut for tightness. If loose, inspect hole for deformation. Replace if necessary.

STEERING

Steering Mechanism

Lubricate the steering mechanism if needed. Inspect all components for tightness.

Section 01 MAINTENANCE Subsection 04 (STORAGE PROCEDURE (V800))

Skis and Runners

Inspect skis and runners for wear, deterioration or damage.

VEHICLE

Vehicle Cleaning

Clean the engine compartment. Remove grass, twigs, cloth, etc. These are combustible under certain conditions.

To clean the entire vehicle, use only flannel cloths or equivalent.

CAUTION: It is necessary to use flannel cloths or equivalent on windshield and hood to avoid further damaging surfaces to clean.

To clean the entire vehicle, including bottom pan and metallic parts use heavy duty cleaner (P/N 293 110 001).

CAUTION: Do not use this product on decals or vinyl.

For vinyl and plastic parts use plastic & vinyl cleaner (P/N 413 711 200).

To remove scratches on windshield or hood use scratch remover (P/N 861 774 800).

CAUTION: Never clean plastic parts or hood with strong detergent, degreasing agent, paint thinner, acetone, products containing chlorine, etc.

Inspect the hood and repair any damage.

Touch up all metal spots with touch-up paint where paint has been scratched off.

Spray all bare metal parts including shock chromed rods with XP-S Lube (P/N 293 600 016).

Wax the hood and the painted portion of the frame for better protection. Use a non-abrasive wax such as silicone wax.

NOTE: Apply non-abrasive wax on glossy finish only.

Vehicle Protection

Block air intake and exhaust system using clean rags.

Protect the vehicle with a cover to prevent dust accumulation during storage.

CAUTION: The snowmobile has to be stored in a cool and dry place and covered with an opaque but ventilated tarpaulin. This will prevent sun rays and grime from affecting plastic components and vehicle finish.

Lift rear of vehicle until track is clear of the ground. Install on a snowmobile mechanical stand.

Section 01 MAINTENANCE Subsection 05 (PRESEASON PREPARATION)

PRESEASON PREPARATION

SERVICE PRODUCTS

Descri	ption

Description	Part Number	Page
pulley flange cleaner	413 711 809	
XP-S chaincase oil	413 801 900	
XP-S synthetic chaincase oil	413 803 300	

Proper vehicle preparation is necessary after the summer months or when a vehicle has not been used for more than one month.

Refer to preseason preparation column from MAINTENANCE CHART jointly with the present preseason preparation procedure in order to cover each and every aspect of the snowmobile preseason preparation procedure.

Any worn, broken or damaged parts found during the storage procedure should have been replaced. If not, proceed with the replacement.

A WARNING

Unless otherwise specified, engine should be turned off for preparation procedure.

ENGINE

Rewind Starter 440F, 550F and 600 Models

Check if rope is fraying.

When pulling starter grip, it must return freely. If not, check for damaged parts or lack of lubrication. Replace parts or lubricate accordingly.

Exhaust Manifold

Check exhaust manifold screws for looseness. Re-torque if necessary.

Muffler

Remove rags that were installed during storage preparation.

Axial Fan 440F and 550F Models

Inspect fan belt, adjust or replace if required.

Cooling System 600 and V800 Models

Inspect cooling system for leaks, to perform a cooling system leak test, refer to COOLING SYS-TEM.

Check coolant level in coolant reservoir. Add coolant if necessary.

If engine is cold, refill up to 15 mm (5/8 in) over COLD level line.

If engine is hot, refill up to 25 mm (1 in) over COLD level line. Use caution when opening pressurized coolant reservoir cap. Place a rag over cap and turn it slowly to release pressure.

Engine Seals

V800 Models

Make sure there is no oil coming out from engine seals

Air Filter and Air Intake Silencer

Remove rags that were installed for storage.

Check that inside of air silencer is clean and dry then properly reinstall the filter.

CAUTION: These snowmobiles have been cal-ibrated with the filter installed. Operating the snowmobile without it, may cause engine damage.

LUBRICATION SYSTEM

440F, 550F and 600 Models

Oil Injection Pump

Make sure oil injection pump is properly adjusted, refer to OIL INJECTION PUMP.

FUEL SYSTEM

Fuel Lines, Fuel Rails and Connections

Inspect fuel system for leaks. Perform a fuel system leak test, refer to FUEL TANK AND FUEL PUMP.

Section 01 MAINTENANCE Subsection 05 (PRESEASON PREPARATION)

Carburetors

440F, 550F and 600 Models

Disassemble carburetors in order to clean all internal parts. Do not hesitate to replace any jets having gum or varnish on their surfaces.

Make sure carburetors are properly adjusted, refer to VM CARBURETORS (440F, 550F AND 600).

Throttle Body

600 HO SDI and V800 Models

Using the pulley flange cleaner (P/N 413 711 809), clean the throttle plates and throttle body bores.

NOTE: To ease cleaning, throttle body should be partially pulled from engine, without disconnecting throttle cable or coolant hose.

CAUTION: Ensure the cleaner does not enter engine intake.

Throttle Cable

Verify adjustment and make sure that cable operates freely. Refer to VM CARBURETORS (440F, 550F AND 600) or ENGINE MANAGEMENT.

Choke Cable

440F, 550F and 600 Models

Verify adjustment and make sure that cable operates freely. Refer to VM CARBURETORS (440F, 550F AND 600).

DRIVE SYSTEM

Drive Belt

Inspect belt for cracks, fraying or abnormal wear. Replace if necessary.

Make sure to install the proper belt with arrow printed on belt pointing front of vehicle.

Drive and Driven Pulleys

Clean drive and driven pulleys sheaves with pulley flange cleaner (P/N 413 711 809).

Check if the drive pulley screw is properly torqued. Refer to DRIVE PULLEY for torguing procedure.

Brake

Brake Fluid

Check brake fluid in reservoir for proper level. Add fluid (DOT 4) as required.

CAUTION: Use only (DOT 4) brake fluid from a sealed container. Do not store or use a started bottle of brake fluid.

Brake Hose, Pads and Disk

Inspect brake hose for wear, deterioration or damage, replace if necessary.

Inspect brake pads for proper thickness. Refer to BRAKE.

Remove any rust built-up on braking surfaces. Clean brake disk braking surfaces with pulley flange cleaner (P/N 413 711 809).

Chaincase

440F Models

Check oil for proper level. Add recommended chaincase oil as required.

MODEL	CHAINCASE OIL
440F	XP-S chaincase oil (P/N 413 801 900)

Gearbox

550F. 600 and V800 Models

Check oil for proper level. Add recommended gearbox oil as required.

MODEL	CHAINCASE OIL
550F	XP-S chaincase oil (P/N 413 801 900)
600 AND V800	XP-S synthetic chaincase oil (P/N 413 803 300)

Track

Verify track tension and alignment, refer to TRACK.

NOTE: Track tension and alignment are interrelated. Do not adjust one without checking the other. Track tension procedure must be carried out prior to track alignment.

ELECTRICAL SYSTEM

Battery (if so equipped)

Verify that battery is fully charged, if not, refer to the appropriate charging procedure in CHARGING SYSTEM.

Spark Plugs 440F, 550F and 600 Models

Once preseason preparation is done, start engine with the old spark plugs to burn excess storage oil. Then, install new properly gapped spark plugs.

NOTE: Ensure to replace with recommended spark plugs.

Section 02 TROUBLESHOOTING Subsection 01 (ENGINE (443/552/593))

ENGINE (443/552/593)

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

NOTE: For 600 HO SDI engine, refer also to ENGINE MANAGEMENT (SDI).

ENGINE GENERAL

Symptom: ENGINE BACKFIRES.

- 1. Check spark plugs.
 - Carbon accumulation caused by defective spark plug(s). Clean carbon accumulation from piston and cylinder head and install dry properly gapped spark plug(s).

2. Check ignition timing.

- Timing is too advanced. Set timing according to specifications (refer to IGNITION SYSTEM).

3. Check for erratic sparks.

- Poor electrical connections. Repair.
- Faulty stator. Replace defective parts.

4. Check carburetor.

- Fuel passages obstructed. Clean carburetor and install new strainer or filter.
- Fuel level too low. Adjust float level according to specifications.

5. Check axial fan (443/552 engines)

- Loose fan belt. Adjust or replace fan belt (refer to AXIAL FAN).
- Dirty cooling fins or blocked air ducts. Clean.

6. Check cooling system (593 Engine).

- Low antifreeze level. Adjust antifreeze level. Proceed with a leakage test (refer to COOLING SYSTEM) and repair as required.
 - Defective tank cap. Replace cap.
 - Defective thermostat. Replace thermostat.
 - Air in system. Bleed system.

Symptom: ENGINE SUDDENLY TURNS OFF AT HIGH RPM AND/OR WITH LIGHT LOAD.

- 1. Check spark plugs.
- Non-resistor type spark plugs installed.
- 2. Check that ground wires are well connected.
- Loose or corroded ground.

Symptom: ENGINE SUDDENLY TURNS OFF.

- 1. Check if engine is leaking.
- Damaged gasket and/or seal. Refer to ENGINE LEAK TEST. Replace defective parts.

2. "Four-corner" seizure of piston(s).

 High acceleration when engine is cold. Piston expands faster than cylinder. Replace piston(s). Ask driver to refer to the WARM-UP PROCEDURE in the OPERATOR'S GUIDE.

Subsection 01 (ENGINE (443/552/593))

Sympton	n:]	ENGINE SUDDENLY TURNS OFF. (cont'd)
		3. Piston(s) seizure on exhaust side (color on piston dome is correct).
		- Kinked fuel tank vent tube. Relocate fuel tank vent tube.
		- Leaks at fuel line connections or damaged fuel lines. Replace defective lines.
		 Fuel does not flow through carburetor(s) (foreign particles in needle area and/or varnish formation in carburetor(s)). Clean carburetor(s) and install new strainer or filter.
		 Spark plug heat range is too warm. Install spark plugs with appropriate heat range (refer to TECHNICAL SPECIFICATIONS).
		- Improper ignition timing. Adjust according to specifications (refer to IGNITION TIMING).
		- Restriction in exhaust system. Replace.
		- Compression ratio is too high. Install genuine parts.
		- Too low fuel octane number. Use proper fuel octane number.
		 Carburetor calibration is too lean. Adjust according to specifications (refer to VM CARBURE- TORS).
		 Improper reed valve adjustment or damage. Adjust according to specifications (refer to appropriate ENGINE subsection) and/or install BRPs recommended reed valve.
		- Poor quality oil. Use proper BRP's XP-S injection oil.
		- Leaks at air intake silencer. Replace air intake silencer grommets.
The second		- Excessive wear of piston rings. Replace piston rings.
	4.	Melted and/or perforated piston dome; melted section at ring end gap.
		- When piston reaches TDC, mixture is ignited by heated areas in combustion chamber. This is due to an incomplete combustion of a poor quality oil. Clean residue accumulation in combustion chamber and replace piston(s). Use proper BRP's XP-S injection oil.
		- Spark plug heat range is too high. Install recommended dry properly gapped spark plugs (refer to TECHNICAL SPECIFICATIONS).
and the second		- Ignition timing is too advanced. Adjust according to specifications (refer to IGNITION SYSTEM).
and in a		- Inadequate fuel quality. Use appropriate fuel.
and a star		- Carburetion is too lean. Adjust according to specifications (refer to VM CARBURETORS).
	5	Seized piston all around the circumference (dry surface).
		- Lack of oil, damaged oil line or defective injection pump. Replace defective part(s).
	6.	Grooves on intake side of piston only.
1. 22.		 Oil film eliminated by water (snow infiltration in engine). This can also be caused by running engine on choke for too long. Excessive fuel will remove the oil film on the piston and make marks. Replace piston(s) and check if intake system leaks.
	7.	Piston color is dark due to seizure on intake and exhaust sides.
		- Loose fan belt. Adjust its tension and/or replace.
		 Cooling system leaks and lowers coolant level. Proceed with a leakage test (refer to COOLING SYSTEM) and repair as required. Add coolant in cooling system until appropriate level is reached. Accumulation of foreign particles in needle valve and/or main jet area. Clean carburetor(s).
	8	Cracked or broken piston(s).
		 Cracked or broken piston(s) due to excessive piston/cylinder clearance or engine over-revving. Check piston/cylinder clearance (refer to TOP END). Replace piston(s).
mptom:	PI	STON RING AND CYLINDER SURFACES ARE SCRATCHED.
	1	Check oil quality.
Carlos a		- Poor quality oil. Use proper BRP's XP-S injection oil.
State.	2.	Check injection pump and its hoses.
		 Inadequate injection pump adjustment and/or defective hoses. Adjust pump according to spec- ifications (refer to OIL INJECTION SYSTEM) and/or replace hoses.

Section 02 TROUBLESHOOTING Subsection 01 (ENGINE (443/552/593))

Symptom: ENGINE DOES NOT OFFER MAXIMUM POWER AND/OR DOES NOT REACH MAXIMUM OPERATING RPM.

- 1. Check spark plug condition and gap.
 - Fouled spark plugs or wrong spark plug gap. Replace or readjust gap.
- 2. Check if there is water in fuel.

- There is water in fuel. Drain fuel system, then fill with appropriate fuel.

3. Check proper operation of RAVE valves (RAVE equipped engines).

 Refer to ENGINE EQUIPPED WITH RAVE VALVE DOES NOT REACH ITS FULL OPERATING RPM (500 TO 1000 RPM LOWER). Repair.

 Check items listed in ENGINE RUNS OUT OF FUEL (refer to FUEL AND OIL SYSTEMS subsection).

5. Check carburetor adjustments and cleanliness.

 Inadequate carburetor adjustments or dirt accumulation. Clean and adjust according to specifications (refer to VM CARBURETORS).

6. Check drive belt.

- Worn belt. Replace belt if width is 3 mm (1/8 in) less than nominal dimension (refer to DRIVE BELT).

7. Check track adjustment.

- Too much tension and/or improper alignment. Align track and adjust its tension to specifications (refer to TRACK).

8. Check drive pulley.

 Improper calibration screw adjustments (TRA pulley) and/or worn bushing(s). Adjust according to specifications (refer to DRIVE PULLEY) and/or replace bushing(s).

9. Check driven pulley.

Worn bushing and/or spring tension. Replace spring and/or adjust its tension according to specifications (refer to DRIVEN PULLEY).

10. Check exhaust system.

 Restriction or exhaust system leakage. Replace or reseal with Loctite 5920 RTV high temperature sealant (P/N 293 800 090).

11. Check ignition timing.

 Decrease in power due to delayed ignition. Adjust according to specifications (refer to IGNITION SYSTEM).

12. Check engine compression.

- Worn piston(s) and ring(s). Replace.

13. Check if engine overheats.

- Improper fan belt tension. Adjust fan belt (refer to AXIAL FAN).
- Coolant level is low, cap fails to pressurize system or air circulates through lines. Adjust level, replace cap or bleed cooling system.

14. Check reed valve.

- Improper tightness and/or opening. Replace or adjust. (Refer to proper ENGINE subsection).

Symptom: ENGINE DETONATION AT MAXIMUM RPM.

1. Check which type of fuel is used.

- Octane number is too low and/or alcohol level is too high. Use recommended fuel type.

2. Check spark plug type.

mmr2007-146

 Improper spark plug heat range. Install recommended spark plugs (refer to TECHNICAL SPECI-FICATIONS).

107

Subsection 01 (ENGINE (443/552/593))

Symptom: ENGINE DETONATION AT MAXIMUM RPM. (cont'd)

3. Check exhaust system.

- Too much restriction. Replace.

4. Check ignition timing.

- Timing is too advanced. Adjust according to specifications (refer to IGNITION SYSTEM).

5. Check if engine is overheating. (Refer to HIGH ENGINE OPERATING TEMPERATURE).

6. Check carburetion.

- Fouled and/or improper carburetor components. Clean or replace according to specifications (refer to VM CARBURETORS).
- 7. Check compression ratio and combustion chamber volume.

- Compression ratio is too high. Install genuine parts.

Symptom: ENGINE TURNS OVER BUT FAILS TO START.

1. Check switches.

 Ignition switch, emergency cut-out switch or tether switch is OFF. Place all switches in the RUN or ON position. If it still does not work, connect DESS switch WH/GN and WH/BK wires together (harness side).

2. Check fuel level.

- Mixture too lean to start cold engine. Check fuel tank level and use choke.

3. Check spark plug.

- Defective spark plug (no spark) or wrong spark plug gap. Replace spark plugs or readjust gap.

 Flooded engine (spark plug wet when removed). Do not overprime or overchoke. Remove wet spark plugs, turn ignition switch to OFF and crank engine several times. Install clean dry properly gapped spark plugs. Start engine following usual starting procedure.

4. Check fuel lines.

No fuel to the engine (spark plugs dry when removed). Check fuel tank level; turn fuel valve on
if applicable; check fuel filter and strainer, replace if clogged; check condition of fuel and impulse
lines and their connections.

5. Check engine compression.

- Insufficient engine compression. Replace defective part(s) (e.g.: piston(s), ring(s), etc.).

Symptom: IRREGULAR ENGINE IDLE (normal use after engine warm up).

1. Check choke.

- Choke plunger may be partially opened. Readjust.

2. Check carburetor adapter.

- Air enters through a crack. Replace.

3. Check air screw position.

 Inadequate fuel/air mixture. Adjust according to specifications (refer to TECHNICAL SPECIFICA-TIONS).

4. Check dimension of pilot jet.

 Inadequate fuel/air mixture. Adjust according to specifications (refer to TECHNICAL SPECIFICA-TIONS).

5. Check reed valve.

- Improper tightness and/or opening. Replace or adjust. Refer to proper ENGINE subsection.

6. Check if engine is leaking.

 Leaking gaskets allow air to enter in engine. Refer to ENGINE LEAK TEST. Replace defective parts.

Section 02 TROUBLESHOOTING Subsection 01 (ENGINE (443/552/593)) Symptom: IRREGULAR ENGINE IDLE (normal use after engine warm up). (cont'd) 7. On models with carburetors, check throttle slide height. - Incorrect throttle slide height. Readjust according to specifications. 8. On SDI models, check cleanness of throttle body. - Deposits inside throttle body. Clean throttle body bores and plates. Symptom: HIGH ENGINE OPERATING TEMPERATURE (fan cooled engines). 1. Check condition and heat range of spark plugs. - Melted spark plug tip or inadequate heat range. Replace. 2. Check fan belt and axial fan. - Loose fan belt. Adjust or replace fan belt (refer to AXIAL FAN). - Dirty cooling fins or blocked air ducts. Clean. 3. Check if there are leak at air intake silencer and/or engine crankcase. - Leak(s). Repair or replace. 4. Check carburetion. - Improperly adjusted or inadequate carburetor components. Adjust according to specifications (refer to TECHNICAL SPECIFICATIONS) or replace inadequate component(s). 5. Check ignition timing. - Ignition timing is too advanced. Adjust according to specifications (refer to IGNITION SYSTEM). 6. Check cylinder O-rings. - Worn O-rings. Replace. Symptom: HIGH ENGINE OPERATING TEMPERATURE (liquid cooled engines). 1. Check coolant level and check if there is air infiltration in the system or if there are leaks in gasket areas. - Low coolant level or air in system. Add coolant until recommended level is reached, bleed system and/or tighten clamps. 2. Check temperature gauge sensor. - False reading. Check terminal connections. If problem persists, replace sensor. 3. Check if heat exchangers are clean. - Dirty heat exchangers. Clean heat exchangers. 4. Check if coolant flows through system properly. - Foreign particles and/or broken coolant pump impeller. Clean cooling system and/or replace coolant pump impeller. 5. Check antifreeze concentration. - Antifreeze concentration is too high. Adjust concentration according to BRP's recommendations. 6. Check thermostat. - Thermostat reacts slowly or not at all. Replace. 7. Check coolant tank cap. - Cap does not hold pressure. Replace. 8. Check condition and heat range of spark plugs. - Melted spark plug tip or inadequate heat range. Replace.

Subsection 01 (ENGINE (443/552/593))

Sympton	n:	HIGH ENGINE OPERATING TEMPERATURE (liquid cooled engines). (cont'd)
	9	0. Check carburation.
		 Improperly adjusted or inadequate carburetor components. Adjust according to specifications (refer to TECHNICAL SPECIFICATIONS) or replace inadequate component(s).
	1	0. Check ignition timing.
		 Ignition timing is too advanced. Adjust according to specifications (refer to TECHNICAL SPECI FICATIONS).
	1	 Check if there are leaks at air intake silencer and/or engine crankcase. Leak(s). Repair or replace.
Symptom		NGINE EQUIPPED WITH RAVE VALVE DOES NOT REACH ITS FULL PERATING RPM (500 to 1000 RPM slower).
	1.	Check RAVE valve pistons.
		- Valve piston(s) is (are) not screwed to the bottom. Screw valve piston(s) to bottom.
	2.	Check that valve moves freely.
		- Valve stuck in closed position. Clean.
	3.	Check RAVE valve stems. - Bent RAVE valve stem(s). Replace.
	4.	Check clamps or sleeves. - Damaged clamp(s) or sleeve(s). Replace.
	5.	Check RAVE valve hoses. - Hose leakage. Repair.
	6.	Check RAVE valve solenoid.
		- Defective solenoid. Check and replace.
Symptom:		IGINE EQUIPPED WITH RAVE. ENGINE HESITATES AT LOW OR MID-SPEED ID REACHES MAXIMUM PERFORMANCE ONLY AFTER A WHILE.
	1.	Check RAVE valve spring(s).
		- Spring tension is too low or spring(s) is (are) broken. Replace.
	2.	Check RAVE valve movement.
		- Valve(s) is (are) stuck in open position. Clean.
		Check RAVE valve solenoid. - Defective solenoid. Check and replace.
symptom:	EN	GINE PINGING.
		Check for proper fuel octane number according to engine type. - Too low fuel octane number. Use appropriate fuel octane number (Refer to TECHNICAL SPECI- FICATIONS).
		Check fuel lines. - Bent fuel lines (preventing fuel from flowing through). Relocate or replace fuel lines.
	3. (Check if carburetor(s) is (are) clean. Dirt prevents fuel from flowing through. Clean.
		Check ignition timing.
		Timing is too advanced. Adjust according to specifications (refer to IGNITION SYSTEM).

Section 02 TROUBLESHOOTING Subsection 01 (ENGINE (443/552/593))

Symptom: ENGINE PINGING. (cont'd)

5. Check compression ratio.

- Compression ratio is too high. Replace inadequate part(s) to obtain manufacturer's recommended compression ratio or use a higher grade fuel.
- Check for carbon accumulation in combustion chamber and/or on piston dome.
 Carbon accumulation. Remove carbon accumulation.

Symptom: ENGINE GENERATES A LOT OF VIBRATIONS.

- 1. Check engine supports and stopper.
 - Loose and/or broken supports or interference between support(s) and chassis. Retighten to specification (refer to ENGINE REMOVAL AND INSTALLATION) or replace.
- 2. Check drive pulley (refer to VIBRATIONS ORIGINATING FROM DRIVE PULLEY).

3. Check carburetor synchronization.

- Throttle slide height is not the same on each carburetor and/or throttle slides opening is not synchronized. Adjust throttle slide heights and throttle cable.

4. Check for crankshaft and bearings.

- Loose crankshaft bearings or uneven crankshaft. Retighten or replace the parts.

REWIND STARTER

nr2007-146

Symptom: REWIND STARTER ROPE DOES NOT REWIND.

- 1. Check rewind spring.
 - Broken spring. Replace spring.

Symptom: REWIND STARTER PAWL DOES NOT ENGAGE.

- 1. Check stopper spring.
- Broken stopper spring. Replace.
- 2. Check pawl and pawl lock.
 - Pawl and pawl lock have stuck together because of heat. Replace.

3. Check pawl and rope sheave.

- Pawl and rope sheave have stuck together because of heat. Replace.

Section 02 TROUBLESHOOTING Subsection 02 (ENGINE (810))

ENGINE (810)

COOLING SYSTEM

Symptom: HIGH ENGINE OPERATING TEMPERATURE.

1. Check coolant level.

- Coolant level lower than recommended. Check for leakage and refill.
- Coolant leaking from leak indicator hole means a damaged water pump rotary seal. Replace rotary seal (refer to COOLING SYSTEM).
- Cylinder head or cylinder base. Gasket is causing coolant leakage. Replace.
- Gasket on water pump housing leaks. Retighten screws and/or replace gasket.
 - Coolant leaking from drain plug on water pump housing. Retighten screw and/or replace copper ring.
 - Hose clamps are loose. Retighten clamps.
 - Hoses are brittle and/or hard. Replace.
 - 2. Check radiator condition.
 - Radiator cracked or deformed. Replace radiator.
 - 3. Check for air bubbles in cooling system.

- Air in cooling system. Refill and bleed cooling system (refer to COOLING SYSTEM).

- 4. Check temperature sensor for electrical/mechanical failure.
- Temperature sensor defective. Replace.

5. Check thermostat.

 Thermostat defective (does not open when engine gets hot). Replace (refer to COOLING SYS-TEM).

- 6. Check condition of water pump impeller.
- Impeller fins broken and/or impeller threads are damaged. Replace.

7. Check intermediate gears behind PTO cover.

- Worn out and/or broken gear(s) is/are causing a loss of coolant flow. Replace worn out and/or broken gear(s), refer to BOTTOM END.

8. Check if water pump shaft is seized.

- Water pump shaft does not turn. Replace defective part(s).

LUBRICATION SYSTEM

Symptom: LOW OR NO OIL PRESSURE.

1. Check oil level and search for leakage on crankcase and/or sealing parts.

- Oil drain plug on engine bottom is loosed and/or sealing ring is missing. Retighten the plug and/or place sealing ring.
 - Oil leaking from leak indicator hole means a damaged oil seal on water pump shaft. Replace oil seal (refer to COOLING SYSTEM).
 - Sealing rings, O-rings and/or gaskets are brittle and/or hard or damaged. Replace damaged parts.
 - Crankcase is leaking due to loose screws. Retighten screws with recommended torque.
 - Crankcase is leaking due to damage. Rebuild engine with new crankcase and gasket parts. Use recommended oil (refer to LUBRICATION SYSTEM).

2. Check oil quality and viscosity used.

- Incorrect oil being used. Use recommend oil (refer to LUBRICATION SYSTEM).

mmr2007-147

13

Section 02 TROUBLESHOOTING Subsection 02 (ENGINE (810))

		Check oil filter for contamination.
		- Oil filter clogged. Replace oil and oil filter at the same time. Use recommend oil (refer to LU- BRICATION SYSTEM).
	4.	Check oil pressure switch function. - Oil pressure switch damaged. Replace oil pressure switch.
	5.	Check oil orifice(s) on the oil pump suction side.
		- Oil orifice(s) is(are) clogged. Clean from contamination. Replace oil and oil filter if necessary (refer to LUBRICATION SYSTEM).
	6.	Check oil pump function.
		 Oil pump rotor is out of wear limit. Replace oil pump shaft (refer to LUBRICATION SYSTEM). Oil pump seized due to oil leakage and/or air inclusion. Replace oil pump (refer to LUBRICATION SYSTEM).
		- Gears driving oil pump are broken or otherwise damaged. Replace gears.
	7.	Check oil pressure regulator valve (spring) function.
		- Valve spring damaged (valve always open). Replace spring.
		- Valve piston is stuck in oil pump housing. Repair valve piston.
1	8.	Check plain bearings in crankcase for heavy wear.
		- Plain bearings out of specification (increased clearance). Replace plain bearings.
:	9.	Check engine oil strainer in crankcase.
		 Oil strainer is clogged due to contamination. Clean or replace strainer and diagnose causes of contamination. Replace possible damaged parts (refer to BOTTOM END).
mptom:	HIG	HOIL CONSUMPTION.
1	1.	Check for oil leakage.
		 Oil drain plug on engine bottom is loosed and/or sealing ring is missing. Retighten the plug and/o place sealing ring.
		 Oil leaking from leak indicator hole means a damaged oil seal on water pump shaft. Replace o seal (refer to COOLING SYSTEM).
		- Sealing rings, O-rings and/or gaskets are brittle and/or hard or damaged. Replace damaged parts
		- Crankcase is leaking due to loose screws. Retighten screws with recommended torque.
		 Crankcase is leaking due to damage. Rebuild engine with new crankcase and gasket parts. Us recommended oil (refer to LUBRICATION SYSTEM).
2		Check engine condition.
		 Piston rings worn out (blue coloured engine exhaust emission). Replace piston rings (refer to CYLINDER AND HEAD).
		 Piston rings are broken (low compression). Replace piston rings (refer to CYLINDER AND HEAD
		 Valve stem seal damaged and/or sealing lip is hard and/or brittle. Replace all valve stem seals Valve piston is stuck in oil pump housing. Repair valve piston (refer to LUBRICATION SYSTEM
mptom:	OIL	CONTAMINATION (white appearance).
the lot a start	1.0	Check both leak indicator holes (front of engine and on PTO side) if water and/or oil leak
		 Leakage of oil/water mixture from the front leak indicator hole means damaged water pump se ring and rotary seal. Replace (refer to COOLING SYSTEM).
		- Leakage of oil from the leak indicator hole on PTO side means damaged oil seal. Replace (re to LUBRICATION SYSTEM).

Subsection 02 (ENGINE (810))

Symptom: OIL CONTAMINATION (white appearance). (cont'd)

2. Check cylinder head and/or cylinder base gasket.

- Gasket damaged or leaking. Retighten cylinder head with recommended torque and/or replace gasket.
- 3. Check tightening torque of cylinder head screws.
 - Screws not properly tightened. Retighten screws to recommended torque and replace oil.
- 4. Check oil for particles (may indicate possible engine internal damages).
 - Oil contamination due to metal or plastic particles. Replace possibly damaged part(s) including oil and oil filter. Use recommended oil (refer to TECHNICAL SPECIFICATIONS).

CYLINDER AND HEAD

Symptom: UNUSUAL ENGINE NOISE AND/OR VIBRATIONS.

- 1. Check noise coming from cylinder head area.
 - Improper valve clearance adjustment. Adjust valve clearance.
 - Rocker arms are worn out. Replace rocker arms.
 - Rocker arm screws not tightened. Replace screws and perform the torque procedure (refer to CYLINDER AND HEAD).
 - Faulty chain tensioner. Replace spring and/or mechanism.
 - Chain guide worn out. Replace chain guide.
 - Stretched timing chain and/or worn out sprockets. Replace timing chain and sprockets.
 - Sprocket screws got loose. Retighten screws with recommended torque.
 - Incorrect camshaft timing adjustment. Replace damaged components and readjust camshaft timing (refer to CYLINDER AND HEAD).

Symptom: OIL LEAKAGE FROM CYLINDER AND/OR CYLINDER HEAD.

1. Check screws for torque.

- Loose screws. Retighten screws with recommended torque.
 - Gaskets are brittle, hard, worn out or otherwise damaged. Replace damaged gaskets, O-rings or the V-ring on breather.

2. Spark plug tube seal condition.

 Contact area between spark plug and ignition coils fouled by oil. Clean spark plug area and replace spark plug tube.

CRANKSHAFT

Symptom: UNUSUAL ENGINE NOISE AND/OR VIBRATIONS.

1. Check noise coming from crankshaft area.

- Crankshaft plain bearings are damaged. Replace the crankshaft plain bearings. (refer to BOT-TOM END).
- Connecting rod plain bearings are damaged. Replace the connecting rod plain bearings (refer to BOTTOM END).

2. Check if magneto screw is loosen.

 Magneto rotor got loose. Replace damaged components and retighten rotor retaining screw with recommended torque.

255

Subsection 02 (ENGINE (810))

ENGINE GENERAL

Symptom:

Symptom: ENGINE BACKFIRES.

 Check spark plug. Carbon accumulation caused by defective spark plugs. Clean carbon accumulation and replace spark plugs.
Check fault codes in B.U.D.S. system. - Check if electrical actuator(s) is/are defective. Replace defective part(s) (refer to ENGINE MAN AGEMENT).
Check leakage on intake manifold. - Air leak on intake system. Retighten screws and/or replace intake manifold gasket.
Check exhaust air leaking. - Exhaust gasket is leaking. Retighten screws and/or replace exhaust gasket.
Check intake valve(s) for leaking. - Intake valve(s) is(are) leaking. Repair or replace valve(s).
Check if fuel supply is sufficient at high RPM. - Fuel line is contaminated and/or bent (engine gets lean). Clean and/or replace defective part(s) - Defective fuel pump. Check fuel pressure.
Check engine ground. - Poor engine ground. Clean and tighten.
IGINE SUDDENLY TURNS OFF.
Check spark plug condition and/or gap. - Fouled spark plug or wrong spark plug gap. Readjust gap and clean spark plug or replace pistons.
Check fault codes in B.U.D.S. system.

- Check if electrical actuator(s) is/are defective. Replace defective part(s) (refer to ENGINE MAN-AGEMENT).
- 3. Check if fuel supply is sufficient at high RPM.
 - Clogged fuel filter or fuel injectors.
 - Defective fuel pump. Check fuel pressure.
 - Fuel line is contaminated and/or bent. Clean and/or replace defective part(s).

4. Engine leakage.

- Damaged head gasket and/or seal and/or leaking inlet/exhaust valve(s). Perform an engine leak test to diagnose problem. Refer to ENGINE LEAK TEST.

5. Melted and/or perforated piston dome; melted section at ring end gap.

- Spark plug heat range is too hot. Install recommended spark plug (refer to TECHNICAL SPECI-FICATIONS).
- Coolant less than recommended level (engine gets too hot). Repair cooling circuit and/or refill with recommended liquid.
- Poor quality and/or wrong fuel. Clean from contamination and use appropriate fuel (refer to TECHNICAL SPECIFICATIONS).
- 6. Piston color is dark due to seizure on intake and exhaust sides.

 Cooling system leaks and lowers coolant level. Tighten clamps or replace defective parts. Add antifreeze in cooling system until appropriate level is reached. Replace damaged parts.

7. Cracked or broken piston.

 Cracked or broken piston due to excessive piston/cylinder clearance or engine overreving. Replace piston. Check piston/cylinder clearance (refer to CYLINDER AND HEAD).

37

Subsection 02 (ENGINE (810)) Symptom: ENGINE SUDDENLY TURNS OFF. (cont'd) 8. Check piston rings and cylinder surface for grooves. - Poor oil quality. Use recommended oil. - Contamination through engine intake. Replace defective part(s) and use new air filter. 9. Check valve springs exhaust/intake. - Broken valve spring damages the cylinder head, valve(s), rocker arm(s), piston, piston rings and connecting rod. Replace defective part(s). 10. Check crankshaft, rocker arms movement. - Oil pump failure due to lack of oil. Repair and replace defective parts and use recommended oil. Oil contamination due to clogged oil filter/oil strainer. Replace oil and oil filter at the same time, replace defective part(s) (refer to LUBRICATION SYSTEM). ENGINE DOES NOT OFFER MAXIMUM POWER AND/OR DOES NOT REACH Symptom: MAXIMUM OPERATING RPM. 1. Check spark plug condition and/or gap. Fouled spark plug or wrong spark plug gap. Readjust gap or replace. 2. Check spark plug type. - Improper spark plug heat range. Install recommended spark plug (refer to TECHNICAL SPECI-FICATIONS). 3. Check fault codes in B.U.D.S system. - Check if electrical actuator(s) is/are defective. Replace defective part(s) (refer to ENGINE MAN-AGEMENT) 4. Perform an engine leak test. - Damaged head gasket, piston, seal or valves. Repair or replace defective part(s). 5. Check for water in fuel (wrong fuel). - There is water in fuel or wrong fuel. Drain fuel system, search for leakage and refill it with appropriate fuel. 6. Check fuel pressure. - Low fuel pressure. Perform fuel pressure test (refer to FUEL TANK AND FUEL PUMP). 7. Check air intake system. - Air filter is clogged due to contamination. Replace air filter. 8. Check drive belt. - Drive belt width is less than specified (refer to DRIVE BELT). Replace. Symptom: ENGINE CRANKS BUT FAILS TO START. 1. Check fault codes in B.U.D.S. system. - Check if electrical actuator(s) is/are defective. Replace defective part(s) (refer to ENGINE MAN-AGEMENT). 2. Check if ignition coils are properly installed on spark plugs. 3. Check spark plugs. - Define spark plugs (no spark) or wrong spark plug gap. Readjust gap and clean spark plugs or replace Flooded engine (spark plugs wet when removed). Activate engine drowned mode and crank engine with rags over the spark plug holes (refer to ENGINE MANAGEMENT). 4. Check engine compression. Perform an engine leak test. Insufficient engine compression. Replace defective part(s) le g. piston, ring(s), etc.).

Subsection 02 (ENGINE (810))

Symptom	: E	NGINE CRANKS BUT FAILS TO START. (cont'd)
	5	 Check fuel level in fuel tank and fuel pressure. - Low or no fuel pressure. Replace defective part(s). - Make sure fuel pump was not disabled with B.U.D.S.
	6.	Check fuel injectors. - Plugged or faulty injector(s). Replace defective part(s).
	7.	Check idle bypass valve. - Bypass valve stuck or defective. Replace.
	8.	Check trigger wheel. - Bent tooth. Refer to MAGNETO SYSTEM.
Symptom:	E	NGINE HARD TO START.
	1.	Check idle bypass valve. - Stuck or defective. Refer to ENGINE MANAGEMENT.
	2.	Check closed throttle and idle actuator with B.U.D.S. - Wrong TPS zero setting or bypass valve reset. Refer to ENGINE MANAGEMENT.
	3.	Check throttle cable adjustment. - Wrong adjustment (likely to tight). Refer to ENGINE MANAGEMENT.
	4.	Check engine compression. - Insufficient engine compression. Replace defective part(s).
	5.	Verify spark plug condition. - Defective, improper, worn out or fouled spark plugs. Identify the source of problem and correct. Replace spark plugs.
	6.	Check fuel level in fuel tank and fuel pressure. - Low or no fuel pressure. Replace defective part(s). Refer to FUEL TANK AND FUEL PUMP.
194	7.	Check CAPS (Camshaft Position Sensor). - Defective sensor or wiring. Refer to ENGINE MANAGEMENT.

Section 02 TROUBLESHOOTING Subsection 03 (FUEL AND OIL SYSTEMS (440F/550F/600))

FUEL AND OIL SYSTEMS (440F/550F/600)

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model. NOTE: For 600 HO SDI models, also refer to ENGINE MANAGEMENT (SDI) section.

FUEL SYSTEM

Symptom: HIGH FUEL CONSUMPTION OR RICH MIXTURE (models with carburetor only).

- 1. Check fuel tank.
 - Perforated fuel tank. Replace fuel tank.
- 2. Check fuel pump, reservoir and carburetor fittings. - Leaking fittings. Replace defective part.
- 3. Check choke adjustment.
 - Fuel flows through choke circuit while engine runs. Readjust choke.
- 4. Check float height in carburetor(s).
 - Fuel level is too high in float bowl(s). Adjust according to specifications (refer to TECHNICAL SPECIFICATIONS).
- 5. Check needle valve on each carburetor.
 - Foreign particles prevent needle valve from closing and/or pounded seating area. Clean or replace needle valve, then clean seating area.
- Symptom: FUEL LEAKS IN ENGINE BASE WHEN ENGINE IS STOPPED (models with carburetor only).
 - 1. Check items 3, 4 and 5 of HIGH FUEL CONSUMPTION.
 - 2. Check fuel pump.
 - Cracked diaphragm, Replace,

Symptom: ENGINE LACKS POWER OR STALLS AT HIGH RPM (models with carburetor only).

- 1. Check fuel tank vent hose. - Kinked or clogged hose. Relocate or replace.
- 2. Check in-tank fuel strainer.
 - Clogged filter. Replace.
- 3. Check fuel lines.
 - Kinked or clogged lines. Relocate or replace.
- 4. Check fuel pump flow.
 - Check impulse hose. Replace.
 - Dried diaphragm. Replace.
- 5. Check if carburetor(s) is (are) clean. - Varnish. Clean.
- 6. Check carburetors calibration. - Wrong calibration. Refer to TECHNICAL SPECIFICATIONS.

Subsection 03 (FUEL AND OIL SYSTEMS (440F/550F/600))

Symptom:	E	NGINE LACKS FUEL (SDI models only).	1.21	
	1.	Check in-tank strainer and in-line fuel filter. - Clogged strainer or filter. Replace fuel strainer or filter.		(44
	2.	Check if lines are perforated, kinked, or if they leak at fittings. - Replace lines.		
	3.	Check fuel pump pressure. - Electric fuel pump defective. Replace. - Regulator defective. Replace.		
	4.	Check fuel injectors flow. - Dirty or defective injectors. Replace.		
OIL INJI	EC	TION SYSTEM		
Symptom:	HI	GH INJECTION OIL CONSUMPTION.		
	1.	Check oil injection pump adjustment. - Oil injection pump adjusted too rich. Adjust.		
	2.	Check injection pump identification. - Wrong pump. Replace with the appropriate pump. Refer to OIL INJECTION SY	STEN	1.
		Check injection oil lines and their fitting. - Leaking lines and/or cover, Replace defective part(s).		
		Check injection pump cover gasket. - Broken gasket. Replace.		
		Check nipple check valve. - Check valve stuck open. Replace.		
		Check pump. - Defective pump. Replace pump or connecting cable.		
	7.	Test pump shaft gear reservoir for leaks. - Leaking seal(s). Replace seal(s).		
			2	
9				mmr2007-148

Section 02 TROUBLESHOOTING Subsection 04 (DRIVE SYSTEM AND BRAKE)

DRIVE SYSTEM AND BRAKE

The following charts are provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

DRIVE AND DRIVEN PULLEYS

Symptom: THE SNOWMOBILE ACCELERATES SLOWLY, ESPECIALLY FROM A STANDING START.

1. Check drive belt condition.

- Belt is too narrow (drive belt engagement is higher in drive pulley). Replace belt if width is less than specified in DRIVE BELT.

2. Check distance between pulleys and/or drive belt deflection.

 Distance is too small between pulleys or deflection is too high (drive belt engagement is higher in drive pulley). Adjust distance between pulleys and/or drive belt deflection according to specifications (refer to PULLEY ALIGNMENT).

3. Check driven pulley sliding sheave play.

- Jammed sliding sheave. Replace.

4. Check spring tension of driven pulley sliding sheave.

- Sliding sheave rotation is accelerated when spring tension is too weak. Adjust according to specifications (refer to DRIVEN PULLEY).

- 5. Refer to VIBRATIONS ORIGINATING FROM DRIVE PULLEY and VIBRATIONS ORIGINATING FROM DRIVEN PULLEY and check items listed.
- 6. Check drive pulley spring tension.
- Spring tension is too weak. Replace.

Symptom: ENGINE MAXIMUM RPM IS TOO HIGH AND TOP SPEED IS NOT REACHED.

- 1. Check items 1, 2 and 3 of THE SNOWMOBILE ACCELERATES SLOWLY, ESPECIALLY WHEN IT IS STOPPED.
- Check driven pulley spring tension.
 Spring tension is too stiff. Adjust according to specifications (refer to DRIVEN PULLEY).
- Check position of the calibration screws (TRA drive pulley).
 Selected numbers are too high. Adjust according to specifications (refer to TECHNICAL SPECI-FICATIONS).

31

- 4. Refer to VIBRATIONS ORIGINATING FROM DRIVEN PULLEY and check items listed.
- 5. Check the driven pulley.
 - Driven pulley does not open completely. Clean, readjust or replace driven pulley.
- 6. Check if levers of drive pulley move freely. - Stuck levers. Replace lever bushings.

Symptom: LOOSENESS IS FELT IN DRIVE SYSTEM WHEN ACCELERATING/ DECELERATING.

- Check drive chain tension.
 Drive chain is too loose. Adjust.
- 2. Check radial play of driven pulley.
 - Worn key, keyway or splines. Replace.

Subsection 04 (DRIVE SYSTEM AND BRAKE)

	1	. Check drive belt.
		- Belt width is uneven at many places. Replace.
	2	Check tightening torque of drive pulley screw. Moving governor cup. Retighten screw.
	3	 Spring cover screws. Spring cover moves and restrains sliding sheave movement. Retighten screws.
	4.	 Check spring cover (TRA type) and/or sliding sheave bushings. Excessive gap between bushings and fixed sheave shaft, thus restraining sliding sheave move ments. Replace bushing(s).
	5.	Check governor cup splines. - Excessive radial play. Replace governor cup.
	6.	Check lever assembly.
		- Lever assembly is damaged (worn bushing, bent lever, etc.). Replace damaged part.
Symptom:	VI	BRATIONS ORIGINATING FROM DRIVEN PULLEY.
	1.	Check sliding sheave side play. - Sliding sheave bushing worn out. Replace sliding sheave bushing.
	2.	Check sliding sheave and fixed sheave straightness. - Sliding sheave/fixed sheave warped. Replace.
	3.	Check cam slider shoes. - One or two slider shoes out of three are broken. Replace.
Symptom:	PU	ILLEYS DO NOT DOWN SHIFT PROPERLY.
And These	1	Check driven pulley spring tension.
		- Spring tension is too low. Adjust according to specifications (refer to DRIVEN PULLEY).
	2.	Refer to VIBRATIONS COMING FROM DRIVEN PULLEY and check items listed.
	3.	Check drive pulley bushings (cleanliness, wear, etc.). - Bushings stick to fixed sheave pulley shaft. Clean or replace.
		businings stick to fixed sheave pulley shart. Clean of replace.
		REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST ive belt is low in driven pulley).
	(dr	REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST
	(dr	REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST ive belt is low in driven pulley). Check pulley distance and alignment.
	(dr 1. 2.	REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST ive belt is low in driven pulley). Check pulley distance and alignment. - Improper adjustment. Adjust according to specifications (refer to PULLEY ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts. Check for reverse sliding shoes.
	(dr 1. 2.	REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST ive belt is low in driven pulley). Check pulley distance and alignment. - Improper adjustment. Adjust according to specifications (refer to PULLEY ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts. Check for reverse sliding shoes. - Sliding shoes are worn or missing. Replace sliding shoes.
	(dr 1. 2. 3.	REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST ive belt is low in driven pulley). Check pulley distance and alignment. - Improper adjustment. Adjust according to specifications (refer to PULLEY ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts. Check for reverse sliding shoes.
	(dr 1. 2. 3.	REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST ive belt is low in driven pulley). Check pulley distance and alignment. - Improper adjustment. Adjust according to specifications (refer to PULLEY ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts. Check for reverse sliding shoes. - Sliding shoes are worn or missing. Replace sliding shoes. Check spring.
	(dr 1. 2. 3.	 REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST in belt is low in driven pulley. Check pulley distance and alignment. Improper adjustment. Adjust according to specifications (refer to PULLEY ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts. Check for reverse sliding shoes. Sliding shoes are worn or missing. Replace sliding shoes. Check spring. Spring is weak or insufficient tension. Replace spring.
	(dr 1. 2. 3.	 REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST in belt is low in driven pulley. Check pulley distance and alignment. Improper adjustment. Adjust according to specifications (refer to PULLEY ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts. Check for reverse sliding shoes. Sliding shoes are worn or missing. Replace sliding shoes. Check spring. Spring is weak or insufficient tension. Replace spring.

Section 02 TROUBLESHOOTING Subsection 04 (DRIVE SYSTEM AND BRAKE) DRIVE BELT Symptom: UNEVEN BELT WEAR ON ONE SIDE ONLY. 1. Check tightening torque of engine mount bolts. - Loose engine mount. Tighten engine mount nuts/bolts equally. 2. Check pulley alignment. - Pulley misalignment. Align pulleys. 3. Check drive belt contact area on pulleys. - Rough or scratched pulley surfaces. Repair or replace pulley sheave. 4. Check driven pulley sliding sheave play. - Driven pulley bushing worn. Replace bushing. Symptom: BELT GLAZED EXCESSIVELY OR HAVING BAKED APPEARANCE. 1. Check if drive pulley bushings are worn. - Slipping due to insufficient pressure on belt sides. Replace bushing. 2. Check condition of drive pulley fixed sheave shaft. - Slipping due to rusted drive or driven pulley shafts. Clean shaft with fine steel wool. 3. Check if pulley sheaves are clean. - Slipping due to oily pulley surfaces. Clean pulley sheaves. 4. Check pulley calibration. - Slipping due to improper pulley calibration. Calibrate according to specifications. Symptom: BELT WORN EXCESSIVELY IN TOP WIDTH. 1. Check drive pulley. - Excessive slippage due to jammed of drive pulley. Inspect drive pulley. 2. Check drive belt identification number. - Improper belt angle. (wrong type of belt). Replace belt with an appropriate drive belt. 3. Check drive belt width. - Considerable use. Replace belt if width is less than specified in DRIVE BELT. Symptom: BELT TOO NARROW ON ONE SECTION. 1. Check for frozen track. - Frozen track. Free track from ice. 2. Check parking brake. - Parking brake is engaged. Release parking brake. 3. Check track tension/alignment. - Track too tight. Adjust track tension and alignment. 4. Check drive pulley. - Drive pulley does not operate properly. Repair or replace drive pulley. 5. Check idle speed. - Engine idle speed is too high. Adjust according to specifications. 6. Check drive belt length. Incorrect belt length. Replace with an appropriate drive belt (refer to TECHNICAL SPECIFICA-TIONS). mmr2007-149 33

Section 02 TROUBLESHOOTING Subsection 04 (DRIVE SYSTEM AND BRAKE) Symptom: BELT TOO NARROW ON ONE SECTION. (cont'd) 7. Check distance between pulleys. - Incorrect pulley distance. Readjust according to specifications. 8. Check belt height. - Belt height is incorrect. Adjust according to specifications. Symptom: BELT SIDES WORN CONCAVE. 1. Check pulley sheave surfaces. - Rough or scratched pulley sheave surfaces. Repair or replace. 2. Check drive belt identification number. - Wrong type of belt. Replace belt with an appropriate drive belt (refer to TECHNICAL SPECIFI-CATIONS). Symptom: BELT DISINTEGRATION. 1. Check drive belt identification number. Excessive belt speed. Wrong type of belt. Replace belt with proper type of belt. (refer to TECH-NICAL SPECIFICATIONS). 2. Check if pulley sheaves are clean. - Oil on pulley surfaces. Clean pulley surfaces with fine emery cloth and wipe clean using pulley flange cleaner (P/N 413 711 809) and a cloth. Symptom: BELT CORD POPPED OUT. 1. Check pulley alignment. - Pulley misalignment. Align pulley according to specifications (refer to PULLEY ALIGNMENT). Symptom: FATIGUE CRACKS BETWEEN COGS. 1. Check drive belt condition. - Belt considerably worn, worn out. Replace. - Distortion of natural belt shape due to improper storage. Store properly. iymptom: TOOTH CHUNK OUT. 1. Check drive belt rotational direction. - Improper belt installation. Replace. 2. Check if drive belt rubs against components. - Belt rubs against fixed components. Relocate components. 3. Check drive pulley. - Violent engagement of drive pulley. Check drive pulley engagement speed, drive pulley bushings and components. ymptom: BELT "FLIP-OVER" AT HIGH SPEED. 1. Check pulley alignment. - Pulley misalignment. Align pulley according to specifications (refer to PULLEY ALIGNMENT). 2. Check drive belt identification number. - Wrong type of belt. Replace with an appropriate drive belt.

	Subsection 04 (DRIVE SYSTEM AND BRA
MECHAN	IICAL BRAKE
Symptom:	BRAKE DOES NOT ADJUST AUTOMATICALLY.
	1. Check ratchet wheel spring.
o ISACKER	
	 Check mobile pad stud. Stud rotates in pad. Replace.
Symptom:	BRAKE HANDLE DOES NOT RETURN COMPLETELY.
in lare OPE	 Check brake return spring. Broken return spring. Replace.
	 2. Check if brake cable moves freely in its housing. - Brake cable movement is limited due to oxidation or dirt accumulation. Replace.
	3. Check distance between brake lever and caliper. - Distance is too wide. Adjust according to specifications (refer to COUNTERSHAFT AND BRA
Symptom:	BRAKE SYSTEM IS NOISY.
	1. Check brake pad thickness. - Pads are worn up to wear indicator. Replace.
	2. Check key/keyway or splines.
	LILIC BRAKE
	ULIC BRAKE SPONGY BRAKE CONDITION. 1. Brake pads worn.
	SPONGY BRAKE CONDITION. 1. Brake pads worn. - Replace brake pads. 2. Air in brake system.
	SPONGY BRAKE CONDITION. 1. Brake pads worn. - Replace brake pads. 2. Air in brake system.
	SPONGY BRAKE CONDITION. 1. Brake pads worn. - Replace brake pads. 2. Air in brake system. - Bleed system. 3. Contaminated brake fluid.
	 SPONGY BRAKE CONDITION. Brake pads worn. Replace brake pads. Air in brake system. Bleed system. Contaminated brake fluid. Replace brake fluid and bleed system. If the problem persists, replace master cylinder. Check for damaged hose, master cylinder and caliper. Replace part(s) and check for proper mounting.
Symptom:	 SPONGY BRAKE CONDITION. Brake pads worn. Replace brake pads. Air in brake system. Bleed system. Contaminated brake fluid. Replace brake fluid and bleed system. If the problem persists, replace master cylinder. Check for damaged hose, master cylinder and caliper. Replace part(s) and check for proper mounting.
Symptom:	 SPONGY BRAKE CONDITION. Brake pads worn. Replace brake pads. Air in brake system. Bleed system. Bleed system. Contaminated brake fluid. Replace brake fluid and bleed system. If the problem persists, replace master cylinder. Check for damaged hose, master cylinder and caliper. Replace part(s) and check for proper mounting. BRAKE FLUID LEAKAGE. Check for loosen hose connectors.
Symptom:	 SPONGY BRAKE CONDITION. Brake pads worn. Replace brake pads. Air in brake system. Bleed system. Bleed system. Contaminated brake fluid. Replace brake fluid and bleed system. If the problem persists, replace master cylinder. Check for damaged hose, master cylinder and caliper. Replace part(s) and check for proper mounting. BRAKE FLUID LEAKAGE. Check for loosen hose connectors. Replace copper washers and retighten. Replace part(s) and check for proper mounting.
Symptom: Symptom:	 SPONGY BRAKE CONDITION. Brake pads worn. Replace brake pads. Air in brake system. Bleed system. Bleed system. Contaminated brake fluid. Replace brake fluid and bleed system. If the problem persists, replace master cylinder. Check for damaged hose, master cylinder and caliper. Replace part(s) and check for proper mounting. BRAKE FLUID LEAKAGE. Check for loosen hose connectors. Replace copper washers and retighten. Replace part(s) and check for proper mounting.
Symptom: Symptom:	 SPONGY BRAKE CONDITION. Brake pads worn. Replace brake pads. Air in brake system. Bleed system. Beed system. Contaminated brake fluid. Replace brake fluid and bleed system. If the problem persists, replace master cylinder. Check for damaged hose, master cylinder and caliper. Replace part(s) and check for proper mounting. BRAKE FLUID LEAKAGE. Check for loosen hose connectors. Replace copper washers and retighten. Check for damaged hose, master cylinder and caliper. Replace copper washers and retighten. BRAKE SYSTEM IS NOISY. Check brake pad thickness.

Subsection 04 (DRIVE SYSTEM AND BRAKE)

Sympton	n: 5	LIDER SHOES WEAR OUT PREMATURELY OR TRACK CLEATS BECOME BLUE
	1	Check track tension.
		 Pressure is too great on slider shoes. Adjust according to specifications (refer to TRACK). Re place defective parts.
	2.	Check idler wheel condition. - Stuck bearing, flat spot on wheel or damaged wheel. Replace defective parts.
	3.	Check snow conditions or lack of snow. - Lack of lubrication of slider shoes. Ask driver to ride in appropriate snow condition (see OPER ATOR'S GUIDE).
	4.	Check slider shoes and/or suspension retaining screws. - Twisted slider shoes or loose retaining screws. Replace defective parts and/or tighten loosen screws.
Symptom:	DE	RAILING TRACK.
	1.	Check track tension. - Track is too loose. Adjust to recommended tension.
	2.	Check if track and slider shoes are properly aligned. - Improper alignment. Adjust.
Symptom:	NC	DISE OR VIBRATION COMING FROM THE TRACK.
oymptom.	199	Check track tension. - Track is too loose. Adjust to recommended tension.
	2.	Check slide suspension retaining bolts. - Missing bolt(s), some components interfere with track rotation. Replace missing bolt(s).
	3.	Check condition of idler wheel(s). - Idler wheel rubber is damaged. Replace idler wheel.
	4.	Check guide cleats. - Top portion of guide cleat(s) is bent. Replace.
	5.	Check sprockets. - One or several teeth of drive shaft sprocket are broken. Replace sprocket(s).
	6.	Check track rods and/or internal traction teeth. - One or several track rods and/or teeth are broken. Replace track.
GEARBO	OX	
Symptom:	UN	USUAL GEARBOX NOISE AND/OR VIBRATION.
	1.	Check oil lever in gearbox.
		 Oil leakage from gearbox. Replace damaged gasket(s) and/or oil seal(s), torque screws and refile oil up to specified level (refer to GEARBOX).
		Check bearings in gearbox for free movement.
	2.	
		- Bearing(s) do(es) not move freely. Replace bearing(s). Check for knocking noise.

Section 02 TROUBLESHOOTING Subsection 04 (DRIVE SYSTEM AND BRAKE)

CHAINCASE

Symptom: UNUSUAL CHAINCASE NOISE AND/OR VIBRATION.

1. Check oil lever in chaincase.

- Oil leakage from chaincase. Replace damaged gasket(s) and/or oil seal(s), torque screws and refill oil up to specified level (refer to CHAINCASE).
- 2. Check drive chain adjustment.
- Drive chain is too loose. Adjust drive chain in accordance with the procedure in CHAINCASE.
- 3. Check bearings in chaincase for free movement. - Bearing(s) do(es) not move freely. Replace bearing(s).
- 4. Check for knocking noise.
 - Teeth of gears are damaged and/or worn. Replace defective gear(s).
 - Chain tensioner is defective. Check roller and needle bearing. Replace defective parts.
 - Chain is stretched over service limit. Replace drive chain.

mmr2007-149	3

Subsection 05 (ELECTRICAL SYSTEM)

ELECTRICAL SYSTEM

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

IGNITION SYSTEM

Symptom: THE ECM AND/OR MPEM DOES NOT WORK.

- 1. Check that high tension coil wires do not touch any metal parts. - Short circuit. Isolate and reroute wires.
- 2. On liquid cooled models), check codes in B.U.D.S. - Defective connections or faulty ECM. Repair or replace.
- Symptom: ENGINE IS MISFIRING ERRATIC SPARK AT SPARK PLUG (riding on wet snow).
 - Check if spark plug wires and/or spark plug cap seals are sealing out moisture.
 Defective wires and/or seals. Replace defective part.
 - Check if ignition system wiring harness connectors are in good condition and/or are sealing out moisture.

 Loose connectors, corroded terminals or defective parts. Clean terminals and apply silicone dielectric grease. Replace defective parts.

Symptom: ENGINE IS MISFIRING — ERRATIC SPARK AT SPARK PLUG (riding in deep and thick snow).

- 1. Perform all verifications outlined under ENGINE DOES NOT START NO SPARK AT SPARK PLUG.
- Check spark plugs. Proceed with spark plug analysis in order to identify source of problem.
 Defective and/or worn spark plug(s) and/or cable(s) and/or cap(s). Engine related problem. Replace defective part(s). Proceed with ignition system testing procedures. Perform engine analysis.

Symptom: ENGINE IS MISFIRING - ERRATIC SPARK AT SPARK PLUG (normal use).

 Verify misfiring by observing flash of stroboscopic timing light; unplug connectors between magneto/generator and vehicle wiring harness to isolate problem. Check condition of connectors.

 Defective spark plug(s) and/or cable(s)/cap(s). Defective electrical system wiring harness and/or accessories and ignition cut-out switches. Condition of connector terminals. Replace defective parts and/or repair damaged wires. Replace defective switch(es). Clean terminals and apply silicone dielectric grease.

Symptom: FOULED (BLACK) SPARK PLUG TIP.

- 1. Check carburetor.
 - Carburetion is too rich. Adjust according to specifications (refer to TECHNICAL SPECIFICA-TIONS).
- 2. Check injection oil consumption.

- Injection pump flow is too high. Adjust according to specifications or replace.

3. Check oil quality.

- Poor quality oil (creation of deposits). Use appropriate BRP's XP-S injection oil.

4. Check engine compression. - Leaking piston ring(s). Replace.

mmr2007-150

99

Subsection 05 (ELECTRICAL SYSTEM)

Symptom: SPARK PLUG TIP IS LIGHT GRAY.

- 1. Refer to ENGINE SLOWS DOWN OR STOPS AT HIGH RPM and check items listed.
- Check spark plug heat range.
 Spark plug heat range is too high. Replace by BRP's recommended spark plug (refer to TECH-NICAL SPECIFICATIONS).
- Check if air intake silencer leaks.
 Air surplus coming from opening(s) located between halves. Seal.
- 4. Check carburetor adapter collars. - Loose collar(s). Tighten.
- 5. Check carburetor adapter(s). - Cracked or deformed adapter(s). Replace.
- 6. Check if primary compression leaks. - Primary compression leaks. Perform leak down test and repair as necessary.

CHARGING SYSTEM

Symptom: BATTERY NOT CHARGING OR CHARGING VOLTAGE INADEQUATE.

- 1. Check battery.
 - Battery shows less power. Reload battery. - Battery has electrical failure. Replace.
- 2. Check voltage regulator/rectifier.
- Refer to CHARGING SYSTEM.
 - Check wiring harness for cracks or other damages.
 Harness shows electrical failure and/or other damages. Replace/repair wiring harness.
 - 4. Check magneto for damage and/or electrical failure.
 - Radial position of rotor wrong due to broken Woodruff key. Replace Woodruff key.
 - Coating on stator winding is damaged. Replace stator.
 - Resistance value is out of specification (refer to TECHNICAL SPECIFICATIONS). Replace magneto.
 - Connector on magneto is damaged and/or has electrical failure. Repair and clean contacts of connector.

STARTING SYSTEM

ymptom: STARTER DOES NOT TURN.

1. Check fuse.

- Burnt fuse. Check wiring condition and replace fuse.
- 2. Check MPEM or ECM.

 Defective ECM or MPEM. Using B.U.D.S. software, check faulty codes and diagnose all components. Repair defective part.

- Check battery charge.
 Discharged or disconnected battery. Recharge battery and check charging system and wires.
- 4. Check ground.
 - Poor, or corroded ground contacts. Check, clean and tighten.

Section 02 TROUBLESHOOTING Subsection 05 (ELECTRICAL SYSTEM)

Symptom: STARTER DOES NOT TURN. (cont'd) 5. Check continuity of start or ignition switch contact points. - Poor contact of start or ignition switch contact points. Replace switch. 6. On fan cooled models, check continuity between ignition switch and solenoid. - Open circuit. Repair. 7. On liquid cooled models, check continuity between start switch and ECM. - Open circuit. Repair. 8. On liquid cooled models, check continuity between ECM and solenoid switch. - Open circuit. Repair. 9. Check starter solenoid. - Inadequate connection (too much resistance) or defective solenoid. Clean, reconnect and/or replace. 10. Check starter. - Inadequate connection (too much resistance) or defective starter. Reconnect and/or replace. 11. Check engine problems. - Damaged engine. Check and repair. Symptom: STARTER TURNS BUT DOES NOT CRANK THE ENGINE. 1. Check battery capacity. - Shorted battery cell(s). Replace. 2. Check battery charge. - Low battery. Recharge battery and check recharge system and wires. 3. Check wire connection. - Inadequate connection (too much resistance). Clean and reconnect. 4. Check solenoid switch contact disc. - Burnt or poor contact of solenoid switch contact disc. Replace solenoid switch. 5. Check starter. - Defective. Replace starter. 6. Check engine. - Engine seized. Overhaul the engine. Symptom: STARTER TURNS, BUT OVERRUNNING CLUTCH PINION DOES NOT MESH WITH RING GEAR. 1. Check clutch pinion gear. - Worn clutch pinion gear. Replace clutch. 2. Check clutch. - Defective clutch. Replace clutch.

- 3. Check brackets. - Worn or broken brackets. Replace brackets.
- 4. Check movement of clutch on splines. - Poor movement of clutch on splines. Clean and correct.
- 5. Check clutch bushing. - Worn clutch bushing. Replace clutch.

Symptom:	STARTER TURNS, BUT OVERRUNNING CLUTCH PINION DOES NOT MESH WITH RING GEAR. (cont'd)			
	1	Check ring gear. - Worn ring gear. Replace ring gear.		
	7.	Check for proper starter rotation direction. - Starter turns in wrong direction, incorrectly installed brushes, wrong polarity or wrong starter Replace starter or reconnect properly.		
Symptom:	ELECTRIC STARTER KEEPS TURNING WHEN ENGINE IS STARTED.			
	1.	Check clutch. - Jammed clutch pinion gear. Replace or clean.		
	2.	Check movement of clutch on splines. - Clutch is stuck on splines. Clean.		
	3.	Check starter brackets. - Broken bracket(s). Replace bracket(s).		
	4.	Check starter solenoid. - Shorted starter solenoid winding(s). Replace starter solenoid. - Melted starter solenoid contacts. Replace starter solenoid. - Starter solenoid returns poorly. Replace starter solenoid.		
	5.	Check start or ignition switch contacts. - Contacts shorted. Replace switch.		
Symptom:	N	DISE OCCURRENCE WHEN STARTING ENGINE.		
	1.	Check if ring gear is well-mounted to drive pulley fixed sheave. - Loose and/or broken bolts. Retighten bolts using thread locker or replace ring gear and drive pulley fixed sheave.		
Symptom:	EL	ECTRIC STARTER SOMETIMES DOES NOT WORK WHEN ACTIVATED.		
	1.	Check battery cables and starter wires. - Corroded and/or loose connection(s). Clean and/or retighten.		
	2.	Check fuse. - Oxidized or burnt fuse. Clean or replace.		
	3.	Check wiring harness connections. - Oxidized connections. Clean or replace defective terminals.		
	4.	Check ignition switch or start switch. - Defective contacts in switch. Replace. - Moisture in switch. Clean switch.		
	5.	Check solenoid of electric starter. - Shorted solenoid wiring harness or corroded contact washer. Replace.		
ROTAX	EL	ECTRONIC REVERSE (RER)		
Symptom	RE	R DOES NOT WORK.		

	Section 02 TROUBLESHOOTING Subsection 05 (ELECTRICAL SYSTEM
Symptom:	RER DOES NOT WORK. (cont'd)
	2. Check spark plugs. - Faulty spark plug(s). Replace.
	 Check engine compression. Too low engine compression; engine stalls when pushing RER button. Rebuilt the engine.
	 4. Check drive belt height. - Wrong belt height. Adjust according to specification (refer to DRIVE BELT).
	 Check carburetor synchronization and air screw adjustment. Wrong adjustment. Adjust according to specification (refer to TECHNICAL SPECIFICATIONS and read VM CARBURETORS subsection.
	 6. Check RER switch and electrical connections. - Defective contacts in switch. Bad electrical connections or damaged wires. Replace or repair.
	7. Check RER trigger coil. - Faulty RER trigger coil. Refer to ROTAX ELECTRONIC REVERSE (RER) section.
Symptom:	RER SOMETIMES DOES NOT WORK WHEN ACTIVATED.
	 Check RER switch. Defective contacts in switch. Replace. Moisture in switch. Clean switch. Check engine condition.
	- Low engine compression and/or defective piston. Replace defective parts.
	, INSTRUMENTS AND ACCESSORIES HEADLAMP NOT LIGHTING (white bulb).
oymptom.	Check bulb. Gas leak. Replace bulb.
Symptom:	HEADLAMP NOT LIGHTING (broken element).
	 Check for loose headlamp housing and bulb socket. Vibration problem. Tighten headlamp mounting screws. Lock bulb in socket. Replace bulb.
Symptom:	HEADLAMP NOT LIGHTING (melted filament, ends of element holder and black bulb).
	1. Check voltage at headlamp at different speeds. Refer to <i>LIGHTS, INSTRUMENTS AND AL CESSORIES</i> .
	 Excessive voltage in lighting circuit. Replace voltage regulator and ensure proper groundin Retest. NOTE: If quartz halogen bulb is involved, ensure that proper voltage regulator is installed.
Symptom:	HEADLAMP DIMMING.
	 Check voltage at headlamp at different speeds. It must be above 11 V. Refer to LIGHT INSTRUMENTS AND ACCESSORIES section.
	- Insufficient voltage in lighting circuit. Replace voltage regulator and retest.
mmr2007-150	

Subsection 05 (ELECTRICAL SYSTEM)

Symptom: HEADLAMP DIMMING. (cont'd)

Visually inspect wiring harness for damaged and/or melted wires and/or bad wire terminal crimping and/or connections.

 Heating, rotating or sharp part in contact with harness. Improper harness routing. Repair/replace damaged wires and/or terminals. Reroute harness where necessary.

3. On 440F, 550F and 600 models, verify if there is an interconnection between AC and DC current.

 Faulty installation of optional equipment. Refer to LIGHTS, INSTRUMENTS AND ACCESSORIES section.

- 4. Check if optional electric accessories are overloading the magneto/generator.
 - Excessive electrical load to magneto/generator. Reduce the electrical load by removing excess
 accessories. Reconnect as recommended by manufacturer.
- 5. Heating grips: Verify if the return wires of the elements were grounded to the chassis by mistake.

- Faulty installation of optional equipment. Reconnect as recommended by manufacturer.

Symptom: FALSE FUEL AND/OR TEMPERATURE GAUGE READINGS.

- 1. On 440F, 550F and 600 models, verify if gauge was connected on DC current by mistake (in case of optional installation).
 - Faulty installation of optional equipment. Refer to LIGHTS, INSTRUMENTS AND ACCESSORIES.
- 2. Verify sender unit for free movement and/or correct arm position.

- Defective or damaged part. Correct or replace sender unit.

3. Verify sender unit/gauge wiring harness condition.

- Heating, rotating or sharp part in contact with harness. Improper harness routing. Replace or repair damaged wires. Reroute where necessary.

Symptom: NO ELECTRICAL ACCESSORIES WORK WHEN ENGINE IS ON IDLE.

1. Check idle speed.

- Too low idle speed. Readjust to specifications.
- 2. Verify regulator.
 - Faulty regulator. Replace.

Symptom: BRAKE LIGHT REMAINS ON.

1. Check if bulb is properly installed.

- Bulb is not installed correctly (contact elements are reversed). Install bulb correctly.

2. Check brake switch.

- Switch contact remains closed. Replace brake switch.

3. Check wiring harness.

- Shorted wiring harness. Replace or repair wiring harness.

Symptom: REAR LIGHT BULB FLASHES.

1. Check bulb tightness in housing.

- Looseness at bulb contact elements. Install bulb correctly.

2. Check if rear light is properly connected.

- Connector housing is partially connected. Install connector housing properly.

3. Check continuity of wires.

- Corroded terminals and/or broken wires. Replace terminal(s) or crimp defective wires.

Section 02 TROUBLESHOOTING Subsection 05 (ELECTRICAL SYSTEM)

mptom:	TACHOMETER DOES NOT WORK.			
	1.	Check continuity of wires. - Corroded terminals and/or broken wires. Replace terminal(s) or crimp defective wires.		
	2.	Check tachometer signal or power supply and ground. - Check. Refer to LIGHTS, INSTRUMENTS AND ACCESSORIES.		

Section 02 TROUBLESHOOTING Subsection 06 (STEERING SYSTEM)

STEERING SYSTEM

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

HANDLEBAR

Symptom: WHEN HANDLEBAR IS TURNED, SNOWMOBILE UNDERSTEERS.

1. Check ski runner condition.

- Worn ski runners. Replace.
 Check ski spring preload.
 - Insufficient ski pressure on the ground. Increase spring preload.
- 3. Check if front arm stopper strap is too long (rear suspension).
 - Insufficient ski pressure on the ground. Shorten stopper strap.
- 4. Check front arm spring preload (rear suspension).
 - Insufficient ski pressure on the ground. Loosen spring tension.

Symptom: HANDLEBAR IS DIFFICULT TO TURN.

- 1. Check if the handlebar turns freely when skis are off the ground.
 - Ball joints corrosion restrains movement. Lubricate or replace the ball joint.
 - Component need proper lubrication. Lubricate. Refer to STEERING AND HANDLEBAR.
 - Bent parts. Replace parts.

2. Check ski spring preload.

- Too much preload. Reduce ski spring preload.
- Check position of front arm spring adjustment cam.
 When spring tension is weak, more weight is transferred to the skis. Increase spring preload.

4. Check position of stopper strap (rear suspension).

- Too much weight when stopper strap is short. Lengthen front arm stopper strap.
- 5. Check ski runners.
 - Wrong ski runners type. Replace.

SKI

Symptom: THE SNOWMOBILE ZIGZAGS.

1. Check ski runners.

- Worn or bent ski runners. Replace ski runners.
- Wrong ski runner type. Replace.

2. Check ski alignment.

- Improper ski alignment. Align skis in order to obtain proper toe-out (opening), refer to SKIS AND STEERING ALIGNMENT.
- 3. Check if bushings are too loose in steering system. - Bushings are too loose. Replace.
- 4. Check ski pressure.
 - Too much pressure on skis. Increase center spring preload (rear suspension).

mmr2007-151

47

Section 02 TROUBLESHOOTING Subsection 07 (SUSPENSION)

SUSPENSION

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

Symptom: SUSPENSION IS TOO LOW.

- 1. Check condition of springs.
 - Springs are broken. Replace springs.
- 2. Check springs preload.
 - Too low spring preload. Increase preload to the recommended position.
- 3. Check springs.

 Installed springs are too soft. Install optional stiffer springs, refer to Service Bulletin SPRING REFERENCE ACCORDING TO LOAD.

- 4. Check condition of shock.
 - Shock frozen. Replace shock.

Symptom: REAR SUSPENSION BOTTOMS OUT.

- 1. Check condition of springs.
 - Springs are broken. Replace springs.
- 2. Check springs preload.

- Too low spring preload. Increase preload to the recommended position.

- 3. Check springs. - Springs installed are too soft. Install optional stiffer springs, refer to Service Bulletin SPRING REFERENCE ACCORDING TO LOAD.
- 4. Check condition of the rear shock absorber. - Damaged rear shock absorber. Replace rear shock absorber.

Symptom: REAR SUSPENSION IS TOO STIFF.


1. Check rear spring preload.


- Too much preload. Adjust to a softer position.


2. Check springs.

- Springs installed are too stiff. Install optional softer springs.

- 3. Check track tension.
 - Track is too tight. Adjust.
- Check if axles are properly lubricated.
 Improper lubrication and/or contaminated grease (sticky oil sludge). Clean and/or lubricate.
- Check condition of the rear shock absorber.
 Damaged rear shock absorber. Replace rear shock absorber.







Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

GENERAL

During assembly/installation, use the torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to.

Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

PROCEDURES

Vehicle and Engine Preparation

Place vehicle at workstation that will have access to an engine-lifting hoist. Then start with initial preparation of vehicle by doing the following.

Disconnect BLACK (-) cable from battery, then the RED (+) cable.

Always disconnect battery or starter cables exactly in the specified order, BLACK (-) cable first. It is recommended to disconnect electrical connections prior to disconnecting fuel lines.

Remove drive and driven pulleys.

Release carburetor from air intake silencer.

Unscrew carburetor clamps then remove carburetors from intake adapters.

Remove impulse line from crankcase.


Remove tuned pipe no. 1 and manifold.

Remove starter cables.

Disconnect the spark plug cables.

Unplug electrical connectors connected to engine.

Install a small hose pincher (P/N 295 000 076) on the oil inlet hose and disconnect it from oil pump. Clean any spillage.





1. Hose pincher 2. Oil inlet hose

Remove rewind starter handle. Remove the engine support nuts **no. 2**. Remove engine from vehicle.

Part Inspection

Check if engine support no. 3 is cracked, bent or damaged. Replace if necessary.

Check rubber mounts no. 4 on engine support. Replace them if brittle, cracked or damaged.

Engine Installation

To install engine in vehicle, reverse the removal procedure. However, pay attention to the following.

Torque engine support bolts to 39 N•m (29 lbf•ft).

Reinstall all removed parts by using the appropriate component/system reinstallation procedures described in this shop manual.

Perform engine and pulley alignment. Refer to PULLEY ALIGNMENT.

Section 03 ENGINE (443 AND 552) Subsection 02 (ENGINE LEAK TEST)

ENGINE LEAK TEST

SERVICE TOOLS

Description	Part Number	Page
intake plug	529 011 000	
manifold plug	529 035 961	
small hose pincher	295 000 076	
vacuum/pressure pump	529 021 800	


Prior to take apart an engine, it is important to proceed with a leak test to diagnose engine problems. Whenever the engine is disassembly, a leak test should be performed after reassembly.

Each cylinder cannot be verified individually due to intentional leakage from one cylinder to the other through labyrinth sleeve in center of crankshaft.

PREPARATION

Remove tuned pipe.

Install manifold plug (P/N 529 035 961) over exhaust manifold.




Remove carburetor(s).

Insert an intake plug (P/N 529 011 000) in each intake adaptor. Tighten with existing clamps.



TYPICAL 1. Intake plug

Using a small hose pincher (P/N 295 000 076), block impulse hose.



Small hose pincher Impulse hose 1.


55

PROCEDURES

NOTE: A flow chart has been prepared as a visual reference. See last page of this chapter. Install vacuum/pressure pump (P/N 529 021 800) on manifold plug.

Section 03 ENGINE (443 AND 552)

Subsection 02 (ENGINE LEAK TEST)



TYPICAL

Activate pump and pressurize engine

TEST PRESSURE: 34 kPa (5 PSI) for 3 minutes

Do not exceed this pressure.


If pressure drops before the recommended time, spray a soapy solution on tester kit (manifold and intake plugs, vacuum/pressure pump and its hose).

- If tester kit (manifold and intake plugs, hoses and pump) is leaking, bubbles will indicate where leak comes from.
- If tester kit is not leaking, check engine, see below for procedure.
- If there is a leak at the tested location, it is recommended to continue testing next items before overhauling engine. There is a possibility of more than one leak.
- If there is no leak at the tested location, continue pumping to maintain pressure and continue with next items until leak is found.

Engine


Check the following:

- All jointed surfaces and screw/stud threads of engine:
 - spark plug base, insulator
 - cylinder head
 - cylinder
 - crankcase halves (joint)
 - oil injection pump mounting flange (O-ring).
- Small injection oil lines coming from pump. Air bubbles or oil column going toward pump, indicates a defective check valve.



TYPICAL - 443 ENGINE Small injection oil lines Check valve inside banjo fittings

2




TYPICAL — 552 ENGINE 1. Check valve inside injector nozzle

- Crankshaft outer seals. One behind drive pulley and the other behind magneto.

If leak still persists, it indicates a defective casting somewhere in engine. Disassemble engine and carefully check for defects in castings. Pay attention to tapped holes which may go through engine sealed area and thus lead to leakage.

mmr2007-154

Section 03 ENGINE (443 AND 552) Subsection 02 (ENGINE LEAK TEST)





11122211

Section 03 ENGINE (443 AND 552) Subsection 03 (AIR INTAKE SYSTEM)

AIR INTAKE SYSTEM

443 Engine





PROCEDURES

AIR FILTER

Air Filter Removal

There are 2 filters. One on hood and another one on the air intake silencer.

Pull filter out of its receptacle for cleaning.

443 Engine





1. Air Filter

mmr2007-155

Section 03 ENGINE (443 AND 552) Subsection 03 (AIR INTAKE SYSTEM)





ACCORDING TO MODEL

A29HOMA

Air Filter Cleaning

Blow low pressure compressed air on filter to clean it.

Replace air filter as required.

NOTE: If the filter is very dirty, clean the interior of the air intake silencer at the same time.

Air Filter Installation

The installation is the reverse of the removal procedure.

AIR INTAKE SILENCER

Air Intake Silencer Removal


Open hood


Remove drive belt guard.


Release collar (if applicable) on air intake adaptor side.

61

Section 03 ENGINE (443 AND 552) Subsection 03 (AIR INTAKE SYSTEM) Separate air intake silencer from carburetor and pull it out of vehicle. Air Intake Silencer Installation The installation is the reverse of the removal pro-cedure.







Section 03 ENGINE (443 AND 552) Subsection 04 (EXHAUST SYSTEM)

GENERAL

To avoid potential burns, never touch exhaust system components immediately after the engine has been run because these compo-nents are very hot. Let engine and exhaust system cool down before performing any servicing. A WARNING

During assembly/installation, use the torque value and service products as in the exploded view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITTE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES

TUNED PIPE

Tuned Pipe Removal

Open hood.

Remove:

all exhaust springs no. 1 using exhaust spring installer/remover (P/N 529 035 983)



Tuned Pipe Inspection

Check: - tuned pipe and muffler for cracks or damages.

Tuned Pipe Installation

Apply Loctite 5920 (RTV high temperature sealant) (P/N 293 800 090) on ball joint contact surfaces. Install all exhaust springs using exhaust spring installer/remover (P/N 529 035 983).

MANIFOLD

Manifold Removal

- Remove:
- tuned pipe no. 2 - manifold screws no. 3

CAUTION: Heat screws for 30 seconds before loosening to prevent screw breakage. - manifold no. 4


- gaskets no. 5.

Manifold Inspection


Check if the manifold is cracked or damaged. Replace if necessary.


Manifold Installation


Install the manifold with new gaskets. Torque manifold screws no. 3.





gear holder 4 leak testing kit 5 multimeter Fluke 111 5 small hose pincher. 2 vacuum/pressure pump 5	19 033 100 19 035 868 50 00 076 29 021 800 11 Number 33 800 060	
gear holder	10 876 695 19 033 100 19 035 868 19 035 868 19 035 800 19 021 800 11 Number 13 800 060	
leak testing kit	19 033 100 19 035 868 50 00 076 29 021 800 11 Number 33 800 060	
small nose pincner 2 vacuum/pressure pump 5 SERVICE PRODUCTS Description P Loctite 243 (blue) 2 Loctite 648 (green) 4 Molykote 111 4	15 000 076 19 021 800	
SERVICE PRODUCTS Description Loctite 243 (blue)	29 021 800	7
Description P Loctite 243 (blue) 2 Loctite 648 (green) 4 Molykote 111 2	93 800 060	
Loctite 243 (blue)	93 800 060	
Molykote 111	93 800 060	
Molykote 111 2	13 711 400	
pulley flange cleaner 4	13 707 000	
	13 711 809	











If pressure drops, locate leak(s) and repair/replace leaking component(s).


PROCEDURES

OIL RESERVOIR

Oil Reservoir Removal

Siphon injection oil from reservoir. 440F Models

Remove ignition coil from reservoir. Remove reservoir retaining screws.



Remove reservoir retaining screw.



440F/550F Models Pull oil reservoir and unplug hose.

mmr2007-158

Oil Reservoir Installation

For installation, reverse the removal procedure. Bleed oil pump. Refer to *OIL PUMP*.

OIL LEVEL SENSOR

Sensor Removal Remove oil reservoir, as mentioned above. Unplug sensor no. 2 connectors. Pull sensor out of reservoir.

Before replacing the oil level sensor, check it according to the following procedure:

Sensor Electrical Test

CAUTION: Do not remove or bend the reed switch protective float magnet. It can damage the reed switch glass.

With the float magnet ring at the lowest position and using the multimeter Fluke 111 (P/N 529 035 868), measure the resistance of the oil level sen-



MEASURE	SENSOR CONDITION
Closed circuit (close to 0 Ω)	Good
Open or resistive circuit more than 0.5 Ω	Defective

Sensor Installation For installation, reverse the removal procedure.

OIL FILTER





550F MODELS

Oil Filter Removal Siphon injection oil reservoir.

550F Models

Remove oil reservoir and ignition coil. 440F and 550F Models

Disconnect oil filter hose from the oil level sensor. Disconnect filter from oil hoses and remove it.

Oil Filter Installation

For installation, reverse the removal procedure. The filter must be installed with the arrow pointing toward the pump.



440F MODEL SHOWN

Bleed oil pump. Refer to OIL PUMP.

OIL PUMP

Oil Pump Identification Different engines need different pumps. See identification on lever no. 3.

CAUTION: Always mount proper pump on en-gine.

ENGINE TYPE	OIL PUMP
443	E8

03

552 **Oil Pump Verification**

NOTE: Since pump is a piston type, it works when engine rotates in both forward and reverse.

On Vehicle

NOTE: Main oil line must be full of oil. See bleed-ing procedure further. Lift rear of vehicle and support with a mechanical stand. Unplug small oil lines from pump.



Start engine and stop it as soon as it fires.

Start engine and stop it as soon as it tires. Check that oil in small oil lines has been sucked up (this will be indicated by a clear section of small oil lines). Repeat the procedure until this condition is attained. Reconnect small oil lines, start engine and run at idle while holding the pump lever no. 3 in ful-ly open position. Oil columns must advance into small oil lines.



If not, remove oil pump no. 1 and check the pump gear no. 8 and drive shaft no. 10 for defects, re-place as necessary. Test pump as described below.

NOTE: Through normal use, oil level must not drop in small tubes. If oil drops, verify check valves no. 4 operation. Replace as necessary.

Test Bench

Connect a hose filled with injection oil to main line fitting. Insert other hose end in an injection oil container. Using a clockwise rotating drill, ro-tate pump shaft. Oil must drip from outer fittings while holding lever in a fully open position. If not, replace pump.

Oil Pump Removal

NOTE: Before removing the oil pump no. 1, check its operation.

CAUTION: Never try to pull out oil pump with-out removing mounting flange no. 7. Damage to pump components would occur. Drain injection oil reservoir.

550F Models

Remove the muffler.

440F/550F Models Remove screws no. 6.




Slightly pull mounting flange. Retain small gear no. 8 to avoid it falls down then, pull it out. Remove circlip then unplug hose from pump. Plug end of hose to prevent oil spillage.

CAUTION: Do not use a hose pincher on inlet hose. This would damage the spring inside hose.

NOTE: Mark outlet hoses location for installation. Unplug outlet hoses from pump.

Remove circlip then pull out throttle cable



TYPICAL

Withdraw pump. Oil Pump Disassembly NOTE: Some oil pump components are not available as single parts. First extract the needle roller with pliers.



Lock gear in place using gear holder (P/N 420 876 695).



Oil Pump Cleaning Clean all metal components in a non-ferrous metal cleaner.

Oil Pump Assembly

For assembly, reverse the disassembly procedure. However, pay attention to the following. At gear no. 8 assembly, apply a light coat of grease Molykote 111 (P/N 413 707 000) on gear teeth. The needle roller must be engaged as deep as possible in the pump mounting flange.



Install small gear no. 10 in mounting flange.

read at the second and the teders which uses

10 Primp Blocking Street Price

Check Valve fast being elapide onserved offer lefte offers -restant

Oil Pump Installation

Reverse removal procedure. However, pay attention to the following.

Install pump mounting flange on rewind starter. CAUTION: Do not force flange onto rewind starter for installation. Rotate flange while inserting so that gear shaft properly mesh with crankshaft end.

Apply Loctite 243 (blue) (P/N 293 800 060) on threads of screws no. 5 and torque them to 6 N•m (53 lbf•in).

Make sure cable barrel is well seated in oil pump

Secure barrel with plastic washer and circlip as shown.

An or a group in here an an atomic a start of the second s



1. Plastic washer on this side 2. Circlip on this side

Verify cable and oil pump lever operation then ad-just cable. Always check for spring clip tightness on inlet hose.

On 550F models, ensure to reinstall tube pro-tector on small oil line as shown.



Bleed oil system.

CAUTION: Always bleed oil pump when the system has been opened.

Oil Pump Adjustment

Prior to adjusting the pump, make sure all car-buretor adjustments are completed and engine is stopped. Refer to CARBURETOR AND THROT-TLE CABLE.

Eliminate the throttle cable free-play by pressing the throttle lever until a light resistance is felt, then hold in place.

The mark on the pump casting and on the lever must align. Width of lever mark is the tolerance. Loosen the adjuster nut and adjust accordingly. Retighten the adjuster nut.



TYPICAL 1. Marks 2. Adjuster nuts

CAUTION: Proper oil pump adjustment is very important. Any delay in the opening of the pump can result in serious engine damage.

Oil Pump Bleeding

Bleed main oil line (between reservoir and pump) by loosening the bleeder screw no. 2 until air has escaped from the line. Add injection oil as required.

Bleed the small oil line between pump and engine by running engine at idle while holding the pump lever in fully open position.



NOTE: Make a "J" hook out of mechanical wire to lift the lever.

Do not operate throttle mechanism. Secure the rear of the vehicle on a stand.

CHECK VALVE 440F Models

Check valve is part of banjo fitting no. 4 installed on oil pump.

550F Models

mmr2007-158

Check valve is part of injection nozzle no. 4 installed on crankcase.

Check Valve Test

Use the vacuum/pressure pump (P/N 529 021 800).



Connect pump to injection nozzle/banjo fittingno. 4. Test check valve as follows.

PUMP	Set to VACUUM	Set to PRESSURE
TO DO	Activate pump several times	Slowly activate pump and listen to check valve
RESULT	Air must not flow through check valve	You should hear it release pressure at approx. 20.7 kPa (3 PSI)
cale s di	Success: Perform next test	Success: Check valve is good
ACTION	Failed: Replace check valve	Failed: Replace check valve


INJECTION NOZZLE

Injection Nozzle Test Refer to CHECK VALVE.


Injection Nozzle Removal CAUTION: Do not remove injection nozzle needlessly. It is likely to be damaged. Remove air intake silencer and carburetor. Clean injection nozzle area to remove oil or dirt. Heat injection nozzle no. 4 then pull it out of crankcase.

Injection Nozzle Installation

Prior to coating it with Loctite, make sure injection nozzle body is clean and dry. Clean from dirt or oil, if any, with pulley flange cleaner (P/N 413 711 809).



	Subsection 06 (REWIN)	
REWIND STARTER		
SERVICE TOOLS		
Description	Part Number	Page
small hose pincher	295 000 076	
SERVICE PRODUCTS		
Description	Part Number	Pape
Molykote PG 54		84-86
and the second residence in the second second		



Section 03 ENGINE (443 AND 552) Subsection 06 (REWIND STARTER)

GENERAL

NOTE: Due to dust accumulation, rewind starter must be periodically cleaned, inspected and relubricated.

CAUTION: It is of the utmost importance that the rewind starter spring be lubricated periodically using specific lubricant. Otherwise, rewind starter component life will be shortened and/or rewind starter will not operate properly under very cold temperatures.

Check if rope no. 6 is fraying, replace if so.

When pulling starter grip, mechanism must engage within 30 cm (1 ft) of rope pulled. If not, disassemble rewind starter, clean and check for damaged plastic parts. Replace as required, lubricate, reassemble and recheck. Always replace O-ring no. 11 every time rewind starter is disassembled. When releasing starter grip, it must return to its stopper and stay againstit. If not, check for proper spring preload or damages. Readjust or replace as required.

When pulling starter grip 10 times in a row, it must return freely. If not, check for damaged parts or lack of lubrication. Replace parts or lubricate accordingly.

PROCEDURES

STARTER HANDLE

Handle Removal

Pull rope for 50 cm (20 in) approximately. Using a small hose pincher (P/N 295 000 076), lock rope near rewind starter.



Using a small screwdriver, extract rope knot from stater handle no. 3. Cut rope close to knot.

Handle Installation

Prior to installation Prior to installing starter handle on rope, it is first necessary to fuse the rope end with a lit match. Pass rope through starter handle and tie a knot in the rope end. Fuse the knot with a lit match then insert rope end down and pull the starter handle over the knot.



REWIND STARTER


Rewind Starter Removal


Remove starter handle no. 3. Remove nuts retaining oil injection pump to rewind starter housing.

Remove oil injection pump shaft. Remove screws no. 2 securing rewind starter no. 1 to engine then remove rewind starter.

Rewind Starter Disassembly

Undo knot previously tied at removal. Let sheave get free to release spring preload. Cut push nut no. 13and discard. Remove lock lever no. 12, O-ring no. 11, colla sleeve no. 10, pawl lock no. 9 and pawl no. 8.






Section 03 ENGINE (443 AND 552) Subsection 06 (REWIND STARTER)



Install collar sleeve no. 10 with its collar first. Lubricate a new O-ring no. 11 and lock lever no. 12 with Molykote PG 54 (P/N 420 899 763). Install over pawl lock.



1. Collar sleet 2. O-ring 3. Lock lever

Position a new push nut no. 13.

Rewind Starter Installation Thread starter rope no. 6 through rope guide when applicable.




TYPICAL

Reinstall rewind starter assembly on engine. Reinstall oil injection pump and its shaft. Refer to OIL INJECTION PUMP.

ROPE

Rope Replacement


Completely pull out rope. Hold rewind starter ina vise.



1. Rope exit hole 2. Key to be removed

With a long thin pin punch or a long screwdriver inserted through rope exit hole, gently tap on key no. 7 to disengage it. Remove key and rope. To install rope no. 6, insert rope into sheave no. 5 orifice and lock it with the key no. 7 as illustrated.

<section-header><section-header><section-header><section-header><text><text><text><text><image><image>



Subsection 03 ENGINE (443 AND 552) Subsection 07 (AXIAL FAN)

GENERAL

During assembly/installation, use torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Refer to SELF-LOCKING FASTENERS and LOCTITE APPL/LGATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

NOTE: The following procedures can be done without removing engine from chassis.

PROCEDURES

CYLINDER COWL

Cylinder Cowl Removal

Unscrew cylinder cowl screws no. 1 on the top of engine.

Remove screws with lock washers, flat washers and rubber washers. Pull cylinder cowl.

Cylinder Cowl Installation

The installation is the reverse of the removal procedure.

A gasket must be placed on both sides (inner and outer) of intake and exhaust cavities of cylinder cowl no. 3 and no. 4.

Torque cylinder cowl screws no. 1 to 14 N•m (124 lbf•in).

AXIAL FAN

Axial Fan Removal

Remove tuned pipe.

Use a flat screwdriver to lift fan protector tabs, then remove fan protector.



1. Lift tab and remove fan protector

Lock fan pulley with holder wrench and 3 screws.

ENGINE	TOOL
443	Holder wrench (P/N 420 876 357)
552	Holder wrench (P/N 529 036 006)





1. Holder wrench


Remove fan pulley retaining nut no. 13.

Axial Fan Inspection Check axial fan for cracks or damaged fins.


Axial Fan Installation At assembly, torque nut no. 13 to 48 N•m (35 lbf•ft).







	Section 03 ENGINE (4 Subsection 08 (MAG)	
MAGNETO SYST	EM	
SERVICE TOOLS		
Description crankshaft protector magneto puller puller ring		
SERVICE PRODUCTS		
Description	Part Number 293 800 060	Pag 98-5
	a transmission	



Section 03 ENGINE (443 AND 552) Subsection 08 (MAGNETO SYSTEM)

GENERAL

NOTE: The following procedures can be done without removing the engine. To facilitate mag-neto removal, hold drive pulley with the appropri-ate tool. Refer to *DRIVE PULLEY*. During assembly/installation, use the torque val-ues and service products as in the exploded views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.


PROCEDURES

MAGNETO FLYWHEEL

Flywheel Removal

To gain access to magneto flywheel no. 1 assembly, remove the following parts: - tuned pipe

- rewind starter
- starting pulley no. 2.



NOTE: To remove starting pulley bolts, hold mag-neto flywheel with a socket as shown. 1 12



TYPICAL

Install the puller ring (P/N 420 876 080) on magne-to flywheel (or counterweight if so equipped).



CAUTION: Use only the following screw length to bolt puller to magneto flywheel. Otherwise damage to stator behind magneto flywheel could occur.

	SCREW LENGTH	
ENGINE	WITHOUT COUNTERWEIGHT INSTALLED	WITH COUNTERWEIGHT INSTALLED
443/552	M8 x 20 mm	M8 x 30 mm

97

Section 03 ENGINE (443 AND 552) Subsection 08 (MAGNETO SYSTEM)



TYPICAL 1. Tab in magneto housing opening 2. M8 screws of appropriate length

Remove magneto flywheel nut, using a 30 mm socket machined to 40 mm (1.580 in) outside di-ameter by 16 mm (5/8 in) long.



TYPICAL 1. Machinad 30 mm socket

NOTE: To correctly remove a threadlocked fasten-er, first tap on the fastener to break threadlocker bond. This will avoid thread breakage. To remove magneto flywheel, install the crank-shaft protector (P/N 420 876 557) on crankshaft end. Screw the magneto puller (P/N 529 035 547) into puller ring.







Flywheel Cleaning

Clean all metal components in a non-ferrous metal cleaner

CAUTION: Clean magneto flywheel using only a clean cloth.

Flywheel Installation

Clean crankshaft extension (taper) and apply Loctite 243 (blue) (P/N 293 800 060) on taper, then position Woodruff key, magneto flywheel no. 1 and lock washer on crankshaft.

Install Woodruff key no. 7 in its keyway. Clean magneto flywheel nut threads and appy Loctite 243 (blue) (P/N 293 800 060) then tighten nut.

ENGINE	TORQUE
443/552	105 N•m (77 lbf•ft

cone dielectric grease (P/N 293 550 004) to pre-vent corrosion or moisture penetration.

Section 03 ENGINE (443 AND 552) Subsection 08 (MAGNETO SYSTEM)

CAUTION: Do not use silicone "sealant", this product will corrode contacts. Do not apply sil-icone dielectric grease on any Deutsch water-proof housing otherwise housing seal will be damaged.

STATOR

Stator Inspection

Always check stator no. 3 before changing it. Re-fer to CHARGING SYSTEM.

Stator Removal

Remove: - magneto flywheel no. 1

- all Allen socket screws no. 4 retaining stator to magneto housing
 grommet from crankcase where trigger coils no. 5 and stator wires exit magneto housing. Unplug the trigger coil connectors and pull the wires through the grommet location.

NOTE: To pass the stator connector into the grom-met location it is necessary to pass the trigger coil connector first.

Unplug the stator connector and remove the stator **no. 3**.

Stator Cleaning

Clean all metal components in a non-ferrous metal cleaner.

CAUTION: Clean stator using only a clean cloth.

Stator Installation

Insert the stator connector into crankcase grom-met then the trigger coil connector(s).

Install the grommet on crankcase.

Position stator no. 3 so that its wire protectors are over crankcase recess.



NOTE: During installation, make sure the stator harness is located on the left side. Apply Locitie 243 (blue) (P/N 293 800 060) on threads of stator screws then torque them to 7 N•m (62 lbf•in). Reinstall all other removed parts.

TRIGGER COIL

Trigger Coil Inspection For trigger coil inspection, refer to IGNITION SYSTEM for forward engine operation or ROTAX ELECTRONIC REVERSE (RER) for reverse engine operation.


Trigger Coil Removal


To replace trigger coll (lis) no. 5, remove or discon-nect the following: - magneto flywheel no. 1 - air intake silencer to allow an access to the trig-ger coil connectors (if necessary)


- grownet coll connector housing(s)
 grownet from crankcase where trigger coil wire(s) exit(s) magneto housing
- retaining screws no. 6 - trigger coil(s) and carefully pull wires.
- Trigger Coil Installation

For installation, reverse the removal procedure. NOTE: It is important to remove the old silicon at trigger coil location then apply new silicon. Screw trigger coil then stick the trigger coil wires in the silicon.

Locating sleeve 529 023 800 10 Paton circlip installer 529 023 561 11 Paton circlip installer 529 035 561 11 Puller 529 035 563 11 Sleeve kit 529 035 541 10 Sleeve kit 529 035 541 10 Sleeve kit 529 035 542 11 Description Part Number Pag Locaties 293 800 038 11	TOP END		
Description Part Number Page Locating sleave. 529 023 800 10 Piston circlip installer 529 023 686 11 Puller 529 023 503 10 Sleave kit 529 035 541 11 Sleave kit 529 035 542 10 Service PRODUCTS 529 035 542 10 Description Part Number Page 100 Locitie 518 293 800 038 11 Locitie Chisel 413 708 500 105-11	SERVICE TOOLS		
Locating sleeve. 529 023 800 10 Piston circlip installer 529 023 686 11 Piston circlip installer 529 035 686 11 Puller 529 035 503 10 Sleeve kit 529 035 542 10 Sleeve kit 529 035 542 10 Secription Part Number Pag Loctite 518 293 800 038 11 Loctite Chisel 413 708 500 105-11			
Piston circlip installer 529 035 561 11 Puller 529 035 503 10 Sleeve kit 529 035 503 10 Sleeve kit 529 035 541 11 Sleeve kit 529 035 542 11 Service PRODUCTS 529 035 542 10 Secription Part Number Pag Loctite 518 293 800 038 10 Loctite Chisel 413 708 500 105-11		Fant Number	Page
Piston circlip installer 529 035 668 11 Sleeve kit 529 035 503 10 Sleeve kit 529 035 541 11 SERVICE PRODUCTS 529 035 542 10 Description Part Number Part Number Loctite 518 293 800 038 1 Loctite Chisel 413 708 500 105-11	Piston circlip installer	520 025 561	111
Puller 529 035 503 11 Sleeve kit 529 035 542 10 SERVICE PRODUCTS 529 035 542 10 Description Part Number Page 293 800 038 11 Loctite 518 293 800 038 11 Loctite Chisel 413 708 500 105-11	Piston circlip installer	529 035 686	11
Sleeve kit 529 035 541 10 Sleeve kit 529 035 542 10 SERVICE PRODUCTS Description Part Number Page 203 Loctite 518 293 800 038 11 Loctite Chisel 413 708 500 105-11	Puller	529 035 503	10
Steeve kit 529 035 542 10 SERVICE PRODUCTS Part Number Page Locitie 518 293 800 038 11 Locitie Chisel 413 708 500 105–11	Sleeve kit	529 035 541	10
Description Part Number Part Loctite 518	Sleeve kit	529 035 542	10
Description Part Number Part Loctite 518	SERVICE PRODUCTS		
Loctite Chisel	Description		Pag
	Loctite 518.		
	Loctite Chisei	413 708 500	
mmr2007-181	mm/2007-161	Constant States of	







GENERAL

Before completely disassembling the engine, check airtightness. Refer to LEAK TEST. To measure internal parts, refer to ENGINE MEA-SUREMENT section.

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

Cleaning

-

Discard all gaskets and O-rings. Use Loctite Chisel (P/N 413 708 500) to clean mating surfaces.

Clean all metal components in a non-ferrous metal cleaner.

PROCEDURES

NOTE: To reach any internal parts, the engine removal is necessary

CYLINDER COWL

Cowl Removal Unscrew cylinder cowl screws no. 14 on the top

of engine.

Remove screws with lock washers, cowl washers and rubber washers. Pull cylinder cowl.

Cowl Installation

The installation is the reverse of the removal pro-cedure.

Torque cylinder cowl screws no. 14 to 14 N•m (124 lbf•in).

CYLINDER HEAD

Cylinder Head Removal Remove cylinder cowl. See above

Remove cylinder head nuts no. 1, distance nuts no. 2 and flat washers.

Lift cylinder heads no. 3 over cylinder studs to

Cylinder Head Inspection

Check cylinder heads for cracks, broken fins, warp or other damages.

Refer to tables below to find cylinder head specifications. For dimension measurement procedures, refer to ENGINE MEASUREMENT. Cylinder Head Warpage

ENGINE	MAXIMUM
440F/550F	0.05 mm (.002 in) per 50 mm (2 in) of surface
440F/550F	0.5 mm (.020 in) for total length of cylinder head

Cylinder Head Combustion Chamber Volume

ENGINE	VOLUME (CC)
440F	25.4 ± 1
550F	35.5

Cylinder Head Cleaning

Scrape off carbon formation from cylinder head. Cylinder Head Installation

Position cylinder head nuts no. 1 and distance nuts no. 2 as shown below.



1. Exhaust 2. Distance nuts

Torque cylinder head nuts no. 1 and no. 2 to 22 N•m (16 lbf•ft) in a criss-cross sequence; torque each cylinder head individually.

CYLINDER

Cylinder Removal

440F Engine Remove intake manifold no. 6.

550F Engine

Remove intake adapters no. 6. Remove reed valves no. 11.


440F and 550F Engines

Remove exhaust manifold. Remove cylinder cowl and cylinder heads. Lift cylinders no. 4.

Discard the cylinder gasket. Cylinder Inspection

Check cylinders for cracks and scoring on the top and bottom of cylinders. Check exhaust flanges for flatness.

Check cylinder O-ring.



Refer to tables below to find cylinder specifications. For dimension measurement procedures, refer to ENGINE MEASUREMENT.

Cylinder Taper

ENGINE	MAXIMUM
440F/550F	0.10 mm (.004 in

ENGINE	MAXIMUM	
440F/550F	0.08 mm (.003 in	

Cylinder Cleaning

Scrape off carbon formation from exhaust ports. Clean mating surfaces using Loctite Chise (P/N 413 708 500).

Cylinder Installation


Install a new cylinder base gasket of the same thickness as previously used. Apply a thin law of Loctite 518 (P/N 293 800 038) on each side d gasket.

gasket. NOTE: If the old gasket thickness is unknown or if a cylinder head or cylinder is replaced, measure the combustion chamber volume to determine the right gasket to use. Refer to ENGINE MEASURE-MENT for the measurement procedures. Refer to CYLINDER HEAD above for the combustor chamber volume specifications.

CAUTION: Always install a gasket of the proper thickness. Failure to do so may cause detonation and severe engine damage.

Apply Loctite 518 on gasket.

Section 03 ENGINE (443 AND 552) Subsection 09 (TOP END) Before inserting piston in the cylinder, lubricate the cylinder with new injection oil or equivalent. Using fingers or a piston ring compressor, slide piston no. 8 linto cylinder no. 4. Install exhaust manifold to align cylinders. Place a clean rag over crankcase to prevent circlips no. 10 from failing into crankcase. Then with a pointed tool inserted in piston notch, remove both circlips from piston no. 8. NOTE: On this engine, piston pin is mounted with cageless bearing. Use piston pin puller along with sleeve kit and lo-cating sleeve as per following table. Lise exh 440F ENGINE TOOL 440F Engine Puller (P/N 529 035 503) Torque intake manifold screws as indicated. Sleeve kit (P/N 529 035 541) (18 mm) NOTE: Check intake manifold for flatness. Locating sleeve (P/N 529 023 800) ENGINE TOROUE 440F 22 N•m (16 lbf•ft) 550F ENGINE TOOL Puller (P/N 529 035 503) 550F Engine Sleeve kit (P/N 529 035 542) (20 mm) Install reed valves Locating sleeve (P/N 529 023 800) Torque intake adapter screws as indicated. When inserting piston pin puller, make sure i sits squarely against piston. NOTE: Check intake adapters for cracks or delamination ENGINE TORQUE 550F 5 N•m (44 lbf•in) 440F and 550F Engines Torque exhaust manifold bolts to 22 N•m (16 lbf•ft). Install cylinder heads and cylinder cowl. PISTON Piston Removal Remove cylinders. NOTE: The PTO cylinder or fan housing have to be removed to give access to MAG piston with puller. mmr2007-161



Push needle bearings along with thrust washers and sleeve.



TYPICAL 1. Locating sleeve 2. Sleeve

 Use a locking tie to fasten all needles and thrust washers along with locating sleeve.

Piston Inspection

Inspect piston for scoring, cracking or other damages. Replace piston and piston rings if necessary. Refer to *ENGINE MEASUREMENT* to complete inspection.

Piston Cleaning

Scrape off carbon formation from piston dome. NOTE: The arrow on the piston dome must be visible after cleaning.



Clean the piston ring groove with a groove cleaner tool or with a piece of broken ring.

mmr2007-161

Piston Installation When reinstalling original needle bearings, make sure the proper quantity of needles is inserted between sleeve and locating sleeve.

 ENGINE
 NEEDLES IN ROLLER BEARING

 440F
 31

 440F
 31

 550F
 34

 When installing a new cageless bearing, replace half plastic cages by sleeve.



TYPICAL 1. Sleeve

Grease thrust washers and install them on each end of needles.



TYPICAL — CAGELESS BEARING AND SLEEVE INSTALLED

Place pistons over the connecting rods with the arrow on the piston dome facing towards the exhaust port.







1. Groove



CIRCLIP READY TO BE INSTALLED ON PISTON

Using a plastic hammer, tap pusher to insert circlip in place. Take care to install new circlips with tab toward top as per following photo.



TAB TOWARD TOP

CAUTION: Always install new mono-hook cir-clips. If circlip installation fails at the first at-tempt, always retry with a new one as on a sec-ond attempt circlip will lose its normal retain-ing capabilities.

EAUTION: Circlips must not move freely after installation; if so, replace them. Before inserting piston in the cylinder, lubricate the cylinder with new injection oil or equivalent.


REED VALVE 550F Engine

Reed Valve Removal


Remove intake adapters no. 6 by removing carbu-retors and screws retaining intake adapters. Remove reed valves no. 11 from engine.


Reed Valve Inspection

With blade stopper no. 13 removed, check reed valve for proper tightness. There must be no play between blade no. 12 and valve body when ex-erting a finger pressure on blade at blade stopper location.



529 035 980 529 035 990 529 036 004 420 876 552 420 876 557 420 876 52 529 035 965 420 876 622	
529 035 969 529 035 980 529 035 980 529 036 094 420 876 552 420 876 557 420 876 557 420 876 557 420 876 557 420 876 557 420 876 620	120 122 120 120 120 120 120 120 120 120
529 035 969 529 035 980 529 035 980 529 036 094 420 876 552 420 876 557 420 876 557 420 876 557 420 876 557 420 876 557 420 876 620	120 122 120 120 120 120 120 120 120 120
529 035 980 529 035 990 529 036 004 420 876 552 420 876 557 420 876 52 529 035 965 420 876 622	12 12 11 11 11 11 11 11 12
529 035 990 529 036 004 420 876 552 420 876 557 420 876 822 529 035 965 420 876 620	12 11 11 11 11 11 11 12
529 036 004 420 876 552 420 876 557 420 876 822 529 035 965 420 876 620	11
420 876 552 420 876 557 420 876 822 529 035 965 420 876 620	
420 876 557 420 876 822 529 035 965 420 876 620	
420 876 822 529 035 965 420 876 620	
529 035 965 420 876 620	
	14
	12
420 977 490	
Part Number CJ951	Pa
Part Number	Pa
293 800 070	
413 /08 500	
420 899 271	
413/11809	
Charles of the second	
	420 840 681 529 035 976 CJ951 1124 Part Number 233 550 021 293 800 081 293 800 081 293 800 070 413 708 500 420 899 271





GENERAL

Before completely disassembling the engine, check airtightness. Refer to LEAK TEST.

To verify internal parts, refer to ENGINE MEA-SUREMENT section.

All oil seals and gaskets must be discarded and replaced with new ones when crankcase is split.

CAUTION: After rebuilding an engine always observe a break-in period as described in OP-ERATOR'S GUIDE.

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES

CRANKCASE

Crankcase Disassembly

Remove:

- engine from chassis (refer to ENGINE RE-MOVAL AND INSTALLATION)
- cylinder cowl, cylinder heads and cylinders (re-fer to TOP END)
- rewind starter (refer to REWIND STARTER) fan belt pulley, trigger coils, magneto flywheel and stator (refer to MAGNETO SYSTEM).

Remove all screws that retain both housings to-

gether Split crankcase and remove internal components.

Crankcase Inspection

Check crankcase for cracks. Replace if needed.

Crankcase Cleaning

Clean all metal components and remove old sealant from crankcase mating surfaces with Loctite Chisel (P/N 413 708 500).

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

Crankcase Assembly

Crankcase halves no. 1 and no. 5 are factory matched and therefore, are not interchangeable as single halves.

Install all internal components.


Close and torque crankcase by performing the following:

IMPORTANT: The total assembly sequence, including sealing compound application, crankcase screw installation and torquing, must be pe-formed within 10 minutes. The torquing se quence must be accomplished without intemption

Before screwing both parts of crankcase, seal t with Loctite 5910 (P/N 293 800 081).

NOTE: It is recommended to apply this specific sealant as described here to get an uniform appli-cation without lumps. If you do not use the roller method, you may use your finger to uniformly ds-tribute the sealant.

Use a plexiglass plate and apply some sealant on it. Use a 50 - 75 mm (2 - 3 in) soft rubber roller and spread the sealant to get a thin uniform cat on the plate (spread as necessary). When read, apply the sealant on crankcase mating surfaces.






TYPICA

Tighten all crankcase screws in place in 2 consec-utive steps as indicated. 443 Engine


TIGHTENING STEP	M6 SCREW	M8 SCREW
Step 1: Initial torque	4 N∙m (35 lbf•in)	13 N•m (115 lbf•in)
Step 2: Final torque	7 N•m (62 lbf•in)	22 N•m (16 lbf•ft)



552 Engine

mmr2007-162

TIGHTENING STEP	M8 SCREW
Step 1: Initial torque	13 N•m (115 lbf•in)
Step 2: Final torque	22 N•m (16 lbf•ft)



CRANKSHAFT

Crankshaft Removal Split crankcase and remove crankshaft.


Crankshaft Inspection

Refer to table below to find bottom end engine di-mension specifications. For dimension measure-ment procedures, refer to ENGINE MEASURE-MENT.

FLIGHT	TOLERANCES		
ENGINE		PARTS (MAX.)	WEAR
Crankshaft deflection on PTO side	N.A.	0.06 mm (.0024 in)	N.A.
Crankshaft deflection on MAG side	N.A.	0.03 mm (.001 in)	N.A.
Crankshaft deflection in center of crankshaft	N.A.	0.08 mm (.0031 in)	N.A.
Connecting rod big end axial play	0.2 mm (.008 in)	0.527 mm (.0207 in)	1.20 mm (.047 in)
Crankshaft end-play	0.10 mm (.004 in)	0.30 mm (.012 in)	N.A.

Crankshaft Installation

Using pulley flange cleaner (P/N 413 711 809), re-move all trace of Loctite 243 from crankshaft ta-per. When installing crankshaft, position drive pins no. 6 in crankcase recesses as illustrated.




TYPICAL 1. Drive pins

At seal no. 2 assembly, apply a light coat of Peta-mo grease (P/N 420 899 271) on seal lip. Put 15 to 20 mL of Isoflex grease (P/N 293 550 021) in a syringe.

NOTE: The 50 g tube corresponds to 50 mL of

grease. With the syringe, fill in the PTO side ball bearings as shown below.



TYPICAL - BALLS COATED WITH A SEAM OF GREASE


CAUTION: Use only the recommended grease. Make sure not to push grease between outside bearing race and half crankcase. Close crankcase and install all removed parts.

CRANKSHAFT BEARINGS

Bearing Removal


NOTE: Normally it takes approximately 10 min-utes to heat up a bearing so in the event of replac-ing bearing, it's recommended to start the bearing heating process prior to removal operation. See procedure further.

To remove PTO side bearings no. 3 from crank-shaft, install half rings (P/N 420 977 475) and puller ring (P/N 420 977 490) on the bearing.



1. Half ring 2. Puller ring

Apply ThermoLube grease (P/N 219 700 417) on the crankshaft end and install crankshaft protector (P/N 420 876 552).



1. Crankshaft protecto

Install bearing puller (P/N 529 036 004) and secure to half rings using screws (P/N 420 840 681).




PULLER INSTALLED ON THE HALF RINGS Secure the bearing puller in a vise by one of its rib.

BEARING PULLER SECURED IN THE VISE

mmr2007-162

CAUTION: Never use any air impact tool for tightening the puller bolt. Lubricate the puller bolt and then proceed with tightening the puller bolt until the bearing comes out.

Follow the same procedure for the inner bearing. NOTE: In the case of damaged bearing or less clearance between crankshaft counterbalance and the bearing or on the MAG side bearing, use a bearing separator Snap-on (P/N CJ951) or a bear-ing separator SPX/OTC (P/N 1124) to facilitate the removal.



1. Bearing separator

Procedure for MAG side bearings no. 4 is same as of PTO side with the exception of the crankshaft protector (P/N 420 876 557).


Bearing Installation

Crankshaft Preparation

Clean crankshaft end with sand paper no. 180 and remove all residue using pulley flange cleaner (P/N 413 711 809).



Smear Loctite 767 (antiseize lubricant) (P/N 293 800 070) on part of crankshaft where bearing fits.



Bearing Preparation

Dearing Preparation Heat up the bearing(s) using bearing heater (PN 529 035 969). This will expand bearings and ease installation. If required, put a suitable plate or shim to avoid the direct contact between integrated seal (if applicable) with the heating surface.




CAUTION: Bearing should not be heated to more than 80°C (176°F). Do not heat bearing with direct flame or heat gun or heated oil. Inappropriate heating procedure(s) may cause inner seal failure.

For even heat distribution, turn bearing several times during heating process.

NOTE: Two bearings can be heated at the same time on one bearing heater.



Touch the inner race of the bearing with the tem-perature indicator stick (P/N 529 035 970). Stick will liquefy when the bearing reach the proper temperature.



Do not touch heated bearing with bare hands. Wear heat resisting gloves before handling the heated bearing(s).

Bearing Installation

Ensure to position bearing grooves as per exploded view.

Slide in the inner PTO bearing on crankshaft. Push bearing to end position.

NOTE: The heated bearing should slide easily on the crankshaft. If required, push with a bearing installer (P/N 529 035 990).






BEARING TO END POSITION Install the O-ring.

443 Engine


mmr2007-162

443 Engine To set proper clearance between inner bearing and crankshaft counterweight, use feeler gauge (P/N 420 876 620). Position outer bearing using the distance gauge (P/N 420 876 822).




552 Engine

Position outer bearing using support plate (P/N 529 035 976) and distance gauge (P/N 529 035 965).



1. Support plate 2. Distance gauge Install bearing locator tool.



Section 03 ENGINE (443 AND 552) Subsection 11 (ENGINE MEASUREMENT) **ENGINE MEASUREMENT** SERVICE TOOLS Description degree wheel dial indicator... Part Number 529 035 607 414 104 700 NOTE: This subsection explains the procedures to correctly measure engine components. For the engine technical specifications, refer to *INSPEC-TION* in the appropriate *ENGINE* subsection. CYLINDER HEAD WARPAGE Check gasketed surface of the cylinder head with a straight edge and a feeler gauge. Make sure part is within the given specification. Otherwise, replace it. Verify combustion chamber volume to use the correct cylinder base gasket with the new part. COMBUSTION CHAMBER VOLUME MEASUREMENT The combustion chamber volume is the region in the cylinder head above the piston at Top Dead Center (TDC). It is measured with the cylinder head installed on the engine. TYPICAL 1. Bring piston to TDC Obtain a graduated burette (capacity 0 - 50 cc) and fill with an equal part (50/50) of gasoline and injection oil. -1 0 1.1 F01DSW TYPICAL stion chambe NOTE: When checking the combustion chamber volume, engine must be cold, piston must be free of carbon deposits and cylinder head must be leveled. Remove both spark plugs and bring one piston to Top Dead Center a using the dial indicator (P/N 414 104 700).

mmr2007-163

1. Graduated burette (0 - 50 cc)

 Open burette valve to fill its tip. Add liquid in burette until level reaches 0 cc.

Section 03 ENGINE (443 AND 552) Subsection 11 (ENGINE MEASUREMENT)

Inject the burette content through the spark plug hole until liquid touches the top spark plug hole.



TYPICAL 1. Top of spark plug hole

NOTE: The liquid level in cylinder must not drop for a few seconds after filling. If so, there is a leak between piston and cylinder. The recorded volume would be false.

- Let burette stand upward for about 10 minutes, until liquid level is stabilized.
- Read the burette scale to obtain the quantity of liquid injected in the combustion chamber.


NOTE: When the combustion chamber is filled to top of spark plug hole, it includes an amount of 2.25 cc corresponding to the spark plug well. – Repeat the procedure for the other cylinder.

- Install a thicker or thinner cylinder/crankcase gasket (refer to PARTS CATALOG) in order to obtain the specified combustion chamber volume

CYLINDER TAPER

Compare cylinder diameter 33 mm (1.3 in) from top of cylinder to just below its intake port area. If the difference exceeds the specified dimension the cylinder should be rebored and honed or should be replaced.

NOTE: If cylinder is rebored, be sure to restore the chamfer around all cylinder sleeve port openings.




TYPICAL 1. Below the intake port A. 33 mm (1.3 in) from top


CYLINDER OUT OF ROUND

Measuring 33 mm (1.3 in) from top of cylinder with a cylinder gauge, check if the cylinder out of round is more than the specified dimension. If large, cylinder should be rebored and honed or should be replaced.

NOTE: If cylinder is rebored, be sure to restore the chamfer around all cylinder sleeve port openings.



TYPICAL 1. Piston pin position 2. Measures to be compared A. 33 mm (1.3 in)



Section 03 ENGINE (443 AND 552) Subsection 11 (ENGINE MEASUREMENT)

Procedure Continuation with a New or Used Piston

With the micrometer set to the piston dimension, adjust a cylinder bore gauge to the micrometer dimension and set the indicator to 0.




1. Use the micrometer to set the cylinder bore gauge 2. Dial bore gauge



I. Indicator set to 0 (zero

NOTE: Make sure the cylinder bore gauge indicator is set exactly at the same position as with the micrometer, otherwise the reading will be false. Position the dial bore gauge at 33 mm (1.3 in) be-

Micrometer, otherwise the reading will be raise. Position the dial bore gauge at 33 mm (1.3 in) below cylinder top edge. IMPORTANT: Always remove cylinder-block from crankcase before measuring.



TYPICAL 1. Measuring perpendicularly (90°) to piston pin axis A. 33 mm (1.3 in)

Read the measurement on the cylinder bore gauge. The result is the exact piston/cylinder wall clearance. If clearance exceeds specified tolerance, replace cylinder and piston. NOTE: Oversize pistons are available for the 43 and 552 engines.

RING/PISTON GROOVE CLEARANCE

Using a feeler gauge check clearance between rectangular ring and groove. Replace piston if clearance exceeds specified tolerance.




Section 03 ENGINE (443 AND 552) Subsection 11 (ENGINE MEASUREMENT)

RING END GAP

Position ring halfway between transfer ports and intake port.

NOTE: In order to correctly position the ring in the cylinder, use piston as a pusher. Using a feeler gauge, check ring end gap. Replace ring if gap exceeds specified tolerance.



CRANKSHAFT DEFLECTION

Crankshaft deflection is measured with the dial indicator (P/N 414 104 700).


Measuring in Crankcase

First, check deflection with crankshaft in crankcase. If deflection exceeds the specified tol-erance, recheck deflection using V-shaped blocks to determine the defective part(s). See below.

Measuring on Bench

2007-163

Measuring on bench Once engine is disassembled, check crankshaft deflection on V-shaped blocks. If deflection exceeds the specified tolerance, it can be worn bearings or a bent crankshaft. Remove crankshaft bearings and check deflection again on V-shaped blocks to determine the defective part(s). See measurement "A" in following illustration.




TYPICAL
1. Measure at mid point between the key and the first thread
A. 3 mm (1/8 in)

NOTE: Crankshaft deflection cannot be correctly measured between centers of a lathe.

If the deflection exceeds the specified tolerance, crankshaft should be repaired or replaced.

CONNECTING ROD BIG END AXIAL PLAY

Using a feeler gauge, measure distance between thrust washer and crankshaft counterweight. If the distance exceeds specified tolerance, repair or replace the crankshaft.




CRANKSHAFT ALIGNMENT


Remove both spark plugs. Install the dial indicator (P/N 414 104 700) in spark plug hole on MAG side.

121


Subsection 03 ENGINE (443 AND 552) Subsection 11 (ENGINE MEASUREMENT)



Install the degree wheel (P/N 529 035 607) on crankshaft end.



Scribe a mark on crankcase. Install degree wheel so that 360° mark aligns with the mark on crankcase. Do not rotate crankshaft.



Remove dial indicator and install it in spark plug hole on PTO side.

Bring PTO piston to top dead center. Degree wheel must rotate with crankshaft. Interval between cylinders must be $180^{\circ} \pm 0.5$. Any other reading indicates a misaligned (twisted) crankshaft.

CHECKING SURFACE FLATNESS 443 Engine

445 Engine Intake manifold, intake manifold cover can be checked for perfectly mating surfaces. Lay part on a surface plate (marble, mirror or thick glass plate).


Holding down one end of part, try pushing down the other end.

If any play is felt, part must be rectified.


Rectifying Surfaces


Stick a fine sand paper sheet on the surface plate then lightly oil the sand paper. Rub part mating surface on sand paper using 8-figure movements.


8-tigure movements. Sand until mating surface is perfectly straight.











Section 04 ENGINE (593) Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

GENERAL

During assembly/installation, use the torque val-ues and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITTE APPL/CATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES

Engine Removal

Place vehicle at a workstation that has access to an engine-lifting hoist.

Open hood.

600 HO SDI Models

Use B.U.D.S. software and release fuel pressure. Refer to ENGINE MANAGEMENT.

600 and 600 HO SDI Models

Disconnect BLACK (-) cable from battery, then the RED (+) cable.

Always disconnect battery or starter cables exactly in the specified order, BLACK (-) cable first. It is recommended to disconnect elec-trical connections prior to disconnecting fuel lines.

Right Side of Vehicle

Remove tuned pipe and muffler. Refer to EX-HAUST SYSTEM.

Disconnect starter cables.

Drain coolant. Refer to COOLING SYSTEM. Remove rewind starter handle. Refer to REWIND STARTER.

Unplug electrical connectors from engine. Disconnect the large coolant hoses from engine.





Unplug carburetor or throttle body heating hose from coolant tank.



Install a small hose pincher (P/N 295 000 0761 or oil injection reservoir outlet line. Disconnect oil lines from injection reservoir.







Section 04 ENGINE (593) Subsection 02 (ENGINE LEAK TEST)

ENGINE LEAK TEST

SERVICE TOOLS

	Part Number	Page
intake plug	529 011 000	
manifold plug	529 035 961	
small hose pincher	295 000 076	
vacuum/pressure pump	529 021 800	

GENERAL

Prior to take apart an engine, it is important to proceed with a leak test to diagnose engine prob-lems. Whenever the engine is disassembly, a leak test should be performed after reassembly. NOTE: A flow chart has been prepared as a visual reference. See last page of this chapter.

PROCEDURES

Remove tuned pipe.

Install manifold plug (P/N 529 035 961) over exhaust manifold,



Remove carburetors/throttle body assembly (as applicable).

600 HO SDI Engine Unplug fuel inlet line from fuel rail.



600 and 600 HO SDI Engines Insert an intake plug (P/N 529 011 000) in each intake adaptors. Tighten with existing clamps.



t. Intake plug

Using a small hose pincher (P/N 295 000 076), block impulse hose.

Section 04 ENGINE (593) Subsection 02 (ENGINE LEAK TEST)



1. Small hose pil 2. Impulse hose

Install vacuum/pressure pump (P/N 529 021 800) on manifold plug.



Activate pump and pressurize engine

TEST PRESSURE: 34 kPa (5 PSI) for 3 minutes

Do not exceed this pressure.

Do not exceed this pressure. Engine must stand this pressure during 3 minutes. If pressure drops before 3 minutes, spray a soapy solution on tester kit (manifold and intake plugs, vacuum/pressure pump and its hose). - If tester kit (manifold and intake plugs, hoses and pump) is leaking, bubbles will indicate where leak comes from.

- If tester kit is not leaking, check engine, see below for procedure.


Engine Verifications

Check the following:

- NOTE: If a leak is detected, it is recommender to continue testing next items before overhauin engine. There is a possibility of more than one leak
- All jointed surfaces and screw/stud threads d engine: • spark plug base, insulator

 - cylinder head
 RAVE valve bellows, piston and housing
- cylinder
 crankcase halves (joint)
 oil injection pump mounting flange (O-ring)

- oii injection pump mounting riange (o-ing)
 coolant pump housing
 bleed screws/plugs
 crankcase fitting PTO side.
 Small injection oil lines coming from pump. *In* bubbles or oil column going toward pump, indicates a defective check valve in injection nppa.



TYPICAL 1. Injection nipples 2. Small injection oil lines


- Air bubbles in antifreeze. It indicates defecte cylinder head O-ring or cylinder base gasket. Crankshaft outer seals. One behind drive pule and the other behind magneto. Leak indicator hole below coolant pump hos-ing. If there is a leak, it indicates that a seal pump shaft is defective (oil seal behind codirt ceramic seal).

Section 04 ENGINE (593) Subsection 02 (ENGINE LEAK TEST)



1. Leak indicator hole

Leaks can be also on oil pump side. Check mounting area for leaks.



TYPICAL 1. Check mounting area

Pump shaft gear oil reservoir. See PUMP SHAFT OIL GEAR RESERVOIR below.
 If leak still persists and can not be located, dis-assemble engine and carefully check for defects in castings. Pay attention to tapped holes which may go through engine sealed area and thus lead to leakage.


Pump Shaft Oil Gear Reservoir

Install air pump on reservoir fitting and pressurize engine

TEST PRESSURE: 34 kPa (5 PSI) for 3 minutes Do not exceed this pressure.



If pressure drops, it indicates a defective crank-shaft inner seal or a defective oil seal either on water pump side or oil pump side.





1. Inner seal on PTO side 2. Inner seal on MAG side




1. Water pump seal 2. Oil pump (seal or O-ring)

mmr2007-165







PROCEDURES

AIR FILTER

1. Air filter

mmr2007-166

Filter Removal There are 2 filters. One on hood and another one on air intake silencer. Pull filter out of its receptacle for cleaning. 600 Models





600 HO SDI Models


Section 04 ENGINE (593) Subsection 03 (AIR INTAKE SYSTEM)


Blow low pressure compressed air on filter to clean it. Replace air filter as required. NOTE: If the filter is very dirty, clean the interior of the air intake silencer at the same time.


Filter Installation

The installation is the reverse of the removal pro-cedure.

-







Section 04 ENGINE (593) Subsection 04 (EXHAUST SYSTEM)

GENERAL

To avoid potential burns, never touch exhaust system components immediately after the engine has been run because these compo-nents are very hot. Let engine and exhaust system cool down before performing any servicing.

During assembly/installation, use the torque value and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed. newed.

NOTE: On applicable models, it is good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to EMS DI-AGNOSTIC AND COMMUNICATION TOOLS.

PROCEDURES

TUNED PIPE

Tuned Pipe Identification

Each tuned pipe is identified by a number. To use the proper tuned pipe with the proper vehicle, check the number on the welded clamp at the end of tuned pipe. This number depicts the 6 last dig-its of the BRP part number.



Tuned Pipe Removal Open hood.

Remove all exhaust springs no. 1 using spring remover and installer tool (P/N 529 035 983)



exhaust gasket no. 7 and no. 8 (600 HO SDI). **Tuned Pipe Inspection**

Check: - tuned pipe shields for damages (600 HO SDI). - tuned pipe ends for cracks or damages.

147

Section 04 ENGINE (593) Subsection 04 (EXHAUST SYSTEM)

Tuned Pipe Installation

600 HO SDI Models Install doughnut shaped exhaust gasket no. 7 with both of its notches aligned with Y-manifold protrusions.

NOTE: If the gaskets are damaged, replace them.



600 and 600 HO SDI Models Install all exhaust springs using spring remover and installer tool (P/N 529 035 983).

MANIFOLD

Manifold Removal

- Remove: tuned pipe no. 2
- doughnut shaped exhaust gasket no. 7 (600 HO SDI)

- manifold screws no. 3


CAUTION: Heat screws for 30 seconds before loosening to prevent screw breakage. - manifold no. 4 - gaskets no. 5.

Manifold Inspection

Check if the manifold is cracked or damaged. Replace if necessary.

Manifold Installation

Install the manifold with new gaskets. Tighten manifold screws no. 3 using the following sequence and torque.



MODEL	TORQUE
600	22 N•m (16 lbf•ft)
600 HO SDI	11 N•m (97 lbf•in

MUFFLER 600 HO SDI Models

NOTE: For 600 models, muffler is part of tuned pipe.

Muffler Identification

Each muffler is identified by a number. To use the proper muffler with the proper vehicle, check the number on the welded clamp at the end of muffler. This number depicts the 6 last numbers of BRP part number.



TYPICAL

Muffler Removal

Remove tuned pipe no. 2. Disconnect the Exhaust Gas Temperature Sensor (EGTS).

Section 04 ENGINE (593) Subsection 04 (EXHAUST SYSTEM)


Remove exhaust springs no. 1 using spring remover and installer tool (P/N 529 035 983). Remove nuts no. 9 retaining the muffler no. 6. Remove the muffler.


Muffler Inspection Check the muffler for cracks or other damages. Check springs condition.


Muffler Installation

For installation, reverse the removal procedure. EXHAUST GAS TEMPERATURE SENSOR (EGTS)

600 HO SDI Models Refer to ENGINE MANAGEMENT section to verify or replace the EGTS.







GENERAL

NOTE: On applicable models, it is good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to EMS DI-AGNOSTIC AND COMMUNICATION TOOLS.

During assembly/installation, use torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

A WARNING

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed newed.

INSPECTION

COOLING SYSTEM LEAK TEST

NOTE: This test confirms if there is no leak in the cooling system, including the engine.

A WARNING

To prevent potential burns, do not remove the radiator cap if the engine is hot.

Install the radiator test cap (P/N 529 035 991) on coolant tank. Using the vacuum/pressure pump (P/N 529 021 800) pressurize all system through coolant reservoir to 100 kPa (15 PSI).

NOTE: It is not necessary to pinch overflow hose. Check all hoses and cylinder/base for coolant leaks. Spray a soap/water solution and look for air bubbles.

Check general condition of hoses and clamp tight-

ness

MAINTENANCE

COOLANT REPLACEMENT

Recommended Coolant

Use BRP premixed coolant (P/N 219 700 362) or a blend of 50% antifreeze with 50% distilled water.

To prevent antifreeze deterioration, always us same brand. Never mix different brands unless cooling system is completely flushed and refiles

CAUTION: To prevent rust formation or free. CAUTION: To prevent rust formation or free, ing condition, always replenish the system with the BRP premixed coolant or with 50% antifreeze and 50% water. Do not use tap we ter, straight antifreeze or straight water in the system. Tap water contains minerals and is, purities which build up in the system. During cold weather, straight water causes the system to freeze while straight antifreeze thickens like slush ice) and does not have the same effi-ciency. Always use ethylene glycol antifrees containing corrosion inhibitors specifically recommended for aluminum engines.


Draining the System

Never drain or refill the cooling system will engine is hot.

To drain the cooling system, siphon the coolant mixture from the coolant tank using the suction pump (P/N 529 035 880).



Unplug from the bottom of coolant reservoir the hose going to the engine.



TYPICAL 1. Coolant hose going to the engine


Siphon as much coolant as you can from the hose. When the coolant level is low enough, lift the rear of vehicle to drain the radiator.

Refilling Procedure

Lift front of vehicle until the tunnel is horizontal. With engine cold, refill coolant tank up to COLD LEVEL line.



SKANDIC WT/SUV 600 1 COLD LEVEL line



EXPEDITION TUV 600 HO SDI

Wait a few minutes then refill to line. Start engine. Refill up to line while engine is idling until all air bubbles have escaped from system (about 4 to 5 minutes).

Install pressure cap. To make sure coolant flows through radiators, touch them by hand. They must feel warm.

Put back front of vehicle on the ground. When engine has completely cooled down, recheck coolant level in coolant tank and refill up to line.

Check for coolant mixture freezing point. Specifi-cation is - 37°C (-35°F). Adjust as necessary.

PROCEDURES THERMOSTAT

Thermostat Removal

For removal of thermostat, drain the cooling system (see above). Remove air intake silencer (refer to AIR INTAKE SYSTEM).

Disconnect carburetor or throttle body from en-



Unplug coolant hose located between cylinder head and radiator.




1. Coolant hose between cylinder head and radiator

Remove:

housing screws
water outlet housing

- gasket.



1. Water outlet housi 2. Socket screws 3. Gasket

Remove thermostat.

Test

Put thermostat in heated water. Thermostar should work as follows.

ENGINE TYPE	TEMPERATURE		
593	Start to open: 42°C (108°F)		
	Almost fully opened: 50°C (122%)		

Thermostat Installation

For installation, reverse the removal procedure.

RADIATOR CAP

Using a pressure cap tester, check the efficient of radiator cap. If the efficiency is feeble, insul a new 90 kPa (13 PSI) cap (do not exceed the pressure).

FRONT RADIATOR

Cleaning and Inspection

Remove all debris between radiator fins. A clean radiator is more efficient than a dirty one. Check if the radiator fins are damaged. Replace the front radiator if necessary. NOTE: A radiator with many broken fins does not work properly.

Front Radiator Removal

Drain cooling system. As applicable, remove air intake silencer, battery, electronic module, engine and fuel tank. Refer to appropriate system.

Remove track (refer to TRACK).

Using a SupertaniumTM bit (P/N 529 031 800), drill all rivets retaining front radiator to the frame or grind the rivets with a grinding disk.

Pull the radiator a little and remove the Oetiker clamps securing coolant hoses to radiator.

Front Radiator Installation

For installation, reverse the removal procedure. Properly refill cooling system.

REAR RADIATOR

Cleaning and Inspection Refer to FRONT RADIATOR above.

Rear Radiator Removal

Drain cooling system.

Remove rear suspension. Refer to REAR SUS-PENSION.

If applicable, remove rear part of seat and tunnel cover.

Using a grinding disk, grind all rivets retaining rear radiator to frame.

Unplug coolant hoses from rear radiator then re-move radiator from vehicle.

Rear Radiator Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Properly refill cooling system.

Insert radiator protector into radiator C-rail and crimp C-rail at rear end.

COOLANT TANK

Coolant Tank Removal

Drain cooling system before removing coolant tank.

Remove all hoses from coolant tank.

Remove injection oil reservoir retaining screws to slide down the coolant tank to disengage it from oil tank.

NOTE: It is necessary to move oil tank for an eas-ier removal/installation of coolant tank.

Coolant Tank Inspection Check if the tank is cracked or melted. Replace if necessary.

Coolant Tank Installation

For installation, reverse the removal procedure.

WATER PUMP Refer to BOTTOM END section.

COOLANT TEMPERATURE SENSOR (CTS)

600 Models (carbureted)

NOTE: For 600 HO SDI models, refer to ENGINE MANAGEMENT.

Static Test

General

General The value of a resistor varies with the tempera-ture. The value for common resistor or windings (such as solenoid) increases as the temperature increases. However, our temperature sensors are NTC types (Negative Temperature Coefficient) and work the opposite which means that the value de-creases as the temperature increases. Use this table for sensor resistive values at given tempera-ture. ture.



TEMPERATURE SENSOR TABLE		
	ERATURE	RESISTANCE
°C	°F	Ω
- 40	- 40	72412
- 35	- 31	52637
- 30	- 22	38681
- 25	- 13	28718
- 20	- 4	21529
- 15	5	16288
- 10	14	12431
- 5	23	9565
0	32	7418
5	41	5807
10	50	4582
15	59	3644
20	68	2919
25	77	2355
30	86	1912
35	95	1562
40	104	1284
45	113	1062
50	122	882.6
55	131	738.9
60	140	622
65	149	526.3
70	158	447.5
75	167	382.3
80	176	328.1
85	185	282.8
90	194	244.8
95	203	212.8
100	212	185.6
105	221	162.4
110	230	142.7
115	239	125.9
120	248	111.5
125	257	99.02
130	266	88.26
135	275	78.93
135	275	70.81
140	284	63.71
145	302	57.49

The resistive value of a temperature sensor nervector test good at a certain temperature but it mightle defective at other temperatures. If in doubt, $b_{\gamma\gamma}$ new sensor,

new sensor. Also remember this validates the operation of the sensor at room temperature. It does not valida the over temperature functionality. To test the sensor could be removed from the engne at heated with a heat gun (ensure not to heat encesively) while it is still connected to the tempersure gauge. The temperature should raise on the gauge (electrical system activated).

gauge telectrical system activated. A good test would be to put sensor in a conteer filled with ice and water and measure restance. Then, boil water and read resistance age. According to the table above, the sensor valwould be approximately 7418 Ω with ice/war (0°C (32°FI) and 185.6 Ω with boiling water (10°C (212°FI).

Resistance Test

Disconnect sensor connector and measure sensor resistance between wires of sensor. If out a specifications, replace sensor.

If resistance tests good, reconnect the CTS and disconnect the gauge connector.

Measure resistance value again between ter minals on gauge connector (see WIRING DA GRAMS).

If resistance value is correct, try a new gauge. If resistance value is incorrect, repair the consetors or replace the wiring harness between gauge connector and the CTS.

Sensor Replacement


Lift rear of vehicle and securely support. Disconnect CTS connector and remove CIS Install the new CTS and torque to 12 lim (106 lbf•in).


Reinstall remaining removed parts. Refill engine coolant. If an important quantity d coolant spilled, bleed cooling system.


Sont Table Removal

and the second second of a second sec

OIL INJECTION SYS	STEM	
SERVICE TOOLS		
Description leak testing kit	529 035 868 529 036 045 295 000 076 529 036 042	
SERVICE PRODUCTS		
Description Loctite 243 (blue)	Part Number	Pag 16
Lastite EAR (groop)	413 711 400	16
pulley flange cleaner		
1.		







GENERAL

NOTE: On applicable models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *EMS DI-AGNOSTIC AND COMMUNICATION TOOLS.*

During assembly/installation, use the torque val-ues and service products as in the exploded views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

Wipe off any oil spills. Oil is highly flammable.

CAUTION: Do not use a hose pincher on inlet/ outlet hoses. This would damage the spring inside hose.

NOTE: The following procedures can be done without removing the engine from chassis.

RECOMMENDED OIL TYPE

mmr2007-169


MODEL	OIL TYPE	
600	All XP-S 2-stroke oil (synthetic, synthetic blend or mineral can be used ^{(2) (3)}	
600 HO SDI	XP-S synthetic 2-stroke oil or XP-S synthetic blend 2-stroke oil (1)	

- CAUTION: The XP-S synthetic 2-stroke oil and the XP-S synthetic blend 2-stroke oil are specially formulated and tested for the severe requirement of these engines. Use of any other brand two-stroke oil may void the limited warranty. Use only XP-S synthetic 2-stroke oil or XP-S synthetic blend 2-stroke oil. There is no known equivalent on the market for the moment. If a high quality equivalent were available, it could be used. If XP-S 2-stroke oil (synthetic, synthetic blend or mineral is not available, API TC high-quality low ash two-stroke oil, XP-S synthetic blend 2-stroke and XP-S mineral injection oil are compatible, they can be mixed together.
- (2)

INSPECTION

OIL SYSTEM LEAK TEST

The following test will indicate any leak from oil injection system.






Remove the air intake silencer and carburetor or throttle body to gain access to the oil pump hoses. Install a small hose pincher (P/N 295 000 076) on each outlet hose.



15

TYPICAL 1. Hose pinchers on outlet hose





coolant tank retaining screws



- oil reservoir retaining screws.





Pull out oil reservoir and unplug all hoses.

Reservoir Installation For installation, reverse the removal procedure. Bleed oil pump. Refer to OIL PUMP BLEEDING

OIL LEVEL SENSOR

Sensor Removal

Remove oil reservoir, as mentioned above. Unplug sensor connectors.

Pull sensor no. 2 out of reservoir.

Before replacing the oil level sensor, check it according to the following procedure:

Sensor Electrical Test

CAUTION: Do not remove or bend the reed switch protective float magnet. It can damage the reed switch glass.

With the float magnet ring at the lowest position and using the multimeter Fluke 111 (P/N 529 035 868), measure the resistance of the oil level sensor.



MEASURE	SENSOR CONDITION
Closed circuit (close to 0 Ω)	Good
Open or resistive circuit more than 0.5 Ω	Defective

Sensor Installation For installation, reverse the removal procedure.

mmr2007-169



Oil Filter Removal

Remove air intake silencer (refer to *AIR INTAKE SYSTEM*). Siphon injection oil reservoir.

Disconnect oil filter hose from the oil level sensor. Disconnect oil filter no. 3 from hoses and remove

Oil Filter Installation

For installation, reverse the removal procedure. The filter must be installed with the arrow pointing toward the pump.



Bleed oil pump. Refer to OIL PUMP BLEEDING.

OIL PUMP

Oil Pump Identification Different engines need different pumps. See identification on lever no. 1.

CAUTION: Always mount proper pump on engi

ENGINE TYPE	OIL PUMP IDENTIFICATION
593	02

Oil Pump Verification

NOTE: Since pump is a piston type, it works when engine rotates in both forward and reverse. On Vehicle

NOTE: Main oil line must be full of oil. See bleed-ing procedure further.

Lift rear of vehicle and support with a mechanical stand. Unplug small oil lines from pump.



Start engine and stop it as soon as it fires.

Check that oil in small oil lines has been sucked up (this will be indicated by a clear section of small oil lines). Repeat the procedure until this condition is attained.

Reconnect small oil lines, start engine and run at idle while holding the pump lever no. 1 in ful-ly open position. Oil columns must advance into small oil lines.

If not, test pump as described below.

NOTE: Through normal use, oil level must not drop in small tubes. If oil drops, verify injection nozzle no. 4 operation. Replace as necessary. Test Bench

Connect a hose filled with injection oil to man line fitting. Insert other hose end in an injector, oil container. Using a clockwise rotating drill re-tate pump shaft. Oil must drip from outer fitting; while holding lever in a fully open position. If not replace pump.

Oil Pump Removal

NOTE: Before removing the injection oil pump no. 2, check its operation. Refer to OIL PUMP VERIFICATION, above in this section. Remove:

air intake silencer
 carburetor (600 models) or throttle body (60) HO SDI models)

screws no. 3 retaining oil pump to engine. Unplug all hoses connected to oil pump no. 2. NOTE: Mark hose locations for installation.

Disconnect the oil pump cable



TYPICAL

Oil Pump Cleaning

Clean all metal components in a non-ferrous metal cleaner.

Oil Pump Installation

For installation, reverse the removal procedure However, pay attention to the following. NOTE: During installation, always check for spring clips tightness on pump inlet hoses.

Apply Loctite 243 (blue) (P/N 293 800 060) on threads of screws no. 3 and torque them to 6 N+m (53 lbf+in). Make sure cable barrel is well seated in oil pump

lever.



TYPICAL 1. Plastic washer on this side 2. Circlip on this side

Verify cable and oil pump lever operation then adjust cable.

Bleed oil pump. See procedure further. CAUTION: Always bleed oil pump when the system has been opened.

Oil Pump Adjustment


Before processing with the oil pump cable adjust-ment, verify throttle cable adjustment. Refer to CARBURETOR AND THROTTLE CABLE for 600 models or ADJUSTMENTS AND REPAIR PRO-CEDURES in ENGINE MANAGEMENT section for 600 HO SDI models).

NOTE: Do not use marks on oil pump. Proceed as follows instead.

Slightly press on throttle lever to eliminate throttle cable free play.

Insert the throttle free play wedge tool (P/N 529 036 042), between throttle lever and housing as shown.

Slide tool up and down until all free-play is re-covered. Stop recovering free-play before throt-tle cam just begins to move at carburetor/throttle body.



Move adjuster boot away and stretch oil pump ca-ble at adjuster.



Insert cable in the appropriate slot of the oil pump cable adjuster (P/N 529 036 045).

MODEL	ADJUSTMENT SPECIFICATION	
600	16.5 mm (.650 in)	16.5
600 HO SDI	20.0 mm (.787 in)	20.0

Section 04 ENGINE (593) Subsection 06 (OIL INJECTION SYSTEM)



NOTE: If tool cannot be inserted, turn cable ad-juster to "lengthen" cable.

Pull cable with a force of 34 N (7.6 lbf) to recover all play in cable.

While still pulling, check if there is a gap as shown.



A. Pull 34 N (7 6 lbf) B. Remove gap here

Turn cable adjuster to recover that gap.



Secure adjustment in place with lock nut.



Remove the throttle free play wedge tool, puth back cable in adjuster and slide adjuster boot h place.

Oil Pump Bleeding

Bleed main oil line (between reservoir and pung) by loosening the bleeder screw until air has es caped from the line. Add injection oil as required



TPICAL 1. Bleeder screw 2. Oil pump lever

Bleed the small oil line between pump and engre by running engine at idle while holding the pump lever in fully open position.

NOTE: Make a "J" hook out of mechanical with to lift the lever.


Do not operate throttle mechanism. Secure the rear of the vehicle on a stand.

INJECTION NOZZLE

A check valve is part of injection nozzle no. 4 in-stalled on crankcase.

Injection Nozzle Inspection

Use the vacuum/pressure pump (P/N 529 @ 800).



Section 04 ENGINE (593) Subsection 06 (OIL INJECTION SYSTEM)

PUMP	Set to VACUUM	Set to PRESSURE
TO DO	Activate pump several times	Slowly activate pump and listen to check valve
RESULT	Air must not flow through check valve	You should hear it release pressure at approx. 20.7 kPa (3 PSI)
S SIVI	Success: Perform next test	Success: Check valve is good
ACTION	Failed: Replace injection nozzle	Failed: Replace injection nozzle

Injection Nozzle Removal

NOTE: Before removing injection nozzle no. 4, check its operation. Refer to the end of this section.

CAUTION: Do not remove injection nozzle needlessly. It is likely to be damaged. Remove air intake silencer and carburetor or throt-tle body.

Clean injection nozzle area to remove oil or dirt. Heat injection nozzle no. 4 then pull it out of crankcase.

Injection Nozzle Installation


Prior to coating it with Loctite, make sure injection nozzle body is clean and dry. Clean from dirt or oil, if any, with pulley flange cleaner (P/N 413 711 809).

Apply Loctite 648 (green) (P/N 413711400) on the outer diameter of the linjection nozzle (machined section). Take care that Loctite is ONLY in this area.



APPLY LOCTITE ON THIS AREA ONLY


Properly install the injection nozzle in the correct position into the crankcase.




POSITION FOR 600 MODELS A. PTO side: 30° ± 10° from c B. MAG side: 0° from cylinder inder axis to the botton



TYPICAL — POSITION FOR 600 HO SDI MODELS A. PTO side 45° ± 5° from cylinder axis to the top B. MAG side 20° ± 5° from cylinder axis to the both



		Section 04 Subsection 07 (RE	ENGINE (693) Wind Starter
REWIND ST	TARTER		
SERVICE TOOLS			
Description	is a godening	Part Number	Fugi
small hose pincher			
SERVICE PRODUCT	rs		
Description		Part Number	Pap
Molykote PG 54			174-17
mmv2003-168			



Section 04 ENGINE (593) Subsection 07 (REWIND STARTER)

GENERAL

NOTE: Due to dust accumulation, rewind starter must be periodically cleaned, inspected and relubricated.

CAUTION: It is of the utmost importance that the rewind starter spring be lubricated periodically using specific lubricant. Otherwise, rewind starter component life will be shortened and/or rewind starter will not operate properly under very cold temperatures.

Check if rope no. 6 is fraying, replace if so.

When pulling starter grip, mechanism must engage within 30 cm (1 ft) of rope pulled. If not, disassemble rewind starter, clean and check for damaged plastic parts. Replace as required, lubricate, reassemble and recheck. Always replace O-ring no. 11 every time rewind starter is disassembled.

When releasing starter grip, it must return to its stopper and stay against it. If not, check for proper spring preload or damages. Readjust or replace as required.

When pulling starter grip 10 times in a row, it must return freely. If not, check for damaged parts or lack of lubrication. Replace parts or lubricate accordingly.

PROCEDURES

STARTER HANDLE

Starter Handle Removal


Pull rope for 50 cm (20 in) approximately. Using a small hose pincher (P/N 295 000 076), lock rope near rewind starter.



Using a small screwdriver, extract rope knot from stater handle no. 3. Cut rope close to knot.

Starter Handle Installation

Prior to installing starter handle on rope, it is first necessary to fuse the rope end with a lit match. Pass rope through starter handle and tie a knot in the rope end. Fuse the knot with a lit match then insert rope end down and pull the starter handle over the knot.




REWIND STARTER

Rewind Starter Removal Remove starter handle no. 3. Remove tuned pipe/muffler. Remove screws no. 2 securing rewind starter no. 1 to engine then remove rewind starter.

Rewind Starter Disassembly


Undo knot previously tied at removal. Let sheave get free to release spring preload. Cut push nut and discard. Remove lock lever Oring on 11 collar sleeve

Remove lock lever, O-ring no. 11, collar sleeve, pawl lock and pawl.





Pull the rope out of the starter housing and tem-porarily make a knot to hold it.




Lubricate pawl no. 8 with Molykote PG 54 (P/N 420 899 763) then install over rope sheave.


Lubricate pawl lock no. 9 with Molykote PG 54 (P/N 420 899 763). Install over pawl.



Install collar sleeve no. 10 with its collar first. Lu-bricate a new O-ring no. 11 and lock lever no. 12 with Molykote PG 54 (P/N 420 899 763). Install over pavil lock.



Section 04 ENGINE (593) Subsection 07 (REWIND STARTER)




1 Collar sleeve 2 O-ring 3. Lock lever

Position a new push nut no. 13.

Rewind Starter Installation

Thread starter rope no. 6 through rope guide when applicable.



Reinstall rewind starter assembly on engine.

ROPE


Rope Replacement

Pull out rope. Hold rewind starter in a vise. Slide rope and untie the knot. Pull out the rope com-pletely.




1. Knot to be untied

To install rope no. 6, insert rope into sheave no.5 orifice and lock it by making a knot, leaving behind a free portion of about 25 mm (1 in) in length





FREE PORTION

Fuse rope end with a lit match and insert it into sheave.



	Section 04 ENGINE (593) Subsection 08 (MAGNETO SYSTEM)	
MAGNETO SYSTE	M	
SERVICE TOOLS		
Description	Part Number	Page
crankshaft protector magneto puller. puller ring.	529 035 547	
SERVICE PRODUCTS		
Description	Part Number	Page
Loctite 243 (blue)silicone dielectric grease		
mm(2007-171		





Section 04 ENGINE (593) Subsection 08 (MAGNETO SYSTEM)

GENERAL

NOTE: The following procedures can be done without removing the engine. To facilitate magneto removal, hold drive pulley with the appropriate tool. Refer to *DRIVE PULLEY*.

During assembly/installation, use the torque val-ues and service products as in the exploded views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

PROCEDURES

MAGNETO FLYWHEEL

Magneto Flywheel Cleaning

Clean all metal components in a non-ferrous metal cleaner.

CAUTION: Clean magneto flywheel using only a clean cloth.

Magneto Flywheel Removal

To gain access to magneto flywheel no. 1 assembly, remove the following parts as needed on different engines:

- tuned pipe and muffler

rewind starter
starting pulley no. 2.




TYPICAL

NOTE: To remove starting pulley bolts, hold may neto flywheel with a socket as shown.



TYPICAL

As necessary, remove the connecting flange it taining the rewind starter to the engine housing



Section 04 ENGINE (593) Subsection 08 (MAGNETO SYSTEM)



Tighten puller bolt and at the same time, tap on bolt head using a hammer to release magneto fly-wheel from its taper.



Magneto Flywheel Installation

Clean crankshaft extension (taper) and apply Loctite 243 (blue) (P/N 293 800 060) on taper, then position Woodruff key, magneto flywheel no. 1 and lock washer on crankshaft.

Clean magneto flywheel nut threads and apply Loctite 243 (blue) (P/N 293 800 060) then tighten nut.

ENGINE	TORQUE
593	125 N•m (92 lbf•ft

At reassembly coat all electric connections except Deutsch housings (waterproof housing) with sili-cone dielectric grease (P/N 293 550 004) to pre-vent corrosion or moisture penetration.

CAUTION: Do not use silicone "sealant", this product will corrode contacts. Do not apply sil-icone dielectric grease on any Deutsch water-proof housing otherwise housing seal will be damaged.

STATOR

Stator Inspection

Always check stator no. 3 before changing it. Re-fer to CHARGING SYSTEM.

Stator Cleaning Clean all metal components in a non-ferrous metal cleaner.

CAUTION: Clean stator using only a clean cloth.

Stator Removal

Remove:

- magneto flywheel no. 1 magneto figwinee no. 1 all Allen socket screws no. 4 retaining stator to magneto housing grommet from crankcase where CPS/trigger coils no. 5 and stator wires exit magneto hous-
- ing.

Ing. Unplug the CPS/trigger coil connectors and pull the wires through the grommet location. NOTE: To pass the stator connector into the grommet location it is necessary to pass the CPS/ trigger coil connector first.

Unplug the stator connector and remove the stator no. 3.

Stator Installation

Insert the stator connector into crankcase grom-met then the CPS/trigger coil connector(s). Install the grommet on crankcase.

Position stator **no. 3** so that its wire protectors are over crankcase recess.



1. Crankcase recess 2. Wire protectors

NOTE: During installation, make sure the stator harness is located on the left side.

Section 04 ENGINE (593) Subsection 08 (MAGNETO SYSTEM)

For installation, reverse the removal procedure. NOTE: It is important to remove the old silicone at CPS location then apply new silicone. Screw CPS then stick the CPS wires in the silicone.

CPS Installation

Apply Loctite 243 (blue) (P/N 293 800 060) on threads of stator screws then torque them to 9 N•m (80 lbf•in). Reinstall all other removed parts.

TRIGGER COIL

600 Models

Trigger Coil Inspection For trigger coil inspection, refer to IGNITION SYS-TEM.

NOTE: It is possible that the engine is equipped with 2 trigger coils. If so, the trigger coil normally used for the electronic reverse (RER) is function-less as these models have a mechanical reverse.

Trigger Coil Removal

To replace the trigger coll no. 5, remove or discon-nect the following: - magneto flywheel no. 1 - air intake silencer

- all intake silencer
 trigger coil connector housing
 grommet from crankcase
- retaining screws no. 6
 trigger coil and carefully pull wires.

Trigger Coil Installation

For installation, reverse the removal procedure. NOTE: It is important to remove the old silicone at trigger coil location then apply new silicone. Screw trigger coil then stick the trigger coil wires in the silicone.

CRANKSHAFT POSITION SENSOR (CPS) 600 HO SDI Models

CPS Inspection


For CPS inspection, refer to ENGINE MANAGE-MENT.


CPS Removal

- To replace the CPS no. 5, remove or disconnect the following: magneto flywheel no. 1 air intake silencer

- trigger coil connector housing
- grommet from crankcase
 retaining screws no. 6
- CPS and carefully pull wires.

		n 09 (TOP END
TOP END		
SERVICE TOOLS		
Description	Part Number	Pag
bearing heater Locating sleeve		
Locating sleeve	529 023 800	19
Piston circlip installer Puller		
Puller. rubber pad		
rubber pad		
Sleeve kit	529 035 542	
SERVICE PRODUCTS		
Description	Part Number	10
Drei Bond sealing compound	100 000	Pag
Loctite Chisel	413 708 500	100 10





GENERAL

Before completely disassembling the engine, check airtightness. Refer to *LEAK TEST*. To measure internal parts, refer to *ENGINE MEA-SUREMENT* section.

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to SELF-LOCKING FASTENERS and LOCTITE APPL/CATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

cleaning

Discard all gaskets and O-rings. Use Loctite Chisel (P/N 413 708 500) to clean mating surfaces. Clean all metal components in a non-ferrous metal cleaner.

PROCEDURES

NOTE: Top end can be serviced with engine in vehicle.

REED VALVE


Reed Valve Removal

Remove intake resonator on top of reed valves no. 15.

Unscrew intake adapter screws no. 16 then remove reed valve(s).


Reed Valve Inspection

Check reed valve for proper tightness. There must not be any play between blade and valve body when exerting a finger pressure on blade at blade stopper location.



1. NO pia

Check distance from blade stopper no. 29 outer edge and distance from center of reed valve block.



TYPICAL A 593 engine: 14.75 - 0, + 0.75 mm (580 - 0, + 0.30 in) 593 HO/SDI engines: 17.5 - 0, + 0.75 mm (689 - 0, + 0.30 in)

Bent blade stopper as required to obtain the proper distance.

Reed Valve Disassembly

To remove blade from housing, remove the blade stopper no. 29.

Reed Valve Assembly

Blades have a curved shape. Install blade with their curve facing reed block housing.

Reed Valve Installation

The installation is the reverse of the removal procedure.

NOTE: Blade stoppers may slightly interfere with cylinder during installation. Adjusted distance will be reduced automatically upon installation.

RAVE VALVE

Rave Valve Basic Operation NOTE: RAVE stands for Rotax Adjustable Variable

The RAVE valves change the height of the exhaust port to enhance the engine powerband and torque according to the engine powerband and throttle position (e-RAVE on SDI engines).

600 Engine

Exhaust.

Exhaust pressure is used to inflate the bellows and open the RAVE valves at the proper engine RPM.

600 HO SDI Engine

The electronically controlled RAVE (e-RAVE) offers two performance enhancements to conventional RAVE system.

The opening and closing of the valve is activat-ed electronically. The ECM monitors altitude, engine temperature, throttle position and RPM, and operates the solenoid in optimal conditions.

and operates the solenoid in optimal conditions. - The valve is opened by crankcase pressure. The greater and more constant pressure from the crankcase opens the valve more crisply. Both RAVE valves operate at the same time. To close the RAVE valves, the ECM deactivates the solenoid and a return spring then closes the valve.

NOTE: An electric heating element has been added to the RAVE solenoid to ensure proper function in very cold weather.

- P. R. L. 0 Solenoid To intake silencer Engine Check valve -017-007_0

Rave Valve Removal and Disassembly Remove RAVE valve cover no. 4 by removing screws no. 5.

Firmly hold cover to valve base no. 6. The compression spring no. 7 inside the valve is applying pressure against the cover.




TYPICAL 1. Cover 2. Retain

Remove the compression spring no. 7.


awe



Unscrew the Allen socket screw no. 8 then re-move the RAVE valve base no. 6.








TYPICAL 1. Bellows 2. Small spring 3. Valve base

Remove bellows from valve base



TYPICAL

Rave Valve Inspection

There are no wear parts anywhere in the system and there are no adjustments to be periodically checked. The only possible maintenance required would be cleaning of carbon deposits from the guillotine slide. Cleaning intervals would depend upon the user's riding style and the quality of the oil used.

BRP suggests annual cleaning of the valve. If a customer uses lower quality oil, than recommended, more frequent cleaning may be required. No special solvents or cleaners are required when cleaning the valve.

600 Engine Check valve rod housing and cylinder for clogged passages.



1. Draining hole 2. Passages

NOTE: Oil dripping from draining hole indicates a loosen spring or damaged bellows.

600 and 600 HO SDI Engines

Check for cracked, dried or perforated bellows no. 13.

Check if the compression springs no. 7 are in specifications.

ENGINE	SPRING P/N	COLOR	WIRE DIA. mm (in)	FREE LENGTH mm (in)
600	420 239 948	GREY	1.0 (.039)	38 (1.5)
600 HO SDI	420 239 942	BLACK	0.8 (.031)	42.5 (1.67)

In its stock configuration, the RAVE valve guillotine has a minimum of 0.5 mm (.020 in) clearance to the cylinder bore measured at the center line of the cylinder. This is the minimum production clearance.

600 HO SDI Engine


Check if solenoid heating element is still functional once a year, the element should be warm after one minute of riding. At the same time, check if crankcase check valve is still functional. NOTE: Make sure hoses are not kinked or damaged.

Rave Valve Assembly and Installation Apply Drei Bord sealing compound (P/N 420 297 906) in the prove of valve base and in the piston valve groove, then install bellows.

Install RAVE valve with its mention TOP as illustrated in the following photo.



NOTE: To ease the installation of the spring no. 12 retaining bellows no. 13 to valve piston, refer to the following photo.



TYPICAL 1. Locking tie 2. Spring

Tighten red cap screw no. 28 to bottom.


CYLINDER HEAD COVER

Cylinder Head Cover Removal Unplug spark plug cables.

On SDI models, disconnect the knock sensor no. 19.

Unplug coolant hose from upper thermostat housing no, 20. Unscrew all cylinder head cover screws no. 21. Cylinder Head Cover Inspection Check cylinder head cover no. 1 for cracks, warpage or other damages. Refer to ENGINE MEASUREMENT for the measurement procedures.

Cylinder Head Cover Installation Torque screws no. 21 to 29 N•m (21 lbf•ft) in the following illustrated sequence. Torque knock sensor screw to 23 N•m (17 lbf•ft).



TYPICAL

If the upper coolant socket no. 20 has been removed, apply Locitie 243 (blue) (P/N 293 800 060) on screw threads. Position the longer screw outwards.



TYPICAL 1. Longer screw

600 HO SDI Engine Install knock sensor. Refer to ENGINE MANAGE-MENT (SDI) section.

CYLINDER HEAD

Cylinder Head Removal

Remove the cylinder head cover no. 1 as explained above. Disconnect the temperature sensor connector.

Remove the cylinder head no. 2.

Cylinder Head Inspection

Check cylinder head no. 2 for cracks, warpage or other damages.

Refer to tables below to find cylinder head specifications. For dimension measurement procedures, refer to ENGINE MEASUREMENT.

CYLINDER HEAD WARPAGE (MAXIMUM) 0.05 mm (.002 in) per 50 mm (2 in) of surface

0.5 mm (.020 in) for total length of cylinder head

COMBUSTION CHAMBER VOLUME (CC) 25.49 - 27.96

Cylinder Head Cleaning

Scrape off carbon formation from cylinder head.

Cylinder Head Installation

Install new rubber ring and round O-rings on each cylinder.

Replace O-rings around spark plug holes and on cylinder head border.

Install cylinder head cover.

CYLINDER

Cylinder Removal

600 HO SDI Engine

Release the fuel pressure of the system. Unplug fuel injector connectors then remove the fuel rail no. 24. Refer to ADJUSTMENT AND RE-PAIR PROCEDURES.

600 and 600 HO SDI Engines

Remove cylinder head no. 2 as explained above Remove exhaust manifold, reed valves and RAVE valves.

Unscrew cylinder screws no. 22 and no. 23 then remove the cylinder(s) no. 3.

Cylinder Inspection

Check cylinders for cracks and scoring on the top and bottom of cylinders.

Refer to tables below to find cylinder specifications. For dimension measurement procedures, refer to ENGINE MEASUREMENT.

MEASUREMENT	MAXIMUM
Cylinder Taper	0.10 mm (.004 po)
Cylinder Out of Round	0.08 mm (.003 po)
Piston/Cylinder Wall Clearance	0.18 mm (.0071 in

RAVE Valve Clearance

In its stock configuration, the RAVE valve guillo-tine has a minimum of 0.5 mm (.020 in) clearance to the cylinder bore measured at the center line of the cylinder. This is the minimum production clearance.

Cylinder Cleaning

Scrape off carbon formation from cylinder exhaust port.

Clean cylinders and crankcase mating surfaces with Loctite Chisel (P/N 413 708 500).

Cylinder Installation

Apply a thin layer of Loctite 518 (P/N 293 800 038) to crankcase mating surface of base gasket. Install a new cylinder base gasket of the same thickness as previously used.

MOTE: If the old gasket thickness is unknown or if the cylinder head or cylinders are replaced, measure the combustion chamber volume to de-termine the right gasket to use. Refer to *ENGINE MEASUREMENT* for the measurement proce-dures. Refer to *CYLINDER HEAD* above for the combustion chamber volume specifications.

CAUTION: Always install a gasket of the proper thickness. Failure to do so may cause detonation and severe engine damage.

Coat gasket with Loctite 518.

Before inserting piston in cylinder, lubricate the cylinder with new injection oil or equivalent. Install cylinders. Do not tighten.

Install new rubber ring and round O-rings on each cylinde

NOTE: Carefully clean screws before reinstalla-tion, specifically under screw head.

195

1007-172

Install exhaust manifold with gaskets. Do not tighten yet. Torque cylinder screws in a crisscross sequence as per the following table.

M8 29 N•m (21 lbf•ft)

M10 40 N•m (29 lbf•ft)

Install all other removed parts.

PISTON

Piston Removal


Remove cylinders, as explained above.

Place a clean cloth or rubber pad (P/N 529 023 400) over crankcase. Then with a pointed tool inserted in piston notch, remove both circlips no. 25 from piston no. 26.



TYPICAL

NOTE: All engines are equipped with cageless pis-ton pin bearings.



To remove piston no. 26, use the following tools:

	TOOLS	
Puller (P/N 529 035 503)	Sleeve kit (P/N 529 035 542) (20 mm)	Locating sleeve (P/N 529 023 800)

NOTE: The locating sleeve is the same that con-tains new cageless bearing.

Insert piston pin puller making sure it sits squarely against piston.



TYPICAL 1. Properly seated all around


Install sleeve then shouldered sleeve over puller



Screw (LH threads) extracting nut.

Pull out piston pin no. 27 by unscrewing puller until shouldered sleeve end is flush with thrust washer of piston pin bearing.





TYPICAL 1. Sleeve inside bearing 2. Thrust washer 3. Shouldered sleeve end

Remove puller. Pull out shouldered sleeve carefully.



Remove piston from connecting rod. Install locating sleeve. Then push needle bearings along with thrust washers and sleeve.



TYPICAL 1. Locating sleeve 2. Sleeve

Piston Inspection


Inspect piston for scoring, cracking or other dam-ages.

Refer to table below to find piston specifications. For dimension measurement procedures, refer to ENGINE MEASUREMENT.

MESUREMENT	MAXIMUM	
Ring/Piston Groove Clearance	0.20 mm (.0079 in	
Ring End Gap	1.0 mm (.039 in)	
Piston/Cylinder Clearance	0.18 mm (.0071 in)	
Piston Skirt Wear	0.15 mm (.006 in)	

Piston Cleaning

Scrape off carbon formation from piston dome. NOTE: The arrow on the piston dome must be visible after cleaning.





Clean the piston ring groove with a groove cleaner tool or with a piece of broken ring.

Piston Installation

When installing a new cageless bearing, replace half plastic cages with sleeve.

NOTE: Cageless bearing contains 28 needles on all engines



TYPICAL 1. Sleeve

Lubricate needle bearings and thrust washers with injection oil then install washers on each end of needles.

Insert cageless bearing into connecting rod.





TYPICAL - CAGELESS BEARING AND SLEEVE INSTALLED

NOTE: To ease piston pin installation if it is tight, heat piston using bearing heater (P/N 529 035 969).





CAUTION: Piston temperature must not exceed $46^{\circ}C$ (115°F). Never use direct flame to heat the piston and never freeze the pin. At assembly, place the pistons over the connecting rods with the arrow facing towards the exhaust port.





Part Number	Pag
259 035 990	2
420 877 635	
529 036 014	
420 876 552	
420 876 557	7
529 035 966	and a second sec
420 977 479	
529 035 970	
529 035 822	2
529 035 757	
420 977 494	
420 840 681	
529 035 976	
1124	
	14 1 1 1 1
293 600 016	
	529 035 969 259 035 980 259 035 980 259 035 980 420 877 635 529 036 014 420 876 652 420 876 657 529 035 014 420 876 657 529 035 966 529 035 966 529 035 970 529 035 970 529 035 970 529 035 970 529 035 970 529 035 970 529 035 970 529 035 970 529 035 970 529 035 976 420 840 681 529 035 976 20 840 681 529 035 976 20 840 681 529 035 976 23 550 021 233 800 021 233 800 081 293 850 081 293 850 081 293 850 081 293 850 081 293 850 081 293 850 081 293 850 081 293 850 081





GENERAL

Before completely disassembling the engine, check airtightness. Refer to LEAK TEST. To verify internal parts, refer to ENGINE MEA-SUREMENT section.

All oil seals and gaskets must be discarded and replaced with new ones when crankcase is split.

CAUTION: After rebuilding an engine always observe a break-in period as described in *OP-ERATOR'S GUIDE*.

During assembly/installation, use torque values and service products as in the exploded view.


Clean threads before applying a threadlocker. Re-fer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES

WATER PUMP

Water Pump Disassembly Remove water pump housing no. 5.



TYPICAL

Water Pump Inspection Verify condition of impeller fins. If any fins are broke or missing, replace impeller.

Water Pump Assembly Install impeller. Install water pump housing with a new gasket and torque screws in a criss-cross sequence to 11 N•m (97 lbf•in).

BEARING HOUSING

Bearing Housing and Water/Oil Pump Shaft Removal

Remove: - oil injection pump water pump housing no. 5 and impeller no. 6 (refer to WATER PUMP)

- bearing housing screws no. 7.



From injection oil pump side, push shaft out while turning shaft to release it from crankshaft worm gear.



Bearing Housing and Water/Oil Pump Shaft Disassembly

Pump Shaft Disassembly CAUTION: Pay attention not to damage the bearing housing no. 8 during disassembly. Marks or other damages will lead to coolant and/or oil leaking. NOTE: For bearing housing disassembly/assem-bly procedures, a press is required. Protect the threads of shaft with a suitable M8 nut. Properly support bearing housing and push shaft out.



CAUTION: When removing water/oil pump shaft, always replace ceramic seal no. 9 and oil seal no. 10. Ceramic seal cannot be removed without damage. Pry inner part of ceramic seal no. 9 out.



Extract bearing no. 11 from the bearing housing using an appropriate pusher.




Push oil seal no. 10 out.



Press the outer part of ceramic seal out. NOTE: Use a mandrel with diameter of approxi-mately 16 mm (.63 in).



n (.63 in) m



Outer part of ceramic seal

Remove sealant from bearing housing with sand paper no. 180.



1. Re ve sealant

To extract bearing no. 12 either use a hammer puller or an appropriate pusher.


Bearing Housing and Water/Oil Pump Shaft Assembly

Reverse disassembly procedure and pay attention to the following.

NOTE: Never put oil in the press fit area of the oil seal and ceramic seal. Push the new oil seal no. 10 in bearing housing using the oil seal pusher (P/N 529 035 757).



Press bearing no. 11 into bearing housing no. 8.



Remove oil seal protector from water/oil pump shaft.

Bearing Housing and Water/Oil Pump Shaft Installation

Pour 50 mL (2 U.S. oz) of injection oil in the pan under worm gear to lubricate pump gearing.

Install bearing housing with shaft in crankcase half while turning shaft to mesh gears. Torque bearing housing screws no. 7.

Install impeller and water pump housing.

NOTE: After impeller installation, ensure shaft turns properly.

Reinstall oil injection pump.

WATER/OIL PUMP SHAFT

For shaft removal and installation procedures, re-fer to BEARING HOUSING.

NOTE: It is not necessary to split crankcase to remove shaft.

CRANKCASE

Crankcase Disassembly

Remove cylinder head and cylinders. Refer to TOP END.

Remove rewind starter. Refer to REWIND STARTER.

600 Engine

Remove trigger coil, magneto flywheel and stator. Refer to MAGNETO SYSTEM.

600 HO SDI Engine



Remove all screws that retain crankcase halves together. Split crankcase and remove internal components.

Clean all metal components in a non-ferrous met-al cleaner. Use Loctite Chisel (P/N 413 708 500) accordingly.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are harmful to crankcase sealing.

Crankcase Inspection

Check crankcase for cracks or other damages, Replace if necessary.

Crankcase Assembly

IMPORTANT: The total assembly sequence, in-cluding sealing compound application, crankcase screw installation and torquing, must be per-formed within 10 minutes. The torquing se-quence must be accomplished without interruption.

Before screwing both parts of crankcase, seal them with Loctite 5910 (P/N 293 800 081).


NOTE: It is recommended to apply this specific sealant as described here to get an uniform appli-cation without lumps. If you do not use the roller method, you may use your finger to uniformly dis-tribute the sealant.

Use a plexiglass plate and apply some sealant on it. Use a 50 - 75 mm (2 - 3 in) soft rubber roller and spread the sealant to get a thin uniform coat on the plate (spread as necessary). When ready, apply the sealant on crankcase mating surfaces.





Tighten all crankcase screws in place in the follow-ing sequence and to the appropriate torque; this must be done in two steps torquing: first, tight-en screws up to 60% of the final torque (18 Nem (159 lbf•in)), then tighten to the required torque (i.e. 29 N•m (21 lbf•ti)).



600 HO SDI Engine Install PTO oil seal cover.

CRANKSHAFT

Crankshaft Removal To remove crankshaft, use crankcase disassembly procedure.


Crankshaft Inspection

Refer to table below to find bottom end engine di-mension specifications. For dimension measure-ment procedures, refer to ENGINE MEASURE-MENT.

ENGINE	TOLERANCES		
MEASUREMENT	NEW PARTS (MIN.) (MAX.)		WEAR LIMIT
Crankshaft deflection on PTO side	N.A.	0.06 mm (.0024 in)	N.A.
Crankshaft deflection on MAG side	N.A.	0.05 mm (.002 in)	N.A.
Crankshaft deflection in center of crankshaft	N.A.	0.08 mm (.0031 in)	N.A.
Connecting rod big end axial play	593 ENGINES		
	0.31 mm (.012 in)	0.677 mm (.027 in)	1.20 mm (.047 in)
	593 HO SDI ENGINES		
	0.31 mm (.012 in)	0.677 mm (.027 in)	1.20 mm (.047 in)
Crankshaft end-play	0.10 mm (.004 in)	0.30 mm (.012 in)	N.A.

Crankshaft Installation


Position drive pins as illustrated.



Subsection 10 (BOTTOM END) ANDCICA

TYPICAL 1. Position pins

Pour 50 mL (2 U.S. oz) of injection oil in the pan under central gear to lubricate pump gearing as per photo.



Apply Isoflex grease (P/N 293 550 021) as per fol-owing procedure:

CAUTION: Use only the recommended grease. Wake sure not to push grease between outside bearing race and half crankcase.

ut the following quantity of grease in a syringe.

ENGINE	QUANTITY OF GREASE	
600	42 ± 5 mL	
600 HO SDI	30 ± 5 mL	

rease.


AUTION: Do not exceed the recommended mount of grease Il inner side of PTO side bearing with grease bout 10 mL).



With the syringe, fill the outer ball bearing and in-ner side of outer seal with the remaining of grease.



BALLS COATED WITH A SEAM OF GREASE





TYPICAL - FILL WITH GREASE AND SET IN PLACE

Apply 6 mL of grease to MAG side outer bearing. NOTE: If replaced with new bearing, do not apply grease as new bearings come with grease already applied.

Assemble crankcase halves.

mmr2007-173

CRANKSHAFT BEARINGS

Crankshaft Bearing Removal

NOTE: It takes approximately 10 minutes to heat up a bearing. In the event of replacing bearing, it's recommended to start the bearing heating process prior to removal operation. See proce-dure further.

To remove bearings no. 2 and no. 3 from crank-shaft no. 4, install half rings (P/N 420 977 479) and puller ring (P/N 420 977 494) on the outer bearing.



1. Half ring 2. Puller ring

NOTE: Apply grease on crankshaft end in order to hold in place the crankshaft protector (P/N 420 876 552) on PTO side and crankshaft protector (P/N 420 876 557) on MAG side. Using screws (P/N 420 840 681), install bearing puller (P/N 420 877 635) on the half rings.

Secure the bearing puller in a vise by one of its rib




BEARING PULLER SECURED IN THE VISE

CAUTION: Never use any air impact tool for tightening the puller bolt. Lubricate the bolt with XP-S Lube (P/N 293 600 016) to avoid damaging the threads.

Screw in the puller bolt until the bearing comes out.

out. Follow the same procedure for the inner bearing. NOTE: In the case of damaged bearing or less clearance between crankshaft counterbalance and the bearing or on the MAG side bearing, use a bearing separator Snap-on (P/N CJ951) or a bear-ing separator SPX/OTC (P/N 1124) to facilitate the removal. 211



Section 04 ENGINE (593) Subsection 10 (BOTTOM END) Do not touch heated bearing with bare hands. Always wear heat resisting gloves before handling the heated bearing(s). CAUTION: Bearing(s) should not be heated to more than 80°C (176°F). Do not heat bearing(s) on direct flame, or with a heat gun or in an oil bath. Inappropriate bearing(s) heating may result in inner seals or cage failure. For even heat distribution, turn bearing several times during heating process. NOTE: Two heatings can be heated at the same CAUTION: Never reinstall a bearing that has been removed. Slide in the inner PTO bearing with the integrated seel facing crankshaft. Push bearing to end posi-tion. NOTE: Two bearings can be heated at the same time on one bearing heater.

Bearings

nr2007-173

Probe the inner race of the bearing with the temperature indicator stick (P/N 529 035 970). Stick will liquefy when the bearing reach the proper temperature.

NOTE: Heated bearing should slide easily onto the crankshaft. If required, push with a bearing installer (P/N 259 035 990) on the inner ring of the bearing.

Install retaining discs. Install support plate (P/N 529 035 976) with appro-priate distance gauge; refer to following table.





1. Support plate 2. Distance gauge

214

Install bearing locator tool.




Slide the heated outer PTO bearing onto the crank-shaft until it contacts the distance gauge. Slide the first MAG bearing with the integrated seal facing crankshaft until it bottoms on crank-shaft shoulder. NOTE: Heated bearing should slide easily onto the crankshaft. If required, push with a bearing in-staller (PN 259 035 980) on the inner ring of the bearing.



Slide-in the second bearing until it contacts the first one.





Section 04 ENGINE (593) Subsection 11 (ENGINE MEASUREMENT) **ENGINE MEASUREMENT** SERVICE TOOLS Description degree wheel dial indicator... Part Number 529 035 607 414 104 700 Page NOTE: This subsection explains the procedures to correctly measure engine components. For the engine technical specifications, refer to *INSPEC-TION* in the appropriate *ENGINE* subsection. CYLINDER HEAD WARPAGE Check gasketed surface of the cylinder head with a straight edge and a feeler gauge. Make sure part is within the given specification. Otherwise, replace it. Verify combustion chamber volume to use the correct cylinder base gasket with the new part. COMBUSTION CHAMBER VOLUME MEASUREMENT The combustion chamber volume is the region in the cylinder head above the piston at Top Dead Center (TDC). It is measured with the cylinder head installed on the engine. TYPICAL 1. Bring piston to TDC DOG Obtain a graduated burette (capacity 0 - 50 cc) and fill with an equal part (50/50) of gasoline and injection oil. TH 0 11 TYPICAL 1. Combo stion chambe NOTE: When checking the combustion chamber volume, engine must be cold, piston must be free of carbon deposits and cylinder head must be lev-eled.

Remove both spark plugs and bring one piston to Top Dead Center using the dial indicator (P/N 414 104 700).

mmr2007-174

1. Graduated burette (0 - 50 cc)

Open burette valve to fill its tip. Add liquid in burette until level reaches 0 cc. 215

section 04 ENGINE (593) Subsection 11 (ENGINE MEASUREMENT)

Inject the burette content through the spark plug hole until liquid touches the top spark plug hole.



TYPICAL 1. Top of spark plug hole

NOTE: The liquid level in cylinder must not drop for a few seconds after filling. If so, there is a leak between piston and cylinder. The recorded volume would be false. - Let burette stand upward for about 10 minutes, until liquid level is stabilized. - Read the burette scale to obtain the quantity of liquid injected in the combustion chamber.


NOTE: When the combustion chamber is filled to top of spark plug hole, it includes an amount of 2.25 cc corresponding to the spark plug well.

 Repeat the procedure for the other cylinder.
 Repeat the procedure for the other cylinder.
 Install a thicker or thinner cylinder/crankcase gasket (refer to PARTS CATALOG) in order to obtain the specified combustion chamber vol-ume ume

CYLINDER TAPER

Compare cylinder diameter 33 mm (1.3 in) from top of cylinder to just below its intake port area. If the difference exceeds the specified dimension the cylinder should be rebored and honed or should be replaced. Nikasil cylinder can be honed using diamond hone but can not be rebored.

NOTE: If cylinder is machined, be sure to restore the chamfer around all cylinder sleeve port openings.





TYPICAL 1. Below the intake port A. 33 mm (1 3 in) from top

CYLINDER OUT OF ROUND

Measuring 33 mm (1.3 in) from top of cylinder with a cylinder gauge, check if the cylinder out of round is more than the specified dimension. If larger, cylinder should be rebored and honed or should be replaced. Nikasil cylinder can be honed using diamond hone but cannot be rebored.

NOTE: Be sure to restore the chamfer around all cylinder sleeve port openings





Section 04 ENGINE (593) Subsection 11 (ENGINE MEASUREMENT)

Procedure Continuation with a New or Used Piston

With the micrometer set to the piston dimension, adjust a cylinder bore gauge to the micrometer dimension and set the indicator to 0.



1. Use the micrometer to set the cylinder bore gauge 2. Dial bore gauge



1. Indicator set to 0 (zero)

NOTE: Make sure the cylinder bore gauge indicator is set exactly at the same position as with the micrometer, otherwise the reading will be false. Position the dial bore gauge at 33 mm (1.3 in) below cylinder top edge.

IMPORTANT: Always remove cylinder-block from crankcase before measuring.



TYPICAL 1. Measuring perpendicularly (90°) to piston pin axis A. 33 mm (1.3 in)

Read the measurement on the cylinder bore gauge. The result is the exact piston/cylinder wall clearance. If clearance exceeds specified tolerance, replace cylinder and piston.

NOTE: Oversize pistons are available for some engines. Refer to appropriate parts catalog.

RING/PISTON GROOVE CLEARANCE

Using a feeler gauge check clearance between rectangular ring and groove. Replace piston if clearance exceeds specified tolerance.




Section 04 ENGINE (593) Subsection 11 (ENGINE MEASUREMENT)

RING END GAP

Position ring halfway between transfer ports and intake port.

NOTE: In order to correctly position the ring in the cylinder, use piston as a pusher.

Using a feeler gauge, check ring end gap. Replace ring if gap exceeds specified tolerance.



TYPICAL 1. Transfer port 2. Intake port

CRANKSHAFT DEFLECTION


Crankshaft deflection is measured with the dial indicator (P/N 414 104 700).

Measuring in Crankcase

First, check deflection with crankshaft in crankcase. If deflection exceeds the specified tol-erance, recheck deflection using V-shaped blocks to determine the defective part(s). See below.

Measuring on Bench

Measuring on Bench Once engine is disassembled, check crankshaft deflection on V-shaped blocks. If deflection exceeds the specified tolerance, it can be worn bearings or a bent crankshaft. Remove crankshaft bearings and check deflection again on V-shaped blocks to determine the defective part(s). See measurement "A" in following illustration.




TYPICAL
1. Measure at mid point between the key and the first the
A. 3 mm (1/8 in)

NOTE: Crankshaft deflection cannot be correctly measured between centers of a lathe. If the deflection exceeds the specified tolerance, crankshaft should be repaired or replaced.

CONNECTING ROD BIG END AXIAL PLAY


Using a feeler gauge, measure distance between thrust washer and crankshaft counterweight. If the distance exceeds specified tolerance, repair or replace the crankshaft.



CRANKSHAFT ALIGNMENT

Remove both spark plugs. Install the dial indicator (P/N 414 104 700) in spark plug hole on MAG side.

<text><text><text><text><image><image><text><text><text>



Section 05 ENGINE (810)

Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

GENERAL

To avoid potential burns, let engine and ex-haust system cool down before performing any servicing.

Refer also to other sections in this manual for removal and installation procedures that are not shown in this section.

Shown in this section. During assembly, use the torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new one where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES

ENGINE REMOVAL

Vehicle and Engine Preparation

Place vehicle on a work station that will have ac-cess to an engine-lifting hoist. Then start with ini-tial preparation of vehicle by doing the following. Unplug the BLACK (-) cable from battery, then the RED (+) cable.

Always unplug battery cables exactly in the specified order, the BLACK (-) cable first. It is recommended to unplug electrical connec-tions prior to disconnecting fuel lines.

Drain cooling system.

Drain engine oil.

NOTE: Drain engine oil only if engine repair is re-quired.

Remove exhaust pipe.

Unplug the camshaft position sensor (CAPS) from cylinder head no. 1.

222



CAMSHAFT POSITION SENSOR (CAPS)

Remove the crankshaft position sensor (CPS) from engine.



CRANKSHAFT POSITION SENSOR (CPS


Unplug the oil pressure switch (OPS).



OIL PRESSURE SWITCH (OPS)

Unplug spark plug cable of cylinder no. 2.

mm/2007-175



Section 05 ENGINE (810) Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



Unplug the starter cable


Lifting Engine Install the engine lifting tool (P/N 529 036 022).



Unscrew engine supports screws



REAR ENGINE SUPPORT SCREWS



TIL

FRONT ENGINE SUPPORT SCREWS

Move engine forward to release the rear support. Lift the engine slightly and remove the coolant hose from water pump. Remove engine from vehicle.

ENGINE INSTALLATION

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Refer to other sections in this manual for prop-er component installation and adjustment proce-dures.

Make sure engine oil drain plug is installed and tight.

Check condition of engine support rubber mounts and replace them if necessary.


Install engine support washers with the teeth to-ward the support.



1. Teet

Position the front heat deflector to obtain a distance of 10 \pm 1.5 mm (1/2 \pm 1/16 in) with the front support. Check pulley alignment and drive belt height.

en-me2007.175



Section 05 ENGINE (810) Subsection 02 (ENGINE LEAK TEST)

ENGINE LEAK TEST

SERVICE TOOLS

Description camshaft locking tool. dial gauge

GENERAL

Before performing the cylinder leak test, verify the following: - clamp(s) tightness

- radiator and hoses.

NOTE: For best accuracy, the leak test should be done with the engine at normal operating temperature.

Prevent burning yourself on hot engine parts.

Repair Tips

- Repair Tips

 - blue exhaust gas means damaged/worn piston rings or valve stem seals

 - oily contamination on leak indicator hole means a damaged oil seal on water pump shaft (refer to COOLING SYSTEM)

 - coolant out of leak indicator hole means a damaged rotary seal on water pump shaft (refer to COOLING SYSTEM)

 - coolant escaping from water pump housing means damaged gasket(s) and/or loosened screws (refer to COOLING SYSTEM).

 NOTE: For all the checkpoints mentioned above

NOTE: For all the checkpoints mentioned above, see the appropriate engine section to diagnose and repair the engine.

PROCEDURES

NOTE: The following instructions are the same for both cylinders.

PREPARATION

Always disconn	respect this order for disassembly, ect BLACK (-) cable first.
	coolant tank cap.

Page228228 Part Number 529 035 926 414 104 700

A WARNING

To avoid potential burns, wear the appropri-ate safety equipment to remove the coolant tank cap.


Unplug and remove spark plug cable. Clean spark plug area and remove spark plug from cylinder head.



TYPICAL 1. Spark plug cable 2. Spark plug

Remove valve cover.

Section 05 ENGINE (810) Subsection 02 (ENGINE LEAK TEST)



1. Valve cover screws 2. Valve cover

Rotate crankshaft until piston is at ignition TDC. See procedure below.

How to Turn Crankshaft

To turn crankshaft, there are two possible proce-dures.

First Procedure - Turn the drive pulley.

Second Procedure

Remove plug screw with O-ring from magneto cover.
 Use a 14 mm Allen key and turn crankshaft.

NOTE: Exhaust pipe must be removed for this op-

eration CAUTION: Turn only clockwise to avoid loosening of magneto flywheel Allen screw.

How to Position Piston at TDC Using the dial gauge (P/N 414 104 700), turn the crankshaft and set the piston to precisely ignition TDC.



TYPICAL 1. Dial gauge

NOTE: If a dial gauge is not available, use a screw-driver or another similarly tool.

CAUTION: Do not scratch or damage piston/ cylinder surface.

At ignition TDC the marks on the camshaft timing gear have to be parallel to cylinder head base as per following illustration.



1. Marks on camshaft timing gear 2. Cylinder head base 3. Camshaft locking tool

How to Lock Camshaft Lock camshaft at TDC by using the camshaft lock-ing tool (P/N 529 035 926).

Section 05 ENGINE (810) Subsection 02 (ENGINE LEAK TEST)



CAMSHAFT LOCKING TOOL

LEAK TEST

Connect to adequate air supply.

Set needle of measuring gauge to zero. NOTE: All testers have specific instructions on gauge operation and required pressure. Install gauge adapter into previously cleaned spark plug hole.

Supply combustion chamber with air pressure.



TYPICAL 1. Leak tester 2. Air supply hose

Note the amount or percentage of leakage (depending on tester).

mmr2007-176

LEAKAGE PERCENTAGE	ENGINE CONDITION
0% to 15%	Excellent condition
16% to 25%	Good condition
26% to 40%	Fair condition; reduced engine performance
41% and higher	Poor condition, diagnose and repair engine

Diagnosis

- Listen for air leaks.
- arten for air feaks. air escaping on intake port/throttle body means leaking intake valve(s) air escaping on exhaust port means leaking ex-haust valve(s) cit biothes


- haust valve(s) air bubbles out of radiator means leaking cylin-der head gasket air/oil escaping from crankcase means dam-aged gasket and/or loosened screws (refer to *BOTTOM END*) air/coolant escaping from cylinder/head means damaged gasket(s) and/or loosened screws (re-fer to *CYLINDER AND HEAD*)
- air escaping into crankcase area means excessively worn cylinder and/or broken piston rings (refer to CYLINDER AND HEAD).


NOTE: For all the checkpoints mentioned above, see the appropriate engine section to diagnose and repair the engine.

REASSEMBLY

Reverse the preparation procedure. Ensure to respect torque values and use of appropriate products/lubricants. Refer to exploded views in other sections of this manual as required.







Section 05 ENGINE (810) Subsection 03 (AIR INTAKE SYSTEM)

GENERAL

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

PROCEDURES


AIR INTAKE SILENCER

Air Intake Silencer Removal Open hood. Unhook latch.



1. Latch 2. Front of air intake silence

Detach vent tube and loosen throttle body clamp.



Vent tube
 Throttle body clamp
 Throttle body

Pull out air intake silencer.

Air Intake Silencer Installation

The installation is the reverse of the removal procedure. However, pay attention to the following. **CAUTION:** Make sure air intake silencer boot is properly installed onto throttle body and the clamp is tight.




INTAKE MANIFOLD

Intake Manifold Removal Remove air intake silencer.

Disconnect manifold air pressure and temperature sensor (MAPTS), coolant temperature sensor (CTS) and both injectors.



	Section 05 ENGINE (\$15) Subsection 04 (EXHAUST SYSTEM)	
EXHAUST SYSTEM		
SERVICE TOOLS		
Description exhaust spring tool	Part Number	Pag
	529 035 983	
SERVICE PRODUCTS		
Description	Part Number	Pu
Loctite 767 (antiseize lubricant)	293 800 070	



Section 05 ENGINE (810) Subsection 04 (EXHAUST SYSTEM)

GENERAL

To avoid potential burns, never touch exhaust system components immediately after the engine has been run because these compo-nents are very hot. Let engine and exhaust system cool down before performing any servicing.

During assembly/installation, use the torque values and service products as in the exploded ues an views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired it must be rea locking device is impaired, it must be renewed.

PROCEDURES

EXHAUST PIPE


Exhaust Pipe Inspection


Check flexible joints and pipes for cracks or other damages. Replace exhaust pipe if necessary.

Exhaust Pipe Removal

Open the hood.

Using the exhaust spring tool (P/N 529 035 983), remove exhaust springs securing the exhaust pipe to muffler.





Unscrew nuts securing exhaust pipe to cylinder heads

Remove exhaust pipe from vehicle. Discard all exhaust pipe gaskets.

Exhaust Pipe Installation

Install new gaskets. Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) on studs.

Using exhaust pipe flange and nuts, install exhaust pipe ends on cylinder heads. Install nuts loosely. Align exhaust pipe end into muffler ball socket. Install exhaust springs.

Torque exhaust pipe nuts to 22 N•m (16 lbf•ft). Install all other removed parts.

MUFFLER

Muffler Removal

Open the hood.

Remove the exhaust pipe, see procedure above. Using the exhaust spring tool (P/N 529 035 983), remove all exhaust springs retaining muffler to vehicle



Section 05 ENGINE (810) Subsection 04 (EXHAUST SYSTEM)



TOP OF MUEELER




Lift and remove muffler.


Muffler Inspection


Check muffler for cracks, perforation or other damages. Replace as required. Check rubber dampers for damages. Replace if necessary.

Muffler Installation

The installation is the reverse of the removal pro-cedure.







Section 05 ENGINE (810) Subsection 05 (LUBRICATION SYSTEM)

GENERAL

During assembly/installation, use the torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

MAINTENANCE


OIL LEVEL VERIFICATION

CAUTION: Check level frequently and refill if necessary. Do not overfill. Operating the en-gine with an improper level may severely dam-age engine. Wipe off any spillage.

With vehicle on a level surface and engine cold, not running, check the oil level as follows: Remove dipstick and wipe clean. Reinstall dipstick.

NOTE: Make sure it is completely inserted inside tube

Remove dipstick and read oil level. Oil level must be between minimum and maximum marks on dipstick.



NOTE: There is a capacity of 300 mL (10 U.S. oz) between the two marks.

Refill oil as necessary. Place a funnel into the dip-stick tube to avoid spillage. Do not overfill. Reinstall dipstick.

OIL CHANGE

Prior to change the oil, ensure vehicle is on a level surface.

Oil and oil filter must be replaced at the same time. Oil change and oil filter replacement should be done with a warm engine.

The engine oil can be very hot. Wait until engine oil is warm.

Dispose oil and filter as per your local environmental regulations

Oil Drain

Remove dipstick. Using the suction pump (P/N 529 035 880), siphon oil through dipstick tube.

Oil Inspection

Oil condition gives information about the engine condition. See TROUBLESHOOTING section.

Oil Fill

Refill engine with BRP XP-S 0W40 synthetic oil or an equivalent.

Oil change capacity with filter: 2 L (2.11 qt). After filling, check the oil level with the dipstick. Refer to OIL LEVEL CHECK above.

NOTE: Run engine to ensure oil filter area is not leaking.

Ensure to completely wipe out oil that may have spilled in bottom pan.

OIL FILTER

Oil Filter Removal


Remove - muffler. Refer to EXHAUST SYSTEM

- oil filter screws

- oil filter cover

- oil filter.


Section 05 ENGINE (810) Subsection 05 (LUBRICATION SYSTEM)



TYPICAL 1. Oil filter screw 2. Oil filter cover 3. O-ring 4. Oil filter

Oil Filter Inspection

Check and clean the oil filter inlet and outlet area for dirt and other contaminations.



Inlet bore from the oil pump to the oil filter
 Outlet bore to the engine oil providing system

Oil Filter Installation

The installation is the reverse of the removal pro-cedure. Pay attention to the following details.

Install a new gasket on oil filter cover. Apply Super Lube grease (P/N 293 550 030) on the following locations to prevent gasket displace-ment and ease filter installation.



INSPECTION ENGINE OIL PRESSURE

NOTE: The engine oil pressure test should be done with a warm engine (90°C (194°F)) and the recommended oil.

Remove the oil pressure switch. See procedure below

Install the oil pressure gauge (P/N 529 035 709) and the adapter hose (P/N 529 035 652).



The engine oil pressure should be within the fol-lowing values.

Section 05 ENGINE (810) Subsection 05 (LUBRICATION SYSTEM)

OIL PRESSURE	IDLE	6000 RPM
MINIMAL	70 kPa (10 PSI)	350 kPa (51 PSI)
NOMINAL	180 kPa (26 PSI)	420 kPa (61 PSI)
MAXIMAL	300 kPa (43 PSI)	550 KPa (80 PSI)

If the engine oil pressure is out of specifications, check the points described in *TROUBLESHOOT-ING* section.

Remove oil pressure gauge and adapter hose. NOTE: To remove adapter hose from oil pressure gauge, use the disconnect tool (P/N 529 035 714).



Reinstall the oil pressure switch.

PROCEDURES

OIL PRESSURE SWITCH

Oil Pressure Switch Activation Oil pressure switch works when engine oil pressure is between 20 and 40 kPa (2.9 and 5.8 PSI).

Oil Pressure Switch Test Refer to ENGINE MANAGEMENT.

244

Oil Pressure Switch Removal Unplug then unscrew the oil pressure switch, mounted on the crankcase.



1. Oil pressure switch

Oil Pressure Switch Installation

Apply Loctite 243 (blue) (P/N 293 800 060) on threads of oil pressure switch. Do not apply threadlocker on the end of switch. Torque switch to 12 N•m (106 lbf•in).


ENGINE OIL PRESSURE REGULATOR

The oil pressure regulator is located on the engine magneto side (inside magneto cover).



TYPICAL 1. Engine oil pressure regulator


NOTE: The oil pressure regulator system works when the oil pressure exceeds 450 kPa (65 PSI).




mmr2007-179

Retaining ring Oil pump gear Needle pin Thrust washer

- oil pump cover screws and pull oil pump cover 245



Section 05 ENGINE (810) Subsection 05 (LUBRICATION SYSTEM)



OIL PUMP - MEASUREMENT "A"



OIL PUMP COVER - MEASUREMENT "B"

Difference between measurements should not exceed 0.2 mm (.008 in). If so, replace the com-plete oil pump assembly. NOTE: When the axial clearance of the oil pump shaft assembly increases, the oil pressure de-creases.

Oil Pump Installation

mmr2007-179

For installation, reverse the removal procedure.

Pay attention to the following details. NOTE: The outer rotor and inner rotor are marked. When installing, make sure both markings are on the upper side.



TYPICAL 1. Markings

Apply Loctite 243 (blue) (P/N 293 800 060) on threads of oil pump cover screws. Torque them to 7 N•m (62 lbf•in).


After reinstallation of the remaining parts, check for smooth operation of the oil pump assembly.

Final Test

After engine is completely reassembled, start en-gine and make sure oil pressure is within specifi-cations (refer to *OIL PRESSURE TEST* above).

ENGINE OIL STRAINER

The engine oil strainer is located between both crankcase halves. Refer to *BOTTOM END* for re-moval, inspection and installation procedures.




247

Engine oil strainer Retaining plate Screws

Section 05 ENGINE (810) Subsection 05 (LUBRICATION SYSTEM)

REED VALVE

The engine is equipped with a reed valve which prevents accumulation of larger oil quantities in the crankcase. The reed valve is fitted into the crankcase.



Reed Valve Removal

Remove PTO cover (refer to BOTTOM END) section.


Unscrew reed valve retaining screws. Remove stopper plate and reed valve.


Reed Valve Inspection Check reed valve for cracks or other damage. NOTE: Replace reed valve if damaged.

Reed Valve Installation

The installation is the reverse of the removal pro-cedure.

SERVICE TOOLS		
Description	Part Number	Page
Fluke 111 multimeter		
installer handle	420 877 650	
oil seal pusher	529 035 757	
pressure/vacuum pump	529 021 800	
rotary seal installer	529 035 766	
small hose pincher.		
suction pump		
test cap	529 035 991	
SERVICE PRODUCTS	Part Number	Pag
BRP premixed coolant	210 700 262	21
Super Lube grease	293 550 030	26





GENERAL

A WARNING Never start engine without coolant. Some engine parts such as the rotary seal on water pump shaft can be damaged.

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

INSPECTION


COOLING SYSTEM LEAK TEST

To avoid potential burns, do not remove the coolant tank cap if the engine is hot.

Open hood and remove the coolant tank cap no. 1. Install the test cap (P/N 529 035 991) on coolant tank and a small hose pincher (P/N 295 000 076) on overflow hose no. 2.

Using pressure/vacuum pump (P/N 529 021 800), pressurize system to 120 kPa (17 PSI).







Test cap with pump Hose pincher on overflow hose


Check all hoses, radiators and cylinder(s)/base for coolant leaks or air bubbles.

Inspection

Check general condition of hoses and clamps tightness. Check the leak indicator holes.

Leak Indicator in Front of Engine

Flowing coolant indicates a defective rotary seal. Oil indicates a defective inner oil seal. If either seal is leaking, both seals must be replaced at the same time. Refer to WATER PUMP SHAFT AND SEALS in this section.



Leak Indicator on PTO Side

The PTO side leak indicator hole indicates if the PTO gasket is in good condition. If a liquid leaks by this hole, the PTO gasket replacement is nec-essary.



TYPICAL 1. Leak indicator hole

MAINTENANCE

COOLANT REPLACEMENT

To avoid potential burns, do not remove the coolant tank cap if the engine is hot.

Recommended Coolant

Use BRP premixed coolant Use BRP premixed coolant (P/N 219 700 362) or a blend of 50% antifreeze with 50% water. To prevent antifreeze deterioration, always use the same brand. Never mix different brands unless cooling system is completely flushed and refilled.

refilled. **CAUTION:** To prevent rust formation or freez-ing condition, always replenish the system with the BRP premixed coolant or with 50% antifreeze and 50% water. Do not use tap wa-ter, straight antifreeze or straight water in the system. Tap water contains minerals and im-purities which build up in the system. During cold weather, straight water causes the system to freeze while straight antifreeze thickens and does not have the same efficiency. Always use ethylene glycol antifreeze containing cor-rosion inhibitors specifically recommended for aluminum engines.

mmr2007-160

Draining the System

∆ warning Never drain or refill cooling system when en-gine is hot.

Remove coolant tank cap no. 1.

Siphon as much coolant through coolant tar with the suction pump (P/N 529 035 880). lant tank no. 3



When the coolant level is low enough, lift the rear of the vehicle to drain the rear radiator. Siphon again. Sinhon

Remove exhaust pipe and muffler. Refer to EX-HAUST SYSTEM.

On Expedition TUV, place a drain pan under bottom pan.

Disconnect the hose no. 4 from the water pump housing.

Let coolant drain. Siphon coolant in bottom pan and clean it.

Refilling the System

Ensure all hoses are installed and clamps tightened.

With vehicle on a flat surface, engine cold, refill coolant tank no. 3 to MAXIMUM mark.



253

1. Maximum mark 2. Minimum mark

Place a lifting strap around the bumper frame (Expedition TUV) or around front engine support (Skandic SWT).



EXPEDITION TUV



SKANDIC SWT --- SOME PARTS REMOVED FOR CLARITY PURPOSE 1. Lifting strap 2. Front engine support

Lift the front of the vehicle 50 cm (20 in) off the ground and secure safely.



254

Connect B.U.D.S. on vehicle. Refer to ENGINE MANAGEMENT for procedure and connector location.


Start engine. Refill coolant tank to keep coolant level between MINIMUM and MAXIMUM marks.

MINIMUM and MAXIMUM marks. **CAUTION:** Never allow coolant tank to be emp-ty during filling procedure. Let engine idling for about 10 minutes or until radi-ators no. 5 and no. 6 are warm (which means that the thermostat no. 7 is open). Keep engine idling until coolant temperature reaches 98°C (208°F). Monitor engine coolant temperature by using B.U.D.S. or any appropriate digital thermometer.

CAUTION: Never allow coolant to exceed 100°C (212°F).

Open the bleed screw of front radiator slightly (up-per right corner) to bleed all air bubbles. Close it when coolant comes out and no more air bubbles appear.

Engine coolant is very hot, to avoid potential burns use pliers to loosen bleed screw.



Stop engine.

Put vehicle back on the ground.

Verify coolant level in coolant tank no. 3, it must reach the MAXIMUM mark. Refill if necessary Install coolant tank cap.

Recheck coolant level after vehicle has completely cooled down. Fill coolant if necessary.

mm(2007-180

After the first few kilometers (miles) of running, recheck level in coolant tank.

PROCEDURES

COOLANT TANK CAP

Using a pressure cap tester, check the efficiency of coolant tank cap no. 1. If the efficiency is fee-ble, install a new 110 kPa (16 PSI) cap (do not ex-ceed this pressure).

FRONT RADIATOR

Cleaning and Inspection

Remove all debris between radiator fins. A clean radiator is more efficient than a dirty one. Check if the radiator fins are damaged. Replace the front radiator no. 6 if necessary.

NOTE: A radiator with many broken fins does not work properly.

Front Radiator Removal

Drain cooling system, see DRAINING THE SYS-TEM.

Remove screws securing front radiator to its support

Unplug radiator hoses no. 8 and no. 9 from the front radiator then remove it from vehicle.

Front Radiator Installation

For installation, reverse the removal procedure.

RADIATOR FAN

Radiator Fan Test


The ECM controls the radiator fan no. 10 via the in-put of the coolant temperature sensor (CTS). The radiator fan should turn on when coolant temper-ature reaches 98°C (208°F) and should turn off when coolant cools down at 95°C (203°F).

To verify the radiator fan, connect the vehicle to B.U.D.S. Refer to ENGINE MANAGEMENT for procedure and connector location.

In Activation tab, press Coolant fan button. If fan turns, check CTS, relay R3, wiring harness and connectors. If all parts are good, check the ECM. Refer to ENGINE MANAGEMENT.

If fan does not turn when the button is pressed, use the following troubleshooting chart to resolve the problem.

mmr2007-180



Use the Fluke 111 multimeter (P/N 529 035 868), and select the ohms position. Rear Radiator Removal Drain cooling system, see DRAINING THE SYS-TEM. Probe relay as follows. Remove rear suspension. Refer to the appropri-ate rear suspension section. TERMINAL RESISTANCE 0.5 Ω max. Remove fuel tank. Refer to FUEL TANK AND FUEL PUMP. 87 30 87a Open circuit (0L) 87 875 Rear Radiator Installation For installation, reverse the removal procedure. COOLANT TANK 2007-200-013_8 Connect battery as shown and probe relay as fol-lows. TERMINAL RESISTANCE Open circuit (OL) 87 Tank Removal 30 87a 0.5 Ω max. Open hood. 1 REAR RADIATOR

Rear Radiator Cleaning and Inspection Remove all debris between radiator fins. A clean radiator is more efficient than a dirty one. Check if the radiator fins are damaged. Replace the rear radiator if necessary.

NOTE: A radiator with many broken fins does not work properly.

mmr2007-180

Section 05 ENGINE (810) Subsection 06 (COOLING SYSTEM)

Using a grinding disk, grind all rivets retaining rear radiator no. 5 to frame.

Unplug radiator hoses no. 8 and no. 13 from the rear radiator then remove it from vehicle.

The coolant expands as the temperature (up to 100 - 110°C (212 - 230°F)) and pressure rise in the system. If the limiting system working pressure cap is reached 110 kPa (18 PSI), the pressure relief valve in the pressure cap is lifted from its seat and allows coolant to flow through the overflow hose into the coolant tank no. 3.

Siphon coolant tank with the suction pump (P/N 529 035 880).

Unplug overflow hose no. 2 and throttle body coolant hose.



1. Overflow hose 2. Throttle body heater hose

Squeeze tabs and lift tank vertically to remove. Unplug coolant tank hose no. 14.

Tank Installation

The installation is the reverse of the removal procedure.

257

COOLANT TEMPERATURE SENSOR (CTS)

Refer to ENGINE MANAGEMENT section for test-ing and replacement procedures of the coolant temperature sensor (CTS).

THERMOSTAT ate

Thermostat Removal

Drain cooling system. Refer to DRAINING THE SYSTEM above in this section. Remove exhaust pipe and muffler.

Disconnect the upper hose no. 8 from the rear radiator no. 5.

Disconnect the lower hose no. 15 from the T-fitting no. 16.

Pull this hose to remove thermostat no. 7.

Thermostat Inspection

To verify the thermostat, put it in water and heat water. Thermostat should open when water temperature reaches 45°C (113°F). If there is no operation, replace the thermostat.

Thermostat Installation

The installation is the reverse of the removal procedure.

Refill cooling system in accordance with the pro-cedure in *REFILLING THE SYSTEM* above in this section.

WATER PUMP HOUSING

It is located on the engine MAG side.

Water Pump Housing Removal

To avoid potential burns, do not remove the radiator cap or loosen the cooling drain plug if the engine is hot.

Drain cooling system, see DRAINING THE SYS-TEM.

Remove hose no. 4 from water pump housing no. 17.

Remove screws retaining water pump housing. Pull water pump housing to remove it.

Water Pump Housing Inspection

Check if gasket is brittle, hard or damaged and replace as necessary.



Water Pump Housing Installation The installation is the opposite of the removal procedure.

CAUTION: To prevent leaking, take care that the gasket is exactly in groove when you reinstall the water pump housing.

Tighten screws of water pump housing in a criss cross sequence.

WATER PUMP IMPELLER

Impeller Removal

Remove water pump housing. Unscrew impeller



TYPICAL 1. Impelle



Section 05 ENGINE (810)

Subsection 06 (COOLING SYSTEM)

CAUTION: Water pump shaft and impeller have right-hand threads. Remove by turning coun-terclockwise and install by turning clockwise.

Impeller Inspection

Check impeller for cracks or other damage. Re-place impeller if damaged.

Impeller Installation

The installation is the opposite of the removal procedure.

CAUTION: Be careful not to damage impeller wings during installation.

WATER PUMP SHAFT AND SEALS

Shaft/Seal Removal


NOTE: To replace the water pump shaft no. 18 and seals no. 19 and no. 20, engine removal and disassembly is necessary.

Remove engine from vehicle. Refer to ENGINE REMOVAL AND INSTALLATION section.

Remove both cylinders and heads, refer to CYLIN-DER AND HEAD.

Separate crankcase, refer to BOTTOM END. Remove water pump housing and impeller. See procedures in this section.

Remove retaining ring with appropriate pliers




TYPICAL 1. Retaining ring 2. Water pump gear

mmr2007-180


Remove the water pump gear. The water pump gear is held by a needle pin on the water pump shaft.

Remove needle pin and thrust washer.



TYPICAL 1. Water pump gear 2. Needle pin 3. Thrust washer

Using a soft hammer to push out water pump shaft no. 18 with rotary seal no. 19 from inside of crankcase MAG side.



1. Water pump shaft with rotary seal





TYPICAL 1. Oil seal behind the rotary seal 2. Rotary seal bore

Extract oil seal no. 20 from inside of crankcase MAG side with a pusher.

CAUTION: Be careful not to damage the surface of the rotary seal bore in crankcase MAG side.



TYPICAL 1. Extract oil seal with a pusher

Parts Inspection

Inspect water pump gear for wear and damage on the snap mechanism to the needle pin. Replace if damaged.

Shaft/Seal Installation

For installation, reverse the removal procedure. However, pay attention to the following.

When installing water pump shaft, always replace together retaining ring, oil seal, water pump shaft with rotary seal with new parts. CAUTION: Never use the retaining ring a sec-ond time. Always install a new one. Apply engine oil on the water pump shaft and in-termediate shaft. termediate sharts NOTE: Never use oil in the press fit area of the oil seal and rotary seal. Use the oil seal pusher (P/N 529 035 757) and the installer handle (P/N 420 877 650) to install inner oil seal.



Apply Super Lube grease (P/N 293 550 030) inside lips of oil seal no. 20. When installing the oil seal on the pusher, make sure sealing lip points outside.


Push inner oil seal in place.



1. Inner oil seal 2. Installer handle with oil seal pusher



MAGNETO SYSTE	M	
SERVICE TOOLS		
Description	Part Number	Page
crankshaft protector magneto puller	529 036 034 529 035 748	
SERVICE PRODUCTS		
Description	Part Number	Page
Drei Bond sealing compound Loctite 648 (green)	412 711 400	
Loctite /b/ lantiseize lubricant	202 000 070	Contractor and the second seco
Loctite Chisel (gasket remover)		
XP-S synthetic 00040 motor oil	293 600 054	



GENERAL

During assembly/installation, use the torque val-ues and service products as in the exploded view. Clean threads before applying threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITTE APPL/CATION at the beginning of this manual for complete procedure.

🛆 WARNING

Torque wench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES

MAGNETO COVER

NOTE: The magneto cover can be removed with-out removing the engine.

Magneto Cover Removal

Remove muffler. Refer to EXHAUST SYSTEM. Drain engine oil (refer to LUBRICATION SYSTEM). Remove crankshaft position sensor (CPS) and cut tie raps.

Disconnect magneto connector. Remove the dipstick's tube and unscrew its adap-

tor.

Remove magneto cover retaining screws.



Section 05 ENGINE (810) Subsection 07 (MAGNETO SYSTEM)

TYPICAL 1. Magneto cover 2. Retaining screws 3. Crankshaft position senso

Pull magneto cover.

Magneto Cover Inspection and Cleaning

Check magneto cover for cracks or other damage. Replace if necessary. NOTE: Clean all metal components in a non-ferrous metal cleaner. Use the Loctite Chisel (gasket remover) (P/N 413 708 500), or suitable equivalent.

Wear safety glasses and work in a well ventilated area when working with strong chemical products. Also wear suitable non-absorbent gloves to protect your hands.

Magneto Cover Installation


For installation, reverse the removal procedure. However, pay attention to the following. NOTE: At installation replace magneto cover gasket.

Apply Drei Bond sealing compound (P/N 420 297 906) on stator cable grommet as shown in next illustration.



An nhy Drei Bond se

Tightening sequence for screws on magneto cov-er is as per following illustration.



TYPICAL - TIGHTENING SEQUENCE


Refill engine with XP-S synthetic 0W40 motor oil (P/N 293 600 054).

STATOR

Stator Removal

Remove magneto cover (refer to MAGNETO COV-ER above).

Remove screws securing holding strip. Remove stator retaining screws then the stator.



Stator Stator retaining screws Holding strip Holding strip screws

Stator Inspection


Check stator condition. If damaged replace it. Check if stator wires are brittle, hard or otherwise damaged.

For electrical inspection, refer to CHARGING SYS-TEM.

Stator Installation

For installation, reverse the removal procedure. However, pay attention to the following.

CAUTION: When installing the stator take care that the cable is in place (guide for the wire). NOTE: There is only one position for the stator (notch in the magneto housing cover).



ROTOR

Rotor Removal

Lock crankshaft (refer to BOTTOM END). Remove magneto cover. Refer to MAGNETO COVER above.

Using a 14 mm Allen key, remove screw and washer securing rotor to crankshaft.



Install the magneto puller (P/N 529 035 748) and the crankshaft protector (P/N 529 036 034) then remove rotor.




MAGNETO PULLER



CRANKSHAFT PROTECTOR

v2007-181

NOTE: Use grease to place protector on crank-shaft end prior to screw on the magneto puller.



Screw magneto puller bolt to remove rotor.

Rotor Inspection

Check inner side of rotor for scratches or other damage.

Check keyway of the rotor for wear or damages. Check if trigger wheel teeth are bent or otherwise damaged.



1. Rotor with trigger whe

Check woodruff key and keyway on the crankshaft for wear or damages. Replace parts as necessary.

Rotor Installation

For installation, reverse the removal procedure. However, pay attention to the following. Clean crankshaft taper and rotor with pulley flange cleaner (P/N 413 701 809).

267

CAUTION: Taper on crankshaft and rotor must be free of grease. Oil sprag clutch in sprag clutch housing and install sprag clutch gear.



1 Sprag clutch 2 Sprag clutch housing 3 Sprag clutch gear 4. Apply engine oil here

Slide rotor onto crankshaft. The woodruff key and the keyway must be aligned.

Rotate starter double gear counterclockwise to align intermediate gear teeth with sprag clutch gear.



SPRAG CLUTCH Sprag Clutch Removal

Remove magneto cover (refer to MAGNETO COV-ER above). Lock crankshaft (refer to BOTTOM END).

140

Loosen sprag clutch housing screws located in-side rotor. Remove rotor (refer to ROTOR above).

Remove sprag clutch gear.

Remove sprag clutch housing screws and sprag clutch housing.



Sprag Clutch Inspection

Inspect sprag clutch and sprag clutch housing for wear and damage.

Also check the collar of the sprag clutch gear. Perform a functional test of the sprag clutch. To do so, rotate sprag clutch gear in sprag clutch. Sprag clutch must lock in counterclockwise direction.



NOTE: Sprag clutch, housing and gear must be replaced at the same time, if damaged.

Sprag Clutch Installation For installation, reverse the removal procedure. Pay attention to the following details.

Apply Loctite 648 (green) (P/N 413 711 400) on threads of sprag clutch housing screws. Install screws but do not torque yet.

Apply engine oil on sprag clutch and inside sprag clutch gear hole.



Sprag clutch
 Sprag clutch housing
 Sprag clutch gear
 Apply engine oil here

Install rotor then torque sprag clutch housing screws to 30 N•m (22 lbf•ft).

SPRAG CLUTCH GEAR

Sprag Clutch Gear Removal Remove rotor (refer to ROTOR above). Pull sprag clutch gear from the rotor.




Sprag Clutch Gear Inspection Inspect gear, especially teeth and sprag clutch col-lar, for wear and other damage. Check needle bearing condition. Replace sprag clutch gear if necessary.



Sprag Clutch Gear Installation The installation is the reverse of the removal pro-cedure. NOTE: Apply engine oil on needle bearing and col-lar of sprag clutch gear.


STARTER DRIVE GEARS


The starter drive gears are located on the engine MAG side behind the magneto cover. No need to remove engine.




<image><section-header><section-header><text><list-item><list-item><list-item><list-item><list-item><section-header><section-header><section-header>

CYLINDER AND HEA	D	
SERVICE TOOLS		
Description	Part Number	Page
camshaft locking tool	529 035 926	
piston circlip installer	529 035 921	
piston ring compressor		
valve guide installer		
valve guide remover		
valve spring compressor clamp	529 035 724	20
valve spring compressor cup		
SERVICE TOOLS - OTHER SUPPLIE	R	
Description	Part Number	Page
Snap-on pliers	YA 8230	
Loctite 767 (antiseize lubricant)	293 800 070	








Section 05 ENGINE (810) Subsection 08 (CYLINDER AND HEAD)

GENERAL

Components which are identical for both cylinders/cylinder heads are identified in the two exploded views by the same number. Com-ponents which are different or which are, for instance, present of one of the cylinders/cylinder heads but not on the other, have different num-bers. The information given below always relates as a general rule.

Special reference is made in the text to work in-structions which are not the same for cylinder no. 1 and cylinder no. 2.



1. Cylinder 1 (front) 2. Cylinder 2 (rear)

When diagnosing an engine problem, always per-form a cylinder leak test. This will help solving a problem. Refer to the instructions included with your leak tester and to *LEAK TEST* section for pro-cedures.

Always place the vehicle on level surface.

Always place the vehicle on tevel surface. NOTE: For a better understanding, the many illus-trations are taken with engine out of vehicle. To perform the following instructions, it is not neces-sary to remove engine from vehicle. Always disconnect BLACK (-) cable from the bat-tion of the DL (-) cable force working on the ad-

tery, then RED (+) cable before working on the engine

Even if the removal of many parts is not neces-

Even in the removal of many parts is not neces-sary to reach another part, it is recommended to remove these parts in order to check them. During assembly/installation, use the torque val-ues and service products as in the exploded views.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPL/CATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

When disassembling parts that are duplicated in the engine, (e.g.: valves), it is a strongly recom-mended to note their position (PTO/MAG side, front/rear cylinder) and to keep them as a "group". If you find a defective component, it would be much easier to find the cause of the failure among its group of parts (e.g.: you found a worn valve guide. A bent spring could be the cause and it will be easy to know which one among the springs is the cause to replace it if you grouped them at dis-assembly). Also, since used parts have matched together during the engine operation, they will keep their matched fit when you reassemble them together within their "group".

MAINTENANCE

VALVE CLEARANCE ADJUSTMENT

NOTE: Check and adjust valve clearance only when engine is cold.

Remove valve covers. Refer to VALVE COVER. Before checking or adjusting the valve clearance, turn crankshaft to TDC ignition of the respective cylinder, see CAMSHAFT.

Using a feeler gauge, check the valve clearance.


VALVE CLEARANCE		
EXHAUST	0.04 to 0.15 mm (.0016 to .0059 in)	
INTAKE	0.04 to 0.10 mm (.0016 to .0039 in)	

If the valve clearance is out of specification, adjust valves as follows.

NOTE: Use mean value of exhaust/intake to en-sure a proper valve adjustment.

Hold the adjustment screw at the proper position and torque the locking nut.

Section 05 ENGINE (810) Subsection 08 (CYLINDER AND HEAD)



1. Adjustment scre 2. Locking nut 3. Feeler gauge

Repeat the procedure for each valve. Before installing valve covers, recheck valve clearance.

PROCEDURES

VALVE COVER

Cover Removal

Open hood.


Remove:
 - air intake silencer, refer to AIR INTAKE SYSTEM
 - distance screws of valve cover

and the second second

Statistical de la constitución de la

and a second source of the second source of the

A CALL AND A CALL



1. Distance screws 2. Valve cover

- valve cover and gasket.



1. Valve cover 2. Gasket

Repeat the procedure for the other valve cover if required.


Cover Inspection

Check the gasket on the valve cover if it is brittle, cracked or hard. If so, replace the gasket. Cover Installation For installation, reverse the removal procedure.


Torque the valve cover distance screws in a crisscross sequence.

TIMING CHAIN TENSIONER

NOTE: Before removal and installation, make sure that the respective cylinder is set to TDC ignition. Refer to CAMSHAFT.



Section 05 ENGINE (810) Subsection 08 (CYLINDER AND HEAD)



Apply engine oil on the plunger before installing. Apply engine of in the planger before installing. Slightly screw in the planger until the timing chain allows no more back and forth movement of the camshaft timing gear. Then screw in the planger an additional 1/8 turn to reach the required torque of 0.1 N•m (.9 lbf•in).

CAUTION: Improper adjustment of the timing chain will lead to severe engine damage. Fit the spring on one side into the slot of the plug screw and on the other side into the plunger. Turn spring only clockwise in order to fit the spring end into the notch of the plunger and to avoid loosen-ing the plunger during spring installation. Do not preload the spring.

NOTE: Do not forget to place the O-ring on chain tensioner plug.

Then compress the spring and screw in the plug screw.

Finally, tighten the plug screw to 4.5 N•m (40 lbf•in).


CAMSHAFT TIMING GEAR

Gear Removal

Remove the valve cover.

Tum crankshaft to TDC ignition of the respective cylinder, see CAMSHAFT. Unscrew timing chain tensioner.

Onscrew unning chain tensioner. Remove camshaft timing gear screw. To prevent timing chain stretching during removal of camshaft timing gear screw, use the camshaft locking tool (P/N 529 035 926).



Camshaft locking tool Camshaft timing gear screw Camshaft timing gear Tingger wheel (cylinder head 1 only)

Remove the camshaft timing gear. NOTE: Secure timing chain with a retaining wire.


Gear Inspection

Check camshaft timing gear for wear or deteriora-tion.

If gear is worn or damaged, replace it as a set (carnshaft timing gear and timing chain). For crankshaft gear, refer to *BOTTOM END* section, see *CRANKSHAFT*.


Gear Installation

For installation, reverse the removal procedure. Pay attention to the following details. Clean mating surface and threads of camshaft pri-or to assemble camshaft timing gear.




Section 05 ENGINE (810)

Subsection 08 (CYLINDER AND HEAD)



1. Camshaft retaining plate 2. Camshaft retaining plate screw 3. Rocker arms


rocker arm shaftsrocker arm



1. Rocker arm shaft 2. Rocker arm (exhaust side) 3. Rocker arm (intake side) 4. Adjustment screw 5. Locking nut

- thrust washers no. 2.

CAUTION: Pay attention not to lose thrust washers or drop them into the timing chain compartment.



2 thrust washers
 2. Rocker arm (exhaust side)
 3. Cylinder head — spark plug side
 4. Big taper to spark plug side

Rocker Arm Inspection

Inspect each rocker arm for cracks and scored fric-tion surfaces. If so, replace rocker arm assembly, Check the rocker arm rollers for free movement, wear and excessive radial play. Replace rocker arm assembly if necessary.



1. Rocker erm (exhaust side) 2. Roller A. Bore for rocker arm shaft

Measure rocker arm bore diameter. If diameter is out of specification, change the rocker arm assembly.

ROCKER ARM BORE DIAMETER		
NEW	12.036 to 12.050 mm (.4739 to .4744 in)	
SERVICE LIMIT	12.060 mm (.4748 in)	

Check adjustment screws for free movement, cracks and/or excessive play.



Rocker Arm Shaft

Check for scored friction surfaces; if so, replace parts

Measure rocker arm shaft diameter.

à

A Measure rocker arm shaft diameter here

ROCKER ARM SHAFT DIAMETER	
NEW	12.000 to 12.018 mm (.4724 to .4731 in)
SERVICE LIMIT	11.990 mm (.4720 in)


Any area worn excessively will require parts replacement.

Rocker Arm Installation

 $\ensuremath{\operatorname{\textbf{NOTE:}}}$ Use the same procedure for exhaust and intake rocker arm.

Apply engine oil on rocker arm shaft.

- Install the rocker arm shafts with the chamfered edge first and use following procedure: Insert a rocker arm shaft in its bore in cylinder head.
- Install a thrust washer no. 2 then the proper rocker arm no. 3 (exhaust side) or no. 4 (intake side).
- Push in rocker arm shaft until its chamfer reaches the end of rocker arm bore.



Rocker arm shaft
 Thrust washer (timing chain side)
 Thrust washer (spark plug side)

Place the other thrust washer and push rocker arm shaft to end position.
Install the camshaft retaining plate no. 5.

TIMING CHAIN

Refer to BOTTOM END, see TIMING CHAIN.

CYLINDER HEAD

Cylinder Head Removal

Open hood.

Remove air intake silencer. Refer to AIR INTAKE SYSTEM.

Disconnect battery. Refer to CHARGING SYS-TEM.

Drain coolant (refer to COOLING SYSTEM). Remove exhaust pipe. Refer to EXHAUST SYS-TEM.

Unplug coolant hoses on the top of cylinder heads.

Disconnect both spark plug cables. Unscrew the Banjo fitting on the top of cylinder 1.

On MAG side, disconnect the camshaft position sensor (CAPS), the oil pressure switch (OPS) and remove the crankshaft position sensor (CPS) from magneto cover.

On PTO side, disconnect the coolant temperature sensor (CTS) on the top of cylinder 2. Remove screws securing intake manifold to cylin-der heads.

Remove intake manifold with throttle body. 261


mr2007-182

Remove:

chain tensioner (see CHAIN TENSIONER above)
valve cover and gasket (see VALVE COVER above)

camshaft timing gear


camshaft timing gear
 NOTE: Before removing cylinder head screws, blow out remaining coolant by air pressure. Dur-ing cylinder head removal, the remaining coolant in cylinder head could leak into the engine and may contaminate the oil.
 cylinder head screws M6
 cylinder head screws M10 retaining cylinder head and cylinder to cylinder base.



1. Cylinder head screws M10 2. Cylinder head screws M6

Pull up cylinder head.

Remove: - chain guide - cylinder head gasket and scrap it.



1. Cylinder head 2. Timing chain 3. Chain guide 4. Cylinder head gasket

Cylinder Head Inspection

Inspect timing chain guide for wear, cracks or oth-er damages. Replace if necessary. Check for cracks between valve seats, if so, re-place cylinder head.

Check mating surface between cylinder and cylin-der head for contamination. If so, clean both sur-faces.

Clean oil support through the cylinder head from contamination.




1. Oil port to lubricate camshaft lobes intake/exhaust 2. Oil supply to camshaft bearing journal timing chain side 3. Oil supply to camshaft bearing journal spark plug side

Cylinder Head Installation


NOTE: The cylinder heads are not identical in de-sign. Do not invert the cylinder heads at assem-bly.

For installation, reverse the removal procedure. Pay attention to the following details.

Section 05 ENGINE (810) Subsection 08 (CYLINDER AND HEAD) Ensure dowel pins no. 9 are in place. CAMSHAFT 2 -Camshaft Timing NOTE: If a piston (of cylinder 1 or 2) is set to TDC ignition, the camshaft timing gear of the opposite cylinder must be in the following position. 100 1 1. Chain guide (fixed between cylinder and cylinder 2. Chain tensioner guide (mounted in crankca 2.2 Install a NEW cylinder head gasket. TYPICAL 1. Marks on timing gear of the opposite cylin 2. Cylinder head base First, torque cylinder head screws M10 in criss-cross sequence to 20 Nem (15 lbfeft) then finish by tightening to 60 Nem (44 lbfeft). Camshaft Timing Cylinder 2 Install cylinder head screws M6. Turn crankshaft until piston is at TDC ignition as follows. Remove: spark plug cable and spark plug of both cylinders valve covers of both cylinders plug screw and O-ring of magneto cover 2.17 100 2 1 Cylinder head screws M10 2 Cylinder head screws M6 Check chain guide for movement. CAUTION: Chain guide has to be fixed between cylinder and cylinder head. Install camshaft timing gear and perform proper camshaft timing. Refer to CAMSHAFT. TYPICAL 1. Plug screw 2. O-ring Install all remaining components as described in this section. - crankshaft position sensor. 253




Use a 14 mm Allen key to turn crankshaft until piston 2, rear is at TDC ignition.



When rear piston is at TDC ignition, marks on mag-neto flywheel "2" and on the magneto cover are aligned.



At TDC ignition, the printed marks on the camshaft timing gear have to be parallel to cylinder head base.



1. Printed marks on camshaft timing gear 2. Cylinder head base

Combat timing Cylinder 1 Turn cylinder 2 to TDC ignition, see CAMSHAFT TIMING CYLINDER 2. Using a 14 mm Allen key, turn crankshaft 280° counterclockwise, until marks on magneto fly-wheel "1" and magneto cover are aligned.



camshaft.


NOTE: For removal rotate camshaft so that in-take/exhaust lobe shows to upper side of cylinder head.



Area for camshaft lobes
 Camshaft
 Camshaft retaining plate

Camshaft Inspection

Check each lobe and bearing journal of camshaft for scoring, scuffing, cracks or other signs of wear. Measure camshaft bearing journal diameter and lobe height using a micrometer.



A. Camshaft lobe (exhaust valves) B. Camshaft lobe (intake valves) C. Camshaft journal timing chain sid D. Camshaft journal spark plug side

NEW	31 940 to 32 140 mm (1.2575 to 1.2654 in)
SERVICE LIMIT	31.920 mm (1.2567 in)
CAMSHAFT	LOBE (intake)
NEW	32.110 to 32.310 mm (1.2642 to 1.2721 in)
SERVICE LIMIT	32.090 mm (1.2634 in)

	FT JOURNAL chain side)
NEW	34.959 to 34.975 mm (1.3763 to 1.3770 in)
SERVICE LIMIT	34.950 mm (1.3760 in
	FT JOURNAL plug side)
NEW	21.959 to 21.980 mm (.8645 to .8654 in)
SERVICE LIMIT	21.950 mm (.8642 in)

Measure clearance between both ends camshaft and cylinder head.



A. Camshaft bearing journal timing chain side B. Camshaft bearing journal spark plug side

CAMSHAFT BEARING JOURNAL (timing chain side) 35.000 to 35.025 mm (1.3780 to 1.3789 in) NEW SERVICE LIMIT 35.040 mm (1.3795 in)


	ARING JOURNAL plug side)
NEW	22.000 to 22.021 mm (.8661 to .8670 in)
SERVICE LIMIT	22.040 mm (.8677 in)

Replace parts that are not within specifications.

Camshaft Installation For installation, reverse the removal procedure Pay attention to the following details.

CAUTION: The camshafts are not identical i design. Do not invert the camshafts during as sembly. Any mix-up of the components wi lead to engine damage.






1. Valve spring compressor clamp 2. Valve spring compressor cup 3. Valve cotter

Withdraw valve spring compressor, valve spring retainer no. 7 and valve spring no. 6.

Valve Spring Inspection

Check valve spring for visible damages. If so, re-place valve spring.

Check valve spring for free length and straightness.



Replace valves springs if not within specifications.

Valve Spring Installation For installation, reverse the removal procedure. Pay attention to the following details.

Colored area of the valve spring must be placed on top.

To ease installation of cotters, apply oil or grease on them so that they remain in place while releas-ing the spring. NOTE: Valve cotter must be properly engaged in valve stem grooves.



1. Position of the valve spring 2. Valve cotter


After spring is installed, ensure it is properly locked by tapping on valve stem end with a soft hammer so that valve opens and closes a few times.

CAUTION: An improperly locked valve spring will cause engine damage.

VALVE

Valve Removal

Remove valve spring, see VALVE SPRING above. Push valve stem, then pull valves (intake and exhaust) out of valve guide.



1. Intake valves 31 mm 2. Exhaust valves 27 mm

Remove valve stem seal no. 8 with a special pli-ers, such as the Snap-on pliers (P/N YA 8230), and discard it. 1 -.

23

Valve Inspection

Valve Stem Seal

Always install new seals whenever valves are re-moved.

Valve

Inspect valve surface, check for abnormal stem wear and bending. If out of specification, replace by a new one.

 VALVE OUT OF ROUND (intake and exhaust valves)

 NEW
 0.005 mm (.0002 in)


 SERVICE LIMIT
 0.06 mm (.0024 in)

Valve Stem and Valve Guide Clearance

Measure valve stem and valve guide in three places using a micrometer and a small bore gauge.

gauge. NOTE: Clean valve guide to remove carbon de-posits before measuring. Change valve if valve stem is out of specification or has other damages such as wear or friction sur-face.

mmr2007-182




Contraction of the State of the
T VALVE
4.956 to 4.970 mm (.1951 to .1957 in)
4.930 mm (.1941 in)
VALVE
4.966 to 4.980 mm (.1955 to .1960 in)
4.930 mm (.1941 in)

Replace valve guide out of cylinder head if valve guide is out of specification or has other damages such as wear or friction surface (see VALVE GUIDE PROCEDURE below).

Y

	DE DIAMETER exhaust valves)
NEW	5.006 to 5.018 mm (.1971 to .1976 in)
SERVICE LIMIT	5.050 mm (.1988 in)



1. Valve seat 2. Exhaust valve contaminated area 3. Valve face (contact surface to valve seat)

Check valve face and seat for burning or pittings and replace valve or cylinder head if there are signs of damage.


Ensure to seat valves properly. Apply some lapping compound to valve face and work valve on its seat with a lapping tool (see VALVE GUIDE PRO-CEDURE below).

Measure valve face contact width. NOTE: The location of contact area should be in center of valve seat.

Measure valve seat width using a caliper.

VALVE SEAT C	ONTACT WIDTH
EXHAU	ST VALVE
NEW	1.25 to 1.55 mm (.049 to .061 in)
SERVICE LIMIT	2.00 mm (.078 in)
INTAK	E VALVE
NEW	1.05 to 1.35 mm (.041 to .053 in)
SERVICE LIMIT	1.80 mm (.070 in)

If valve seat contact width is too wide or has dark spots, replace the cylinder head.



And the second second

Valve Installation For installation, reverse the removal procedure. Pay attention to the following details. Install a NEW valve stem seal. Make sure thrust washer is installed before installing seal. Apply engine oil on valve stem and install it.

CAUTION: Be careful when valve stem is passed through sealing lips of valve stem seal.



1. Thrust washer 2. Sealing lips of valve stem seal

To ease installation of cotters, apply oil or grease on them so that they remain in place while releasing the spring.

After spring is installed, ensure it is properly locked by tapping on valve stem end with a soft hammer so that valve opens and closes a few times.

CAUTION: An improperly locked valve spring will cause engine damage.

007-182

VALVE GUIDE

Valve Guide Removal

Remove cylinder head (see CYLINDER HEAD above)
valve spring (see VALVE SPRING above)
valves (see VALVE above).

NOTE: Clean valve guide area from contamination before removal.

Using the valve guide remover (P/N 529 035 924), remove valve guide with a hammer.





1. Valve guide remover 2. Valve guide

mmv2007-182

Valve Guide Inspection

Always replace valve stem seals whenever valve guides are removed.

Clean the valve guide bore before reinstalling the valve guide into cylinder head.

Valve Guide Installation

For installation, reverse the removal procedure. Pay attention to the following details. Use the valve guide installer (P/N 529 035 853) to install valve guide.



-1. Valve guide i 2. Valve guide

NOTE: Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) on valve guide prior to install it into the cylinder head.

CAUTION: Push valve guide in the cold cylinder head as per following illustration.



Thrust surface of cylinder head
 Velve guide
 Measurement from thrust surface to valve guide top

	/E GUIDE rement "A")
NEW	14.00 to 14.40 mm (.5512 to .5669 in)

Valve guide to be adjusted in diameter by using a reamer.

Section 05 ENGINE (810) Subsection 08 (CYLINDER AND HEAD) camshaft timing gear (see CAMSHAFT TIMING GEAR) VALVE GUIDE DIAMETER (intake and exhaust valves) cylinder head (see CYLINDER HEAD). 5.006 to 5.018 mm (.1971 to .1976 in) NEW Pull cylinder. Discard cylinder base gaskets 0 1. Valve guide A. Valve guide diameter NOTE: Ensure to turn reamer in the right direction. Use cutting oil and make brakes to clean reamer/valve guide from metal shavings. Cylinder Piston assembly Cylinder base gasket Camshaft timing chain Apply some lapping compound to valve face and work valve on its seat with a lapping tool. TA A Cylinder Inspection Check cylinder for cracks, scoring and wear ridges on the top and bottom of the cylinder. If so, re-place cylinder. 34 6 Cylinder Taper Cylinder Taper Measure cylinder bore and if it is out of specifica-tions, replace cylinder and piston rings. Measure cylinder bore at 3 recommended posi-tions. See the following illustration. 3 AC 14 -¥ 1. Valve seat 2. Valve face (contact surface to valve seat) 3. Turn valve while pushing against cylinder head A. Valve seat angle 45° A NOTE: Ensure to seat valves properly. Apply marking paste to ease checking contact pattern. B Repeat procedure until valve seat/valve face fits together. CYLINDER 1. First measuring of diameter 2. Second measuring of diameter 3. Third measuring of diameter A. 7 mm (276 inf from cylinder bottom 8. 68 mm (2.68 in) C. 32 mm (1.260 in) Cylinder Removal NOTE: Before removal or installation, make sure respective cylinder is set to TDC ignition. Refer to CAMSHAFT. Remove - chain tensioner (see CHAIN TENSIONER)

CYLINDER TAPER IN DIAMETER NEW (maximum) 0.038 mm (.0015 in) SERVICE LIMIT 0.090 mm (.0035 in)

Distance between measurements should not exceed the service limit mentioned above. Cylinder Out of Round

Measure cylinder diameter in piston axis direction from top of cylinder. Take another measurement 90° from first one and compare.

NOTE: Take the same measuring points like de-scribed in CYLINDER TAPER above.

5.L


A. Perpendicular to crankshaft axis B. Parallel to crankshaft axis

CYLINDER O	UT OF ROUND
NEW (maximum)	0.015 mm (.0006 in)
SERVICE LIMIT	0.020 mm (.0008 in)

Cylinder Installation

For installation, reverse the removal procedure. Pay attention to the following details.

Pay attention to the following details. **CAUTION:** Always replace cylinder base gasket before installing the cylinder. First mount cylinder 2. Then remove the crank-shaft locking bolt. Crank the engine further and position piston 1 at TDC. Mount cylinder 1. The cylinder can not be pushed fully over the piston unless the piston is located at TDC. Apply engine oil in the bottom area of the cylinder bore and also on the band of the piston ring com-pressor (P/N 529 035 919) piston ring compressor tool.



NOTE: Put timing chain through the chain pit then put the cylinder in place.

put the cylinder in place. **CAUTION:** Chain guide has to be fixed between cylinder and cylinder head. NOTE: After both cylinders are installed, turn crankshaft until piston of cylinder 2 is at TDC igni-tion and lock crankshaft. Refer to CAMSHAFT. Install cylinder head and the other parts in accor-dance with the proper installation procedures.

PISTON

Piston Removal

NOTE: Before removal or installation, make sure respective cylinder is set to TDC ignition. Refer to CAMSHAFT.

Remove

remove:
 cylinder head (see CYLINDER HEAD above)
 cylinder (see CYLINDER above).
 Place a rag under piston and in the area of timing chain compartment.

Piston circlips are spring loaded.



NOTE: The removal of both piston circlips is not necessary to remove piston pin. Push piston pin out of piston.




1. Piston 2. Piston pin

Detach piston from connecting rod.

Piston Inspection

Inspect piston for scoring, cracking or other dam-ages. Replace piston and piston rings if neces-sary.

Using a micrometer, measure piston at 8 mm (.315 in) perpendicularly (90°) to piston pin.



The measured dimension should be as described in the following tables. If not, replace piston.

PISTON MI	EASUREMENT
NEW	90.950 to 90.966 mm (3.5807 to 3.5813 in)
SERVICE LIMIT	90.850 mm (3.577 in)

Piston/Cylinder Clearance Adjust and lock a micrometer to the piston dimension

NOTE: Make sure used piston is not out of speci-



1. Micrometer set to the piston dimension

With the micrometer set to the dimension, adjust a cylinder bore gauge to the micrometer dimen-sion and set the indicator to 0 (zero). NOTE: Make sure the cylinder bore gauge indica-tor is set exactly at the same position as with the micrometer, otherwise the reading will be false.



1. Use the microm 2. Dial bore gauge ter to set the cy r bore gauge



TYPICAL 1. Indicator set to 0 (zero)

Position the dial bore gauge 20 mm (.787 in) above cylinder base, measuring perpendicularly (90°) to piston pin axis.

Read the measurement on the cylinder bore gauge. The result is the exact piston/cylinder wall clearance.

PISTON/CYLINDER CLEARANCE	
NEW	0.027 to 0.057 mm (.0011 to .0022 in)
SERVICE LIMIT	0.100 mm (.0040 in)

If clearance exceeds specified tolerance, replace piston by a new one and measure piston/cylinder clearance again.

Connecting Rod Small End Radial Clearance Using synthetic abrasive woven, clean piston pin from deposits.

Inspect piston pin for scoring, cracking or other damages. Measure piston pin. See the following illustration for the proper measurement positions.



19.996 to 20.000 mm (.7872 to .7874 in) NEW SERVICE LIMIT 19.980 mm (.7866 in)

Replace piston pin if diameter is out of specifica-tions.

Measure inside diameter of connecting rod small end bushing.



CONNECTING ROD SMALL END DIAMETER 20.010 to 20.020 mm NEW

and the second second second	(.7878 to .7882 in)
SERVICE LIMIT	20.060 mm (.7898 in

Replace connecting rod if diameter of connecting rod small end is out of specifications. Refer to *BOTTOM END* for removal procedure. Compare measurements to obtain the connecting rod small end radial clearance.

CONNECTING ROD SMALL END RADIAL CLEARANCE

SERVICE LIMIT 0.080 mm (.0035 in) Piston Installation

For installation, reverse the removal procedure. Pay attention to the following details.

Apply engine oil on the piston pin.

Insert piston pin into piston and connecting rod.

CAUTION: Take care that piston and connecting rod. CAUTION: Take care that pistons will be in-stalled with the punched arrow on piston top direction to the rear side of the engine. Front cylinder: Mark on top of piston must show to intake side. Rear cylinder: Mark on top of piston must show to exhaust side.




on must show to intake side of cylinder 1 nder 2 t show to exhaust side of cylin

Use the piston circlip installer (P/N 529 035 921) piston appropriate circlip installer to assemble the new piston circlip as per following procedure:



CAUTION: Always replace disassembled pis-ton circlip(s) by new ones. Place a rag on cylin-der base to avoid dropping the circlip inside the engine. Place circlip in sleeve as per following illustra-tion.



1. Circlip 2. Sleeve 3. Assembly jig from piston clip instal

Push taper side of assembly jig until circlip reaches middle of sleeve. Align sleeve with piston pin axis and push assembly jig until circlip engages in piston.



Hold piston while pushing circlip in place Sleeve Assembly jig Direction to push circlip

NOTE: Take care that the hook of the piston circlip is positioned properly.



CORRECT POSITION OF THE PISTON CIRCLIP

PISTON RINGS

Ring Removal

Remove: - cylinder head - cylinder

- piston.

Ring Inspection

Ring/Piston Groove Clearance

Using a feeler gauge measure each ring/piston groove clearance. If the clearance is too large, the piston and the piston rings should be replaced.

RING/PISTON GR	OOVE CLEARANCE	
UPPER COMP	RESSION RING	
NEW	0.030 to 0.070 mm (.0012 to .0028 in)	
SERVICE LIMIT	0.150 mm (.0059 in)	
LOWER COM	PRESSION RING	
NEW	0.020 to 0.060 mm (.0008 to .0024 in)	
SERVICE LIMIT	0.150 mm (.0059 in	
OIL SCR	APER RING	
NEW	0.010 to 0.180 mm (.0004 to .0071 in)	
SERVICE LIMIT	0.250 mm (.0098 in	



1. Piston 2. Feeler gauge

Ring End Gap


Ring End Gap To measure the ring end gap place the ring in the cylinder in the area of 8 to 16 mm (5/16 to 5/8 in) from top of cylinder. NOTE: In order to correctly position the ring in the cylinder, use piston as a pusher. Using a feeler gauge, check ring end gap. Replace ring if gap exceeds above described specified tol-erance.

RING E	ND GAP
UPPER COMP	RESSION RING
NEW	0.20 to 0.40 mm (.008 to .016 in)
SERVICE LIMIT	1.50 mm (.059 in)
LOWER COMP	RESSION RING
NEW	0.20 to 0.40 mm (.008 to .016 in)
SERVICE LIMIT	1.50 mm (.059 in)
OIL SCR	PER RING
NEW	0.20 to 0.70 mm (.008 to .028 in)
SERVICE LIMIT	1.50 mm (.059 in)


Ring Installation


For installation, reverse the removal procedure. Pay attention to the following details.

Pay attention to the following details. NOTE: First install spring and then rings of oil scraper ring. Install the oil scraper ring first, then the lower com-pression ring with the word "N and TOP " fac-ing up, then the upper compression ring with the word "N and TOP" facing up.



Part Number 529 036 031 529 035 617 529 036 033 529 036 032 529 035 917 529 035 917 903 917	Pag 30 31 31 303-30 303-30 309-31
529 036 031 529 035 617 529 036 033 529 036 032 529 036 032 529 035 917	30 31 30
529 036 031 529 035 617 529 036 033 529 036 032 529 036 032 529 035 917	30 31 30
202 000 000	
202 000 000	
. 293 550 030	Pag 307, 31 302, 30





Section 05 ENGINE (810)

Subsection 09 (BOTTOM END)

GENERAL

During assembly/installation, use the torque val-ues and service products as shown in the explod-ed view(s).

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION in INTRODUCTION section.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed newed.

The following components can be serviced with-out removing engine from vehicle: - PTO cover oil seal

- PTO cover
- drive gears
- timing chaintiming chain guide.
- Engine removal is necessary to service the follow-ing components: - engine oil strainer
- crankcase
- crankshaft.

PROCEDURES

PTO COVER OIL SEAL

To replace oil seal no. 2, it is not necessary to remove engine from vehicle and PTO cover from the crankcase.

Oil Seal Removal

Remove belt quard.

Remove drive pulley.

Remove oil seal no. 2 with a small flat screwdriver. CAUTION: Avoid scoring surfaces with tool.

Oil Seal Inspection Check oil seal running surface of crankshaft PTO side for grooves. Replace if necessary.

Oil Seal Installation

The installation is the reverse of the removal pro-cedure.

Pay attention to the following details. Lubricate oil seal with Super Lube grease (P/N 293 550 030).

CAUTION: Oil seal must be installed with seal-ing lip toward the engine. Push oil seal in place by using the oil seal installer (P/N 529 036 033).



OIL SEAL INSTALLER



TYPICAL 1. PTO cover 2. Oil seal 3. Oil seal install


PTO COVER

PTO Cover Removal

Drain engine oil. Disconnect battery. Refer to CHARGING SYS-TEM.

Remove air intake silencer.

Remove drive pulley. Refer to DRIVE SYSTEM. Remove PTO cover screws and pull the cover.



1. PTO cover 2. PTO cover screws 3. Vent hose nipple

it.

mmr2007-183

PTO Cover Inspection

Check the PTO cover for cracks or other damage Replace PTO cover if damaged. Clean oil breather bore in PTO cover from contami-nations with part cleaner then use an air gun to dry


A WARNING

Always wear eye protector. Chemicals can cause a rash break out and injure your eyes.



Check plain bearings no. 1 for scorings or other damages.

aamages. NOTE: Measure plain bearing indeed aameter and compare to crankshaft journal diameter (PTO sup-port bearing). Refer to *CRANKSHAFT* in this sec-tion. Replace if the measurement is out of speci-fication.



Plain bei Oil bore Measure

PLAIN BEARING INSIDE DIAMETER (PTO side support bearing) SERVICE LIMIT 34.120 mm (1.3433 in


Plain Bearing Replacement Procedure Plain Bearing Removal

Train Bearing hemoval Carefully remove the oil seal no. 2 with a screw-driver, without damaging the PTO cover. Push-out the plain bearings from the outside towards the inside using the plain bearing remover/installer (P/N 529 036 032).



PLAIN BEARING REMOVER/INSTALLER - PTO COVER

The PTO cover has to be supported from below with suitable support with straight surface, in or-der to prevent damage of the sealing surface.




PTO co Plain be

Plain Bearing Installation

CAUTION: Unless otherwise instructed, never use hammer to install plain bearings. Use press only.

press only. Install plain bearings with the proper plain bearing remover/installer (P/N 529 036 032) in a cool PTO cover. Do not lubricate plain bearings and/or PTO cover for installation. Carefully press-in the plain bearings in the same direction as during disassembly, from the outside towards the inside. Support PTO cover with suit-able support with strafact, in order to pre-vent damage of the sealing surface. CAUTION: Mark position of oil bore on PTO cover and on plain bearing remover/installer. Align mark on plain bearing remover/installer with mark on PTO cover.



NOTE: Wrong oil bore position will stop oil supply to plain bearings and will damage the engine.

CAUTION: The partition of the plain bearings must be positioned near to oil bore in counter-clockwise direction. (refer to no. 3 in next il-lustration).



1. PTO cover 2. Partition 3. Oil bore

PTO Cover Installation


For installation, reverse the removal procedure, but pay attention to the following details. put pay attention to the following details. NOTE: At installation, replace PTO cover gasket and oil seal. Lubricate oil seal with Super Lube grease (P/N 293 550 030).

Tightening sequence for screws on PTO cover is as per following illustration.



DRIVE GEARS

The drive gears are located on the engine PTO side behind the PTO cover.



Intermediate gear
 Oil pump gear
 Water pump gear
 Breather gear

PTVe Stor. PTO cover (refer to PTO COVER) - intermediate gear no. 3 - ol pump gear no. 4 (refer to OIL PUMP in LU-BRICATION SYSTEM) - water pump gear no. 5. To remove water pump gear, pull the shaft assem-

To remove water pump gear, pull the shaft assembly a bit out and turn it about one teeth until it stays out.

Now you can push water pump gear down. Re-move needle pin no. 6 and pull water pump gear out.

Remove breather gear no. 7.

Drive Gear Inspection Intermediate Gear/Oil Pump Gear/ Water Pump Gear

Inspect gears for wear or other damage. Replace if damaged.

Breather Gear

The engine is equipped with a breather gear which prevents engine oil coming out through the breath-ing system into the air intake silencer.



1. Breather gear 2. V-ring

Inspect gear for wear or other damage.

Check ball bearing for excessive play and smoo operation. Replace breather gear assembly if n essary.

Drive Gear Installation

The installation is essentially the reverse of th moval procedure, but pay attention to the fo ing details.

Install a NEW V-ring no. 8 on the breather g

Adequately oil the ball bearing of the breather gear.

TIMING CHAIN

The engine is equipped with two timing chains. One of the timing chain is located on engine MAG side behind the magneto cover. The second tim-ing chain is located on engine PTO side behind the PTO cover.

Magneto Side Timing Chain Removal Remove:

valve cover, chain tensioner and carnshaft tim-ing gear (refer to CYLINDER AND HEAD) magneto cover and rotor (refer to MAGNETO SYSTEM)

timing chain guide and lower timing chain guide.



Timing chain
 Timing chain guide
 Lower timing chain guide

Carefully pull the timing chain sideward and down from the crankcase.

NOTE: Mark the operating direction of the timing chain before removal.

PTO Side Timing Chain Removal

Remove:


- Nemove:
 valve cover, chain tensioner and camshaft timing gear (refer to *CYLINDER AND HEAD* section)
 PTO cover (refer to *PTO COVER*)
- intermediate gear and breather gear (refer to DRIVE GEARS)
- timing chain guide and lower timing chain guide (see illustration above).

Carefully pull the timing chain sideward and down from the crankcase.

NOTE: Mark the operating direction of the timing chain before removal.

Timing Chain Inspection

Inspection is the same for both timing chains. NOTE: Check timing chain on camshaft timing gear for excessive radial play. Check chain condition for wear and teeth condi-tion.



If chain is excessively worn or damaged, replace it as a set (camshaft timing gear and timing chain),

Timing Chain Installation (MAG and PTO)

The installation is essentially the reverse of the re-moval procedure, but pay attention to the follow-ing details.

Refer to CYLINDER AND HEAD for proper camshaft timing gear installation.

CAUTION: Improper valve timing will damage engine components.

TIMING CHAIN GUIDE



1. Timing chain gu 2. Bearing screw

Guide Removal

Refer to TIMING CHAIN above.

Guide Inspection Check timing chain guide for wear, cracks or other damage. Replace if necessary.

Guide Installation

The installation is the reverse of the removal pro-cedure. Apply Loctite 243 (P/N 293 800 060) to bearing screw.

CRANKCASE


NOTE: Before disassembly, remove engine from vehicle, refer to ENGINE REMOVAL AND INSTAL-LATION.

Crankcase Disassembly

It is recommended to measure crankshaft axial play on PTO end prior to disassemble crankcase. Refer to *CRANKSHAFT*. Remove:

- ervlinder heads and cylinders
 pistons
 PTO cover (refer to PTO COVER)
 drive gears (refer to DRIVE GEARS)

NOTE: Oil pump removal from crankcase is not necessary, but recommended to see condition of oil pump (refer to LUBRICATION SYSTEM sec-tion).



Section 05 ENGINE (810) Subsection 09 (BOTTOM END)

Electric starte Screw

- magneto cover and rotor (refer to MAGNETO SYSTEM section) electric starter drive gears (refer to MAGNETO SYSTEM section)


- SYSTEM section) water pump housing (refer to COOLING SYS-TEM section) oil filter (refer to LUBRICATION SYSTEM sec-tion) cylinder heads, cylinders and pistons (refer to CYLINDER AND HEAD section) timing chains and timing chain guides (refer to TIMING CHAIN).

Remove retaining screws of crankcase.




2 PVPICAL 1. Four screws MB x 85 2. 12 screws MB x 75 3. One screw MB x 35 (13)

Carefully split crankcase halves by using a screwdriver and a soft hammer.




NOTE: During disassembly, do not damage the sealing surfaces of the crankcase halves. Pull crankshaft out of crankcase.

Remove the water pump intermediate shaft and the water pump gear.



Water pump intermediate shaft
 Water pump gear





1. Engine oil strainer 2. Retaining plate 3. Screws


Crankcase Inspection


NOTE: Remove all remaining parts from the crankcase halves; they could get damaged during repair work.

Clean the engine oil strainer with part cleaner and use an air gun to dry it. After cleaning, check if the strainer is damaged (cracks, holes). If so, replace it.

Clean crankcase halves from contaminations and blow the oil supply lines with compressed air.

WARNING Use safety goggles to avoid eye injuries. Check crankcase halves for cracks or other damage. Replace if damaged.





PUSH PLAIN BEARINGS OUTSIDE 1. Crankcase half 2. Plain bearing remover/installer (P/N 529 035 917) 3. Crankcase support sleeve (P/N 529 036 031)

Plain Bearing Installation

CAUTION: Unless otherwise instructed, never use harmer to install ball bearings or plain bearings. Use press only.


Install plain bearings with the plain bearing remover/installer (P/N 529 035 917) in a cool crankcase. Do not lubricate plain bearings and/or crankcase for installation.

NOTE: Place the proper crankcase support sleeve under crankcase halves before installing the plain bearings (refer to BEARING REMOVAL PROCE-DURE).

Carefully press-in the plain bearings in the same direction as during disassembly, from the crankcase inside towards the outside.

During reassembly, make sure not to damage the sealing surfaces of the crankcase halves.

CAUTION: Mark position of oil bore on crankcase half and on plain bearing remover/ installer. Align mark on plain bearing remover/installer with mark on crankcase half.



1. Oil bore position marked on crankcase 2. Oil bore position marked on plain bearing remover/in


NOTE: Wrong oil bore position will stop oil supply to plain bearings and will cause engine damage.

CAUTION: The partition of the plain bearings in crankcase half MAG side must be positioned near to oil bore in clockwise direction (refer to no, 3 in next illustration).




Crankcase half MAG (inside) Oil bore Partition

CAUTION: The partition of the plain bearings in crankcase half PTO side must be positioned near to oil bore in counterclockwise direction (refer to no. 3 in next illustration).



Subsection 09 (BOTTOM END)

Crankshaft Locking Procedure NOTE: When crankshaft is locked, the rear piston (cylinder 2, rear) is at TDC ignition. Crankshaft can not be locked at cylinder 1 (front) TDC. Remove: - spark plug cable and spark plug of both cylinders - valve covers of both cylinders - plug screw and O-ring of magneto cover




TYPICAL 1. Plug screw 2. O-ring

- crankshaft position sensor



TYPICAL 1. Crankshaft position sensor 2. Screw - plug screw with sealing ring.




TYPICAL 1. Plug screw 2. Sealing ring 3. Crankcase PTO side, front side

Use a 14 mm Allen key to turn crankshaft until piston 2, rear is at TDC ignition.



TYPICAL 1. Allen key 14 mm

When rear piston is at TDC ignition, marks on mag-neto flywheel "2" and on the magneto cover are aligned.



2007-183



1. Mark "2" on magneto flywheel 2. Notch on magneto cover 3. Crankshaft position sensor location

Use a screwdriver to check if the groove in the crankshaft is aligned with the hole.



TYPICAL 1. Screw driver

Lock crankshaft with the crankshaft locking bolt (P/N 529 035 617).



TYPICAL 1 Crankshaft locking bolt

Crankshaft Removal Refer to CRANKCASE. NOTE: It is recommended to verify crankshaft ax-ial play before splitting the crankcase. Refer to CRANKSHAFT INSPECTION.

Crankshaft Inspection

Check crankshaft plain bearings as explained in CRANKCASE.

Replace crankshaft if the gears are worn or other-wise damaged.

CAUTION: Components with less than the service limit always have to be replaced. If this is not observed, severe damage may be caused to the engine.



Crankshaft timing gears Connecting Rod Small End Radial Clearance

Refer to CYLINDER AND HEAD section.

Connecting Rod Big End Axial Play Using a feeler gauge, measure distance between butting face of connecting rods and crankshaft counterweight. If the distance exceeds specified tolerance, replace the crankshaft.



 CONNECTING ROD BIG END AXIAL PLAY


 NEW
 0.200 to 0.500 mm (.008 to .020 in)

 SERVICE LIMIT
 0.6 mm (.024 in)

Connecting Rod Big End Radial Play NOTE: Prior to remove connecting rod from the crankshaft, mark big end halves together to ensure a correct reinstallation (cracked surface fits in only one position).

Remove connecting rods from crankshaft. CAUTION: Always replace connecting rod screws no. 11 if removing the connecting rod. It is recommended to replace plain bearings no. 12, in case of installing the connecting rod. Interesting rod screws


Measure crankpin. Compare to inside diameter of connecting rod big end.



1. Micrometer 2. Crankpin area for plain bearing

To measure the connecting rod big end diameter, use the OLD screws no. 11.

Install the OLD plain bearings no. 12 as they were mounted initially. Do the torque procedure as described further.



Service Limit Oo mint Lo24 in/r NeW (1:6545 to 1:6 Crankshaft Radial Play MAG/PTO Side SERVICE LIMIT 42:000 mm (1: 42:000 mm (1: binside diameter of MAG/PTO plain bearing (refer to <i>CRANKCASE</i>). CRANKSHAFT MAG/PTO SIDE RAD CLEARANCE	CRANKSHAF	PIN DIAMETER		
SERVICE LIMIT 19.990 mm (1.574/m) CONNECTING ROD BIG END DIAMETER SERVICE LIMIT 40.100 mm (1.5787/m) CONNECTING ROD BIG END RADIAL CLEARANCE SERVICE LIMIT 0.09 mm (0.035 in) Crankshaft Axial Play Measure crankshaft axial play on PTO end using tolerance, replace crankcase and/or crankshaft. NEW 0.200 to 0.500 mm (0.06 to 0.200 m) (0.06 to 0.200 m) (0.06 to 0.200 m) SERVICE LIMIT 0.6 mm (0.24 in) Crankshaft Radial Play MAG/PTO Side Measure crankshaft on MAG/PTO side. Compare to inside diameter of MAG/PTO plain bearing (refer to CRANKCASE). Construction of MAG/PTO Side Measure crankshaft gray (roff) Measure crankshaft not MAG/PTO Side Measure crankshaft not MAG/PTO plain bearing (refer to CRANKCASE). Construction of MAG/PTO plain bearing (refer to CRANKCASE). Construction of MAG/PTO side. Compare to inside diameter of PTO sup rg. Compare to inside diameter of PTO sup rg.	NEW		347	
CONNECTING ROD BIG END DIAMETER SERVICE LIMIT 40.100 mm (1.5787 in) CONNECTING ROD BIG END RADIAL CLEARANCE SERVICE LIMIT 0.09 mm (0.035 in) Crankshaft Axial Play Measure crankshaft axial play on PTO end using a dai indicator. If the distance exceeds specified tolerance, replace crankshaft. CRANKSHAFT AXIAL PLAY NEW 0.000 to 0.500 mm (0.08 to .020 in) SERVICE LIMIT 0.6 mm (0.24 in) Crankshaft Radial Play MAG/PTO Side Measure crankshaft on MAG/PTO side. Compare to inside diameter of MAG/PTO plain bearing (refer to CRANKCASE). Constant Radial Play MAG/PTO plain bearing (refer to CRANKCASE). Constant Radial Play Constant to the constant of the crankshaft on MAG/PTO plain bearing (refer to CRANKCASE). Constant Radial Play (CONTRONCE) Constant Radial Play (PTO side support bearing) Measure crankshaft on OMAG/PTO plain bearing (PTO side support bearing) Measure constant flournal of PTO sup rg. Compare to inside of PTO sup rg. Compare to i	SERVICE LIMIT	1111111111111		
CONNECTING ROD BIG END RADIAL LEARANCE SERVICE LIMIT 0.09 mm (0035 in) crankshaft Axial Play Magazine crankshaft axial play on PTO end using oblerance, replace crankcase and/or crankshaft. Image: CrankSHAft axial play on PTO end using oblerance, replace crankcase and/or crankshaft. Image: CrankSHAft axial Play 0.000 to .020 in) Image: CrankSHAft axial Play MAG/PTO Side Conside diameter of MAG/PTO Side. Conside diameter of MAG/PTO Side. Conside diameter of MAG/PTO plain bearing (refer o CRANKCASS). Image: CrankSHAft axial MAG/PTO Side CRANKCASS). Image: CrankSHAft on MAG/PTO Side. Conside diameter of MAG/PTO plain bearing (refer o CRANKCASS). Image: Crankshaft nadial Play MAG/PTO Side. Conside diameter of MAG/PTO Side. Conside diameter of MAG/PTO Side. Conside diameter of MAG/PTO Side. Conside diameter of PTO plain bearing (refer o CRANKCASS). Image: Compare to inside dameter of PTO sub right. Compare to inside dameter of PTO sub right. Compare to inside dameter of PTO sub r			au //	12
CLEARANCE SERVICE LIMIT 0.09 mm (0.035 in) Crankshaft Axial Play Weasure crankshaft axial play on PTO end using to dial indicator. If the distance exceeds specified olerance, replace cranksaba and/or crankshaft. CRANKSHAFT AXIAL PLAY Crankshaft Axial Play MCG/PTO side to 020 in) SERVICE LIMIT 0.6 mm (024 in) SERVICE LIMIT 0.6 mm (024 in) Crankshaft Radial Play MAG/PTO Side Measure crankshaft on MAG/PTO plain bearing ifferer to origide diameter of MAG/PTO plain bearing ifferer to crankshaft Radial Play MAG/PTO plain bearing ifferer to CRANKCASE. Correct Address Correct Address Correct Address Correct Address Measure crankshaft numain of PTO sub repring. Corankshaft Radial Play MAG/PTO side RAD CLEARANCE Service LIMIT 0.07 mm (021 in) Crankshaft Radial Play MAG/PTO side RAD CLEARANCE Service LIMIT 0.07 mm (021 in) Crankshaft Radial Play 0.07 mm (021 in) Core diameter of MAG/PTO side RAD CLEARANCE Service LIMIT Out on the model of PTO sub repring. Out on the OPTO sub repring. Measure crankshaft journal of PTO sub repring. Measure crankshaft journal of PTO sub repring. Measure crankshaft journal of PTO sub repr				
Crankshaft Axial Play Weasure crankshaft axial play on PTO end using olderance, replace crankcase and/or crankshaft. Image: crankshaft axial Play Image: crankshaft on MAG/PTO Side Vesure crankshaft on MAG/PTO plain bearing (reference) Image: crankshaft nama (reference)			TRACE	
Adeasure crankshaft axial play on PTO end using clearnce, replace Crankshaft. Image: Crankshaft axial play Image: Cranks	SERVICE LIMIT	0.09 mm (.0035 in)		3
NEW 0.200 to 0.500 mm (008 to 0.20 in) SERVICE LIMIT 0.6 mm (024 in) Crankshaft Radial Play MAG/PTO Side Measure crankshaft on MAG/PTO Side. Compare to inside diameter of MAG/PTO plain bearing (refer to CRANKCASE). Crankshaft Radial Play MAG/PTO plain bearing (refer to CRANKCASE). Crankshaft Radial Play (PTO side support bearing) Measure crankshaft journal of PTO sup rg. Compare to inside diameter of PTO sup rg. Compare	a dial indicator. If the o olerance, replace cran	distance exceeds specified kcase and/or crankshaft.	Instantial and the set of the set	
Constraint Constraint SERVICE LIMIT 0.6 mm (024 in) Crankshaft Radial Play MAG/PTO Side NEW Measure crankshaft on MAG/PTO plain bearing trefer to inside diameter of MAG/PTO plain bearing trefer CRANKCASE.		0.200 to 0.500 mm		
Crankshaft Radial Play MAG/PTO Side Veasure crankshaft on MAG/PTO side. Compare o inside diameter of MAG/PTO plain bearing (refer to CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKCASE). CRANKSHAFT MAG/PTO SIDE RAL CLEARANCE SERVICE LIMIT 42.000 mm (1). CRANKSHAFT MAG/PTO SIDE RAL CLEARANCE SERVICE LIMIT 0.07 mm (0). Crankshaft Radial Play (PTO side support bearing) Measure crankshaft journal of PTO sup ing. Compare to inside diameter of PTO bearing in PTO cover (refer to PTO COV	CERVICE LINUT			42.024 to 42.040
easure crankshaft on MAG/PTO side. Compare inside diameter of MAG/PTO plain bearing (refer <i>CRANKCASE</i>).		0.0 11111 (.024 11)	INEYY	(1.6545 to 1.655
(PTO side support bearing) Measure crankshaft journal of PTO sup ing. Compare to inside diameter of PTi bearing in PTO cover (refer to PTO COV	Crankshaft Radial Pla Measure crankshaft or to inside diameter of M	MAG/PTO side. Compare	CRANKSHAFT M	AG/PTO SIDE RADIA
	Crankshaft Radial Pla Measure crankshaft or to inside diameter of M	MAG/PTO side. Compare	CRANKSHAFT M/ CLE SERVICE LIMIT Crankshaft Radial PI	0.07 mm (.0031
I. Micrometer 2. Crankshaft area for MAG plain bearing 2. Crankshaft area for MAG plain bearing	Crankshaft Radial Pla Measure crankshaft on to inside diameter of M to <i>CRANKCASE</i> .	MAG/PTO side. Compare	CRANKSHAFT M. CEL SERVICE LIMIT Crankshaft Radial PI (PTO side support be Measure crankshaft jo ing. Compare to insid bearing in PTO cover (AG/PTO SIDE RADIA ARANCE 0.07 mm (.0031 ay earing) urnal of PTO suppo e diameter of PTO e refer to PTO COVER



NEW	34.024 to 34.040 mm (1.3395 to 1.3402 in)
SERVICE LIMIT	34.010 mm (1.3390 in

CRANKSHAFT PTO SUPPORT BEARING RADIAL CLEARANCE SERVICE LIMIT 0.10 mm (.0039 in)

Crankshaft Assembly

For assembly, reverse the disassembly procedure. Pay attention to following details. NOTE: Use NEW plain bearings no. 12, when con-necting rod big end diameter is out of specifica-tion.


Put plain bearings correctly in place and clean the split surface on both sides (cracked area) carefully with compressed air.





Half plain bearing of connecting rod big end Split surface of the connecting rod Nose of plain bearing in line with connecting 123 on rod o


NOTE: Oil the plain bearing surface of the con-necting rod and crank pin before installation.

- necting rod and crank pin before installation.
 Torque NEW connecting rod screws no. 11 as per following procedure:
 First, install screws with half of the recommended torque. Do not apply any thread locker.
 Secondly, torque connecting rod screws to 20 New folls locf 40.
 Finish tightening the screws with an additional 60° turn using an angle torque wrench.









Section 06 FUEL SYSTEM Subsection 01 (FUEL TANK AND FUEL PUMP (440F, 550F AND 600))

INSPECTION

FUEL SYSTEM LEAK TEST



TYPICAL 1. Test cap on tank 2. Vacuum/pressure pump

Install a small hose pincher (P/N 295 000 076) on vent line.





On applicable models, ensure primer button is fully depressed. Using the vacuum/pressure pump (P/N 529 021 800), inject air into fuel tank.



Pressurize fuel system as follows.

PRESSURE	TIME TO HOLD PRESSURE
21 kPa (3 PSI)	3 minutes

If pressure drops, locate fuel leak(s) and repair or replace leaking component(s). To ease locating leak(s), spray soapy water on components; bubbles will indicate leak loca-tion(s).

PROCEDURES

DIAPHRAGM FUEL PUMP

Fuel Pump Verification

Check fuel pump valves operation as follows:


Empty fuel tank. NOTE: For the following test, ensure hoses have a tight fit.


Disconnect outlet hose from fuel tank. Alternately apply pressure and vacuum with vacuum/pressure pump (P/N 529 021 800) to disconnected hose. The inlet valve should release with pressure and hold under vacuum.


Disconnect inlet hose from carburetor. Repeat the same procedure to disconnected hose. This time the outlet valve should hold with pressure and release under vacuum.


Fuel Pump Removal


Remove the air intake silencer and carburetor(s). NOTE: Do not disconnect cables from carbure-tor(s).











Using the vacuum/pressure pump (P/N 529 021 800), inject air into fuel tank.



TIME TO HOLD PRESSURE 3 minutes

Section 06 FUEL SYSTEM Subsection 02 (FUEL TANK AND FUEL PUMP (600 HO SDI))

The fuel hose may be under pressure. Cov-er the fuel line connection with an absorbent shop rag. Slowly disconnect the fuel hose to release the pressure. Wipe off any fuel spillage inside engine compartment.

The pressure test will show the available pressure at the fuel pump outlet. It validates the pressure regulator, the fuel pump and leaks in the system. Ensure there is no leak from hoses and fittings. Repair any leak.

Ensure there is enough gas in fuel tank. Disconnect outlet hose from fuel pump.

Install fuel pressure gauge (P/N 529 035 591) be-tween disconnected hose (in-line installation).



Remove tether cord cap. Depress START/IER button and observe fuel pressure. Do not crank engine. Repeat twice. Release pressure using B.U.D.S. between tests so that the gauge is "re-set" to zero (0).

FUEL PRESSURE (when depressing START/RER button) 400 kPa (58 PSI)

Crank or start engine and observe fuel pressure. The fuel pressure should be the same as above. If pressure is within limits, fuel pump and pressure regulator are working adequately. A rapid pressure drop indicates leakage either from the fuel rail or from the fuel pump check valve. Check fuel rail for leaks. If it is not leaking then replace fuel pump.

A slow pressure drop indicates leakage either from the fuel injector or from the fuel pressure regulator. Check fuel injector for leaks (see be-low). If it is not leaking then replace fuel pressure regulator.

NOTE: For resolving a fuel pressure problem, re-fer to TROUBLESHOOTING in this section. Release fuel pressure in the system using B.U.D.S. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS for connections. In B.U.D.S., look in the Activation tab. Remove pressure gauge and plastic clip. Reinstall fuel hose.

Wipe off any fuel spillage in the engine com-partment. Fuel is flammable and explosive under certain conditions. Always work in a well ventilated area.

PROCEDURES


OETIKER CLAMPS

Clamp Replacement To secure or cut Oetiker clamps on fuel lines, use pliers Oetiker 1099 (P/N 295 000 070).





ng clamp








Subsection 02 (FUEL TANK AND FUEL PUMP (600 HO SDI))

Install a torque wrench perpendicularly (90°) to fu-el pump nut wrench (P/N 529 035 899). Torque fuel pump nut to 30 N•m (22 lbf•ft).



2. Torque wrench A. 90°

h.,

Bleed the fuel system as per following procedure. Fuel Bleeding Procedure

The rear fuel pickup hose has to be bled.

Pour 12 L (3.17 U.S. gal.) of recommended fuel in the fuel tank.

Apply parking brake. Start the engine. Let it run at idle speed.

Lift the front of vehicle at a 45° angle.

Put the vehicle back on the ground. Do the above procedure three times.

Stop the engine. The rear fuel pickup hose is now bled

IN-TANK FUEL STRAINER

Strainer Replacement Remove fuel pump as explained above. Replace fuel strainers.

Reinstall fuel pump as explained above.

FUEL FILTER

Filter Replacement

A WARNING Fuel lines remain under pressure at all times. Always proceed with care and use appro-priate safety equipment when working on pressurized fuel system. Wear safety glasses and work in a well ventilated area. Do not allow fuel to spill on hot engine parts and/or on electrical connectors. Proceed with care when removing/installing high pressure test equipment or disconnecting fuel line connections. Use the B.U.D.S. software to release fuel pressure prior to removing a hose. Cover the fuel line connection with an absorbent shop rag. Slowly disconnect the fuel hose to minimize spilling. Wipe off any fuel spillage in the engine compartment. Fu-el is flammable and explosive under certain conditions. Always disconnect battery prior to working on the fuel system.

Fuel filter, inlet and outlet hoses come as an as-sembly.

Use B.U.D.S. release the fuel pressure. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS for connections.

Disconnect both ends of fuel filter line. Unscrew the fuel filter support nut then remove the filter no. 3.

The installation is the reverse of removal procedure.

FUEL TANK

Fuel Tank Removal Open hood.


Release the fuel pressure in the system us-ing B.U.D.S. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS for connections. In B.U.D.S., refer to the Activation tab.

Drain fuel tank no. 1 as much as possible. Remove steering pad. Unbolt handlebar and move it forward.


Unscrew fuel tank nut using wrench (P/N 529 035 603).







FUEL TANK	AND FU	JEL PUMP	(V800)	
SERVICE TOOLS				
Description				
fuel pressure T-fitting leak tester kit pressure gauge small hose pincher.		529 033 100 529 035 709		P
vacuum/pressure pump		529 021 800 529 035 899		



Section 06 FUEL SYSTEM Subsection 03 (FUEL TANK AND FUEL PUMP (V800))

INSPECTION

FUEL SYSTEM LEAK TEST

Fill up fuel tank. Install a small hose pincher (P/N 295 000 076) on vent line.



1. Vent line 2. Small hose pincher

Install the test cap of leak tester kit (P/N 529 033 100) on fuel tank. Install the vacuum/pressure pump (P/N 529 021 800) on test cap.



TYPICAL 1. Test cap on tank 2. Air pump

Pump air to pressurize fuel tank as follows.

	PRESSURE	TIME TO HOLD PRESSURE
F	21 kPa (3 PSI)	3 minutes

If pressure drops, locate fuel leak(s) and repair/ replace leaking component(s). To ease locating leak(s), spray soapy water on components; bubbles will indicate leak loca-tion(s).




The fuel hose may be under pressure. Cov-er the fuel line connection with an absorbent shop rag. Slowly disconnect the fuel hose to release the pressure. Wipe off any fuel spillage inside engine compartment.

The pressure test will show the available pressure at the fuel pump outlet. It validates the pressure regulator, the fuel pump and leaks in the system. Ensure there is no leak from hoses and fittings. Repair any leak.

Ensure there is enough gas in fuel tank. Disconnect outlet hose from fuel pump.



 Install the fuel pressure T-fitting (P/N 529 036 023) and the pressure gauge (P/N 529 035 709) between disconnected hoses (In-line installation). Image: The two pressure that two pressure that the two pressure the two pressure that the two pressure that the two pressure that two pressure that two pressure the two pressure that two pressure the two pressure that two pressure that two pressure that two pressure the two pressure that two pressure the two pressure that two pressure the two pressure that two pressure that two pressure that two pressure that two pressure the two pressure that two pressure that two pressure that two pressure that two pressure the two pressure that two pressure that two pressure that two pressure the two pressure the two pressure that two pressure the two pressure that two pressure the two pressure the two pressure that two preservet the two pressure that two pressure the two pressure th	A slow pressure drop indicates leakage eith from the fuel injector or from the fuel pressu regulator. Check fuel injector for leaks (see b low). If it is not leaking then replace the fu jump. More than the state of the section of the section. Release fuel pressure from fuel gauge value. Remove pressure gauge and T-fitting from ink hose. Reconnect inlet hose. Market and the spillage in the engine com- partment. Fuel is filammable and explosive under certain conditions. Always work in a well ventilated area.
Re-enable fuel pump using B.U.D.S.	Reinstall removed parts.
Ten Piter Idad	
not crank engine. Repeat twice. Release pres-	
sure using valve on fuel gauge. Ensure gauge is "reset" to zero (0).	
FUEL PRESSURE (when installing DESS key)	
345 ± 20 kPa (50 ±3 PSI)	
Crank or start engine and observe fuel pressure. The fuel pressure should be the same as above.	
f pressure is within limits, the fuel pump and pres- sure regulator are working adequately.	
A rapid pressure drop indicates leakage either from the fuel rail or from the fuel pump check valve. Check fuel rail for leaks. If it is not leaking then replace the fuel pump.	




Section 06 FUEL SYSTEM Subsection 03 (FUEL TANK AND FUEL PUMP (V800))

PROCEDURES

FUEL FILTER

Fuel Filter Replacement NOTE: The fuel filter comes as an assembly with the hoses.



The fuel filter is located on LH side of the vehicle in engine compartment near steering column.



1. Fuel filter 2. Steering column

Release fuel pressure. Refer to FUEL PRESSURE TEST above.

Remove console. Refer to *BODY*. Disconnect both ends of fuel filter hoses. On **Skandic SWT**, unscrew fuel filter support then remove the filter with hoses.

Installation is reverse of removal procedure. Install a new Oetiker clamp.

Re-enable fuel pump. Refer to FUEL PRESSURE TEST above.

FUEL PUMP

Fuel Pressure Test Refer to INSPECTION in this section. Fuel Pump Electrical Test NOTE: Ensure fuel pump is enabled in B.U.D.S. Install DESS key. The fuel pump should run for 2 seconds to build up the pressure in the system. If pump does not work, remove console and disconnect its plug connector.



1 Fuel pump connecto

Install a temporary connector to the suspected fuel pump connector to test. Apply 12 V (+) on pin 3 and (-) on pin 4 to this test harness. If pump does not run, replace it.

Otherwise, probe pin 3 and battery ground of fuel pump connector on vehicle harness side.

Install DESS key. You should read battery voltage, otherwise, the problem can be in fuse 4, relay R1, harness or in fuel pump connector. Repair or replace appropriate part.

Check continuity between pin 4 of the fuel pump connector on the vehicle harness side and terminal 29 of the ECM connector "B". If there is no continuity the problem is in the harness. Otherwise, try a new ECM.

Fuel Pump Removal

Remove console, refer to *BODY*. Release fuel pressure and disable fuel pump. Refer to *FUEL PRESSURE TEST* above. Disconnect hose from fuel pump. Disconnect the fuel pump connector.

Section 06 FUEL SYSTEM Subsection 03 (FUEL TANK AND FUEL PUMP (V800))



1. Fuel pump hose 2. Fuel pump connect

With two screwdrivers or a bent rod holding the flange, unscrew the fuel pump nut using fuel pump nut wrench (P/N 529 035 899).





TYPICAL 1. Bent rod

PICAL

Remove fuel pump assembly.

Fuel Pump Installation

For installation, reverse the removal process but pay attention to the following. Ensure to insert strainer to the rearmost and left most position in fuel tank.

most position in fuel tank. Install a new gasket. Align the arrow on fuel pump assembly with the one on fuel tank. Keep arrows aligned when tight-ening fuel pump assembly. Install a torque wrench perpendicularly (90°) to fu-el pump nut wrench (PM 529 035 899). Torque fuel pump nut to 43 N•m (32 lbf•ft).



TYPICAL 1. Arrows 2. Torque wrench A. 90°

Use new clamps to secure hoses to fuel pump fitting.


CAUTION: Make sure that hose clamps are tight to avoid that they turn on their fittings. Re-enable fuel pump. Refer to FUEL PRESSURE TEST above.


FUEL TANK


Fuel Tank Removal Release fuel pressure. Refer to FUEL PRESSURE TEST above. Remove console. Refer to BODY.

Unscrew seat support and move it rearward. Disconnect outlet hose from fuel pump. Disconnect the fuel pump connector. Unplug vent tube from tank.









CARBURETOR

Carburetor Identification All carburetors are identified on their body



TYPICAL 1. Identification: 34-617

Carburetor Removal Lift hood.

Loosen/remove clamp(s) retaining air intake silencer adapter to carburetor(s). Remove the air intake silencer.

NOTE: When applicable, the following procedure applies to both carburetors. Carburetors can be removed individually.

Loosen clamp retaining carburetor to intake adapter.

Remove carburetor from engine. Disconnect fuel inlet line.





Unscrew carburetor cover no. 1 then pull o throttle slide no. 5 from carburetor.





TYPICAL


Disconnect throttle cable from throttle slide. Unscrew choke plunger from carburetor.

Carburetor Disassembly

NOTE: To ease the carburetor disassembly an assembly procedures it is recommended to us carburetor tool kit (P/N 404 112 000).








Main Jet

Remove float bowl as explained above.

Unscrew main jet from carburetor body.

NOTE: To replace main jet by a different size, main jet is accessible through the drain plug without removing float bowl.



Carburetor Cleaning

The entire carburetor should be cleaned with a general solvent and dried with compressed air.

CAUTION: Heavy duty carburetor cleaner may be harmful to the float material and to the rub-ber parts. O-rings, etc. Therefore, it is recom-mended to remove those parts prior to clean-ing.


Carburetor body and pilot/main jets should be cleaned in a carburetor cleaner following manu-facturer's instructions.

Solvent with a low flash point such as gaso-line, naphtha, benzol, etc., should not be used as they are flammable and explosive.

Carburetor Inspection Check inlet needle tip condition. If worn, the inlet needle and seat must be replaced as a matched set.

NOTE: Install needle valve for snowmobile carbu-retor only. It is designed to operate with a fuel pump system.

Check throttle slide no. 5 for wear. Replace as necessary.



Check idle speed screw straightness. Replace as necessary

Check for fuel soaked into float no. 11; replace as necessary.

Check float for cracks or other damages affecting free movement; replace as necessary.

Carburetor Assembly

The assembly is the reverse of the disassembly procedure. Pay attention to the following. Float


Verify float adjustment after installation.


CAUTION: Spark plugs will foul if float is ad-justed too low. Engine may be damaged if float is adjusted too high.

Correct fuel level in float chamber is vital toward maximum engine efficiency. To check for correct float level proceed as follows: - Make sure that float arm no. 9 is symmetrical

not distorted.


With carburetor chamber upside-down on a lev-el surface, measure height "H" between bowl seat and top edge of float arm. Keep ruler per-fectly vertical and in line with main jet hole.






CLIP POSITIONS

Install the nylon packing no. 4 underneath jet nee-die E-clip on all applicable throttle slides. CAUTION: Serious engine damage can occur if this part is not installed.



Install jet needle in throttle slide 550F and 600 Models

When installing jet needle plate, do not obstruct hole in throttle slide.



Carburetor Installation

To install carburetor on engine, inverse removal procedure.


However, pay attention to the following: Prior to installing carburetor, adjust air screw and preliminary idle speed as described in ADJUST-MENTS.

On applicable models, make sure to align tab of carburetor with notch of intake adapter.

CarDiretor with notch of intake adapter. CAUTION: The rubber intake adapter must be checked for cracks and/or damage. At as-sembly, the intake adapter must be perfectly matched with carburetor and engine otherwise severe engine damage will occur.

440F Models

Hook throttle cable into throttle slide.



550F and 600 Models


Hook throttle cable into jet needle plate

Subsection 04 (VM CARBURETORS (440F, 550F AND 600))

Jet Needle

Air Screw

Ensure throttle slide return spring is installed.



1. Throttle cable 2. Jet needle plate 3. Throttle slide

All Models

Install throttle slide with spring in carburetor. CAUTION: Never allow throttle slide to snap shut. Be careful not to bent jet needle.

Tighten carburetor cap

Ensure throttle lever operates normally.

Carburetor Adjustments

NOTE: Carburetor Adjustments NOTE: Carburetor is calibrated at the factory for a temperature of -20°C (0°F) at sea level. For colder temperature or high altitude applications, carbure-tor must be recalibrated. A Service Bulletin gives information about carburetor calibration according to altitude and temperature.

Adjustments should be performed following this sequence: - float height - jet needle - air screw

- preliminary idle speed adjustment
 throttle cable and carburetor synchronization (twin carbs)
- choke cablefinal idle speed adjustment.
- Float Height

Refer to ASSEMBLY to verify float height.

Completely close the air screw no. 6 (until a slight seating resistance is felt) then back off as specified.

Refer to ASSEMBLY to position E-clip in the proper jet needle groove.

-

1. Air screw

NOTE: Turning screw in clockwise enriches mix-ture and conversely, turning it out counterclock-wise leans mixture.


al

Γ	MODEL	AIR SCREW
	440F	1-1/2 turns
	550F	1/2 turn
	600	2 turns
t		

Preliminary Idle Speed Adjustment

Using a drill bit, adjust hortet slide height (see following table) by turning idle speed screw no. 7. Throttle slide height is measured on outlet side of carburetor (engine side). NOTE: Make sure that throttle cable does not hold throttle slide. Loosen cable adjuster accordingly.

MODEL	IDLE THROTTLE SLIDE HEIGHT (drill bit size) ± 0.1 mm (± .004 in)
440F	1.4 (.055)
550F	1.6 (.063)
600	1.5 (.059)



TYPICAL 1 Drill bit used as gauge for throttle s

Throttle Cable and Carburetor Synchronization Refer to THROTTLE CABLE further in this section for proper procedure.


Choke Cable

Adjust choke cable. Refer to CHOKE CABLE further in this section.

Final Idle Speed Adjustment

Final idle Speed Adjustment CAUTION: Before starting engine for the final idle adjustment, make sure that oil pump is adjusted. The oil injection pump adjustment must be checked after each time carburetor idle is adjusted. Refer to OIL INJECTION SYSTEM. Start engine and allow it to warm then adjust idle speed to specifications by turning idle speed screw clockwise to increase engine speed or counterclockwise to decrease it.

CAUTION: Do not attempt to set the idle speed by using the air screw. Severe engine damage can occur.



NOTE: Turn adjustment screw the same amount on each carburetor to keep carburetors synchro-nized.

IDLE SPEED (RPM)

1650

Final idle speed adjustment (engine running at idle speed) should be within 1/2 turn of idle speed screw from preliminary adjustment.

THROTTLE CABLE

MODEL

440F

Throttle Cable Removal NOTE: Before removing throttle cable from vehi-cle, note its routing for installation.

Remove the circlip retaining throttle cable to throttle cable housing.

Using long nose pliers to hold cable, push the end of cable out of its location in throttle lever.

Remove cable from throttle cable housing. Unscrew carburetor cover then pull out throttle slide from carburetor.

440F Models Raise spring and hold while removing retaining plate no. 10 then, remove the jet needle no. 3. 550F and 600 Models

Disconnect throttle cable from needle retaining plate.

Subsection 04 (VM CARBURETORS (440F, 550F AND 600))

1. Throttle cable lock 2. Throttle cable 3. Throttle slide

All Models

Disconnect cable end from oil pump. Cut all locking ties and remove throttle cable.

Throttle Cable Inspection Inspect throttle cable and housing for any damages. Replace as necessary.

Throttle Cable Installation

The installation is the reverse of the removal pro-cedure.

CAUTION: Check that throttle cable is routed away from sharp edges, hot or vibrating parts.


Throttle Cable Adjustment

Ensure the engine is turned OFF, prior to per-forming the throttle cable adjustment.


Carburetor(s) must be installed on engine and throttle cable properly routed.

Adjust throttle cable as per following procedure: Loosen throttle cable housing adjusting and locking nuts.

Ing nuts. While holding throttle lever to wide open throttle position, adjust throttle cable until cut-away lower edge is equal or 1 0 mm (040 in) lower than the venturi bore on engine side. In this position, run cable housing adjusting nut and tighten lock nut. Proceed on both carburetors if applicable. CAUTION: If the throttle slide rests against the carburator cover at full throttle opening, this will create too much strain and may damage the throttle cable or other components in throt-tle mechanism.



FULL OPENING (THROTTLE LEVER AGAINST HANDLE GRIP) 1. Cover 2. Free play 3. Throttle side



FULL OPENING (THROTTLE LEVER AGAINST HANDLE GRIP) 1. Adjusting nut 2. Throttis elide flush or 1.0 mm (040 in) lower than carburetor outlet bore (engine side)

Also ensure that, when throttle is released to idle position, the idle adjusting screw end touches its stopper. No tension should be applied to throttle cable.

CAUTION: Oil pump cable must be readjust-ed whenever throttle cable adjustment or idle speed are changed, otherwise serious engine damage may occur.

Carburetor Synchronization 550F and 600 Models When depressing throttle lever, both carburetor slides must start to open at same time.

Section 06 FUEL SYSTEM Subsection 04 (VM CARBURETORS (440F, 550F AND 600))

Screw or unscrew cable adjuster until all carbure-tor slides start to open at the same time. Cable play will be identical on all carburetors. Retighten jam nut.

CAUTION: Make sure carburetors start to oper-ate simultaneously.



TYPICAL 1. Screw or unscrew adjuster 2. Check that all slides start to open at the same time

CHOKE CABLE

Choke Cable Removal

NOTE: Before removing choke cable, note its routing for installation. Remove choke cable nut and pull cable underneath console.

Unscrew choke cable from carburetor.

Cut all locking ties retaining cable and remove it from vehicle.

Choke Cable Installation The installation is the reverse of the removal procedure.

Choke Cable Adjustment

Set choke lever to half open position.




-


TYPICAL - CHOKE LEVER - HALF OPEN POSITION

Use choke plunger tool (P/N 529 035 602). Insert the choke plunger tool into choke air inlet of carburetor. Tool stopper may not lean against recess wall.



AIR SILENCER SIDE SHOWN 1. Choke plunger tool





GENERAL

There are 3 main systems in interaction with the engine management system: 1. air induction system 2. fuel delivery system 3. electrical system.

OPERATING PRINCIPLE

AIR INDUCTION

Air flows through the air intake silencer. Air pres-sure and temperature are measured at this point. Then, air is drawn through two throttle bodies mounted on the engine. The air flow is controlled by two throttle plates. Fitted on dual throttle body, there is a TPS (Throttle Position Sensor) that sends position information to the ECM.

The throttle bodies are heated by the engine coolant.




THROTTLE BODY ASSEMBLY 1. Coolant hose

The air continues through the reed valves into the cylinder base then the crankcase.

FUEL DELIVERY SYSTEM

Electric Fuel Pump and Fuel Pressure Regulator They provide constant fuel pressure to the fuel rail.

The fuel pump module is located inside the fuel remained that the fuel pump and the solution includes the fuel pump and the fuel pressure regulator. The fuel pump inlet includes a filter.



The fuel pressure regulator controls the pressure in the system and allows the excess of fuel to return to the fuel tank. The fuel pressure regulator regulates the fuel pressure at 400 kPa (58 PSI).

Fuel Rail

The fuel rail is a small tube on which the four in-jectors are mounted. It provides fuel at constant pressure to the fuel injectors. The fuel rail is fed by the fuel pump module.

Fuel Injectors Fuel injectors (two per cylinder) are used to inject fuel into the transfer port of cylinder.

In-Line Fuel Filter


The in-line 10 micron fuel filter is fastened under the steering console. It should be replaced as rec-ommended in MAINTENANCE CHART.



TYPICAL

Fuel Pickups

The two fuel pickups come with 70 micron filter. One is located at the front right side of the fuel tank and the other at the rear left side.



1. Fuel tank 2. Fuel pickups

ELECTRICAL SYSTEM

General

The electrical system is managed by the engine control module (ECM), which is the brain of the engine management system (EMS).



The ECM is mounted in the front of the vehicle.



The ECM is directly powered by the bat-tery. It is responsible for the following engine management/electrical functions: - receiving information from sensors - interpreting information - distributing information

- ignition
 fuel injection

- tell injection
 e-Rave
 e-Rave
 DESS (Digitally Encoded Security System)
 start/stop function
 RER (Rotax Electronic Reverse)
 inference writem
- Hen (Hotax Electronic Revers)
 monitoring system
 diagnostic mode
 limp home mode
 engine modes of operation.

The ECM features a permanent memory that will keep the programmed tether cord cap(s) code, fault codes and other vehicle information, even when the battery is removed from the vehicle.

Charging System

The magneto is the primary source of electrical energy. It transforms magnetic field into electric current (AC).

current (AC). The magneto has a 3 phases, delta wound stator on 18 poles. Capacity is 480 watts. AC current is rectified and regulated between 13.4 and 15 volts DC to charge battery and for the ve-hicle electrical system. The battery supplies the ECM with DC voltage.

Power Distribution

Accessories are protected by fuses located in the fuse holder. Fuses are identified besides their holder.

IMPORTANT: Engine-related sensors and injec-tors are continuously powered from the battery. The ECM switches the ground to complete the electrical circuits it controls. Take this into account when troubleshooting the electrical sys-

The system uses 2 relays

ignition/injectors, fuel pump and starting sys-tem relay (R1)

headlights and accessories relay (R2).

headlights and accessories relay (K2).
 When the START/REF switch is activated, it wakes up the EMS and power the relay (R1), the ECM, the fuel pump, the ignition coil, the injectors, and the gauges. Then, if the cut-off switch and the DESS switch are in position to allow starting and START/REF switch is held, the starter solenoid relay is activated.

When engine reaches approximately 800 RPM, the ECM activates the headlights and accessory relay (R2).

Gauges Voltage Supply

Gauges are supplied with voltage for 30 seconds when connecting the tether cord cap on its post and momentarily pressing the START/RER switch.

NOTE: Each time the tether cord cap is connected to the post and START/RER switch is depressed, the fuel pump is activated for 2 seconds to build up pressure in the fuel injection system.

Automatic Power Shut-Down

The ECM is equipped with an automatic power shut-down. This feature prevents the battery from losing its charge if the tether cord cap is left on the post when the engine is not running for more then 30 seconds. The ECM will remain offline until the START/RER switch or the rewind starter is activated. The ECM will shut down all outputs diff. Seconds when the tether cord cap outputs after 5 seconds when the tether cord cap is removed.

Rotax Electronic Reverse (RER)

Refer to the section in this manual for a complete explanation of the system.

Digitally Encoded Security

System (DESS)

Refer to the section in this manual for a complete explanation of the system

ENGINE MANAGEMENT SYSTEM (EMS)

For this SDI 2-stroke engine, a highly advanced Engine Management System (EMS) has been used to ensure a high power output combined with cleaner combustion. An ECM (Engine Con-trol Module) calculates the proper air/fuel mixture, ignition timing for each cylinder separately. The fuel is injected into the transfer port of each cylin-der.

The ECM controls also the e-RAVE via a solenoid.

FUEL INJECTION

The ECM receives the signals from different sen-sors which indicate engine operating conditions at millisecond intervals.

Signals from sensors are used by the ECM to de-termine the injection parameters (fuel maps) re-quired for optimum air-fuel ratio.

The CPS and TPS are the primary sensors used to control the injection and ignition timing. Other sensors are used for secondary input.

IGNITION SYSTEM

Ignition Timing

The ECM is programmed with data (it contains ig-nition mappings) for optimum ignition timing un-der all operating conditions. Using engine operat-ing conditions provided by the sensors, the ECM controls the ignition timing for optimum engine op-eration.

Ignition Coil

Double ignition coil has two separate windings, one for each spark plug.

Ignition coil induces voltage to a high level in the secondary windings to produce a spark at the spark plug.

Two separate windings circuits are switched to ground through the ECM. Each winding induces high voltage to its corresponding secondary wind-ing to produce a spark.

This ignition system allows spark plugs to spark independently.

CAUTION: Do not interchange spark plug ca-bles. Match reference (PTO or MAG printed on high tension cable yellow tag) with corre-sponding cylinder spark plug.

Double ignition coil is located underneath air intake silencer

Knock Sensor

A knock sensor is mounted on top of the cylinder head. It detects specific vibration that would be typically generated by engine detonation. If detonation occurs, the knock sensor detects it and the ECMs retards the ignition advance and extend the injection period temporarily (it goes in a specific mode) until detonation stops.

E-RAVE

Refer to TOP END (593/793) in this manual for a complete explanation of the system.

ENGINE MODES OF OPERATION

The ECM controls different operation modes of the engine to allow proper operation for all possible conditions. Cranking, start up, idle, warm up, normal operation, engine speed limiter, flooded engine and limp home (see below).

Engine RPM Limiter

The ECM will limit the maximum engine speed.

Drowned Mode (flooded engine)

If the engine does not start and is fuel-flooded, the drowned mode can be activated to prevent fuel injection and to cut ignition while cranking. Proceed as follows:

With tether cord cap on its post while engine is stopped, press completely and HOLD throttle lever.

Press the START/RER button.

Do not attempt to use the rewind starter. The drowned mode is active only by using the electric starter.

The engine should be cranked for 20 seconds. Release START/RER button and throttle lever.

Restart engine normally. NOTE: If the engine does not start, it may be necessary to replace the spark plugs.

Limp Home Mode

The ECM may automatically set default parameters to ensure the adequate operation of the vehicle if a component of the engine management system is not operating properly.

NOTE: Sensor failures will not lead automatically to a limp home mode. The check engine LED will turn on and in some cases the beeper. The engine RPM may be limited if some critical components fail. In this case, releasing throttle and letting the engine returning to idle speed may allow normal operation to come back. If it does not work, try removing and reinstalling the tether cord cap on DESS post.

core cap on UESS post. These performance-reduced modes allow the rider to go back home which would not be possible without this advanced system. Refer to the EMS DIAGNOSTIC AND COMMUNICATION TOOLS for a complete chart.

MONITORING SYSTEM

The ECM monitors the electronic components of the engine management system and other components of the electrical system.

When a fault occurs, it sends a signal to the check engine LED or also to the beeper to inform the driver of a particular condition. Refer to the EMS DIAGNOSTIC AND COMMUNICATION TOOLS.

Low-Oil Level Warning Device

When the oil falls under a certain level, the low oil level LED will be illuminated. The beeper will also be activated intermittently.


High Coolant Temperature Warning Device

When the coolant temperature is getting too high, the ECM sends out signals to the beeper and the high temperature LED. This occurs at 95°C (203°F).

DIAGNOSTIC MODE

The malfunctions are recorded in the memory of the ECM. The memory of the ECM can be checked using the B.U.D.S. software to see the fault codes. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS section.

363



Section 07 ENGINE MANAGEMENT (SDI)

Subsection 02 (EMS DIAGNOSTIC AND COMMUNICATION TOOLS)

EMS DIAGNOSTIC AND COMMUNICATION TOOLS

SERVICE TOOLS

Description	Part Number	Page
Communication kit	529 035 981	
DESS post interface		
MPI-2	529 036 018	
Optional extension cable	529 035 697	
Optional extension cable		
Supply T-harness	529 035 869	

DIAGNOSTIC

GENERAL

Warning lights in speedometer and/or a beeper provide signals as vehicle operation feedback or to indicate a problem. Refer to the following tables for more information.

When there is a problem, the EMS (engine man-agement system) can provide fault codes to ease the troubleshooting. Refer to EMS FAULT CODE TABLES in this section. Fault codes can be read with B.U.D.S. software. Refer to COMMUNICA-TION TOOLS further in this section for more infor-mation. mation

The faults registered in the ECM (engine control module) are kept when the battery is disconnect-

IMPORTANT: After a problem has been solved, ensure to clear the fault(s) in the ECM using the B.U.D.S. software. This will properly reset their states.

Many fault codes at the same time is likely to be burnt fuse(s).

For more information pertaining to the faults code status and report, refer to B.U.D.S. online help or to the EMS fault code tables.

Here is the basic order suggested to diagnose a suspected engine management related problem:
Check if the EMS pliot lamp lights up. If so, use the 8 U D.S. software and look for fault codes to diagnose the trouble.
Check all fuses, relay(s) and battery.
Check vel pressure.
Check spark plugs condition.
Check all connections of the wiring harness.

EMS	FAULT COL	DE TAI	BLES			
		WARNIN	G SIGNA	LS	100	TYA STATISTICS
FAULT	REEPER	LED			A 4.64.5	DESCRIPTION
CODE	BEEPEN	DESS	ENGINE	TEMP	OIL	
P0117	1 short 1 long	-	Blink	-	-	Engine Temperature Sensor fault (voltage too low).
P0118	1 short 1 long	-	Blink	-	-	Engine Temperature Sensor fault (voltage too high).
P0217	1 short 1 long	-	-	Blink	-	High engine temperature detected.
P0336	-	-	-	-	-	High engine RPM detected.
P0513	3 shorts/second repetitive	Blink	-	-	-	Anti theft security: invalid key or key not programmed.
P0605	1 long 3 shorts	-	-	-	-	System fault (calibration checksum).
P0648	-	-	-	-	-	DESS Lamp output fault (shorted to battery/open circuit/shorted to ground).
P0650	-	-	-	-	-	Check Engine Lamp output fault (shorted to battery/open circuit/shorted to ground).
P0654	-	-	-	0-	-	Tachometer output fault (shorted to battery/open circuit/shorted to ground).
P0655		-	-	-	-	Engine Temperature Lamp output fault (shorted to battery/open circuit/shorted to ground).
P1217	1 short 1 long	-	-	Blink	-	Overheat shutdown occurred.
P1655	-	-	-	-	-	DESS communication link fault (shorted to battery).
P1656	-	-	-	-	-	DESS communication link fault (shorted to ground).
P1670	-	-	-	-	-	Buzzer output fault (shorted to battery).
P1671	-	-	-	-	-	Buzzer output fault (open circuit/shorted to ground).
P1675	-	-	-	-	-	Relay output fault (open circuit/shorted to ground).
P1676	-	-	-	-	-	Relay output fault (shorted to battery).
-	1 long/second repetitive	Blink	-	-	-	Engine running in reverse direction.
-	1 short/ 1.5 second repetitive	Blink	-	-	-	DESS key immobilizer (unable to read key)
-	2 shorts	Blink	-	-	_	DESS key immobilizer (good key).

-

Section 07 ENGINE MANAGEMENT (SDI) Subsection 02 (EMS DIAGNOSTIC AND COMMUNICATION TOOLS)

EMS FAULT CODES SUPPLEMENTAL INFORMATION

Fault Code P0336

Fault Code PO336 This code occurs when engine RPM goes too high which could happen under some mechanical-related circumstances and is not necessarily related to a problem with the engine management system.

Fault Code P0654

If this code occurs and tachometer works normal-ly, disregard this fault code.

TPS (Throttle Position Sensor) Faults TPS Faults which are reported in B.U.D.S. fall into two groups; out of range and adaptation failure faults.

TPS "OUT OF RANGE" Fault

It is caused by the sensor reading going out of its allowable range. This fault can occur during the whole range of movement of the throttle. To diagnose this fully, it is recommended to oper-ate the throttle through its full range. It is also rec-ommended to release the throttle quickly as this may also reveal a fault that is intermittent.

POSSIBLE CAUSES	ACTION
Check if connector is disconnected from TPS	Reconnect.
Check if sensor is loose	Tighten sensor and reset Closed Throttle.
Inspect sensor for damage or corrosion	Replace sensor and reset Closed Throttle.
Inspect wiring (voltage test)	Repair.
Inspect wiring and sensor (resistance test)	If bad wiring, repair. If bad TPS, replace and reset Closed Throttle.
Test sensor operation (wear test)	Replace sensor and reset Closed Throttle.

TPS "ADAPTATION FAILURE" Fault

It is caused by the idle position moving out of an acceptable range.

Following problems can be caused by a TPS "Adaptation Failure":
Idle speed is out of range.
Engine stops, when throttle is released quickly.
Engine runs inconsistent in low partload or low RPM.

POSSIBLE CAUSES	ACTION
Sensor has been replaced and TPS closed position not reset	Reset Closed Throttle.
Throttle body has been replaced and TPS closed position not reset	Reset Closed Throttle.
ECM has been replaced and TPS closed position not reset	Reset Closed Throttle.
Throttle cable too tight	Adjust cable and reset Closed Throttle.
Sensor is loose	Tighten sensor and reset Closed Throttle.
Throttle bracket is loose	Fix and reset Closed Throttle.
Adjustment screw worn or loose	Adjust idle speed screw using B.U.D.S.


Section 07 ENGINE MANAGEMENT (SDI) Subsection 02 (EMS DIAGNOSTIC AND COMMUNICATION TOOLS)


COMMUNICATION TOOLS

Two different MPI (Multi-Purpose Interface) can be used with B.U.D.S. software: MPI and MPI-2. Refer to the following for proper connections. NOTE: The MPEM programmer does not work on any liquid cooled models.

NOTE: The MPEM programmer does not work on any liquid cooled models. MPI (Multi-Purpose Interface)

	OPERATION		
PART REQUIRE	PROGRAMMING KEY(S) ENTERING CUSTOMER INFORMATION SETTING IGNITION TIMING/ CLOSED TPS READING FAULT CODES	- ACTIVATION OF COMPONENTS (IGNITION COIL, FUEL PUMP ETC.)	
PC computer	X	Х.,	
B.U.D.S. software Use latest version available on BOSSWeb	x	×	
Communication kit (P/N 529 035 981)	X	x	
Optional extension cable (P/N 529 035 703)	x	x	
Supply T-harness (P/N 529 035 869)	X	x	





	OPERAT	ION
PART REQUIRE	PROGRAMMING KEY(S) ENTERING CUSTOMER INFORMATION SETTING IGNITION TIMING/ CLOSED TPS READING FAULT CODES	- ACTIVATION OF COMPONENTS (IGNITION COIL, FUEL PUMP ETC.
PC computer	X	X
B.U.D.S. software Use latest version available on BOSSWeb	x	x
	X	x
optional extension cable (IP/N 529 035 697)	x	x
ESS post interface (P/N 529 036 019)	x	x
upply T-harness (P/N 529 035 869)	x	x

Section 07 ENGINE MANAGEMENT (SDI) Subsection 02 (EMS DIAGNOSTIC AND COMMUNICATION TOOLS)

Power Supply

MPI-2

The MPI-2 uses the PC computer USB port for its power supply.

DESS Post Interface

The DESS post interface can use the vehicle pow-er for its supply. Two AA batteries or an AC/DC power supply can also be used. Make sure to re-spect the interface specification if a power supply is used.

Connections with Vehicle

If the computer you are using is connected to the power outlet, there is a potential risk of electrocution when working in contact with water. Be careful not to touch water while working with the computer.

Remove the 6-pin connector from the protective cap on the right side of the vehicle.



Connect the supply T-harness (P/N 529 035 869), to vehicle 6-pin connector.



Connect DESS post interface (P/N 529 036 019), to supply T-harness connector.



Connect MPI-2 (P/N 529 036 018) to DESS post interface.



TYPICAL


These models do not need any external 9 V or 12 V power to allow programming and troubleshooting. The use of the supply T-harness will keep the ECM ON. Not using it will make the ECM shuts-off after a few seconds.

CAUTION: Always use the proper supply har-ness and cables. Ensure to respect polarity when connecting cable clips to battery. Match RED cables together.

NOTE

NOTE It is suggested to disconnect headlights fuse and to turn off heated grips to reduce battery discharge rate.

NOTE: Some components will generate heat when leaving vehicle in diagnostic mode for a long period. Always disconnect MPI supply har-ness and supply cable from vehicle/battery when not working on vehicle.



ADJUSTMENT AND REPAIR PROCEDURES

SERVICE TOOLS

Description	Part Number	Page
ECM adapter Fluke 111 multimeter hose pinchers	420 277 010 529 035 868 295 000 076	

SERVICE TOOLS - OTHER SUPPLIER

Description rigid back probe Fluke....

SERVICE PRODUCTS

Description	Part Number	Page
dielectric grease	293 550 004	
Loctite 243 (blue)	293 800 060	
Loctite 512 (pipe sealant)	293 800 018	
	293 800 081	
Loctite 767 (antiseize lubricant)	293 800 070	
oulley flance cleaner	413 711 809	386

GENERAL

Engine problems are not necessarily related to the engine management system.

engine management system. It is important to ensure that the mechanical in-tegrity of the engine and drive system are present: – good transmission system operation – good engine compression and properly operat-ing mechanical components, no leaks, etc. – proper fuel pump pressure and fuel system without leaks.

Check the chart in *TROUBLESHOOTING* section to have an overview of problems and suggested solutions.

When replacing a component, always check its operation after installation.

FUEL SYSTEM

Part Number TP88

The fuel system of a fuel injection system holds much more pressure than that of a car-bureted snowmobile. Prior to disconnecting a hose or to removing a component from the fuel system, follow the recommenda-tion described here. Pay attention that some hoses may have more than one clamp at their ends. Ensure to reinstall the same quantity of clamps at assembly.

Use the latest B.U.D.S. software available from BOSSWeb. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS for proper connection instructions.

Use B.U.D.S. to release the fuel pressure in the system. Look in the Activation section.

Fuel lines remain under pressure at all times. Always proceed with care and use appropri-Always proceed with care and use appropri-ate safety equipment when working on pres-surized fuel system. Wear safety glasses and work in a well ventilated area. Proceed with care when removing/installing high pressure test equipment or disconnecting fuel line connections. Use the B.U.D.S. software to release fuel pressure prior to removing a hose. Cover the fuel line connection with an absorbent shop rag. Slowly disconnect the fuel hose to minimize spilling. Do not allow fuel to spill on hot engine parts and/or on electrical connectors. Wipe off any fuel spillage in the engine compartment. Fuel is flammable and explosive under certain conditions. Always disconnect battery or remove 30 A fuse prior to working on the fuel system. After performing a pressure test, release the pressure.

Always disconnect battery properly or remove 30 A fuse prior to working on the fuel system. Refer to *BATTERY* section.

Fuel Rail and Hose

Pressure at fuel rail is supplied and controlled by the electric fuel pump.

When a repair is completed, ensure that hose be-tween fuel rail and fuel pump is properly secured in the supports. Then, perform a fuel pressure test. Refer to *FUEL SYSTEM*.

To remove fuel rail, refer to FUEL INJECTORS in this sectio

Ensure to verify fuel line connections for damage and that NO fuel line is disconnect-ed prior to installing the tether cord cap on the DESS post. Always perform the high pressure test if any component has been removed. The fuel pump is started and pressure quickly builds-up each time the tether cord cap is installed and the START/RER but-ton is depressed (or rewind starter is pulled).

Never use a hose pincher on injection system high pressure hoses.

 Dattery
 capacitor (manual start models) fuses relays - DESS

- battery

- ignition (spark) ground connections
- wiring connectors.

Wing connectors.
 It is possible that a component seems to operate in static condition but in fact, it is defective. In this case, the best way to solve this problem is to remove the original part and replace it with one which is in good condition.

ELECTRICAL SYSTEM

It is important to check that the electrical system is functioning properly:

which is in good condition. Never use a battery charger to substitute tem-porarily the battery, as it may cause the ECM (engine control module) to work erratically or not to work at all. Check related-circuit fuse solidity and condition with an ohmmeter. Visual inspec-tion could lead to false results.

All electrical actuators (injectors, fuel pump, ignition coils and starter solenoid) are con-tinuously supplied by the battery when the start button is depressed or if engine is rotat-ed (with the rewind starter). Always discon-nect the tether cord cap and the battery pri-or to disconnecting any electric or electronic nats. parts.

Pay particular attention to ensure that pins are not out of their connectors or out of shape. The troubleshooting procedures cover problems not resulting from one of these causes.

CAUTION: Ensure all terminals are properly crimped on wires and connector housings are properly fastened.

Demped of metal and connector housings are properly fastened. Before replacing an ECM, always check electrical connections. Make sure that they are very tight and they make good contact and that they are corrosion-free. Check if wining harness shows any signs of scoring. Particularly check ECM ground connections. Ensure that contacts are good and clean. A "defective module" could possibly be repaired simply by unplugging and replugging the ECM. The voltage and current might be too weak to go through dirty wire pins. Check carefully if pins show signs of moisture, corrosion or if they look dull. Clean pins properly and then coat them prior to assembling as follows:

Section 07 ENGINE MANAGEMENT (SDI) Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES) NOTE: Do not apply dielectric grease or other lu-bricant on the ECM connectors. If the newly replaced ECM works, try the old one and recheck if it works. Ensure that all electronic components are genuine -any modification on the wiring harness may lead to generate fault codes or bad operation. NOTE: For diagnostics purposes, use the latest B.U.D.S. software available from BOSSWeb, Refer to EMS DIAGNOSTIC AND COMMUNICA-TION TOOLS for proper connection instructions. Diagnostic Tools Disconnect the desired connector from ECM and reconnect on the tool connector. Probe required terminals directly in the tool holes. To perform verifications, the Fluke 111 multimeter (P/N 529 035 868) should be used. 55 Ny 1 529 035 868 To easily probe wire terminals through the back of their connectors, rigid back probe Fluke (P/N TP88) pins or equivalent can be used. Resistance Measurement Resistance Measurement When measuring the resistance with an ohmme-ter, all values are given for a temperature of 20°C (68°F). The value for a resistor varies with the tem-perature. The value for common resistor or wind-ings (such as solenoid) increases as the temper-ature increases. However, our temperature sen-sors are NTC types (Negative Temperature Coef-ficient) and work the opposite which means that the value decreases as the temperature increas-es. Use this table for sensor resistive values at given temperature. They can be inserted at the end of the standard probes of the Fluke 111 multimeter. The most recommended and safest method to probe ECM connector terminals is to use the ECM adapter (P/N 420 277 010). This tool will prevent deforming or enlarging terminals which would lead to bad ECM terminal contact creating intermittent or permanent problems.

Т	EMPERAT	URE SEN	SOR TA	BLE		
TEMPE	RATURE	RESISTANCE (OHMS)				
°C	۰F	ATS	CTS	FOR		
-C	4	AIS	ECM	GAUGE		
- 40	- 40	-	72412	-		
- 30	- 22	28000	38681	-		
- 20	- 4	14500	21529	734		
- 10	14	9000	12431	474		
0	32	5500	7418	314		
10	50	3500	4582	214		
20	68	2500	2919	149		
30	86	1750	1912	106		
40	104	1200	1284	77		
50	122	875	883	56		
60	140	600	622	42		
70	158	450	448	32		
80	176	320	328	25		
90	194	239	245	19		
100	212	180	186	15		
110	230	148	143	_		
120	248	119	112	-		
130	266	90	88	_		
135	275	-	79	-		
140	284	-	71	-		
145	293	-	64	-		
150	302	-	57	-		

TEMPERATURE SENSOR TABLE			
TEMPE	TEMPERATURE		
°C	°F	EGTS	
- 40	- 40	170	
- 20	- 4	185	
0	32	201	
25	77	220	
50	122	239	
100	212	276	
150	302	313	
200	392	349	
250	482	385	
300	572	420	
350	662	454	
400	752	488	
450	842	521	
500	932	554	
600	1112	618	
700	1292	679	
800	1472	738	
900	1652	795	
1000	1832	849	

The resistive value of a temperature sensor may test good at a certain temperature but it might be defective at other temperatures. If in doubt, try a new sensor.

detective at other temperatures. It in doubt, try a new sensor. Also remember this validates the operation of the sensor at room temperature. It does not validate the over temperature functionality. To test it, the sensor could be removed from the engine/air silencer and heated with a heat gun (ensure not to heat excessive)/ while it is still connected to the harmess to see if the ECM will detect the high temperature condition and generate a fault code. A good test would be to put sensor in a container filled with ice and water and measure resistance. Then, boil water and read resistance again. According to the table above, an ATS value would be approximately 5500 Ω with ice/water (0°C (32°F)) and 180 Ω with boiling water (100°C (212°F)).

Section 07 ENGINE MANAGEMENT (SDI) Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES) ECM Connector Engine Wiring Harness Check ECM connector pin condition. For ECM connector maintenance and repair procedures, re-fer to *ELECTRICAL CONNECTORS* section. Pin Identification Use the following illustration to locate the pin numbers on the ECM connector (wiring harness side) when performing tests. 12 81 - ECM ECM EGS connector EGTS connector EGTS connector EGTS connector Egration colo connector Egration colo Econector Esconector Esconector Esconector ItS connector ĩ 5 18 1 ALTER TATALANT AND AND A Resistance Test Check continuity of the circuits according to the wiring diagram in the WIRING DIAGRAMS section of this manual. 19 36 If wiring harness is good, check the respective sensor/actuator as described in this section. Engine/Vehicle Connector Use this illustration to locate the pin numbers on the engine connector of the wiring harness when performing tests. Otherwise, repair the connectors, replace the wiring harness or the ECM as diagnosed. Removal 4 3 2 1 Remove air intake silencer. Disconnect the wiring harness from all sensors/ actuators. * * * * * Disconnect the connector from the ECM. D. C. Shareng Cut all locking tie which are holding the wiring har-ness in position. 29 -2 Remove complete wiring harness. 5 6 7 8 Installation First connect the connector "A" to the ECM and the engine connector to the vehicle wiring harness. Reconnect the wiring harness to all sensors/ actuators and reinstall all locking tie that have been removed. ENGINE CONNECTOR PIN-OUT (WIRING HARNESS SIDE) Install all remaining parts, which have been removed.

BASIC ADJUSTMENTS

NOTE: These adjustments are not routine main-tenance. They should be performed only to solve problems when recommended in procedures of this manual.

IDLE SPEED

Idle speed is controlled by the EMS (Engine Man-agement System) and is **not adjustable**. If idle speed is not as per specification (refer to TECHNICAL SPECIFICATIONS), perform the CLOSED THROTTLE RESET.

CLOSED THROTTLE RESET

General

General This operation performs a reset of the throttle po-sition sensor (IPS) values in the ECM. This reset is very important as the setting of the TPS will de-termine the basic parameters for all fuel mapping and several ECM calculations in idle speed control of the engine. Reset must be done each time TPS in the


Reset must be done each time TPS is loosened/ removed or throttle body or ECM is replaced.


CAUTION: An improperly set TPS may lead to poor engine performance.

Adjustment

Excessively unscrew idle set screw until there is a contact between stop lever and zero position screw (capped).

CAUTION: Do not alter setting of the zero po-sition screw, otherwise throttle body must be replaced.





re (zero position screw)

NOTE: If contact cannot be reached, loosen throt-tle cable. See THROTTLE CABLE further. Push throttle lever approximately one quarter than quickly release. Repeat 2 - 3 times to settle throt-tle plates.

Use the B.U.D.S. software.

The throttle opening displayed in Setting tab of B.U.D.S. must be within the following specification

THROTTLE OPENING	1
0.0 - 0.1	
Press Reset button in Closed Throttle.	See illus-

Setting	With throttle lever released, ensure there is som free-play in throttle cable to allow a contact be
- Closed Throfile	tween stop lever and idle set screw.
Closed Throttle	New York Street
Throttle Opening: 0,00 Deg	
Reset	
Hmi-2007 406-600, an	And the second second
NOTE: If TPS is not within the allowed range, the ECM will generate a fault code and will not accept	
the setting. Check if stop lever rest against the	
zero position screw. If so, verify the TPS.	
CAUTION: Do not alter setting of the zero po- sition screw, otherwise throttle body must be replaced.	Em1201-00-001_3
After reset has been accepted, turn in idle set	VIEW BETWEEN THROTTLE BODIES 1. Contact here (idle set screw)
screw until throttle opening value in B.U.D.S. is within the following specification.	Otherwise, loosen throttle cable.
	Set cable adjuster nuts accordingly.
THROTTLE OPENING (idle set screw) Sea level:	
below 1800 m (6000 ft)	A STATE OF
High altitude: 4.95 - 5.05	
above 1800 m (6000 ft)	
Setting	
Closed Throttle	
Throttle Opening: 5,00 Deg	
0,00 Deg	
Reset	
	1911/2007-020-402_8
	1. Cable adjuster nuts
Procedure is completed.	Push throttle lever approximately one quarter the
Verify throttle cable adjustment.	quickly release. Repeat 2 - 3 times to settle thro the plate. Recheck adjustment.
	Use B.U.D.S. software.
THROTTLE CABLE	Perform the wide open throttle (WOT) verification
CAUTION : Do not alter throttle cable routing. It may cause poor startability and erratic idling.	The throttle opening displayed in Setting tab
Handlebar and throttle cable must be at their nor-	B.U.D.S. must be within the following specific tion.
mal position.	and but all and man from the but the ar

Section 07 ENGINE MANAGEMENT (SDI) Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES) Fuel Injector Flow Measurement THROTTLE OPENING (wide open throttle) 82 - 86 Setting D'L -Closed Throttle Throttle Opening: 86.00 Deg Reset NOTE: If value is below the minimum, tighten throttle cable. If value is above the maximum value, loosen throttle cable

IGNITION TIMING

Refer to IGNITION SYSTEM.

REPAIR PROCEDURES

FUEL INJECTORS

Leakage Test and Fuel Flow Measurement

Preparation

First ensure fuel pressure is within specifications. The injectors and fuel rail have to be removed together from the engine. Do not remove injectors from the fuel rail. Refer to FUEL INJECTOR RE-PLACEMENT further in this section as necessary. To ensure continuous fuel availability for the elec-

tric fuel pump, first fill up fuel tank prior to perform-ing the following tests. This is required because engine is not running to activate diaphragm fuel pump with the crankcase pulses.

Leakage Test

Place each injector in a clean bowl.

Install the tether cord cap on the DESS post and press the engine START/RER button to activate the fuel pump.

Check for fuel leakage from the injector nozzle. There should be less than 1 drop per minute. Perform the test for 2 minutes.

If not within specification, replace the fuel injector(s)

Use an appropriate burette graduated for 25 m (.85 U.S. oz). The Pyrex® no. 3075 (or equivalen works fine.



Place injector inside top of burette.



Use B.U.D.S. software.

Install the tether cord cap on the DESS post and press the engine START/RER button to wake up the ECM.

Use appropriate wires and connect fuel pump di-rectly to battery posts to continuously supply fuel pump

Energize the appropriate injector under Injector Flow Measurement in Activation tab.

Energize each injector individually and measure the fuel volume injected. Quantity of fuel must

be within the followi	ing specifications.
INJECTOR	VOLUME of FUEL mL (U.S. oz)

BLUE	16 ± 1 (.54 ±.03)			
If an injector is out	of specification, retest it 2 -			
3 times. If it still fails	s, replace it.			

a times. In it still fails, replace it. If all injectors fail, it is unlikely a failure of injectors. First ensure your reading from the buretle is appropriate (pay attention to the division lines). Ensure fuel tank is full. Test for leaks in fuel system, fuel pump pressure, filter condition (in-line and in tank).

Properly reinstall parts.

Electrical Test

Voltage Test

Tether cord cap must be on DESS post. Use B.U.D.S. software.

Energize the fuel injector from the Activation section.

If the injector does not work, disconnect the connector from the injector.

Install a temporary connector to the injector with wires long enough to make the connection outside the engine compartment and apply voltage (12 V) to this test harness.

This will validate the injector mechanical and electrical operation.

If it does not work, replace it. If it works, continue procedure.

Wake up ECM using START button and measure voltage between pin 1 (of injector on harness side) and battery ground.

If 12 V is read, disconnect connector "A" from the ECM and check continuity of circuit as per following table. If it is good, refer to ENGINE CONTROL MODULE (ECM).
 CIRCUIT NUMBER (ECM connector "A")
 PIN 2 OF INJECTOR HARNESS

 A-15
 Injector 1.1 ^{III} (MAG external)

 A-33
 Injector 2.1 ^{III} (PTO external)

 A-14
 Injector 1.2 ^{III} (MAG internal)

 A-30
 Injector 2.2 ^{III} (PTO internal)

III Injector identification on the wiring diagram. If it does not read 12 V, check the corresponding fusels), relay 1 (refer to LIGHTS, INSTRUMENTS AND ACCESSOFIES) and continuity of circuit. If continuity is faulty, repair wiring harness.


Resistance Test

Disconnect the injector from the wiring harness and check the resistance of the injector itself.

The resistance should be around 14.5 $\Omega_{\rm s}$. If resistive value is incorrect, replace the injector.


Reconnect the injector and disconnect the connector "A" from the ECM as well as the engine connector.

Using a multimeter, check resistive value between terminals as shown in the table below.



ENGINE CONNECTOR

-



ECM CONNECTOR CONTACT LOCATION COMPONENT 4 (Engine connector) and A-15 (ECM connector) Fuel injector, MAG external

Fuel injector, MAG internal	3 (Engine connector) and A-14 (ECM connector)
Fuel injector, PTO external	4 (Engine connector) and A-33 (ECM connector)
Fuel injector, PTO internal	3 (Engine connector) and A-30 (ECM connector)

The resistance should be around 14.5 Ω .


If resistive a live is correct, check wrining of corre-sponting relay. If good, try a new ECM. Refer to ENGINE CONTROL MODULE (ECM) elsewhere in this section.

If resistive value is incorrect, repair the wiring harness/connectors or replace the wiring harness between ECM connector and fuel injector.

Fuel Injector Replacement Removal

Release the fuel pressure in the system using B.U.D.S. Look in the Activation tab. Disconnect fuel hose at the connector.

Wrap a rag around the hose end to prevent rail draining.




Fuel inject

Disconnect wiring harness from the four fuel injectors.

Cut tie raps and remove the wiring harness from the fuel rail. Unscrew rail retaining nuts.

Gently pull rail up by hand, working each side slightly at a time. Pull rail out with fuel injectors.

Then remove the injector clip.



FUEL RAIL ASSEMBLY 1. Fuel injector 2. Injector clip 3. O-ring

Now the fuel injector can be easily pulled out of the fuel rail. Installation

For the installation, reverse the removal proce-dure. Pay attention to the following details. Replace O-rings with new ones.

NOTE: A thin film of engine oil should be applied to O-rings to ease insertion in rail and cylinders.

Insert injectors with your hand. Do not use any tool. Ensure clip and injector are properly installed.

Torque rail retaining nuts to 10 Nom (89 lbfoin).

When installing fuel line connector to the fuel rail, put some oil on the O-ring to ease installation. Attach injector wires with locking tie as shown in following photo.



Add dielectric grease (P/N 293 550 004) to injector electrical connector. Reconnect fuel injector connectors.

Perform a fuel pressure test and ensure that there is no leak. Refer to *FUEL SYSTEM*. Run engine and check for leaks.

ENGINE CONTROL MODULE (ECM)

General

ECM SUPPLY PINOUT		
FUNCTION	PIN	
Power (Vdc)	11	
Signal from voltage regulator to wake up ECM at cranking (manual start only)	36	
Ground	1, 2, 9, 32, 41	

NOTE: Ensure also that relay 1 is functional. Refer to *LIGHTS, INSTRUMENTS AND ACCESSORIES* to test it.

Prior to replacing a suspected ECM, ensure that all the recommendations in the general introduction of this section have been followed.

IMPORTANT: When the ECM is replaced, the DESS key(s), the ignition timing and the **Closed Throttle** must be reprogrammed/reset. Refer to their specific section for adjustment.

To allow transferring the previous recorded infor-mation from the old ECM to the new one, use the B.U.D.S.software. Use Replace ECM in the ECM menu. Follow instructions provided by the help system.

NOTE: If the old ECM can still communicate, it must be read inside B.U.D.S. prior to removing it from the vehicle to carry vehicle information and history to the new ECM.

ECM Replacement

ECM Replacement Prior to replacing a possibly faulty ECM, ensure that all the recommendations in the general intro-duction of this section have been carried out. Al-so, check ECM power supply and all grounds for proper contact/cleanliness and tightness. Disconnect battery cables.

Battery BLA					be	dís

Remove air intake silencer.

Disconnect both connectors from ECM. Unscrew all retaining screws and remove the en-gine ECM from its support. Install the new ECM to the support.

Reconnect ECM connectors to ECM.


Install air intake silencer and connect battery cables.

Transfer the data from the previous ECM to the new one using B.U.D.S. then proceed with the required resets and reprogram tether cord cap(s), if you were unable to transfer the data.

NOTE: If data cannot be transferred, manually en-ter information in Vehicle tab.

After performing the required resets, ensure to clear all faults from the newly replaced ECM. Start the engine and increase engine speed above 6000 RPM to be sure no fault appears.

THROTTLE BODY



Mechanical Inspection

Check that the throttle plate moves freely and smoothly when depressing throttle lever.

IMPORTANT: Do not alter the setting of the zero position screws or synchronization screw, other-wise throttle body must be replaced.

whe directe body thus be replaced. Before replacing any part, check the following as these could be causing the fault. Perform the test while the engine is not running. – Throttle cable adjustment too tight. Not return-ing fully to idle stop.

- Throttle body idle set screw is loose or worn.

- Throttle body idle set screw is loose or worn.
 TPS is loose.
 Corroded or damaged wiring or connectors.
 Throttle body or ECM has been replaced and the
 Closed Throttle reset has not been performed.

Electrical Inspection

Refer to THROTTLE POSITION SENSOR (TPS) be-low.

Replacement

Removal

- To remove the throttle body from engine, proceed as follows: Disconnect connectors from ATS (Air Tempera-ture Sensor). Disconnect air intake silencer from throttle body. Move boot away.

- Install hose pinchers (P/N 295 000 076) on inlet and outlet coolant hoses connected to throttle body.
 Remove clamps and hoses for throttle body heating from nipples.
 Disconnect connectors and hoses from e-RAVE solenoid and TPS.
 Disconnect throttle cable.
 Unscrew retaining clamps of throttle body.



TYPICAL 1. Throttle body 2. Clemp

- Slightly pull throttle body out.

Installation

Installation of the new throttle body is the reverse of the removal procedure. Pay attention to the following details.


Before installation, clean throttle plates and bores with pulley flange cleaner (P/N 413 711 809). Refill engine coolant. If an important quantity of coolant was spilled, bleed cooling system. Refer to COOLING SYSTEM section.

For TPS and e-RAVE solenoid replacement proce-dures, refer to their paragraphs elsewhere in this section.

Throttle Body Synchronization

No synchronization is required as it has already been done at the factory.

CAUTION: Do not alter setting of the zero po-sition screws or synchronization screw. Other-wise throttle body must be replaced.





TYPICAL THROTTLE BODY 1. Synchronization screw

THROTTLE POSITION SENSOR (TPS)

General

NOTE: Before replacing a TPS, ensure there is not too much pull on the wires and they are not chaffed or cuts.

The throttle position sensor (TPS) is a potentiome-ter that sends a signal to the ECM which is propor-tional to the throttle shaft angle.



TLE POSITION SENSOR (TPS)

IMPORTANT: Prior to testing the TPS, ensure that mechanical components/adjustments are adequate according to *THROTTLE BODY* in this section.

The ECM may generate several fault codes per-taining to the TPS. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS section for more information.

Wear Test

While engine is not running, activate throttle and pay attention for smooth operation without physi-cal stops of the cable. Use B.U.D.S. software.

Use the Throttle Opening display under Monitoring

ing Slowly and regularly depress the throttle. Ob-serve the needle movement. It must change gradually and regularly as you move the throttle. If the needle "sitcks", bounces, suddenly drops or if any discrepancy between the throttle move-ment and the needle movement is noticed, it indicates a worm TPS that needs to be replaced.

Voltage Test

Check the voltage output from ECM to the throttle position sensor.

position sensor. Disconnect connector from throttle position sen-sor. To unlock connector, insert a small screwdriv-er between the folded tab. To see the connector pin-out and its pin numbers, temporarily remove the connector shield joining the harness. Install the tether cord cap, turn OFF engine cut-out switch and push START/RER button momentarily to activate the ECM.

Connect a voltmeter between pin 1 and 2 in the wiring harness.

Voltage should be 5 V.

Check the continuity between pin 3 on wiring har-ness TPS connector and pin 24 on wiring harness ECM connector. If tests are good, replace the TPS.

If voltage tests are not good, continue to check the resistance of the rest of the TPS circuit.

Resistance Test

Reconnect the TPS. Disconnect the connector "A" from the ECM.

(25) (24)

1503motr191A



Using a multimeter, check resistive value as per the following table.

ECM CONNECTOR		THROTTLE IDLE POSITION	WIDE OPEN THROTTLE POSITION
PIN	PIN	RESIST	ANCE Ω
A-24	A-25	2500	1000
A-25	A-39	1600 - 2400	1600 - 2400
A-24	A-39	1000	2500

NOTE: The resistive value should change smooth-ly and proportionally to the throttle movement. Otherwise, replace TPS.

Unerwayse, replace 1PS. If resistive values are correct, try a new ECM. Re-fer to *ENGINE CONTROL MODULE (ECM)* else-where in this section. If resistive values are incorrect, repair the connec-tors or replace the wining harness between ECM connector and the TPS.

Replacement

Remove the throttle body as described above. Loosen two screws retaining the TPS. Remove TPS.



THROTTLE BODY 1. Throttle position sensor (TPS) 2. Screws

Install the new TPS. Apply Loctite 243 (blue) (P/N 293 800 060) on the TPS retaining screws, then torque to 3 N•m (27 lbf•in).

Reinstall remaining removed parts Proceed with the Closed Throttle Reset.

CRANKSHAFT POSITION SENSOR (CPS)

NOTE: The CPS is used for forward and reverse.



Disconnect CPS wiring harness connector. Probe terminals coming from CPS while cranking engine. Voltage should be within 1 - 2 Vac. Otherwise, inspect wiring and replace CPS if wiring is good.

Resistance Test

Disconnect the CPS connector from the wiring harness and check the resistive of the sensor it-self.

The resistive value should be between 190 Ω and 300 Ω.

Otherwise, replace the CPS. If sensor tests good, reconnect the CPS and dis-connect the connector "A" on the ECM.

(5) Concerning of the (19) R150

Using a multimeter, measure resistive value be-tween terminals 5 and 19.

tween terminats 5 and 19. If resistive value is correct, try a new ECM. Re-fer to *ENGINE CONTROL MODULE (ECM)* else-where in this section. If resistive value is incorrect, repair the connectors or replace the wiring harness between ECM con-nector and the CPS.

Replacement


Disconnect connectors and remove the rewind starter, then the magneto flywheel. Refer to MAGNETO SYSTEM.

Remove CPS.



When installing new CPS apply Loctite 5910 (P/N 293 800 081) between CPS and crankcase. Torque to 8 Nom (71 lbfoin). Reinstall remaining removed parts.

AIR TEMPERATURE SENSOR (ATS)



Air temperature sensor (ATS)

Resistance Test

Disconnect the connector from the ATS and check the resistance of the sensor itself. Refer to TEMPERATURE SENSOR TABLE at the beginning of this section to find the corresponding resistive value for this sensor temperature.

If out of specification, replace the sensor.

If resistance tests good, reconnect the ATS and disconnect the connector "A" on the ECM. The second 21 R1503motr186A

Using a multimeter, recheck resistive value between terminals 7 and 21. If resistive value is correct, try a new ECM. Re-fer to ENGINE CONTROL MODULE (ECM) else-where in this section.

If resistive value is incorrect, repair the connectors or replace the wiring harness between ECM connector and the ATS.

Replacement


Disconnect ATS connector.

Pull the ATS out of the air intake silencer. Spray soapy water on grommet. Install grommet on air intake silencer then push the sensor in place. Reconnect it.

COOLANT TEMPERATURE SENSOR (CTS)

Resistance Test

Disconnect the connector from the CTS and check the resistive of the sensor itself.




The resistance between pin 1 and 2 is used for temperature gauge.


Refer to TEMPERATURE SENSOR TABLE at the beginning of this section to find the corresponding resistive value for this temperature sensor.

If out of specification, replace the sensor. The resistor between pin 3 and 4 is used for ECM. Refer to *TEMPERATURE SENSOR TABLE* at the beginning of this section to find the corresponding resistive value for this temperature sensor.

If out of specification, replace the sensor. If sensor tests good, reconnect the CTS and disconnect the connector "A" on the ECM as well as the engine connector.



(11)



Using a multimeter, measure resistive value between terminals 5 and 6 on engine connector. This resistor is used for temperature gauge. Refer to TEMPERATURE SENSOR TABLE at the

Refer to TEMPERATURE SENSOR TABLE at the beginning of this section to find the corresponding resistive value for this sensor temperature. Also measure resistive value between terminals

Also measure resistive value between terminals 11 and 27 on ECM connector "A". This resistor is used for ECM. Refer to TEMPERATURE SENSOR TABLE at the

Refer to TEMPERATURE SENSOR TABLE at the beginning of this section to find the corresponding resistive value for this sensor temperature.

If resistive value is correct, try a new ECM. Refer to ENGINE CONTROL MODULE (ECM) elsewhere in this section.

If resistive value is incorrect, repair the connectors or replace the wiring harness between ECM connector and the CTS.


Replacement

Drain cooling system. Disconnect CTS connector and remove CTS. Apply Loctite 512 (pipe sealant) (P/N 293 800 018) on CTS threads.

Install the new CTS and torque to 12 N•m (106 lbf•in).

Reinstall remaining removed parts. Refill engine coolant and bleed cooling system. Refer to LIQUID COOLING SYSTEM section.

AIR PRESSURE SENSOR (APS)



Ensure sensor is correctly installed on air intake si-lencer. Otherwise, the APS could generate a fault code. Remove sensor and check for oil or dirt on its end and if problem persists, check the wiring harness. Perform the following tests.

Voltage Test

Check the voltage output from ECM to the APS. Install the tether cord cap, turn OFF engine cut-out switch and push START/RER button momentarily to activate the ECM.

Disconnect connector from APS and connect a voltmeter between pin 1 and 2 of wiring harness. Voltage should be 5 V.

Check the continuity between pin 3 on APS connector and pin 18 on ECM connector.

If tests are good, replace the APS.

If tests are not good, continue to check the conti-nuity of the rest of the APS circuit on the harness. Disconnect the connector "A" from the ECM.

Using a multimeter, check continuity of circuits as per following table.

CIRCUIT NUMBER (ECM connector "A")	APS CONNECTOR
A-3	Pin 1
A-4	Pin 2
A-18	Pin 3

If wiring harness is good, try a new ECM. Refer to ENGINE CONTROL MODULE (ECM) elsewhere in this section.

Otherwise, repair the connectors or replace the wining harness between ECM connector and the APS.

Replacement

Disconnect APS connector and remove the APS. The APS is retained with a screw. Install the new APS.

EXHAUST GAS TEMPERATURE SENSOR (EGTS)



1. Muffler 2. Exhaust gas temperature sensor (EGTS)

Resistance Test

Disconnect the connector from the EGTS and check sensor resistor.

Refer to TEMPERATURE SENSOR TABLE at the beginning of this section to find the corresponding resistive value for this sensor temperature. If out of specification, replace the sensor.

If resistor tests good, reconnect the EGTS and disconnect the connector "A" on the ECM. Using a multimeter, measure resistive value be-tween terminals 10 and 26.

If resistive value is correct, try a new ECM. Re-fer to ENGINE CONTROL MODULE (ECM) else-where in this section. If resistive value is incorrect, repair the connector or replace the wiring harness between ECM con-nector and the EGTS.

Removal

NOTE: If sensor is removed from muffler to then be reinstalled, verify if there is a green dot on sen-sor. If not, scribe a reference mark on sensor fac-ing the right side of the vehicle. Disconnect EGTS connector.

Remove EGTS.

Installation

Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) over the EGTS threads to prevent possible seizure.

Install sensor and turn it so that its green dot (or reference mark) will be facing the right side of the vehicle.

NOTE: The sensor needs to be oriented in this specific position for optimum efficiency. Torque the EGTS to 45 N•m (33 lbf•ft) while preventing sensor to turn.

Replug connector.

KNOCK SENSOR (KS)



Knock sensor (KS

Dynamic Test

Lift rear of vehicle off the ground and support it with a wide-base mechanical stand. Use B.U.D.S. software.

Monitor the knock sensor using the Faults section

Start the engine and bring engine RPM above 6000 RPM. If no fault code occurs, the knock sensor is good.

Otherwise, do the following. Ensure sensor and head contact surfaces are clean and mounting bolt and washer are correct and properly torqued down.

Check the knock sensor circuit on wiring harness. Disconnect the connector from knock sensor har-

ness. Disconnect connector "A" form the ECM and check continuity of circuit as per following table.



CIRCUIT NUMBER (ECM connector "A")	KS CONNECTOR	
A-22	Pin 1	
A-8	Pin 2	

If test is not good, repair the connector or replace the wiring harness between ECM connector and knock sensor.


Replacement


Unscrew and remove knock sensor from cylinder head.

Clean contact surface, apply Loctite 5910 (P/N 293 800 081) on both contact surfaces on the knock sensor then install the new sensor.

CAUTION: Install screw and torque it within 10 minutes to prevent the sealant to dry be-fore torquing. A dried sealant before torquing would impair the knock sensor operation. Torque screw to 24 Nom (18 lbfoft).

CAUTION: Improper torque might prevent sen-sor to work properly and lead engine to severe damage of internal components.





OPERATING PRINCIPLE

A highly advanced engine management system (EMS) has been used to ensure a high power output with cleaner combustion.


Dut with cleaner combustion. There are 3 main systems in interaction with the engine management system (EMS): 1. air induction 2. fuel system 3. electrical system.

AIR INDUCTION

Air flows through air intake silencer, throttle body, intake manifold and then goes into combustion chamber. Air pressure and temperature are mea-sured directly in the intake manifold.

Throttle Body


The 46 mm throttle body is mounted on the side of intake manifold. Fitted on the throttle body, there is the TPS and the idle bypass valve which allows the ECM to control the idle speed while the throt-tle plate is closed.



TYPICAL 1. Intake manifold 2. Throttle body 3. Idle bypass valve

Intake Manifold

The intake mainfold is mounted on the top of the engine on both cylinder heads. It provides support for the throttle body, fuel injectors, the fuel rails and the MAPTS (manifold air pressure and tem-perature sensor).



re and temperature sensor (MAPTS)

FUEL SYSTEM

During the intake stroke, the ECM (engine con-trol module) activates the fuel injector and fuel is sprayed into the intake port. The injector uses the high pressure inside the fuel rail. The air/fuel mix-ture then enters the combustion chamber through the open intake valve. This mixture is then ignit-ed by the spark plug at the end of the compression stroke.

Fuel Rail

The fuel rail distributes the correct fuel pressure to each injector which are mounted on the intake manifold. The fuel rail is fed by the fuel pump at a specific fuel pressure.

Fuel Injector


Two fuel injectors (one per cylinder) are used to inject fuel into the intake port of the cylinder head.

Fuel Pump Module

The fuel pump module is inside fuel tank. The fuel pump inlet includes 2 fuel pickups with nylon filters. Refer to FUEL SYSTEM.

Ø The module includes the fuel pump and the fuel pressure regulator. An inline filter is used.

The ECM is located under fuse box



Fuel Pressure Regulator

B R

A fuel pressure regulator, inside fuel pump mod-ule, controls the pressure in the system. Excess fuel is returned to the fuel tank. Refer to *FUEL* SYSTEM.

ELECTRICAL SYSTEM

A communication link (CAN lines) is used to com-municate between the ECM and the B.U.D.S. soft-ware. CAN lines consist of a pair of WHITE wires. Refer to EMS DIAGNOSTIC AND COMMUNICA-TION TOOLS.

Engine Control Module (ECM)

The ECM controls the electrical system and the engine management functions by processing the information given by various sensors.

The ECM features a permanent memory that will keep the programmed DESS keys, fault codes, customer information and other engine informa-tion, even when the battery is removed from the unbield.

vehicle. When START button is activated, the ECM ini-tiates a self-diagnostic mode. However, some components need the engine to be running so that they can be monitored. Some problems will turn on a warning lamp and will set the engine in limp home mode. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS section for more information. vehicle.

Digitally Encoded Security System (DESS)

If there is no DESS key on its post, no cranking is allowed.

If an unprogrammed DESS key is installed on its post, engine may crank and run but drive pulley will not engage. Refer to DESS SYSTEM.

Power Distribution

Electrical system is protected by fuses located in the fuse box. Refer to *LIGHTS, INSTRUMENTS* AND ACCESSORIES.

Engine-related sensors and injectors are con-tinuously powered from the battery when the ECM is woken up. The ECM switches the ground to complete the electrical circuits it controls. Take this into account when trou-bleshooting the electrical system. Always disconnect the battery prior to disconnecting any electric or electronic parts.

Expedition TUV


The system uses 3 relays that control different components. See illustration.



R1 ECM, EMS lig R2 Lights and aci R3 Cooling fan ors fuel ournol and dauge

Skandic SWT

The system uses 4 relays that control different components. See illustration.



R1. ECM, EMS (ignition/inje R2. Lights and accessories R3. Cooling fan R4. Rear power outlet mp) and gauge

Skandic SWT and Expedition TUV

Skand: SWI and Expedition IDV When the START button is briefly pressed or held, it wakes up the EMS and powers the relay 1. Then, if the cut-off switch and the tether cord are in the RUN position while the START position is held, the starter solenoid is activated.


When engine reaches approximately 800 RPM, the ECM activates the relay 2.

The ECM controls relay 3 at predefined tempera-ture tresholds to start and stop cooling fan. The relay 4 (Skandic SWT) is activated when the rear power outlet switch is turned on.

Gauges Current Supply

Gauges are supplied with current for 30 seconds when briefly pressing START button. At the same moment, the fuel pump is activated for 2 seconds to build up pressure in the fuel injection system. Automatic Power Shut-Down

Automatic Power Shit-Down The ECM is equipped with an automatic power shut-down. This feature prevents the battery from discharging if the ignition key is left in the ON position when the engine is not running for more then 30 seconds. The ECM will remain offline until the START button is pressed.



The ignition coil is located next to fuse box.



Ignition Timing

Ignition Timing The ECM is programmed with data (it contains ignition mappings) for optimum ignition timing under all operating conditions. Using engine operating conditions provided by the sensors, the ECM controls the ignition timing for optimum engine operation. There is no mechanical adjustment to perform.

ENGINE MODES OF OPERATION

Engine RPM Limiter

The ECM will limit the maximum engine speed to approximately 8000 RPM by cutting fuel injection and ignition.

The ECM uses the CPS for this function.

Limp Home Mode

The ECM may automatically set default parameters to the engine management to ensure the adequate operation of the engine if a component of the fuel injection system is not operating properly. The engine will operate with reduced performance to protect the engine. In more severe cases, the engine RPM will be limited, also to protect the engine.

These performance-reduced modes allow the ider to go back home which would not be otherwise possible without this advanced system. Refer to the EMS DIAGNOSTIC AND COMMUNICATION TOOLS for a complete chart.

In the following situations, engine RPM will be limited.

CONDITION	MAX ALLOWED RPM
High engine temperature	5000
Low oil pressure	4500
Safety fuel cut-off (TPS or internal memory error)	5000

Drowned Mode (flooded engine)

If engine is fuel-flooded and does not start, this special mode can be activated to prevent fuel injection and ignition while cranking. Proceed as follows to activate it.

Install tether cord and set engine cut-off switch to RUN. Press and HOLD throttle lever at WOT position.

Press START button. The mode is now on.

If engine does not start, it may be necessary to remove spark plugs and crank engine with rags over spark plug holes. Refer to ADJUSTMENT AND REPAIR PROCEDURES subsection.

To leave the drowned mode, release START button and throttle lever.

MONITORING SYSTEM

The ECM monitors the electronic components of the fuel injection system and also parts of the electrical system. When a significant fault occurs, it sends visual messages through the signals through a beeper to inform you of a particular condition. Refer to the EMS DIAGNOSTIC AND COMMUNICATION TOOLS for a chart.

For some faults, the warning light/beeper may disappear automatically when the condition no longer exists.

Releasing throttle and letting the engine returning at idle speed may allow normal operation to come back. If it does not work, try stopping engine then restarting it. An analysis of occurred faults using B.U.D.S. is recommended. Refer to the EMS DI-AGNOSTIC AND COMMUNICATION TOOLS.

Battery Voltage Warning Device

When the battery voltage is either too low or too high, the ECM sends out a signal to the check engine light, battery light and beeper will warn. Limp home will be set.

Low Oil Pressure Warning Device When the oil pressure falls under a certain level, the OPS sends out a signal to the low oil pressure light and to the ECM. The ECM then activates the check engine light. Limp home will be set.

Cooling Fan


The ECM controls the cooling fan. Whenever intake temperature or engine coolant temperature reaches a certain threshold, the ECM triggers the fan relay to start the fan. When temperature cools down to a certain threshold, the ECM stops the fan. See table below.

ENGINE TEMPERATURE	INTAKE TEMPERATURE	COOLING FAN	CHECK ENGINE LIGHT	LIMP HOME MODE
	50°C (122°F)	Turns ON		
	45°C (113°F)	Turns OFF		
100°C (212°F)		Turns ON		
95°C (203°F)		Turn OFF		
118°C (244°F) (1)		ON	Flashes	Engine RPM limited to 4000

(1) Engine will automatically shut down after idling 30 seconds.

When engine is stopped by using the cut-out switch and the engine temperature is high, the cooling fan will remain on approximately 30 seconds. NOTE: If engine is stopped by removing the DESS key, cooling fan will immediately stop.





EMS DIAGNOSTIC AND COMMUNICATION TOOLS

SERVICE TOOLS

Description	Part Number	Page
Communication kit		
DESS post interface	529 036 019	406-407
Diagnostic cable	710 000 851	
MPI-2	529 036 018	
Optional extension cable	529 035 697	
Optional extension cable		
supply T-harness		
Supply T-harness	529 035 869	

GENERAL

GENERAL.
Here is the basic order suggested to diagnose a suspected engine management or fuel injection related problem:
Check the chart in the *TROUBLESHOOTING* section to have an overview of problems and suggested solutions.
Check the engine management system (EMS) piot lamp blinks. It so, use the B UD.S. software and look for fault codes to diagnose the trouble.
Check all these.
Check relay 1.
Check spart plugs condition.
Check spart plugs condition.
Check solutions of the wiring harness.
Refer to ADJUSTMENT AND REPAIR PROCEDURES section for procedures.
When using the service action suggested in the Fault section of B.U.D.S., the system circuits are referred to as A-41, which means connector "A" on the ECM and pin 41.

COMMUNICATION TOOLS

Two different MPI (Multi-Purpose Interface) can be used with B.U.D.S. software: MPI and MPI-2.

MULTI-PURPOSE INTERFACE (MPI)

PART REQUIRED PC computer B.U.D.S. software Use latest version available on BOSSWeb Communication kit (P/N 529 035 981) 2 7 1 on cable (P/N 529 035 703) Optional ex



MPI Supply

The MPI can use the vehicle power for its supply. Four AA batteries or an AC/DC power supply can also be used. Make sure to respect MPI specifi-cation if a power supply is used.

Connections with Vehicle

A WARNING

If the computer you are using is connected to the power outlet, there is a potential risk of electric shock when working in contact with water. Be careful not to touch water while working with the computer.

Remove the 6 pin connector from its receptacle on the right side of the vehicle.



Connect supply T-harness (P/N 529 035 869), to vehicle 6-pin connector.



NOTE: The use of the supply T-harness will keep the ECM ON. Not using it will allow the ECM shutting-off after some time.

CAUTION: Connecting MPI directly to vehicle connector (without supply T-harness) may lead to an incomplete data transfer to the ECM if it shuts down during the transfer. If this oc-curs during a reflashing of the ECM, it could be-come unusable. Always use the proper supply T-harness to allow continuous communication. Connect the 6 pin diagnostic cable from MPI to supply to T-harness.



Connect the other diagnostic cable connector to MPI connector. Connect serial cable to MPI connector.



Connect remaining MPI connector to the serial port of a PC (personal computer).

	- ⁻	
Use B.U.D.S. software as described B.U.D.S. SOFTWARE.	d further in	
MULTI-PURPOSE INTERFA	ACE-2 (MPI-2)	
	OP	ERATION
PART REQUIRED	- PROGRAMMING KEY(5) - ALL FUNCTIONS LISTED IN NEIGHBORHOOD COLUMN	- ENTERING CUSTOMER INFO - CLOSED TPS AND IDLE ACTUATOR RESET - READING FAULT CODES - ACTIVATION OF COMPONENT (IGNITION COIL, FUEL PUMP ETC.)
PC computer	X	X
B.U.D.S. software Use latest version available on BOSSWeb	X	X
MPI-2 (P/N 529 036 018)	X	x
Deptonal extension cable (P/N 529 035 69	7) X	X

	OP	ERATION
PART REQUIRED	- PROGRAMMING KEY(S) - ALL FUNCTIONS LISTED IN NEIGHBORHOOD COLUMN	- ENTERING CUSTOMER INFO - CLOSED TPS AND IDLE ACTUATOR RESET - READING FAULT CODES - ACTIVATION OF COMPONENTS (IGNITION COIL, FUEL PUMP ETC.)
Diagnostic cable (P/N 710 000 851)		- Andrewski and a
"O"		x
DESS post interface (P/N 529 036 019)		
	x	
Supply T-harness (P/N 529 035 869)		A second s
I	×	x

MPI-2 Supply

The MPI uses the PC computer USB port power for its supply.

Connections with Vehicle

If the computer you are using is connected to the power outlet, there is a potential risk of electric shock when working in contact with water. Be careful not to touch water while working with the computer.

Remove the 6 pin connector from its receptacle on the right side of the vehicle.



Connect supply T-harness (P/N 529 035 869), to vehicle 6-pin connector.



NOTE: The use of the supply T-harness will keep the ECM ON. Not using it will allow the ECM shutting-off after some time.


CAUTION: Connecting MPI directly to vehicle connector (without supply T-harness) may lead to an incomplete data transfer. If this oc-curs during a reliashing of the ECM, it could be-come unusable. Always use the proper supply T-harness to allow continuous communication.

Connection to Program DESS Key(s) Connect DESS post interface (P/N 529 036 019) to T-harness.





Connect remaining MPI-2 connector to the USB port of a PC (personal computer).



 MPI Only Ensure that 115200 speed is properly selected in "MPI" under "Choose speed". 	Changes in ECM Anytime a change is brought in ECM throug B.U.D.S., there will be an "EMS Tracking" me
Elec Yew Model Doda Elec Internation Internation Fridemation Fridemation Internation Internation Fridemation Fridemation Vehict Course Speed \$500 \$500 Vehict Bress \$3400 \$500 Internation Internation \$500 \$500	sage that will say "Remove key from vehicle When this occurs, remove DESS key from vehic DESS post and wait untilthe message disapear Then, the operation will be completed.
NOTE: If you are using an old PC computer, it may be necessary to use a slower speed so that the communication works.	
MPI and MPI-2 - Ensure that the protocol "kW2000" is properly selected in "MPI" under "Choose protocol.	
Ele Yew MDM Hodde Iool Heo Information Inet Key Read D Groce Proceed P Kr2000	
Ensure the status bar shows the kW2000 and	
the number 1 to the right. To communicate with the ECM, number 1 must be displayed. Number 1 indicates that the ECM is recognized by the MPI.	
kW2000	
CONNECTION SUCCESSFUL	
If an "X" is shown, this means that no communi- cation between the MPI and the ECM is possible In this case possible causes are: = ECM is not powered-up = wrong protocol is used = bad connection between MPI and ECM.	

DIAGNOSTIC

MONITORING SYSTEM

When one of the below conditions occurs, the monitoring system emits the following beep signals.

CODED SIGNALS	POSSIBLE CAUSE	REMEDY
2 short beeps (when engine is started). DESS/RER pilot lamp also blinks.	Confirms that proper tether cord cap is installed. Engine can rev above pulley engagement.	Normal condition.
1 short beep every 1.5 seconds (when engine is started).	Bad DESS system connection.	Reinstall tether cord cap correctly over post.
DESS/RER pilot lamp also blinks. Engine cannot reach pulley	Defective tether cord cap.	Use another programmed tether cord cap.
engagement speed.	Dirt or snow in tether cord cap.	Clean tether cord cap.
Vehicle cannot be driven.	Defective DESS post.	Replace DESS post.
1 long beep per second.	Reverse is selected.	Vehicle can be driven in reverse.
3 short beeps per second. DESS/RER pilot lamp also blinks. Engine cannot reach pulley engagement speed. Vehicle cannot be driven.	Wrong tether cord cap is installed.	Install proper tether cord cap. Program key into electronic module
3 short beeps per second. Engine overheating pilot lamp also blinks.	Engine is overheating.	Stop engine immediately and allow to cool. Check cooling system.
3 short beeps per second and EMS lamp flashing. Oil pilot lamp also lights up.	Low oil pressure.	Stop engine immediately and check oil level and top it. Check lubrication system.
	Low battery voltage, No charging.	Check battery and charging system.

FAULT CODES

General

General The faults saved in the ECM (Engine Control Mod-ule) are kept even if the battery is disconnected. IMPORTANT: After a problem has been solved, ensure to clear the fault(s) in the ECM using the B.U.D.S. software. This will properly reset the ap-propriate counter(s) and will also record that the problem has been fixed in the ECM memory. Many fault codes at the same time is likely to be burnt fuse(s) or a faulty relay. For more information pertaining to the fault codes (state, count, first, etc.) and report, refer to B.U.D.S. online help.

TPS (Throttle Position Sensor) Faults

-

Faults which are reported in B.U.D.S. fall into two groups: TPS faults and adaptation faults. These are displayed on the B.U.D.S. system as TPS OUT OF RANGE and TPS ADAPTATION FAILURE. TPS "OUT OF RANGE" Fault

It is caused by the sensor reading going out of its allowable range. This fault can occur during the whole range of movement of the throttle.

To diagnose this fully, it is recommended to oper-ate the throttle through its full range. It is also rec-ommended to release the throttle quickly as this may also reveal a fault that is intermittent.

POSSIBLE CAUSES Check if connector is disconnected from TPS Check if sensor is loose ACTION Fix. Tighten and reset Closed Throttle and Idle Actuator Lineck IT sensor is loose Tiphten and reset Closed Inspect sensor for damage or corrosion (hospect wiring (voltage tast) Inspect wiring and sensor fresistance test) Test sensor operation (war test) Replace and reset Closed Protect and Idle Actuator.

TPS "ADAPTATION FAILURE" Fault TPS "ADAPTATION FAILURE" Fault It is acused by the idle position moving out of an acceptable range. Following problems can be caused by a TPS "Adaptation Failure": - Idle speed is out of range. - Engine stops when throttle is released quickly. - Engine runs inconsistent in low partload or low RPM.

FAULT CODE TABLE

POSSIBLE CAUSES	ACTION
Sensor has been replaced and TPS closed position not reset	Reset Closed Throttle and Idle Actuator.
Throttle body has been replaced and TPS closed position not reset	Reset Closed Throttle and Idle Actuator.
ECM has been replaced and TPS closed position not reset	Reset Closed Throttle and Idle Actuator.
Throttle cable too tight	Tighten and reset Closed Throttle and Idle Actuator.
Sensor is loose	Tighten and reset Closed Throttle and Idle Actuator.
Throttle bracket is loose	Tighten and reset Closed Throttle and Idle Actuator.
Idle speed screw (tamper proof) worn or loose	Change throttle body.
Idle bypass valve replaced but not reset	Reset Closed Throttle and Idle Actuator using B.U.D.S

Fault Code P0654

If this code occurs and tachometer works normal-ly, disregard this fault code.

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P0106	Air pressure sensor voltage out of range	Sensing port dirty or blocked. Sensor failure or unexpected reading at idle. Sensor fallen out of intake manifold.	Make sure sensor's connector is fully inserted. Check for voltage within 0 and 5 volts between sensor connector pins 1 and 4. Check system circuits DA-12, DA-28 and DA-40.
P0107	Air pressure sensor voltage too low	Damaged circuit wires, damaged or disconnected sensor, sensor shorted to ground.	Make sure sensor's connector is fully inserted. Check for approximately 5 volts between sensor connector pins 1 and 2. Check system circuits DA-12, DA-28 and DA-40.
P0108	Air pressure sensor voltage too high	Damaged circuit wires, damaged or disconnected sensor, sensor shorted to a supply.	Make sure sensor's connector is fully inserted. Check for approximately 5 volts between sensor connector pins 1 and 2. Check system circuits DA-12, DA-28 and DA-40.
P0111	Air temperature sensor functional problem	Intermittent air temperature sensor reading or circuit wires shorted to ground.	Check system circuits DA-7 and DA-21. Replace the sensor if necessary.

FAULT		CAUSE	ACTION
P0112	Air temperature sensor voltage too low	Air temperature sensor or circuit wires shorted to ground.	Disconnect the sensor and check for a change in the fault code. If the fault code stays the same, look for a short circuit on the hamess. If the fault code is different, replace the sensor. Check system circuits DA-7 and DA-21.
P0113	Air temperature sensor voltage too high	Disconnected sensor or sensor's resistance too high.	Check for disconnected air temperature sensor on the airbox. Check the air temperature sensor for approximately 2280 to 2736 ohms at 19 to 21°C (66 to 70°F). Replace the sensor if necessary. Check system circuits DA-7 and DA-21.
P0116	Engine temperature sensor functional problem	Intermittent engine temperature sensor reading or circuit wires shorted to ground.	Check system circuits DA-11 and DA-27. Replace the sensor if necessary.
P0117	Engine temperature sensor voltage too low	Engine temperature sensor or circuit wires shorted to ground.	Disconnect the sensor and check for a change in the fault code. If the fault code stays the same, look for a short circuit on the harness. If the fault code is different, replace the sensor. Check for leakage between sensor's connection and ground. Check system circuits DA-11 and DA-27.
P0118	Engine temperature sensor voltage too high	Disconnected sensor or sensor's resistance too high.	Check for disconnected engine temperature sensor. Check the engine temperature sensor for approximately 2280 to 2736 ohms at 19 to 21°C (66 to 70°F). Replace the sensor if necessary. Check system circuits DA-11 and DA-27.
P0122	Throttle position sensor voltage too low	Damaged circuit wires, damaged throttle position sensor or damaged ECM pins.	Check system circuits DA-24, DA-25 and DA-39. Refer to the SHOP MANUAL for complete throttle position sensor testing procedure.
P0123	Throttle position sensor voltage too high	Damaged circuit wires, damaged throttle position sensor or damaged ECM pins.	Check system circuits DA-24, DA-25 and DA-40. Refer to the SHOP MANUAL for complete throttle position sensor testing procedure.
P0231	Fuel pump open circuit or shorted to ground	Damaged or disconnected fuel pump, damaged circuit wires, damaged connectors or damaged ECM output pins.	Check for approximately 1 ohm between pins PE-3 and PE-4 of the fuel pump connector. Check for approximately 1 ohm between pins F3 and DB-29.
P0232	Fuel pump shorted to battery	Damaged fuel pump, damaged circuit wires, damaged connectors or damaged ECM output pins.	Check for approximately 1 ohm between pins PE-3 and PE-4 of the fuel pump connector. Check for approximately 1 ohn between pins F3 and DB-29. Check if system circuit DB-29 is shorted to 12 V.
P0261	MAG injector open circuit or shorted to ground	Blown fuse, damaged or disconnected injector, damaged or disconnected circuit wires, damaged ECM output pins.	Check fuse F1. Check connections on injector. Check for approximately 14.5 ohms on injector. Check system circuit DA-15. Check connector CJ connecting the two harnesses together.

FAULT	DESCRIPTION	CAUSE	ACTION
P0262	MAG injector shorted to battery	Damaged injector, damaged circuit wires, damaged connector or damaged ECM output pins.	Check for approximately 14.5 ohms on injector. Check if system circuit DA-15 is shorted to 12 V.
P0264	PTO injector open circuit or shorted to ground	Blown fuse, damaged or disconnected injector, damaged or disconnected circuit wires, damaged ECM output pins.	Check fuse F2. Check connections on injector. Check for approximately 14.5 ohms on injector. Check system circuit DA-33. Check connector CJ connecting the two harnesses together.
P0265	PTO injector shorted to battery	Damaged injector, damaged circuit wires, damaged connector or damaged ECM output pins.	Check if system circuit DA-33 is shorted to 12 V.
P0344	Cam phase sensor signal missing	Blown fuse, damaged circuit wires or damaged sensor.	Check fuse F5. Check for 12 volts between sensor's connector pins 1 and 3. Check system circuits DA-20, DA-34 and F5.
P0351	No MAG ignition output stage	Blown fuse, damaged circuit wires, damaged connector or damaged ignition coil.	Check fuse F1. Check for 0.85 to 1.15 ohm between ignition coil pins. Check connector CJ connecting the two harnesses together. Check system circuit DA41.
P0352	No PTO ignition output stage	Blown fuse, damaged circuit wires, damaged connector or damaged ignition coll.	Check fuse F2. Check for 0.85 to 1.15 ohm between ignition coil pins. Check connector CJ connecting the two harnesses together. Check system circuit DA-1.
P0505	Idle air control valve output stage cutoff memory difference	Damaged actuator, damaged circuit wires, damaged connector or damaged ECM output pins.	Check for approximately 50 ohms between pins A and D and also between pins B and C of the idle air control valve. Check for damaged circuit wires. Check system circuits DA-35, DA-36, DA-37 and DA-38. Check for damaged connector or damaged ECM output pins.
P0505	Idle air control valve output stage fault	Damaged actuator, damaged circuit wires, damaged connector or damaged ECM output pins.	Check for approximately 50 ohms between pins A and D and also between pins B and C of the idle air control valve. Check for damaged circuit wires. Check system circuits DA-35, DA-36, DA-37 and DA-38. Check for damaged connector or damaged ECM output pins.
P0520	Oil pressure switch functional problem	Low oil level, engine leak, oil pump failure, damaged sensor, damaged or shorted circuit wires.	Check oil level. Check oil pressure switch resistance. With engine stopped, the resistance should be less than 1 ohm. With engine running, the resistance should be infinitely high (0L). Check system circui DA-10.
P0562	Battery voltage too low	Blown fuse, battery failure, damaged circuit wires, damaged or disconnected alternator, damaged alternator drive system.	Check fuses F4 and F12. Check battery voltage for 11 to 13 volts with engine stopped. Check battery voltage for 14.1 to 14.7 volts with engine idling. Check connections on alternator. Check ground and positive connections near the starter relay.

-			
FAU		N CAUSE	ACTION
P056	53 Battery voltage high	too Blown fuse, damaged circuit wire or damaged alternator. An externa battery charger may have been used.	
P060	1 Throttle position sensor adaptatic failure		Check cable adjustment. Check idle sto for wear. Make sure throttle plate is against throttle stop. Reset closed TPS.
P060	1 Module call monitoring	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0603	ECM not coded	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0604	RAM fault	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0605	EEPROM fault	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0605	EEPROM checksum fault	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0605	Coding ID checksum fault	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0605	Coding checksum fault	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0605	Programming checksum fault	Damaged ECM or faulty programmation.	Try updating the ECM. If the problem persists, replace the ECM.
P0608	Sensor's power supply voltage too low	Inverted connectors between air pressure sensor and TPS. Damaged circuit wires, shorted air pressure sensor or shorted TPS.	Check system circuits DA-12, DA-28, DA-40, DA-24, DA-25 and DA-39,
P0608	Sensor's power supply voltage too high	Damaged circuit wires, TPS or air pressure sensor shorted to a supply.	Check system circuits DA-12, DA-28, DA-40, DA-24, DA-25 and DA-39.
P0616	Starter relay open circuit or shorted to ground	Blown fuse, damaged or disconnected starter relay, damaged circuit wires, damaged connectors or damaged ECM output pins.	Check fuse F4. Disconnect the starter relay and check for approximately 7.3 ohms between the small starter relay terminals. Check for approximately 12 volts between starter relay RD/GY wire and ground. Check system circuit DB-31.
0617	Starter relay shorted to battery	Damaged solenoid, damaged circuit wires, damaged connector or damaged ECM output pins.	Disconnect the starter relay and check for approximately 7.3 ohms between the small starter relay terminals. Check if system circuit DB-31 is shorted to 12 V.
0648	DESS® lamp shorted to battery	Damaged or wrong speedometer, damaged circuit wires, damaged connector or damaged ECM output pins.	Check if system circuit DB-3 is shorted to 12 V. Check if the right speedometer part number is installed.

ACTION	CAUSE	DESCRIPTION	FAULT
Check fuse F4. Check for approximately 12 volts between pins 8 and 11 of the speedometer connector. Check system circuit DB-3.	damaged or disconnected circuit wires, disconnected connector on	DESS® lamp open circuit or shorted to ground	P0648
Check if system circuit DB-33 is shorted to 12 V.		Engine lamp shorted to battery	P0650
Check fuse F4. Check for approximately 12 volts between pins 8 and 11 of the speedometer connector. Check system circuit DB-33.	Blown fuse, damaged speedometer, damaged or disconnected circuit wires, disconnected connector on speedometer or cab, damaged ECM output pins.	Engine lamp open circuit or shorted to ground	P0650
Check if system circuit DB-4 is shorted to 12 V. Check if the right speedometer part number is installed.	Damaged or wrong speedometer, damaged circuit wires, damaged connector or damaged ECM output pins.	Tachometer RPM signal shorted to battery	P0654
Check fuse F4. Check for approximately 12 volts between pins 8 and 11 of the speedometer connector. Check system circuit DB-4.	Blown fuse, damaged speedometer, damaged or disconnected circuit wires, damaged ECM output pins.	Tachometer RPM signal open circuit or shorted to ground	P0654
Check if system circuit DB-5 is shorted to 12 V.	Damaged speedometer, damaged circuit wires, damaged connector or damaged ECM output pins.	Engine temperature lamp shorted to battery	P0655
Check fuse F4. Check for approximately 12 volts between pins 8 and 11 of the speedometer connector. Check system circuit DB-5.	Blown fuse, damaged speedometer, damaged or disconnected circuit wires, disconnected connector on speedometer or cab, damaged ECM output pins.	Engine temperature lamp open circuit or shorted to ground	P0655
Check cable adjustment. Check idle stop for wear. Make sure throttle plate is against throttle stop. Reset closed TPS.	Wrong throttle body mechanical position during reset of closed TPS or no initialisation after ECM replacement.	Throttle position sensor adaptation failure	P1102
Check cable adjustment. Check idle stop for wear. Make sure throttle plate is against throttle stop. Reset closed TPS.	Wrong throttle body mechanical position during reset of closed TPS or no initialisation after ECM replacement.	Throttle position sensor adaptation failure	P1104
Check cable adjustment. Check idle stop for wear. Make sure throttle plate is against throttle stop. Reset closed TPS.	TPS adaptation failure, TPS failure, damaged ECM memory or battery voltage out of range.	Safety fuel cut off detected	P1148
Check oil level. Check oil pressure switter resistance. With engine stopped, the resistance should be less than 1 ohm. With engine running, the resistance shou be infinitely high (0L). Check system circ DA-10.	Low oil level, engine leak, oil pump failure, damaged sensor, damaged or shorted circuit wires.	Oil pressure switch still closed	P1202
Check oil level. Check oil pressure switt resistance. With engine stopped, the resistance should be less than 1 ohm. With engine running, the resistance shou be infinitely high (0L). Check system circ DA-10.	Low oil level, engine leak, oil pump failure, damaged sensor, damaged or shorted circuit wires.	Oil pressure switch leakage	P1203

FAULT DESCRIPTION		CAUSE	ACTION	
P1502	T.O.P.S. functional problem	Damaged circuit wires or damaged ECM output pins.	Check for continuity between pin DB-9 and ground.	
P1611	P+ Test of idle air control valve output signal failed	Damaged actuator, damaged circuit wires, damaged connector or damaged ECM output pins.	t Check for approximately 50 ohms betwee pins A and D and also between pins B and C of the idle air control valve. Check for damaged circuit wires. Check syster circuits DA-35, DA-36, DA-37 and DA-38 Check for damaged connector or damag ECM output pins Replace the idle air control valve if necessary.	
P1646	Engine temperature lamp shorted to battery	Damaged speedometer, damaged circuit wires, damaged connector or damaged ECM output pins.	Check if system circuit DB-5 is shorted to 12 V.	
P1647	Engine temperature lamp open circuit or shorted to ground	Blown fuse, damaged speedometer, damaged or disconnected circuit wires, disconnected connector on speedometer or cab, damaged ECM output pins.	12 volts between pins 8 and 11 of the speedometer connector. Check system	
P1652	Engine temperature gauge signal shorted to battery	Damaged circuit wires or damaged gauge.	Check system circuit DB-30.	
P1653	Engine temperature gauge signal open circuit or shorted to ground	Damaged or disconnected circuit wires, disconnected connector on gauge or cab, damaged ECM output pins. Improper temperature gauge installation.		
P1655	DESS® line shorted to battery	Damaged circuit wires or mixed up connections.	Check system circuits DB-26, DB-38 and DB-39	
P1656	DESS® line shorted to ground	Damaged circuit wires or mixed up connections.	Check system circuits DB-26, DB-38 and DB-39.	
P1670	Buzzer shorted to battery	Damaged buzzer, damaged circuit wires, damaged connector or damaged ECM output pins.	Check if system circuit DB-18 is shorted to 12 V. Refer to the SHOP MANUAL for complete buzzer testing procedure.	
P1671	Buzzer open circuit or shorted to ground	Blown fuse, damaged buzzer, damaged or disconnected circuit wires, disconnected connector on buzzer or cab, damaged ECM output pins.	Check fuse F4. Check for approximately 12 volts between connector pin AR-A and negative battery terminal. Check system circuit DB-18. Refer to the SHOP MANUAL for complete buzzer testing procedure.	
P1675	Relay 2 shorted to battery	Damaged relay, damaged circuit - wires, damaged connector or damaged ECM output pins.	Check for approximately 100 ohms between relay pins 85 and 86. Check if system circuit DB-16 is shorted to 12 V.	
P1676	to ground	Blown fuse, damaged or disconnected relay, damaged or disconnected circuit wires, damaged ECM output pins.	Check fuse F4. Check for approximately 100 ohms between relay pins 85 and 86. Check system circuit DB-16.	

Section 08 ENGINE MANAGEMENT (V800) Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES) ADJUSTMENT AND REPAIR PROCEDURES SERVICE TOOLS Description ECM adapter. Fluke 111 multimeter hose pincher..... Part Number 420 277 010 529 035 868 295 000 076 295 000 070 529 014 500 Page ...419 ...418 429 427, 431 420 SERVICE TOOLS - OTHER SUPPLIER Description rigid back probe Fluke... Part Number TP88 Page ...419 SERVICE PRODUCTS Description Loctite 243.. Part Number 293 800 060 Page ...433, 437, 439 GENERAL Always disconnect battery prior to working on the fuel system. Always disconnect bat-tery exactly in the specified order, BLACK (-) cable first. It is recommended to disconnect electrical connections prior to disconnecting fuel lines. Engine problems are not necessarily related to the electronic fuel injection system. electronic fuel injection system. It is important to ensure that the mechanical in-tegrity of the engine/propulsion system is present: – good transmission system operation – good engine compression and properly operat-ing mechanical components, no leaks etc. **∆** WARNING - fuel pump connection and fuel lines without leaks. Check the chart in TROUBLESHOOTING section to have an overview of problems and suggested solutions.

The components of a fuel injection system holds much more pressure than on a carbu-reted engine. Prior to disconnecting a hose or removing a component from the fuel sys-tem, follow the recommendation described here.

417

Fuel is flammable and explosive under cer-tain conditions. Ensure work area is well ven-tilated. Do not smoke or allow open flames or sparks in the vicinity.

FUEL SYSTEM

When replacing a component, always check its operation after installation.

- Use the B.U.D.S. software to release the fu-el pressure in the system (refer to EMS DI-AGNOSTIC AND COMMUNICATION TOOLS. Look in the Activation section of the software B.U.D.S.

Section 08 ENGINE MANAGEMENT (V800)

Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES)

Fuel lines remain under pressure at all times Always proceed with care and use appropri-Aways proceed with care and use appropri-ate safety equipment when working on pres-surized fuel system. Wear safety glasses. Proceed with care when removing/installing pressure test equipment or disconnecting fuel line connections. Use the B.U.D.S. software to release fuel pressure prior to removing a hose. Cover the fuel line con-nection with an absorbent shop rag. Slowly disconnect the fuel hose to minimize spilling. Wipe off any fuel spillage in the engine com-partment. Do not allow fuel to spill on hot engine parts and/or on electrical connectors. Never use a hose pincher on injection system high pressure hoses. Replace any damaged or deteriorated fuel lines.

When the repair is completed, ensure that all hoses are connected and secured. Perform the FUEL PRESSURE TEST and the FUEL TANK LEAK TEST as explained in FUEL TANK AND FUEL PUMP section. A fuel pressure drop indicates a leak. Check for leaking fuel.

Always perform the fuel pressure test if any component has been removed. A pressure component has been removed. A pressure test must be done before turning the igni-tion key to START. The fuel pump is activat-ed each time ignition key is turned to START. After performing a fuel pressure test, use the valve on the fuel pressure gauge to release the pressure (if so equipped).

ELECTRICAL SYSTEM

It is important to check that the electrical system is functioning properly.

- battery

- relay 1
- ignition (spark)
- ground connections
- wiring connectors
- ~ speedometer.

spectorized:
 It is possible that a component seems to operate in static condition but in fact, it is defective. In this case, the best way to solve this problem is to remove the original part and replace it with one which is in good condition.

Never use a battery charger to substitute tem-porarily the battery, as it may cause the ECM (engine control module) to work erratically or not to work at all. Check related-circuit fuse solidity and condition with an ohrmeter. Visual inspec-tion could lead to false results.

Some EMS components are continuous-ly powered when ignition key is turned to START. The ECM switches the circuit to the SIARI. The ECM switches the circuit to the ground to complete the electrical circuits it controls. Take this into account when trou-bleshooting. Always disconnect the battery prior to disconnecting any electric or elec-tronic parts.

Pay particular attention to ensure that pins are not out of their connectors or out of shape.

When probing terminals, pay attention not to bend the terminal as this could bring a losse connection that would be difficult to troubleshoot.

Ensure all terminals are properly crimped on wires and connector housings are properly fastened.

Before replacing an ECM, always check electri-cal connections. Make sure terminals are prop-erly crimped on wires and fastened in housing, and that they are free of corrosion or moisture. Check if wiring harness shows any signs of scor-Check it winng harness shows any signs of sco-ing. Ensure proper electrical connection. Parti-ularly check ECM ground connections. A "defec-tive module" could possibly be "repaired" simply by unplugging and replugging the ECM. The volt-age and current might be too weak to go through dirty wire pins.

Ensure that all electronic components are gen-uine. Any modification on the wiring harness may lead to generate fault codes or bad operation.

NOTE: For diagnostics purposes, use B.U.D.S. software. See EMS DIAGNOSTIC AND COM-MUNICATION TOOLS subsection.


After a problem has been solved, ensure to clear the fault(s) in the ECM using the B.U.D.S. soft-ware. Refer to EMS DIAGNOSTICAND COMMU-NICATION TOOLS subsection.

Diagnostic Tools

To perform verifications, use Fluke 111 multimeter (P/N 529 035 868).



To easily probe wire terminals through the back of their connectors, rigid back probe Fluke (P/N TP88) pins or equivalent can be used.



They can be inserted at the end of the standard probes of the Fluke 111 multimeter.



The most recommended and safest method to probe ECM connector terminals is to use the ECM adapter (P/N 420 277 010). This tool will prevent deforming or enlarging terminals which would lead to bad ECM terminal contact creating intermittent or permanent problems.



Disconnect the desired connector from ECM and reconnect on the tool connector. Probe required terminals directly in the tool holes.



Resistance Measurement

Resistance Measurement When measuring the resistance with an ohmme-ter, all values are given for a temperature of 20°C (68°F). The resistance value for usual resistor or windings (such as injectors) in-creases as the temperature. The resistance value for usual resistor or windings (such as injectors) in-creases as the temperature increases. However, our temperature sensors are NIC types (Negative Temperature Coefficient) and work the opposite which means that the resistance value decreases as the temperature increases. Take it into account when measuring at temperatures different from 20°C (68°F). Use this table for resistance value derived resistance temperature for temperature sensors.

TEMPERATURE SENSOR TABLE				
TEMPER	ATURE	RESISTAN	CE (ohms)	
°C	°F	MAPTS	CTS	
- 40	- 40	-	45000	
- 30	- 22	28000	28000	
- 20	- 4	15000	15000	
0	32	5500	5500	
20	68	2500	2500	
40	104	1200	1200	
60	140	600	600	
80	176	320	320	
100	212	180	180	
130	266	90	90	

CONVERSION CHART FOR TEMPERATURE SENSORS

The resistance value of a temperature sensor may test good at a certain temperature but it might be defective at other temperatures. If in doubt, try a new sensor.

Also remember this validates the operation of the sensor at room temperature. It does not validate the over temperature functionality. To test it, the sensor could be removed from the engine and heated with a heat gun while it is still connected to the harness to see if the ECM will detect the high temperature condition and generate a fault code.

ECM Connectors

The ECM connectors are identified by the letter "A" and "B".




NOTE: Do not apply dielectric grease or any other lubricant in ECM connectors.

Engine Connector

Engine connector is located besides ECM.



Use this illustration to locate the pin numbers on the engine connector when performing tests.




BASIC ADJUSTMENTS

IDLE SPEED

The idle speed is not adjustable. The ECM controls the idle speed of the engine.

trois the idle speed of the engine. **CAUTION:** Never attempt to adjust the sealed idle stop screw. It is calibrated at the factory. If the screw adjustment is changed, the throttle body must be replaced. If desired, the engine RPM can be verified with the tachometer (P/N 529 014 500).



THROTTLE CABLE

Handlebar and throttle cable must be at their nor-mal position.

Wide Open Throttle Position Verification


Squeeze throttle lever and hold it at wide open throttle (WOT).

throttle (WOT). There must be free-play in throttle cable. Push against throttle cable to see if cam stopper will move just a little to touch throttle body. If so, it confirms proper free-play.



WOT POSITION 1. Push here to feel free-play 2. Stopper just close to touching throttle body

If adjustment is needed, use adjuster nuts.



When done, turn handlebar side to side and en-sure there is still free-play in each position while at WOT.

CAUTION: Improper cable adjustment will cause strain on cable and/or damage cable bracket or throttle lever at handlebar.

Idle Position Verification

Activate throttle lever a few times. Make sure throttle cam of throttle body rests against set screw with some free-play in the cable.



CAUTION: If there is no free-play at idle posi-tion, it may cause poor idling and startability problems.

∆ WARNING

Make sure idle speed stopper contacts throt-tle cam when throttle lever is fully released at handlebar.

CLOSED THROTTLE AND IDLE ACTUATOR RESET

ACTOATOR RESET NOTE: This operation performs a reset of the val-ues in the ECM. This reset is very important. The setting of the TPS will determine the basic parameters for all fuel mapping and several ECM calculations. NOTE: Reset must be done each time the throt-tle position sensor (TPS) is loosened, removed or replaced, and also if throttle body or ECM are re-placed.

CAUTION: An improperly set TPS may lead to poor engine performance and emission compliance could possibly be affected.

Reset

Heset Use the B.U.D.S. software to perform this adjust-ment. Open throttle approximately one quarter then quickly release. Repeat 2 - 3 times to settle throttle plate.

Ensure the throttle cam of throttle body rests against set screw without any tension in the cable. Otherwise, perform the throttle cable ad-justment.

1. Contact here 2. Free-play here

Select the Setting tab of B.U.D.S.

Ensure the proper variant according to vehicle is selected.

V800 MODEL	VARIANT
Legend, Expedition Sport and Tundra	Platform RF
Skandic SWT and Expedition TUV	Platform Yeti

Incle Setting Municomp Activation Faults History

County 0.00 Deg 1

Step 1: Select variant according to vehicle Step 2: Click reset Reset is completed.

NOTE: No message will be displayed if operation is successful. If TPS is not within the allowed range while resetting the Closed Throttle and Idle Actuator, the ECM will generate a fault code and will not accept the setting. Start engine and make sure it operates normally through its full engine RPM range. If fault codes appear, refer to EMS DIAGNOSTIC AND COM-MUNICATION TOOLS section for more informa-tion.

tion

IGNITION TIMING

The ignition timing is not adjustable. **REPAIR PROCEDURES**

ENGINE CONTROL MODULE (ECM)

Power Supply to ECM

BAT]→[Fuse F8	\rightarrow	Ţ
•			-	Ļ
Charging system fuse				Ļ
F1	1			1
Relay 1	+	ECM]+[Start switch
ECM fuse F4				
ECM				

FUNCTION CONNECTOR PIN Power 12 Vdc B-11 B1, B2, B9, B32 and B41 Grounds

Troubleshooting ECM

Briefly push START button. NOTE: This will wake up the ECM for approxi-mately 15 seconds then it will automatically shut down.

Open hood

1

A WARNING Battery BLACK negative cable must always be disconnected first and connected last.

Remove muffler. Refer to EXHAUST SYSTEM. Release fuel hose from fuse box support Remove fuse box support.


QUICK INDICATION THAT ECM IS NOT WORKING (assuming the observed component is working)

Speedometer does not turn on. Fuel pump does not turn on for approx. 5 seconds.

NOTE: It is not required that DESS key be installed on its post or engine cut-out switch be in RUN position to allow ECM power-up. If ECM does not turn on, check the following.

Check charging system fuse F1 and fuse F4. If they test good, check relay 1. Refer to *LIGHTS, INSTRUMENTS AND ACCESSORIES.*

Check fuse F8 and start switch. Refer to START-ING SYSTEM. If switch tests good, check ECM grounds.



If everything is good, refer to ECM REPLACE-MENT.

ECM Replacement

ECM Replacement Prior to replacing a possibly faulty ECM, ensure that all the recommendations in the general intro-duction of this section have been carried out. Al-so, check ECM power supply and all grounds for proper contact/clean/intess. IMPORTANT: When the ECM is replaced, the Closed Throttle and Idle Actuator must be re-set. Refer to BAS/C ADU/STMENTS. To allow transferring the previous recorded infor-mation from the old ECM to the new one, use the BU.D.S. software. Use Replace ECM in the ECM menu. Follow instructions in its help system. NOTE: If the old ECM still works, its information must be read by B.U.D.S. before being removed from the vehicle in order to transfer vehicle infor-mation and history to the new ECM. Disconnect battery cables. Disconnect battery cables.



Disconnect both connectors from ECM. Remove ECM.

4



Install the new ECM to the vehicle. Reconnect connectors to ECM, and then battery cables.

Reinstall remaining removed parts.

Transfer the data from the previous ECM to the new one using B.U.D.S. then proceed with the required resets and reprogram ignition key(s), if you were unable to transfer the data.

NOTE: If data cannot be transferred, manually enter information in Vehicle tab and Engine Serial Number in History, Part Replacement.



Add Part In History Part Type © Engine © ECM © Cluster Serial Number Gancel writest date, write Cancel I faults from the newly replaced ECM.

FUEL INJECTOR

Injector Leakage Test

The leakage test is validated when performing the "fuel delivery system diagnostic flow chart" in FU-EL TANK AND FUEL PUMP (V800).

Injector Electrical Test

Briefly push START button. Using the B.U.D.S. software, energize the fuel injector from the Activation section.



You should hear the injector working. **CAUTION:** While doing fuel injector electrical test, do not apply continuous voltage for more than 10 seconds. This can damage the injector. This will validate the injector mechanical and electrical operation.

CYLINDER

FRONT

TYPICAL

If supply voltage is not good, check continuity between fuse F6 and injector (see *WIRING DIA-GRAMS*).

NOTE: Probe fuse exactly as shown. This validates fuse at the same time. Use a multimeter and set it to Ω . Read resistance.

MEASUREMENT

Close to 0 Ω

INJECTOR CIRCUIT

WIRE

VIOLET/ BLUE Fuse F6

If the injector does not work, check injector power supply.

Injector Voltage Test

Disconnect the connector from the injector. NOTE: If connector is hard to unlock, gently use a screwdriver to release connector.



Briefly push START button Use a multimeter and set it to Vdc. Read voltage.

INJECTOR

CYLINDER	CONNECTOR		MEASUREMENT
FRONT	BROWN/	Battery	12 Vdc
REAR	RED	ground	12 Vac

If continuity is good, check relay 1 and wiring from battery.
 If continuity is faulty, check fuse; if OK, repair/ replace wiring going to injector.

Injector Resistance Test

Reconnect the injector connector.

Disconnect the connector "A" from the ECM and the engine connector.

Using a multimeter, check resistance value be-tween terminals as follows.

INJECTOR	ENGINE CONNECTOR PIN	ECM CONNECTOR "A"	RESISTANCE @ 20°C (68°F)
FRONT		A-15	100 1500
REAR	1	A-33	13.8 - 15.2 Ω

If supply voltage is good, check ground circuit between injector and ECM (see WIRING DIA-GRAMS).

1.4

X

Vdd

If ground circuit is faulty, repair/replace.
If ground circuit is good, refer to ECM RE-PLACEMENT.

--



If resistance value is correct, refer to ECM RE-PLACEMENT.

If resistance value is incorrect, remove injector connector and check resistance value between in-jector pins as follows.

RESISTANCE @ 20°C (68°F) INJECTOR INJECTOR PIN FRONT 1 2 13.8 - 15.2 Ω REAR




If readings are out of specifications, replace injector.

If readings are good, repair/replace wiring going to injector.

Fuel Injector Replacement

Injector Removal

Before removing the injector, the fuel rail has to be removed from the engine. Refer to FUEL RAIL for the procedure.



FUEL RAIL ASSY 1. Fuel rail 2. Fuel injector 3. Injector top O-ring 4. Injector bottom O-ring 5. Manifold O-ring

The fuel injector can be easily pulled out of the fuel rail.

Injector Installation

Injector installation For the installation, reverse the removal proce-dure. Pay attention to the following details. Apply a thin film of engine oil to O-rings to ease insertion in rail.

insertion in rail. Install new O-rings, if you reinstall a used injec-tor then insert the fuel injector in place with your hand. Do not use any tool. Carefully insert injector in manifold. Gently push in evenly all around while inserting injector. O-ring must be completely inserted and not visible, be-fore finishing pushing injector.

Unscrew rail retaining screws. Gently pull rail up by hand.

× 1



Firmly push injector until it bottoms. Reinstall fuel rail.


FUEL RAIL

Pressure at fuel rails is supplied and controlled by the fuel pump module. Refer to FUEL TANK AND FUEL PUMP (V800) for pressure test.

Fuel Rail Replacement

Rail Removal

Disable fuel pump using B.U.D.S. Look in the Activation tab.



Release fuel pressure by running engine until it runs out of gas. Remove relay 1. To disconnect fuel rail, cut clamp on fuel hose using pliers (P/N 295 000 070). Refer to FU-EL TANK AND FUEL PUMP (V800) for clamp removal/installation procedures. NOTE: If fuel rail is removed purposely to access fuel injector, it is not necessary to cut hose clamp. Only to replace fuel rail.

Wrap a rag around the inlet hose and release the quick fitting.


13

Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES) THROTTLE BODY Rail Installation For installation, reverse the removal process but pay attention to the following. Install new clamps using pliers as per removal (if fuel rail was replaced). 2 A thin film of oil should be applied to O-rings of fuel injector to ease installation of fuel rail. Install new O-rings. Install fuel rail and evenly tighten screws a little at a time each side. Tightening torque of the rail retaining screws is 6 N•m (53 lbf•in). Reinstall relay 1. 4 3 After securing inlet hose at quick fitting, re-enable fuel pump using B.U.D.S. wm/bdst-keesw.a Throttle body Throttle cable attachment Throttle plate TPS Idle bypass channel Idle bypass valve Coolent hoses Monitorry Activition Faults History Purp rabled O Deubled Press Raled Mechanical Inspection Check that the throttle plate moves freely and smoothly when depressing throttle lever. IMPORTANT: Never attempt to adjust the sealed idle stop screw. It is calibrated at the factory. If the screw adjustment is changed, the throttle body must be replaced. Page 1 30 Perform a fuel pressure test and ensure that there is no leak. Refer to FUEL TANK AND FUEL PUMP (V800). Run engine and check for leaks. Before replacing any part, check the following as these could be causing the fault. Perform the test while the engine is off. - Throttle cable adjustment too tight. Not returning fully to idle stop.

Section 08 ENGINE MANAGEMENT (V800)

<text><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item><list-item>





Release cam and ensure throttle cable is properly locked. Activate throttle lever several times.

Perform the throttle cable adjustment and the Closed Throttle and Idle Actuator reset. Refer to BASIC ADJUSTMENTS in this section.

To install coolant hose clamps, use pliers (P/N 295 000 070).


0 JE: 0

Refill and bleed cooling system if necessary. Re-fer to COOLING SYSTEM.

THROTTLE POSITION SENSOR (TPS)

General

The throttle position sensor (TPS) is a potentiome-ter that sends a signal to the ECM which is propor-tional to the throttle shaft angle.



NOTE: Air intake silencer may be removed to ease

IMPORTANT: Prior to testing the TPS, ensure that mechanical components/adjustments of throttle body are adequate.

The EMS may generate several fault codes per-taining to the TPS. Refer to EMS DIAGNOSTIC AND COMMUNICATION TOOLS section for more information.

TPS Wear Test

While engine is not running, activate throttle and pay attention for smooth operation without physi-cal stops of the cable. Using the B.U.D.S. software, use the Throttle Opening display under Monitoring.



431

Slowly and regularly depress the throttle. Ob-serve the needle movement. It must change gradually and regularly as you move the throt-tle. If the needle "sticks", bounces, suddenly drops or if any discrepancy between the throttle movement and the needle movement is noticed, it indicates that the TPS needs to be replaced or the computer used may be too slow to transfer data fast enough for real time display.

TPS Resistance Test

Ensure TPS is connected to wiring harness. Disconnect the "A" connector from the ECM. Using a multimeter, check resistance values on ECM connector as per the following table.

ECM CO	NNECTOR	THROTTLE IDLE POSITION	WIDE OPEN THROTTLE POSITION
F	PIN		ANCE Ω C (68°F)
A-24	A-25	710 - 1300	2600 - 2700
A-25	A-39	1600 - 2400	1600 - 2400
A-24	A-39	2600 - 2700	710 - 1300



NOTE: The resistance value should change smoothly and proportionally to throttle movement. Otherwise, replace TPS.


ment. Otherwise, replace IPS. If resistance values are correct, perform the VOLT-AGE TEST below. If resistance values are incorrect, check wiring har-ness. If wiring is faulty, repair/replace. If wiring is good, replace TPS. Reconnect ECM connector.

TPS Voltage Test

Check the ECM voltage output to the TPS.

Disconnect connector from TPS. Briefly push START button. Check the voltage readings from harness connec-tor as follows

CONNECTION	VOLTAGE
Pin 1 with battery ground	5.0 V
Pin 2 with battery ground	0 V
Pin 3 with battery ground	4,75 - 5 V




If voltage test is not good, check/repair wining harness. If wining tests good, refer to ECM RE-PLACEMENT.

If voltage test is good, everything is in order (as-suming resistance test was performed).

TPS Replacement

Open hood. Remove air intake silencer. Refer to AIR INTAKE SYSTEM. Loosen two screws retaining the TPS. Remove TPS.



THROTTLE BODY 1. Throttle position sensor (TPS) 2. Screws

Install the new TPS.


Apply Loctite 243 (P/N 293 800 060) on the TPS retaining screws, then torque to 3 N•m (27 lbf•in). Reinstall remaining removed parts.

Proceed with the Closed Throttle and Idle Ac-tuator Reset. See BASIC ADJUSTMENTS at the beginning of this section.

IDLE BYPASS VALVE



IBV Information in B.U.D.S. Software The IBV position (Idle By-pass Valve) is displayed for information purposes only.



This value implies no maintenance, it is not adjustable. The value is given in steps, with 0 being fully cosed, and 150 being fully open. The ECM constantly controls the IBV to maintain its target idle speed when the throttle is closed. Typical IBV position at idle for a warm engine ranges from 25 to 50 steps, depending on alti-tude, air temperature and production tolerances NOTE: An engine giving an IBV position outside of this range is not necessarily faulty. It may only give clues if poor idle or light throttle behavior is experienced. Lower values may indicate a leakage in the air intake system; higher values can suggest a dirty throttle body, obstructed idle by-pass valve passage, friction between the drive pulley and the belt, etc.

Resistance Test Open hood.

Remove pulley guard. Refer to DRIVE SYSTEM AND BRAKE.

NOTE: Air intake silencer may be removed to ease access

access. An idle bypass valve with good resistance mea-surement can still be faulty. It is also possible that a mechanical failure occurs which is not de-tectable without measuring the air flow. Replac-ing the idle bypass valve may be necessary as a test.


Disconnect idle bypass valve from the wiring harness.

Using a multimeter, check the resistance in both windings.

433

Check the resistance between pins as shown.

Section 08 ENGINE MANAGEMENT (V800) Subsection 03 (ADJUSTMENT AND REPAIR PROCEDURES) CAUTION: Always make sure relay 1 is re-moved while the idle bypass valve is removed. CAUTION: Do not try to operate the piston of the idle bypass valve when it is dismounted. Also do not move the piston by hand. The drive screw is very sensitive and may be de-stroyed. IDLE BYPASS VALVE MEASUREMENT RESISTANCE Ω @ 20°C (68°F) PIN 50 Using a part cleaner, clean idle bypass in throttle body from contamination then use an air gun to dry it. Always wear eye protector. Chemicals car cause a rash break out and injure your eyes. If the resistance of one or both windings is not good, replace the idle bypass valve. If resistance test of valve windings is good, check continuity of circuits A-35, A-36, A-37, A-38. If not good, check/repair wiring/connectors. IT THE TYPICAL - IDLE BYPASS VALVE REMOVED 1 Clean bore from contamination Visual Inspection Clean all remaining parts and install the idle bypass valve on the throttle body. NOTE: Make sure to remove relay 1 before the following procedure. Reinstall relay 1. R1 CRANKSHAFT POSITION SENSOR (CPS) TYPICAL Remove idle bypass valve from throttle body. Check the piston and bypass channel for dirt/ deposits which can cause a sticking piston.




Section 08 ENGINE MANAGEMENT (V800)

07-199

MEASUREMENT RESISTANCE Ω @ 20°C (68°F) 700 - 900 Ω







If voltage is appropriate, check/repair wining/ connector between sensor and ECM. If it is good, refer to ECM REPLACEMENT. If voltage is wrong, try a new CAPS.

CAPS Replacement

Unscrew the retaining screw and replace the CAPS. Ensure to reinstall O-ring.



CAPS

Apply Loctite 243 (P/N 293 800 060) on thread and torque to 10 N•m (89 lbf•in).

MANIFOLD AIR PRESSURE AND TEMPERATURE SENSOR (MAPTS)



NOTE: This sensor is a multifunction device. It measures ambient pressure, intake manifold air pressure and temperature for air flow calculations. Open hood

Sensor Pressure Function

Sensor Pressure Function Ensure sensor is correctly installed on intake manifold. Otherwise, the MAPTS could generate a fault code for an unexpected sensor range at idle when it reads the atmospheric pressure. Remove sensor and check for oil or dirt on its end and if problem persists, check throttle plate condition/position and the wiring harness. Per-form the following tests.

MAPTS Voltage Test

Check the voltage output from ECM to the pres-sure sensor. Briefly push START button.

Disconnect plug connector from MAPTS and connect a voltmeter as shown.

MAPTS CONNECTOR PIN		VOLTAGE	



If voltage test is good, replace the MAPTS. If voltage test is not good, check the continuity of the MAPTS circuit. See below.

MAPTS Resistance Test

Disconnect the connector "A" from the ECM. Using a multimeter, check continuity of circuits 12, 28 and 40.

If wiring harness is good, refer to ECM REPLACE-MENT.

Otherwise, repair the connectors or replace the wiring harness between ECM connector and the MAPTS.

MAPTS Test with B.U.D.S.

Using B.U.D.S. software, look the MAPTS from the Monitoring section and read out the pressure value while engine is stopped.



Perform the same test with a new MAPTS and compare both readings. Values have to be within \pm 3.4 kPa (0.5 PSI).

If old MAPTS's value is out of this range, replace it

Sensor Temperature Function The sensor also monitors the temperature at manifold.

MAPTS Resistance Test Disconnect the connector from the MAPTS. Using a multimeter, check the resistance of the sensor itself as shown.







If resistance is not within specification, replace the MAPTS.

If resistance tests good, reconnect the MAPTS and disconnect the connector "A" from the ECM. Using a multimeter, recheck resistance value between pins as shown.

PIN		MEASUREMENT
		RESISTANCE Ω @ 20°C (68°F)
A-7	A-28	2280 - 2740



Using a multimeter, recheck resistance on the ECM connector as per table.



If resistance value is correct, refer to ECM RE-PLACEMENT.

If resistance value is incorrect, repair the connectors or replace the wiring harness between ECM connector and the CTS.

CTS Replacement

Disconnect CTS connector and remove CTS. Install the new CTS and torque to 16 N·m (142 lbf•in).

Reinstall remaining removed parts.

Refill and bleed the cooling system, refer to COOLING SYSTEM subsection.

OIL PRESSURE SWITCH (OPS



Oil Pressure Test

To check the function of the oil pressure switc an oil pressure test has to be performed. Refer OIL PRESSURE TEST in LUBRICATION SYSTE section.

If the engine oil pressure is good, check the r sistance of the OPS while engine is off and whi engine is running.

OPS Resistance Test

Disconnect the connector from the OPS. Use a multimeter to check the resistance i shown.

OPS CONNECTOR PIN		ENGINE NOT RUNNING	ENGINE RUNNING
		RESISTANCE (Ω)	
1	Engine ground	Close to 0 Ω (normally closed switch)	Infinitely high when pressure reache 30 - 60 kPa (4.4 - 8.7 PSI)



If resistance values are incorrect, replace OPS.

If the values are correct, check the continuity of the wining harness. Disconnect the connector "A" from the ECM and check continuity of circuit 10.

If wiring harness is good, refer to ECM REPLACE-MENT.

Otherwise, repair the connector or replace the wiring harness between ECM connector and OPS.

OPS Dynamic Test

First, ensure an oil pressure test has been per-formed and the pressure is within specifications. Start the engine.

Ground the OPS connector. Oil pilot lamp should turn on,


Wait approximately 5 seconds. EMS light should begin to flash and beeper should be heard. If the test succeeded, try a new sensor.


Otherwise, check wiring continuity between sen-sor and ECM.


OPS Replacement

Refer to LUBRICATION SYSTEM section.

Subsection 01 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE (600 MODELS)) COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE (600 MODELS) SERVICE TOOLS Description 9-volt adapter communication kit DESS adapter DESS post interface MPI-2 optional extension cable optional extension cable supply T-harness Part Number 529 035 675 529 035 981 529 035 904 529 036 019 529 036 019 529 036 018 529 035 697 529 035 703 529 035 869 **COMMUNICATION TOOLS** MULTI-PURPOSE INTERFACE Two different MPI (Multi-Purpose Interface) can be used with B.U.D.S. software: MPI and MPI-2. NOTE: This section applies to 600 models. For 600 HO SDI and V800 models, refer to their re-spective ENGINE MANAGEMENT section. (MPI) PARTS REQUIRED (MPI) PC computer B.U.D.S. softwa (Use latest version t version available on BOSSWeb) cation kit (P/N 529 035 981) MPI 1 P/N 529 035 703 100 443







The MPI-2 uses the PC computer USB port power for its supply.

Two installations are possible. For the first instal-lation type , the engine will run during operation. In the second, a 9-volt adapter is used to supply the MPEM instead of magneto.

First Installation Type (with engine running) Connect the connector of the DESS adapter (P/N 529 035 904) onto the 6-pin adapter of sup-ply T-harness (P/N 529 035 869).

NOTE: If necessary, install the optional extension cable (P/N 529 035 697) between the DESS post interface and the MPI-2.

Connect the DESS connector of the DESS adapter (P/N 529 035 904) to the DESS post of the vehicle. Connect remaining MPI-2 connector to the USB port of a PC (personal computer).



Start vehicle and bring engine to approximately 2000 RPM.



Section 09 ELECTRICAL SYSTEM Subsection 01 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE (600 MODELS))


If an "X" is shown, this means that no communi-cation between the MPI and the ECM is possible. In this case possible causes are: - ECM is not powered-up - wrong protocol is used - bad connection between MPI and ECM.

Changes in ECM

Anytime a change is brought in ECM through B.U.D.S.

B.U.D.S.. Transfer with Engine Running When data are being transferred, rev engine speed to 2000 - 2500 RPM and make sure con-nection between B.U.D.S. and vehicle is good. **CAUTION:** Engine must run for the entire pro-cedure. Engine will misfire while vehicle information is be-ing transferred. If engine stalls, restart it and keep engine speed at 2000 - 2500 RPM.

IGNITION SVS		
Idiarriola 313	TEM (440F/550F)	
SERVICE TOOLS		
Description	Part Number	Page
digital inductive type tachometer Fluke 111 multimeter	Part Number 529 014 500 529 035 868	
	023 005 000	
SERVICE PRODUCTS		
Description		
antiseize lubricant	Part Number 293 800 070	Page .452
	293 800 070	402



GENERAL

Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile engine type. The CDI system features an ignition coil integrated to the MPEM.

NOTE: For information pertaining to RER on 440F models, refer to ROTAX ELECTRONIC REVERSE (RER).

Multi-Purpose Electronic Module (MPEM) Connector Identifications



MPEM 1. Reverse switch, reverse indicator and reverse trigger coil (440F only) 2. Trigger coil (forward totation) 3. Ignition generator coil and cut-off switches

Electrical Connectors

Electrical Connectors Before replacing a component, always check electrical connections. The voltage and current might be too weak to go through dirty wire ter-minals. Clean as required. Make sure terminals are properly crimped on wires and fastened in housing, and that they are free of corrosion or moisture. Check MPEM ground connections. A MPEM problem can be resolved simply by un-plugging and replugging the module, indicating a connection problem.

IGNITION SYSTEM TESTING SEQUENCE

In the case of ignition problems, check the follow-ing in the prescribed order until the problem can be solved.

- 1. spark plug
- ignition switch
 tether cut-out switch 4. engine cut-out switch

wiring harness ignition coll ignition generator coil 6 trigger coil MPEM.

Testing Tool

For best results, use the Fluke 111 multimeter (P/N 529 035 868).



Testing Conditions

Voltage measurements are always taken upon en-gine cranking using the rewind starter. Readings when the engine is running would be higher than specified range. Part temperature must be ap-proximately 20°C (68°F) (room temperature), oth-erwise readings could be distorted.

CAUTION: When taking measurements, it is useless to try to run the engine since readings would then be distorted.

Analysis of Readings

Voltage Readings

Take into consideration that readings vary accord-ing to the force applied onto the manual starter. It is therefore important to employ enough force upon each trial.

The reading must be 3 times within or above the range indicated in the corresponding table. If the reading is too low, replace the part.

Resistance Readings

Readings must be within the indicated range. Otherwise, replace the part.

Intermittent Ignition Problems

It is difficult to make a diagnostic in the case of in-termittent ignition problems. Thus, problems oc-curring only when the engine operating tempera-ture is normal must be checked in similar condi-tions.

451

In most cases when problems are caused by tem-perature or vibrations, these can only be solved by replacing parts. Most problems cannot be detect-ed when the engine is stopped.

Multiple Problems

More than one component can be defective. As a result, if the problem remains although a part was replaced, start over the whole verification from the beginning in order to identify the other defective component.

PROCEDURES

SPARK PLUG

Spark Plug Removal

First unscrew the spark plug 1 turn.

Clean the spark plug and cylinder head with pres-surized air, then completely unscrew. **∆** WARNING

Whenever using compressed air, always wear protective eye wear.


Spark Testing

Use the snowmobile spark plug and not a new one. Bring the plug in contact with the engine. Pull rewind starter. If no spark is produced, re-place the spark plug with a new one and do the test again.

If there is still no spark, continue testing.

Spark Plug Installation Prior to installation make sure that contact sur-faces of the cylinder head and spark plug are free of grime. Using a feeler gauge, set electrode gap (except if spark plug is an ECS type) as per TECHNICAL SPECIFICATIONS

- SPECIFICATIONS.
 Apply antiseize lubricant (P/N 293 800 070) over the spark plug threads to prevent possible seizure.
 Hand screw spark plug into cylinder head and tighten with a torque wrench and a proper socket.



Use the following table to torque the spark plug.

ENGINE TYPE	SPARK PLUG	TORQUE N•m (lbf•ft)
443/552	NGK	27 (20)


IGNITION SWITCH

Ignition Switch Resistance Test Remove LH screw and raise side of console



Unplug ignition switch connector.





ENGINE CUT-OUT SWITCH

Engine Cut-Out Switch Resistance Test Upplug connector from engine compartment.



Check the condition of engine cut-out switch as follows

SWITCH POSITION	TEST PROBES	RESISTANCE
Run	BLACK/YELLOW and BLACK wires	OL
Stop	BLACK/YELLOW	0 to 0.5 Ω



If readings do not correspond to the above-mentioned indications, check switch wires/ connector and if good, replace switch.

WIRING HARNESS

Check if wiring harness shows any signs of scoring, chaffing or other damage.

ing, chaffing or other damage. Check wiring harness as follows. No spark problem: Disconnect all switches from the main wiring harness and ensure BLACK/ YELLOW wire is completely isolated from ground. Otherwise, repair/replace wiring. No engine stop problem: Disconnect all switch-es from the main wiring harness and ensure there is continuity between each end of wires of the same color related to ignition. Otherwise, repair/replace wiring. NOTE: All wires of the same color within a given harness are connected together.

IGNITION COIL

Disconnect spark plug cables and remove each cap.


Take measurements and compare readings with the following tables. Proceed with each cylinder spark plug cable.

NOTE: Primary side of ignition coil cannot be measured.

Ignition Coil Resistance Test

TEST	TEST PROBES	RESISTANCE
Secondary winding resistance (WITHOUT spark plug cap)	Each spark plug cable end	900 - 1000 Ω
Spark plug cap resistance	Each side of cap	4 - 6 kΩ





Verifying Timing Mark Position General

- General

 Verification of the position of the timing mark on the magneto flywheel is required for the following reasons:

 To detect a missing or broken magneto flywheel Woodruff key.


 To correctly locate and mark a timing mark on a new service magneto flywheel.

 To verify the correct location of the factory timing mark.

 To detect a wrong magneto flywheel corresponding to a different engine type.


 TDC Gene location

- TDC Gauge Installation Clean the area around the spark plugs, and re-move them. move them. Remove the rewind starter from the engine. Install the TDC gauge in the MAG spark plug hole, and adjust as follows: • Position the magneto flywheel at approxi-mately TDC.



TYPICAL — INSTALLATION OF TDC GAUGE 1. Adaptor lock nut 2. Gauge on MAG side cylinder

- Assemble the gauge to the adaptor and tight-en the roller lock nut. Do not tighten the adaptor lock nut.
 Screw the adaptor into the spark plug hole and tighten to prevent movement in the plug hole.



Trigger Coil Voltage Test

Check the voltage for forward trigger coil. NOTE: Manually crank engine with the spark plug installed. Always repeat the procedure 3 times.

TEST PROBES	VOLTAGE
BLUE/YELLOW and WHITE/YELLOW wires	0.35 to 1.0 Vac

If trigger coil is out of specification, replace it.

MPEM

When other components have been tested above and are good, the electronic module can be sus-pected. NOTE: It is not possible to test MPEM with accu-

racy

ADJUSTMENT

IGNITION TIMING

If for any reason, ignition timing accuracy is suspected, it can be verified as follows.

Verify timing mark position	-
verify timing mark position	
Scribe a new mark if existing mark is not g	000
Check ignition timing with a timing light	

- Position the dial face toward the MAG side. Move the gauge down until the needle just begins to move, then move down a further 5 or 6 mm (approximately 1/4 in). Tighten adaptor lock nut by hand.
 Locate the piston TDC position as follows:
 Slowly rotate the magneto flywheel back and forth across TDC while observing the needle. Note that the needle stops moving only as the piston is changing direction.
 Rotate the dial face so that <0> is in line with the needle when it stops moving.
 Again, slowly rotate the magneto flywheel back and forth across TDC and adjust the dial face to <0, until the needle always stops exactly at <0> before changing direction.
 *0> now indicates exact TDC.

Verification of Timing Mark

Verification of Timing Wark NOTE: When checking timing, certain procedures require that the magneto flywheel be turned in a clockwise direction, viewed facing the MAG side. If it is necessary to turn back (counterclockwise) for any reason, rotate the magneto flywheel at least one-quarter turn counterclockwise, and then rotate it clockwise to ensure the slack in engine moving parts is taken-up.


- neving parts is taken-up.
 Rotate the magneto flywheel counterclock-wise, one-quarter turn then carefully rotate it clockwise until the needle indicates the specified measurement. Refer to TECHNICAL SPECIFICATIONS.
- Verify that the magneto flywheel mark perfectly aligns with the mark on the trigger coil, refer to illustration.
- 1 Trigger coil mark 2 Magneto flywheel r If the marks align, check ignition timing using those marks

 If the marks do not align, check magneto fly-wheel and trigger coil part numbers and check Woodruff key condition. If all parts are good continue procedure to scribe a new mark. NOTE: If marks were not aligned, do not use them to check ignition timing with a timing light.

Scribing a Mark on Magneto Flywheel

- Scribing a Mark on Magneto Flywheel Remove the fan cover from the engine. Maintain magneto flywheel so that previous marks remain aligned. Scribe or punch a mark on magneto flywheel so that it perfectly aligns with the arrow on crankcase, refer to illustration. NOTE: This new timing mark should be used for future timing checks (dynamic verification with timing light). Reinstall rewind starter. Check the timing with a timing light.

Check the timing with a timing light.



Use a timing light and the digital inductive type tachometer (P/N 529 014 500).



IGNITION SYSTEM (600)

SERVICE TOOLS


Description		
digital inductive type tac Fluke 111 multimeter		

SERVICE PRODUCTS

Description Loctite 767 (antiseize lubricant).....

GENERAL

Multi-Purpose Electronic Module (MPEM) Connections



Trigger coil Coolant temperature sensor Januar Col DESS, ignition and engine cut-out switches, DESS pilot lamp

IGNITION SYSTEM TESTING SEQUENCE

In the case of ignition problems, check the follow-ing in the prescribed order until the problem can be solved.

- spark plugs
 electrical connectors
 DESS post
- 4. engine cut-out switch
 5. wiring harness

- 6. ignition coil 7. trigger coil 8. MPEM (Multi-Purpose Electronic Module).

Testing Conditions

Part Number 293 800 070

Part Number 529 014 500 529 035 868

Voltage measurements are always taken upon en-gine cranking using the rewind starter. Readings when the engine is running would be higher than specified range. Part temperature must be ap-proximately 20°C (68°F) (room temperature), oth-erwise readings could be distorted.

CAUTION: When taking measurements, it is useless to try to run the engine since readings would then be distorted.

Diagnostic Tool

For best results, use the Fluke 111 multimeter (P/N 529 035 868).



Analysis of Readings

Voltage Readings

Take into consideration that readings vary accord-ing to the force applied onto the manual starter. It is therefore important to employ enough force upon each trial.

The reading must be 3 times within or above the range indicated in the corresponding table. If the reading is too low, replace the part.

Page ... 462

Resistance Readings

Readings must be within the indicated range. Otherwise, replace the part.

Intermittent Ignition Problems

It is difficult to make a diagnostic in the case of in-termittent ignition problems. Thus, problems oc-curring only when the engine operating tempera-ture is normal must be checked in similar conditions.

In most cases when problems are caused by tem-perature or vibrations, these can only be solved by replacing parts. Most problems cannot be detect-ed when the engine is stopped.

Multiple Problems

More that one component can be defective. As a result, if the problem remains although a part was replaced, start over the whole verification from the beginning in order to identify the other defective component.

PROCEDURES

SPARK PLUG

Spark Plug Removal

First unscrew the spark plug 1 turn. Clean the spark plug and cylinder head with pres-surized air, then completely unscrew.

Whenever using compressed air, always wear protective eye wear.

Spark Testing

Use the samwabile spark plug and not a new one. Bring the plug in contact with the engine. Pull rewind starter. If no spark is produced, re-place the spark plug with a new one and do the test again.


If there is still no spark, continue testing.

Spark Plug Installation

Prior to installation make sure that contact sur-faces of the cylinder head and spark plug are free of grime.

Using a feeler gauge, set electrode gap as per TECHNICAL SPECIFICATIONS.
 Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) over the spark plug threads to pre-vent possible seizure.

Hand screw spark plug into cylinder head and tighten with a torque wrench and a prope socket.



Torque the spark plugs to 27 N•m (20 lbf•ft). ELECTRICAL CONNECTOR

Make sure that none of the connectors are disconnected.

Before replacing a component, always check eler trical connections. The voltage and current migh be too weak to go through dirty wire terminal Clean as required. Make sure terminals are proj erly crimped on wires and fastened in housing and that they are free of corrosion or moisture.

DESS POST

Refer to DIGITALLY ENCODED SECURITY SY. TEM (DESS) section.

ENGINE CUT-OUT SWITCH

Unplug connector under console. Check the condition of engine cut-out switch a follows

SWITCH POSITION	TEST PROBES	RESISTANC
Run	BLACK/YELLOW and	OL
Stop	BLACK wires	0 to 0.5 Ω

If readings do not correspond to the abov mentioned indications, check switch wire connector and if good, replace switch.

WIRING HARNESS

Check if wiring harness shows any signs of scor-ing or other damage. Check wiring harness as follows.

No spark problem: Disconnect all switches from the main wring harness and ensure BLACK/ YELLOW wire is completely isolated from ground. Otherwise, repair/replace wiring.

Otherwise, repair/replace wiring. No engine stop problem: Disconnect all switch-es from the main wiring harness and ensure there is continuity, between each end of wires of the same color related to ignition. Otherwise, repair/replace wiring. NOTE: All wires of the same color within a given harness are connected together.

IGNITION COIL

Resistance Test

NOTE: Keep institute that an ignition coil with good resistance measurement can still be faulty. Volt-age leak can occur at high voltage level which is not detectable with an ohmmeter. Replacing the ignition coil may be necessary as a test.


Unplug connector between ignition coil and MPEM.

Connect multimeter probes to WHITE/BLUE and BLACK wires and measure primary winding resis-



TYPICAL - PRIMARY WINDING

Measure the secondary winding resistance.



If resistances are out of specification, replace ig-nition coil.

TEST	TEST PROBES	RESISTANCE
Primary winding resistance	WHITE/BLUE and BLACK wires	00.0 to 00.9 Ω
Secondary winding resistance with cap	Between both spark plug caps	19 to 27 KΩ

Voltage Test

Disconnect spark plug cable from spark plug.

Eastern mitimeter probe with an alligator clip to spark plug cable, near the spark plug. Connect other multimeter probe to engine ground; then place selector switch to Vac and scale to 0.00.



1. MAG side spark plug cable 2. Connected to ground

Activate the manual starter and check values indi-cated by the multimeter. Repeat operation 3 times.

TEST	TEST PROBES	VOLTAGE
Secondary winding voltage	Spark plug cable and engine	0.1 to 1.4 Vac

TRIGGER COIL

Resistance Test

Unplug connector between trigger coil and MPEM. Connect multimeter probes to WHITE/YELLOW and BLUE/YELLOW wires and measure resis-

ce.	
TEST PROBES	RESISTANCE
WHITE/YELLOW and BLUE/YELLOW wires	190 to 300 Ω

If the trigger coil is out of specification, replace it.

Voltage Test Unplug connector between trigger coil and MPEM.

Connect multimeter probes to WHITE/YELLOW and BLUE/YELLOW wires and measure resis-

tance

Manually start engine and check values indicated by the multimeter.

TEST PROBES	VOLTAGE
WHITE/YELLOW and BLUE/YELLOW wires	.200 to .350 Vac

Reneat test 3 times	 	100 TO 100 TO	


If the trigger coil is out of specification, replace it.

MULTI-PURPOSE ELECTRONIC MODULE (MPEM)

When other components have been tested above and are good, The MPEM can be suspected. En-sure wiring and connectors are in good condition and perform the following tests prior to replacing the MPEM.

Install tether cap on DESS post and place engine cut-out switch in run position.

Disconnect the connector between module and ignition coil.



Trigger coil Coolant temperature sensor Ignition coil DESS, ignition and engine cut-out sw hes, DESS pilot lamp

Install probes on WHITE/BLUE and BLACK wires. Manually start engine and check values indicated by the multimeter.

TEST PROBES	VOLTAGE
WHITE/BLUE and BLACK wires	25.0 to 100.0 Vac

Repeat test 3 times.

If the MPEM is out of specification, replace it.

ADJUSTMENT

IGNITION TIMING

Normally ignition timing adjustment should not be required. It has been set at factory and it should remain correctly adjusted since every part is fixed and not adjustable.

and not adjustable. The only time the ignition timing might have to be changed would be when removing and rein-stalling the magneto housing, replacing the crank-shaft, the magneto flywheel, the trigger coil or the MPEM. If the ignition timing is found incorrect, first check for proper crankshaft alignment. This might be the indication of a twisted crankshaft. Refer to ENGINE MEASUREMENT.

PROCEDURE O	VERVIEW
Scribe a timing mark	

Check ignition timing with a timing light Adjust timing if necessary using B.U.D.S, software

Scribing a Timing Mark

TDC Gauge Installation Clean the area around the MAG spark plug, and remove it.

Install a TDC gauge in the MAG spark plug hole, and adjust as follows: Position the MAG piston at approximately TDC.



TYPICAL 1. TDC gauge on MAG side

- Assemble the gauge to the adaptor and tighten the roller lock nut. Do not tighten the adaptor lock nut.
 Screw the adaptor into the spark plug hole and tighten to prevent movement in the plug hole.
 Position the dial face toward the PTO. Move the gauge down until the needle just begins to move, then move down a further 5 or 6 mm (approximately 1/4 m). Tighten adaptor lock nut by hand.
 Locate the piston TDC position as follows:
- approximately (74 in), ingriterin adaption lock hut by hand.
 Locate the piston TDC position as follows:
 Slowly rotate the drive pulley back and forth across TDC while observing the needle. Note that the needle stops moving only as the piston is changing direction.
 Rotate the dial face so that «0» is in line with the needle when it stops moving.
 Again, slowly rotate the drive pulley back and forth across TDC and adjust the dial face to «0», until the needle always stops exactly at «0» before changing direction.
 «0» now indicates exact TDC.
 Rotate the drive pulley clockwise, one-quarter tum then carefully rotate it counterclockwise until the needle indicates the specified measurement.

MODEL	TIMING MARK (BTDC)
600	3.0 mm (.118 in)

stall the wire on upper starter bolt.



Scribing the Mark

With the TDC gauge indicating specified timing (refer to TECHNICAL SPECIFICATIONS), scribe a mark on drive pulley inner half in line with pointer end




no mark in line with Checking Ignition Timing

The ignition timing can be checked with either the engine hot or cold at the specified RPM.

ENGINE SPEED TO C	HECK IGNITION TIMING
MODEL	ENGINE RPM
600	3500 (1)

¹⁰ Within 3000 and 4000 RPM, the spark advance does not change. Therefore, at 3500 RPM, a change in engine speed of ± 500 RPM will not affect the timing mark.





TYPICAL

The timing mark must be aligned with pointer end within the specified tolerance.

TOLERANCE

If marks are not aligned, note if timing is retarded or advanced as shown. Then, adjust timing as de-scribed below.





Use the latest B.U.D.S. software available from BOSSWeb. Refer to COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE for proper connection instructions

Uses the Setting tab to change the ignition timing. Detailed information about the B.U.D.S. software and its usage is available under its Help section.

IGNITION SYSTEM (V800)

SERVICE TOOLS

-

Description ECM adapter. Fluke 111 multimeter .

Part Number 420 277 010 529 035 868

GENERAL

NOTE: It is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to EMS DIAGNOSTIC AND COMMU-NICATION TOOLS.

NICATION TOOLS. The EMS controls the ignition system. For more information, refer to ENGINE MANAGEMENT. The battery supplies the primary side of ignition coil through a relay (R1) while the ECM completes the circuit for each cylinder by switching it to the ground at the right moment. Upon engine start-ing, the ECM can detect open and short circuit in the primary winding but it does not check the sec-ondary winding.

Diagnostic Tools

For most accurate measurements, use the Fluke 111 multimeter (P/N 529 035 868).



NOTE: To probe the ECM connector terminals, use the ECM adapter (P/N 420277 010) to prevent damaging terminals. Refer to ENGINE MANAGE-MENT for more information.



PROCEDURES

DESS SWITCH

NOTE: DESS switch failure does not prevent ECM power-up. It is mainly used for key recognition and to stop engine. Refer to DESS SYSTEM.

ENGINE CUT-OUT SWITCH

Resistance Test Unplug connector under console.



Check the cond follows.	dition of engine	cut-out switch	as
SWITCH POSITION	RUN	STOP	

 TEST PROBES
 BLACK/YELLOW and BLACK wires

 RESISTANCE
 Open circuit (0L)
 0 to 0.5 Ω




If readings do not correspond to the above-mentioned indications, check switch wires and connector. If good, replace switch.

IGNITION COIL



Quick Test with B.U.D.S. Using the B.U.D.S. software, energize the ignition coil for each spark plug.



You should hear the spark occurring. In doubt, use an inductive spark tester. If there is no spark, per-form the following checks. NOTE: Keep in mind that even if there is a spark during this static test, voltage requirement is high-er to produce a spark in the combustion chamber when engine is running. Ignition coil could be not working in real operation. Replacing ignition coil may be necessary as a test. NOTE: Ensure spark plug cable is on the appropri-ate cylinder.

ate cylinder

Ignition Coil Power Supply

Ensure ignition coil is properly powered as follows. Open hood.

Disconnect the 3-pin connector from the ignition coil and check the voltage supplied by the relay R1.



Briefly press START button to wake up ECM. eter read voltage.



Section 09 ELECTRICAL SYSTEM Subsection 04 (IGNITION SYSTEM (V800))

Reconnect connector to ignition coil. Locate engine connector besides fuse box. Vd BAT +

VOLTAGE

Pin 2 with battery ground

If proper voltage is NOT read, check continuity of ignition coil supply circuit (charging system fuse, relay R1 and fuse F2 and wiring/connectors). If adequate voltage is read, disconnect the ECM connector "A" and check the continuity of appro-priate circuit.

CIRCUIT NUMBER (ignition coil connector)

-<u>0</u>-

If wiring harness is defective, repair the connector or replace the wiring harness between ECM con-nector and the ignition coil. If wiring harness is good, refer to ECM in ENGINE MANAGEMENT.

CIRCUIT NUMBER (ECM connector)

A-1

A-41

IGNITION COIL CONNECTOR

TYPICAL

COMPONENT

Cylinder 1 (front)

Cylinder 2 (rear)

2007-048-004_8

Resistance Test

An ignition coli with good resistance measure-ment can still be faulty. Voltage leak can occur at high voltage level which is not detectable with an ohmmeter. Replacing the ignition coil may be necessary as a test.

Disconnect ignition cable from spark plug.

Disconnect engine connector

ENGINE

Pin 2

PRIMARY

Front

Disconnect connector "A" from ECM (under fuse box).

Using a multimeter, check resistance in primary windings as follows.

If any resistance is not good, replace ignition coil.

ECM CONNECTOR "A" RESISTANCE @ 20°C (68°F)

3-.6Ω

A-1

Primary Windings

Subsection 04 (IGNITION SYSTEM (V800))

If the windings test good, check wiring/ connectors and if adequate, try a new ECM. Reinstall ECM and plug connectors.

Secondary Windings

Due to the integrated diode, it is not possible to take any resistance measurement of the sec-ondary winding.

IGNITION TIMING

Ignition timing is not adjustable.

SPARK PLUG

Spark Plug Removal


Unplug the spark plug cable. Clean the spark plug area with pressurized air. Unscrew spark plug.



TYPICAL 1. Spark plug cable 2. Spark plug

Troubleshooting Fouled Spark Plug

Troubleshooting Fouled Spark Plug Fouling of the spark plug is indicated by irregular running of the engine, decreased engine speed due to misfiring, reduced performance, and in-creased fuel consumption. This is could due to a loss of compression. Other possible causes are: a clogged air filter, incorrect spark plug gab, lubri-cating oil entering the combustion chamber, or too cold spark plug. The plug face of a fouled spark plug has either a wet black deposit or a black car-bon fouling. Such coatings form a conductive con-nection between the center electrode and ground.




TYPICAL 1. Overheated (light grey, white) 2. Normal light brown, brown) 3. Fouled (black, wet or dry, dark de its, grey, m

The plug face reveals the condition of the engine, operating condition, method of driving and fuel mixture. For this reason it is advisable to inspect the spark plug at regular intervals, examining the plug face (i.e. the part of the plug projecting into the combustion chamber).

Spark Plug Installation

Prior to installation make sure that contact sur-faces of the cylinder head and spark plug are free of grime.

- of grime. Using a wire feeler gauge, set electrode gap as per TECHNICAL SPECIFICATIONS. Apply antiseize lubricant over the spark plug threads to prevent possible seizure. Hand screw spark plug into cylinder head and tighten with a torque wrench and a proper sock-et.



1. Proper socket 2. Improper socket

- Torque spark plug to 20 N•m (15 lbf•ft)

CHARGING SYSTEM

SERVICE TOOLS Description Fluke 111 multimeter magneto harness adapter

Part Number	Page
 529 035 868	
529 036 021	

Part Number MT110

Part Number 293 550 004

SERVICE TOOLS - OTHER SUPPLIER

SERVICE PRODUCTS

Description silicone dielectric grease

Description Snap-on inductive ammeter.

GENERAL

NOTE: On applicable models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to EMS DI-AGNOSTIC AND COMMUNICATION TOOLS

Voltage measurements are always taken upon en-gine cranking. Readings when the engine is run-ning would be higher than specified range. Part temperature must be approximately 20°C (68°F) (room temperature), otherwise readings could be distorted.

CAUTION: When taking measurements, it is useless to try to run the engine since readings would then be distorted.

When testing the different magneto components, it is important to take into consideration that read-ing vary according to the force applied onto the manual starter. It is therefore important to employ enough force upon each trial.

The reading must be 3 times within or above the range indicated in the corresponding table. If the reading is too low, the part is considered to be defective and must be replaced.

For best results, use the Fluke 111 multimeter (P/N 529 035 868).



Place the selector switch of the multimeter to the appropriate position for the tests. Readings must be within the indicated range. Otherwise, the part is considered to be defective and must be replaced.

It is difficult to make a diagnostic in the case of intermittent problems. Thus, problems occurring only when the engine operating temperature is normal must be checked in similar conditions.

normal must be checked in similar conditions. In most cases when problems are caused by tem-perature or vibrations, these can only be solved by replacing parts. Most problems cannot be detect-ed when the engine is stopped. As a matter of fact, more that one component can be defective. As a result, if the problem remains although a part was replaced, start over the whole verification from the beginning in order to identify the other defective component.

Page 474

Page . 481-482

Current Type (AC and DC)

Refer to the following chart to identify the current type used on the snowmobile. Pay attention that both AC (alternating current) and DC (direct current) can be used. NOTE: For power distribution diagrams, refer to LIGHTS. INSTRUMENTS AND ACCESSORIES.

MODEL	SYSTEM	CURRENT TYPE
	Lights and accessories	AC
440F and 550F	Starting system Power outlet	DC
	Lights and accessories	AC
600	Starting system Power outlet	DC
600 HO SDI	All	DC
V800	All	DC

PROCEDURES

CHARGING FUSE 440F and 550F Models



600 Models 1. Fuse ho

600 HO SDI Models

To open fuse box push on cover tab and tilt cov-er. A fuse description decal is inside the cover. Charging system uses fuse F1.



1. Cover tat V800 Models

Charging system uses fuse F1.



1. Fuse box 2. Cover tab

VOLTAGE REGULATOR

NOTE: The voltage regulator could be the culprit of a blown charging system fuse. To check, sim-ply disconnect the regulator from the circuit. If the fuse still burns, check for a defective wire.

Continuity Test

Due to internal circuitry, there is no static test available to check continuity.

AC Voltage Test

- AC Voltage lest 400; 550F and 600 Models Proceed as follows: Set multimeter to Vac scale. Disconnect headlamp connector. Set headlamp switch to LOW beam and con-nect multimeter to headlamp connector. Start engine

- Start engine.

MODEL	TEST ENGINE SPEED	WIRE	COLOR	VOLTAGE
440F	5000 0014	WHITE/ GREY	YELLOW/	13.8 Vac
550F, 600	5000 RPM	GREY/ RED	GREEN	± 0.4

- Read voltage.



If voltage is above specification, replace voltage regulator.
 If voltage is below specification, check charging generator coil and wirring/connections. If good, try a new voltage regulator.

DC Voltage Test Proceed as follows: - Set multimeter to Vdc scale. - Connect multimeter to battery posts. - Start engine.

MODELS	TEST ENGINE SPEED	VOLTAGE
440F, 550F and 600	5000 RPM	14.7 Vdc ± 0.4
V800	4000 RPM	
600 HO SDI	5000 RPM	14.1 Vdc ± 0.5



473

Subsection 05 (CHARGING SYSTEM)

If voltage is above specification, replace voltage regulator.
 If voltage is below specification, check charging generator coil and wiring/connections.
 NOTE: If the battery will not stay charged, the problem can be any of the charging system com-ponents. If these all check good, try a new voltage regulator.

DC Current Test

440F and 550F Models

Proceed as follows:
Ensure to turn OFF heated grips and heated throttle lever.

Remove charging system fuse.



1. Fuse h

Set multimeter to Adc.
Start engine by manually cranking engine.
Connect multimeter probes between fuse holder terminals.

-

TEST ENGINE SPEED	CURRENT
5000 RPM	Approx. 1 - 4 A



Read curre

If current is below specification, check magneto (stator) output prior to concluding that voltage regulator is faulty.
 Reinstall fuse.

600, 600 HO SDI and V800 Models

Use a Snap-on inductive ammeter (P/N MT110) and place it over the RED wire going to charging system fuse (connected to starting solenoid).

- Proceed as follows:
 Ensure to turn OFF heated grips and heated throttle lever.
- Set multimeter to Adc.
- Start engine.
- Read current.

MODEL	TEST ENGINE SPEED	CURRENT
600 600 HO SDI	5000 RPM	Approx. 1 - 4 A
V800	4000 RPM	Approx. 3 - 7 A

If current is below specification, check magneto (stator) output prior to concluding that voltage regulator is faulty.

Voltage Regulator Removal

Disconnect battery. V800 Models

Remove fuse block retaining support from frame then move it away to get access to voltage regulator.



All Models Unplug the voltage regulator connector. Remove retaining screws.

Voltage Regulator Installation

The installation is the reverse of the removal pro-cedure. Torque voltage regulator screws to 5 N•m (44 lbf•in).

STATOR

Continuity Test Disconnect engine connector.




Set multimeter to Ω . Read the resistance between wires as follows.

MODEL	W	RE	RESISTANCE @ 20°C (69°F)
440F	VELLOW	VELLOW	0.17 - 0.21 Ω
550F	YELLOW	YELLOW	0.15 - 0.18 Ω
600, 600	HO SDI ar	nd V800 N	lodels
MODE	L TER	MINAL	RESISTANCE @ 20°C (69°F)
1000	1	and 2	STATE OF STREET

440F and 550F Models

	1 0110 2	
600	1 and 3	0.1 - 0.4 Ω
	2 and 3	
	1 and 2	10000
600 HO SDI	1 and 3	0.1 - 0.18 Ω
	2 and 3	the second structure and
	1 and 2	A REPORT OF THE
V800	1 and 3	0.1 - 0.5 Ω
	2 and 3	



TYPICAL

If resistance is out of specification, replace stator. Replug connector properly,

475


Insulation Test Disconnect engine connector.



Set multimeter to Ω . Read resistance as follows

RESISTANCE @ 20°C (69°F) WIRE

Engine OL (open circuit) Any YELLOW wire



If results are out of specification, the generator coil and/or the wiring need to be repaired/replaced.
 Replug connector properly.

AC Voltage Test

- Disconnect the voltage regulator connector.

V800 Models

Install the magneto harness adapter (P/N 529 036 021) on magneto connector. Leave the other connector unplugged.



All Models

Set multimeter to Vac scale. Manually crank engine (on V800, use electric start) and read the voltage as follows. Repeat the test 3 times.

MODELS	V	VOLTAGE	
440F/550F	YELLOW	Remaining YELLOW	3 - 7 Vac
600/600 SDI V800	Any YELLOW	Any other YELLOW	3.5 - 7.5 Vac

If voltage is lower than specification, replace generator coil.
 Re-plug connector properly.

Stator Replacement Refer to appropriate MAGNETO section.

BATTERY 440F Models

General

These models are equipped with a conventional lead acid battery. A ventilation tube is attached to the battery.

MODEL	BATTERY
440F	12N14-3A

Battery Removal Refer to removal information in VRLA battery be-low.

Battery Maintenance

When electrolyte level is too low, refill to upper level line using distilled water only.

Battery Inspection

Visually inspection Visually inspect battery casing for cracks, leaks or raised top, indicates that battery has overheated or been overcharged. If casting is damaged, re-place battery and thoroughly clean battery tray and close area with water and baking soda.

Should the battery casing be damaged, wear a suitable pair of non-absorbent gloves when removing the battery by hand.

Inspect battery posts for security of mounting. Inspect for cracked or damaged battery caps, re-place defective caps.

Battery caps do not have vent holes. Make sure that vent tube is not obstructed.

Battery Cleaning

Clean the battery, battery casing, vent tube, caps, cables and battery posts using a solution of baking soda and water soda and water

CAUTION: Do not allow cleaning solution to en-ter battery interior since it will destroy the elec-trolyte.

trolyte. Remove corrosion from battery cable terminals and battery posts using a firm wire brush. Bat-tery top should be cleaned by soft brush and any grease-cutting soap or baking soda solution.

Battery Testing

Dartery resting There are 2 preferred types of battery test: elec-trolyte reading and load test. An electrolyte read-ing is made on a battery without discharging cur-rent. A load test gives more accuracy of the bat-tery condition.

Electrolyte Reading

Check charge condition using either a hydrometer. A hydrometer measures the charge of a battery in terms of specific gravity of the electrolyte.

BATTERY CONDITION	SPECIFIC GRAVITY
Fully charged	1.265 - 1.280

Most hydrometers give a true reading at 21°C (70°F).



Section 09 ELECTRICAL SYSTEM Subsection 05 (CHARGING SYSTEM)

In order to obtain correct readings, adjust the initial reading by adding .004 points to the hydrometer readings for each 5 5°C (10°F) above 21°C (70°F) and by subtracting .004 point for every 5 5°C (10°F) below 21°C (70°F).

This chart will be useful to find the correct reading.

	OPERATION T	ELECTROLYTE TEMPERATURE	
OHM	PER	°F	°C
1.1.2	.012	100	38
Add to the reading	.008	90	32
reading	.004	80	27
READING	CORREC	70	21
2.000	.004	60	16
Subtract	.008	50	10
from the reading	.012	40	4
	.016	30	-1.

EXAMPLE NO. 1 EXAMPLE NO. 2

EAAMPLE NO. 1 TEMPERATURE ABOVE 21°C (70°F) Hydrometer reading: 1250 Electrolyte temperature: -1°C (30°F) Subtract: 018 Sp. Gr Corrected Sp. Gr. is 1234 EXAMPLE NO. 2 TEMPERATURE ABOVE 21°C (70°F) Hydrometer reading: 1235 Electrolyte temperature: 38°C (100°F) Add: 012 Sp.: Gr. Corrected Sp.: Gr. is 1247

STATE OF	ELECTROLYTE TEMPERATURE	
CHARGE	27°C (80°F)	4°C (40°F)
100%	1.26 - 1.27	1.27 - 1.28
75%	1.21 - 1.22	1.22 - 1.23
50%	1.16 - 1.17	1.17 - 1.18
25%	1.12 - 1.13	1.13 - 1.14
0%	1.10 or less	1.11 or less

Load Test

This is the best test of battery condition under a starting load. Use a load testing device that has an adjustable load. Apply a load of 3 times the ampere-hour rating of the battery for 14 seconds, then check battery

voltage.

LOAD	VOLTAGE
42 A•h for 14 seconds	10.5 Vdc min.

Battery Storage

Battery Storage CAUTION: Battery storage is critical for battery life. Regularly charging the battery during stor-age will prevent cell sulfation. Keeping the bat-tery in vehicle for storage may lead to con-tacts degradation/corosion and case damage if freezing occurs. A discharged battery will freeze and break in area where freezing point is experienced. Electrolyte leakage will dam-age surrounding parts. Always remove battery from vehicle for storage and regularly charge to keep an optimal condition.

Disconnect and remove battery from vehicle as explained in *REMOVAL*.

Check electrolyte level in each cell, add distilled water up to upper level line.

CAUTION: Do not overfill.

The battery must always be stored in fully charged condition. If required, charge until specific gravity of 1.265 is obtained.

CAUTION: Battery electrolyte temperature must not exceed 50°C (122°F). The casing should not feel hot.

Clean battery terminals and cable connections us-ing a wire brush. Apply a light coat of dielectric grease on terminals.

Clean battery casing and caps using a solution of baking soda and water.

CAUTION: Do not allow cleaning solution to enter battery

Rinse battery with clear water and dry well using a clean cloth.

Store battery in a cool dry place. Such conditions reduce self-discharging and keep fluid evaporation to a minimum. Keep battery away from dew, high moisture and direct sunlight.

moisture and direct sunlight. During the storage period, recheck electrolyte level and specific gravity readings at least every month. If necessary, keep the battery at its upper level line and near full charge as possible (trickle


Activation of a New Battery

Never charge or boost battery while installed in vehicle.

Perform the following operations anytime a new battery is to be installed. - Remove the sealing tube from the vent elbow.


Failure to remove the sealing tube could re-sult in an explosion.

 Remove caps and fill battery to UPPER LEVEL line with electrolyte (specific gravity: 1.265 at 21°C (70°F)). NOTE: This battery may fill slower than others due to the anti-spill check ball design.



Sealing tube remo Battery electrolyte Upper level line

Allow the battery to stand for 30 minutes MIN-IMUM so that electrolyte soak through battery



Charging a Used Battery

Never charge battery while installed in vehi cle.

For best results, battery should be charged when the electrolyte and the plates are at room tempera-ture. A battery that is cold may not accept current for several hours after charging begun.

Do not charge a frozen battery. If the battery charge is very low, the battery may freeze. If it is suspected to be frozen, keep it in a heated area for about 2 hours before charging.

Always charge battery in a well ventilated area.

- The time required to charge a battery will vary de-pending on some factors such as: Battery temperature: The charging time is in-creased as the temperature goes down. The current accepted by a cold battery will remain low. As the battery warms up, it will accept a binder rate of charge
- Identify a contrast of a contrast with a coopt a higher rate of charge. State of charge. State of charge. Because the electrolyte is nearly pure water in a completely discharged battery, it cannot accept current as well as electrolyte. This is the reason the battery will not accept current when the charging cycle first begins. As the battery remains on the charger, the current from the charger causes the elec-trolytic acid content to rise which makes the electrolyte a better conductor and then, the battery will accept a higher charging rate. Type of charger: Battery chargers vary in the amount of voltage and current that they can supply. Therefore, the time required for the bat-tery to begin accepting measurable current will also vary. Darging a Very Flat or Completely

Charging a Very Flat or Completely Discharged Battery

The battery charger should have an adjustable charging rate. Variable adjustment is preferred, but a unit which can be adjusted in small incre-ments is acceptable.

The battery charger must be equipped with an am-meter capable of accurately measuring current of less than 1 ampere.

- Unless this procedure is properly followed, a good battery may be needlessly replaced. Measure the voltage at the battery posts with an accurate voltmeter. If it is below 10 volts, the battery will accept current at very low rate, in term of milliamperes, because electrolyte is nearly pure water as explained above. It could be some time before the charging rate increases. Such low current flow may not be detectable on some charger ammeters and the battery will seem not to accept any charge. Exceptionally for this particular case, set the charger to a high rate.

charger to a high rate. NOTE: Some chargers have a polarity protection feature which prevents charging unless the charg-er leads are connected to the correct battery may not have enough voltage to activate this circuitry, even though the leads are connected properly. This will make it appear that the battery will not accept a charge. Follow the charger manufacturer's in-struction on how to bypass or override this circuitry by that the charger will turn on and charge a low-voltage battery. low-voltage battery.

- w-votage battery. Since the battery chargers vary in the amount of voltage and current they provide, the time required for the battery to accept measurable charger current might be up to approximately 10 hours or more.
- If the charging current is not up to a measurable amount at the end of about 10 hours, the bat-tery should be replaced.
- tery should be replaced. If the charging current is measurable before the end or at the end of about 10 hours, the battery is good and charging should be completed in the normal manner as specified in ACTIVATION OF A NEW BATTERY.
- It is recommended that any battery recharged by this procedure be load tested prior to return ing it to service

Battery Installation

Refer to installation information in VRLA battery below

BATTERY (VRLA)

550F, 600, 600 HO SDI and V800 Models

General

These models are equipped with a sealed valve regulated lead acid (VRLA) battery. They are non-spillable and require low maintenance — no elec-trolyte level to be checked and readjusted. No ventilation tube is attached to the battery.

MODEL BATTERY 550F, 600, 600 HO SDI V800 YTX24HL-BS

Battery Removal

Battery BLACK (-) cable must always be dis-connected first and connected last.

Never charge or boost battery while installed on vehicle.

NOTE: According to model, battery is located ei-ther between fuel tank and air intake silencer or under seat.

Remove battery protector



Disconnect BLACK (--) cable end from the terminal.

Slide off rubber boot from RED (+) cable and disconnect it

Unfasten battery.

Remove battery.

CAUTION: Should any electrolyte spillage oc-cur, immediately wash off with a solution of baking soda and water to prevent damage to vehicle components.

Battery Cleaning

Clean the battery, battery casing, cables and bat-tery posts using a solution of baking soda and wa-ter.

Remove corrosion from battery cable terminals and battery posts using a firm wire brush. Bat-tery top should be cleaned by soft brush and any grease-cutting soap or baking soda solution.

Battery Inspection Battery inspection Visually inspect battery casing for cracks, leaks or other possible damage. Discoloration, warping or raised top, indicates that battery has overheated or been overcharged. If casting is damaged, re-place battery and thoroughly clean battery tray and close area with water and baking soda.

Should the battery casing be damaged, wear a suitable pair of non-absorbent gloves when removing the battery by hand.

Inspect battery posts for security of mounting.

Battery Charge Testing Voltmeter Test

Use a multimeter and set it to Vdc.

BATTERY CHARGE TESTING		
PREREQUISITE	VOLTAGE READ	ACTION
Voltage stabilized with battery disconnected for 1 ~ 2 hours before test	12.8 V and above	Nothing required
	Below	Charge battery
	12.8 V	Refer to BATTERY CHARGING below

Battery Storage

CAUTION: A discharged battery will freeze and it may damage its casing. A damaged casing will allow electrolyte spillage that may damage surrounding parts. Disconnect and remove battery from the vehicle.

The battery must always be stored in fully charged condition.

Clean battery terminals and cable connections us-ing a wire brush. Apply a light coat of silicone di-electric grease (P/N 293 550 004) or petroleum jel-ly on terminals.

Clean battery casing using a solution of baking so-da and water. Rinse battery with clear water and dry well using a clean cloth.

Charge the battery every month if stored at temperature below 15°C (60°F).

451

Charge the battery every two week if stored at temperature above 15°C (60°F).

Activation of New Battery

Refer to the instructions provided with the battery. Battery Charging

Always wear safety glasses and charge in a ventilated area. Never charge or boost battery while installed on vehicle. Do not open the sealed caps during charging. Do not place battery near open flame.

CAUTION: If battery becomes hot, stop charg-ing and allow it to cool before continuing. NOTE: Sealed VRLA batteries have an internal safety valve. If battery pressure increases due to overcharging, the valve opens to release excess pressure, preventing battery damage. Perform BATTERY CHARGE TESTING above then

proceed as described here.

proceed as described here. An automatic charger is the fastest and most con-venient way for error-proof charging. When using a constant current charger, charge battery according to the chart below.

Battery Voltage Below 12.8 V and Above 11.5 V

STANDARD CHARGING recommended BATTERY TYPE TIME CHARGE YTX20L-BS 4-9 hours 2 A QUICK CHARGING

BATTERY TYPE	TIME	CHARGE
YTX24HL-BS	50 minutes	10 A

Battery Voltage Below 11.5 V

Batteries with voltage below 11.5 V requires spe-cial procedures to recharge. In charging an over discharged battery, its internal resistance may be too high to charge at a normal charging voltage. Therefore, it may be necessary to raise the volt-age of the battery initially to 25 V as a maximum, and charge for approximately 5 minutes.

If the charger ammeter shows no change in cur-rent after 5 minutes, you need a new battery. Cur-rent flowing into the battery at high voltage can become excessive. Monitor amperage and adjust voltage as necessary to keep current at the bat-tery's standard amp rating. Charge for approxi-mately 20 hours.


Battery Installation


Reinstall battery and secure properly. Connect RED (+) cable it to positive battery termi-nal. If applicable connect the small RED wire. Connect BLACK (-) cable LAST,


Battery BLACK (-) cable must always connected first and connected last.	Battery BLACK (-) cable must always be dis connected first and connected last.		


Never charge or boost battery while installed on vehicle.


Apply silicone dielectric grease (P/N 293 550 004) on battery posts and connectors.

















GENERAL

NOTE: On applicable models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to EMS DI-AGNOSTIC AND COMMUNICATION TOOLS. For best results, use the Fluke 111 multimeter (P/N 529 035 868).



When START is activated, a signal is sent to the starting solenoid. The battery then supplies current to the starter through the starting solenoid to crank the engine. In case of problems, first ensure the problem is not related to engine mechanical components. If not, test the starting system. Causes of problems are not necessarily related to starter but may be due to a burnt fuse, faulty battery, start button or rightion switch, engine cut-out switch (600 HO SDI and V800), starting solenoid, electrical cables and connections.

Electrical Cables and Connections

Check all connections, harnesses and wires. Tighten any loose connections. Replace any chafed wires.

Engine Cranking Conditions V800 Models

Volu Models The following conditions must be met to allow en-gine cranking: – gearbox set to forward. – DESS key on its post – engine stop switch in RUN position – START button pressed and held.

PROCEDURES

FUSES





1. Fuse holde

600 HO SDI Models

To open fuse box push on cover tab and tilt cover. A fuse description decal is inside the cover. Start-ing system uses fuses F1, F3 and F8.



1. Cover tab V800 Models

Starting system uses fuses F1, F3 and F8.



1. Fuse box 2. Cover tab

BATTERY

Refer to CHARGING SYSTEM to check battery condition. If the test is good, continue with the next tests.

REVERSE SWITCH All Models except 440F Check reverse switch. Refer to GEARBOX.

IGNITION SWITCH 440F and 550F Models

Refer to IGNITION SYSTEM.

If the switch works correctly, continue with the next tests.

DESS SWITCH

600, 600 HO SDI and V800 Models NOTE: DESS switch failure does not prevent ECM power-up. It is mainly used for key recognition and to stop engine. Refer to DESS SYSTEM. If the DESS switch works correctly, continue with the next tests.

ENGINE CUT-OUT SWITCH 600 HO SDI and V800 Models Refer to IGNITION SYSTEM.

START SWITCH 600 HO SDI and V800 Models

Switch Resistance Test

Open steering padding. Disconnect the 3-pin connector of switch harne



Measure resistance of switch as follows.

SWITCH POSITION		WIRES	RESISTANCE
Released	PINK	WHITE/PINK	High value or infinite (OL)
Pressed and held	PINK	WHITE/PINK	0.2 Ω (closed)



If resistance test fails, replace switch. Check resistor in WHITE/PINK circuit (see WIRING DIAGRAMS). It should be approximately 48-59.0. If resistor is good, check continuity of WHITE/ PINK wire going to ECM. Replace connector or wiring if test fails.

If connector and wiring tests good, refer to EN-GINE CONTROL MODULE (ECM) in ENGINE MANAGEMENT section.

STEERING CONNECTOR WIRE	ECM CONNECTOR WIRE	RESISTANCE
WHITE/PINK	Pin 19	Continuity (0.2 Ω max.)



Section 09 ELECTRICAL SYSTEM Subsection 06 (STARTING SYSTEM)

STARTING SOLENOID (440F/550F/600)

General Inspect connections and clean as necessary.

Power Supply to Solenoid Winding

Disconnect connector with RED/GREEN wire from solenoid. Check voltage as follows.

Either set engine cut-out switch to STOP or re-move tether cord to prevent engine to run. Activate START and hold to take the measure-ment.

Read voltage.

SOLENOID CONNECTOR (harness side)	VOLTAGE
RED/GREEN with battery ground	Battery voltage

If voltage is not adequate, check continuity of wiring as follows. Disconnect ignition switch connector.

CONN	CONNECTIONS	
RED/GREEN wire at solenoid	RED/GREEN wire at ignition switch connector	Ch
RED wire at ignition switch connector	RED wire (small wire) at battery post	- Close to 0 Ω

Check ground connections of solenoid and starter. If good, test solenoid itself.

Static Test: Continuity

Disconnect the solenoid small terminal from sole-noid.

With a multimeter, check primary winding resis-tance as follows.

CONNECTOR TERMINAL		MEASUREMENT
		RESISTANCE @ 20°C (68°F)
Solenoid small terminal	Engine ground	Approximately 7.5 Ω

Check for stuck solenoid plunger. Disconnect bat-tery ground cable and measure resistance as fol-lows.

SOLENOID CONNECTOR MEASUREMENT Battery post Starter post Open circuit

If any measurement is out of specification, replace solenoid.

Dynamic Test

Reconnect battery ground cable and solenoid ter-minal.

minal. Either set engine cut-out switch to STOP or re-move tether cord to prevent engine to run. Activate START and hold. While engine is crank-ing, measure the voltage drop as follows.

SOLENOID CONNECTOR VOLTAGE

Post coming from battery	Post going to starter	0.2 Vdc max.
from battery	starter	

If voltage is out of specification, replace solenoid. If solenoid tests good, check the electric starter.

STARTING SOLENOID (600 HO SDI)

General

Inspect connections and clean as necessary. Power Supply to Solenoid Winding

Disconnect connector with YELLOW/RED wire from solenoid.



Check voltage as follows. Remove spark plug cables to prevent engine start-ing for the test.


Do not touch spark plug or cables when cranking engine. High voltage would cause a powerful electrical shock if you touch them.

Press START button and hold to take the measurement.

Read voltage.







SOLENOID CONNECTOR MEASUREMENT Battery post Starter post Open circu



If any measurement is out of specification, replace solenoid.

Dynamic Test

Reconnect battery ground cable and solenoid con-nectors.

Remove spark plug cables to prevent engine start-ing for the test.

Do not touch spark plug or cables when cranking engine. High voltage would cause a powerful electrical shock if you touch them.

Press START button and hold. While engine is cranking, measure the voltage drop as follows.

SOLENOID CONNECTOR VOLTAGE Post coming from battery Post going to starter 0.2 Vdc max.



Reconnect spark plug cables. If voltage is out of specification, replace solenoid, If solenoid tests good, check the electric starter.

STARTING SOLENOID (V800)


General

Inspect connections and clean as necessary. Power Supply to Solenoid Winding To gain access to starter solenoid, do the follow

In gain access to state of states, see an access of the states of t



Remove front plate of fuse box support.





If voltage is out of specification, replace spleneed If solenoid tests good, check the electric starter Properly reinstall removed parts.

ELECTRIC STARTER

Starter Test

440F, 550F and 600 Models Either set engine cut-out switch to STOP or re-move tether cord to prevent engine to run.

600 HO SDI and V800 Models

Disconnect spark plug cables.

A WARNING Do not touch spark plug or cables when cranking engine. High voltage would cause a powerful electrical shock if you touch them.

All Models

If any measurement is out of specification, replace solenoid. Reconnect battery ground cable and solenoid con-nectors.

Remove spark plug cables to prevent engine start-ing for the test.

Do not touch spark plug or cables when cranking engine. High voltage would cause a powerful electrical shock if you touch them.

Press START and hold. While engine is cranking, measure the voltage drop as follows.

SOLENOID MEASUREMENT Battery post Starter post 0.2 Vdc max.

Dynamic Test

Remove tuned pipe if necessary. Using booster cable, carefully supply current from the battery directly to the starter. Connect the BLACK cable first. Connect the remaining boost-er cable from the battery then to the starter.



TYPICAL -- VIOD MODEL SHOWN


If the starter does not turn, check for mechanical problem in the starter.


problem in the starter. If the starter turns, ensure wining harmess and com-nectors between battery and starter are in gisted condition. If they test good, the ECM can be aub-pected ROO HO SDI and VS00. Refer to ENGINE MANAGEMENT.

Starter Removal

Turn off ignition switch or remove DESS key
 Disconnect BLACK H cable from bettery

140





Clean starter area. Disconnect starter cable



TYPICAL — SOME PARTS REMOVED FOR CLARITY PURPOSE ONLY

Pull out starter.

Starter Installation 440F and 550F Models

Make sure that starter and engine mating surfaces are free of grime. Serious trouble may arise if starter is not properly aligned.


CAUTION: Make sure that both starter brackets are well seated against engine crankcase and starter before torquing all retaining bolts.

Torque all M8 bolts to 24 ± 4 N•m (18 ± 3 lbf•ft). Torque all M5 bolts to 5 ± 0.5 N•m (44 ± 5 lbf•in).

CAUTION: Before checking engaging depth of starter pinon teeth, make sure that battery cables are disconnected.

Install starter.

NOTE: Check proper engaging depth of starter pinion teeth to ring gear teeth (see illustration). Install hardened washers (P/N 503 007 900) be-tween engine and starter supports accordingly. CAUTION: All starter bracket fasteners must be secured with Loctite 271 (P/N 293 800 005). 1 2



1. Screwdriver pulling starter pinio 2. Ring gear 3. No excessive backlash A. 0.5 to 1.5 mm (020 to .060 in) Connect the RED battery cable and the RED wire to the large terminal of the relay. Connect RED/GREEN wire to small terminal of relay. Connect BLACK cable to battery.

Always disconnect ground cable first and connect last.

600 and 600 HO SDI Models

- Use new teflor washers on the 3 bolts retaining starter to engine.
 Torque the bolts to 28 ± 1 N•m (21 ± 1 lbf•ft).
- Iorque ine bolis to 26 ± 1 (x m 121 ± 1 bir0).
 Make sure that starter and engine mating surfaces are free of grime. Serious trouble may arise if starter is not properly aligned.
 Connect the RED battery cable and the RED wire to the large terminal of the starter.
 Torque large terminal nut to 7 N•m (62 bbf•in).



Section 09 ELECTRICAL SYSTEM Subsection 07 (DIGITALLY ENCODED SECURITY SYSTEM (DESS))

DIGITALLY ENCODED SECURITY SYSTEM (DESS)

SERVICE TOOLS

Description Fluke 111 multimeter

Part Number 529 035 868

GENERAL

NOTE: On applicable models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to EMS DI-AGNOSTIC AND COMMUNICATION TOOLS.

The following components are specially designed for this system: ECM, DESS key and DESS post.

This system allows the engine to reach pulley en-gagement speed only if a programmed DESS key is installed on DESS post.

The DESS key contains a magnet and a ROM chip. The magnet actually closes the reed switch inside the post which is the equivalent of a mechani-cal ON/OFF switch. The chip has a unique digital code

NOTE: Actually, it is the memory of the ECM which is programmed to recognize the digital code of the DESS key. This is achieved with B.U.D.S. SOFTWARE.

The system is quite flexible. Up to 8 DESS keys may be programmed in the memory of the ECM. They can also be erased individually.

They can also be dissed induced, NOTE: if desired, a DESS key can be used on oth-er vehicle equipped with the DESS. It only needs to be programmed for that vehicle. When starting the engine with a DESS key on the post, the DESS is activated and will emit audible

- 2 short beeps indicate a working DESS key. Vehicle can be driven.

1 short beg indicates a wrong DESS key is be-ing used or that something is defective. Vehicle can not be driven.

Engine Starting

If the ECM recognizes a valid DESS key, it allows engine to rev above 3000 RPM.

The ECM will shut down immediately after stop-ping the engine.

KEY PROGRAMMING

Use the latest B.U.D.S. software available from BOSSWeb. For proper connection instructions, refer to the ap-propriate section according to the following table.

Page 502

501

-_

MODEL	SECTION
600	COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE (600)
600 HO SDI	EMS DIAGNOSTIC AND COMMUNICATION TOOLS (SDI)
V800	EMS DIAGNOSTIC AND COMMUNICATION TOOLS (V800)

The B.U.D.S. software is designed to allow, among other things, the programming of DESS key(s) and entering customer information.


For more information pertaining to the use of the software B.U.D.S., use its help which contains de-tailed information on its functions.

If the computer you are using is connected to the 110 Vac power outlet, there is a poten-tial risk of electrocution when working in con-tact with water. Be careful not to touch water while working with the VCK.

Section 09 ELECTRICAL SYSTEM Subsection 07 (DIGITALLY ENCODED SECURITY SYSTEM (DESS)) Ele ⊻iew MEl® Module Iook Help Read ECM using READ DATA button. it. Elle View MPI® Module Iools Help n n 57 Read Data and 1 Read Data Write Data NOTE: There will be an "EMS Tracking" message that will say "Remove key from vehicle". When this occurs, wait until the speedometer turns off, then, click the "Ignore" button and exit B U.D.S. The change is complete. 600 Models Install the new key to be programmed on vehicle DESS post. 600 HO SDI and V800 Models TROUBLESHOOTING Install the new key to be programmed on DESS post interface. If no beep is heard when starting the engine, test beeper operation. Refer to *LIGHTS, INSTRU-MENTS AND ACCESSORIES*. All Models Click on KEYS tab. DESS Post De thes MEAN Status Just the The following continuity tests can be performed using an ohmmeter. • e -For best results, use the Fluke 111 multimeter (P/N 529 035 868). d Date Keys Setting Monitoring Key Usage sed 529 035 868 Click on ADD KEY button on bottom of screen 00 0 1 Disconnect DESS post wires. ۷ DESS Key Removed from Post Connect test probes to DESS post as per tables and measure resistance. Click on this tab A new key is now saved in the computer. NOTE: To program other key(s), install a new key and click again on ADD KEY tab. Ensure to save new data in ECM using WRITE DATA button.

D

Write Data



Section 09 ELECTRICAL SYSTEM Subsection 08 (ROTAX ELECTRONIC REVERSE (440F))

ROTAX ELECTRONIC REVERSE (440F)

SERVICE TOOLS

Description Fluke 111 multimeter

Part Number 529 035 868

Page .505

GENERAL

For best results, use the Fluke 111 multimeter (P/N 529 035 868).



There is 3 main components used for the RER system : the RER switch, the MPEM and the RER trigger coil.

The MPEM receives signals from the trigger coils for the following functions:

Forward engine rotation.
Reverse engine rotation.

The MPEM recognizes a signal sent by the RER switch.

When switch is activated and engine is not run-ning, nothing takes place.

When switch is activated and engine is running, MPEM cuts off ignition. Therefore, engine RPM gradually drops. When engine reaches a low threshold RPM, MPEM sends an ignition spark at a great advance creating a thrust which reverses engine rotation.

engine rotation. In reverse operation, the RER trigger coil is used to give the ignition signal to the MPEM. NOTE: On the 443 engine, RER trigger coil is used only when engine is in reverse operation. Under a threshold low RPM or above drive pulley engagement speed, the RER function is disabled. Nothing takes place when pressing RER button.

TROUBLESHOOTING

RER Does Not Respond When Depressing RER Button Check if engine RER switch works properly.

Engine Stops after Pressing RER Button This confirms that RER switch works. Check trigger coil.

RER Works Erratically

Check engine compression. A low compression engine may result in RER working erratically mak-ing you think the problem is an electronic problem. Check piston condition. Verify piston condition through the intake and exhaust ports. Look for scoring on piston skirts. Scored piston skirts may result in REP working erratically making you think the problem is an electronic problem. Check RER switch.

TESTING PROCEDURES

RER SWITCH

Switch Resistance Test Unplug terminals on RER switch, Check switch as follows.

SWITCH	TERMINAL	RESISTANCE
Released	1 and 2	Infinite (OL)
Heleased		Infinite (UL

Pushed and held 2.8 MΩ

If any reading is out of specification, replace switch.

If switch is good, check wiring/connectors.

Section 09 ELECTRICAL SYSTEM Subsection 08 (ROTAX ELECTRONIC REVERSE (440F))

A switch may pass the test and still cause erratic or no operation of RER because of moisture/water in switch. To check, perform the following voltage test.

Switch Voltage Test


NOTE: This test validates if any moisture/water in switch could cause RER malfunction. Reconnect connector besides MPEM. Start engine and check voltage as follows.

WIRE VOLTAGE 5 Vdc BLUE/BLACK Engine ground



TYPICAL

If voltage is within specification, there is no moisture/water in switch. If voltage is lower than specification, there is mois-ture/water in the switch. Do the following test. NOTE: If voltage is less than approximately 3.5 Vdc the RER system will not work. Unplug connector besides MPEM and restart en-gine to read voltage again.



If voltage is now within specification, problem is in switch or wiring/connectors going to switch. Reconnect connectors.

RER TRIGGER COIL


Trigger Coil Resistance Test Disconnect 4-pin connector from MPEM.




TYPICAL VIEW OF RER TRIGGER COIL CONNECTOR

Check the resistance for RER trigger coil as follows.


TEST PROBES	RESISTANCE	
BLUE/YELLOW and WHITE/YELLOW wires	160 to 180 Ω	



LIGHTS, INSTRUMEN	ITS AND	
SERVICE TOOLS		
Description Fluke 111 multimeter supply harness		
SERVICE TOOLS - OTHER SUPPLIER	R	
Description Fluke rigid back probe	Part Number TP88	Page 509
It is recommended to always disconnect the battery when replacing any electric or elec- tronic parts. Always disconnect battery ex- actly in the specified order, BLACK (-) cable first. Do not place tools on battery. During assembly/installation, use the torque val-	To easily probe wire termin their connectors, Fluke rigi or equivalent can be used	d back probe (P/N TP8
ues and service products as in the exploded views. Clean threads before applying a threadlocker. Re- fer to SELF-LOCKING FASTENERS and LOCITE APPLICATION at the beginning of this manual for complete procedure.		
A WARNING	smc2007-050-004	
Torque wrench tightening specifications must be strictly be adhered to. Locking de- vices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.	They can be inserted at 1 probes of the Fluke 111 r	



Generator	120 Jan 1	122			
coil AC current			Lights and	d accessorie	s
() () () () () () () () () ()	Voltage egulator/ rectifier				
	-	DC surrent	• Starting • Power o	system outlet]
	Battery			1.4	
1440F, 550F AND 600 MODELS	La constantino		1992		
				-	Starting system
			ECM	Battery	
Generator coils AC current		DC current		Relay (R1)	• EMS • Gauges
	Voltage regulator/ rectifier		L	Relay (R2)	Lights Accessorie
mm 2008 disk dick agen		1.1.201			
600 HO SDI MODELS					




NOTE: It is suggested to disconnect headlamp or to connect a battery charger to reduce battery dis-charge rate. NOTE: The use of the supply harmess will keep the ECM ON to give you more time to work. Not using it will make the ECM shut-off after approxi-mately 30 seconds. Use the wiring diagram in *WIRING DIAGRAMS* section to troubleshoot lighting and accessories systems. Once testing is done disconnect supply harmese

systems. Once testing is done, disconnect supply harness from vehicle and then from supply cable. Recon-nect the 6-pin connector in its cap.

PROCEDURES

FUSES

Check if filament is melted. Replace as neces-sary.



1. Fuse 2. Check if melted

CAUTION: Do not use a higher rated fuse as this can cause severe damage to electric components and/or fire.

If fuse has burnt out, source of malfunction should be determined and corrected before restarting.

Electric Power Outlet Fuse

550F and 600 Models Electric power outlet is protected with a 20 amperes rated fuse.



550F MODELS 1. Fuse holder




Fuse Box 600 HO SDI and V800 Models

These models have a fuse box that contains fuses to protect the electrical system.

513

To open fuse box push on cover tab and tilt cover. A fuse description decal is inside the cover.



RELAY R2

600 HO SDI and V800 Models Voltage Test

WIRE TEST VOLTAGE NOTE COLOR YELLOW/ RED and WHITE ingine idling (1500 to 1600 RPM) COIL 10.5 to 13.5 Vdc Engine idling (1500 to 1600 RPM) BLUE/RED CONTACT 00.0 to 0.10 Vdc and RED/BLACK

Test with B.U.D.S.

side

Use B.U.D.S. software

Energize relay 2 from Activation tab. Headlamp should turn on.

If the relay does not work, remove the relay to test the input side of relay coil.

Connect a voltmeter as indicated in the following table.

TEST PROBE (+)	TEST PROBE (-)	VOLTAGE
YELLOW/GRAY wire	Battery ground	Battery voltage

If proper voltage is read, check continuity of WHITE wire between relay connector and pin B-16 of ECM connector. If faulty, repair wire/ connector.

If voltage is not appropriate, check fuse F3 (in-struments will not turn on) and continuity of wire on supply side of relay through relay 1. If faulty, repair wire/connector. If wire/connectors test good, test output side or relay.

Continuity Test

Refer to RELAY R1 for procedure.

RELAY R4

Skandic SWT V800 Models

Voltage Test

TEST	WIRE COLOR	VOLTAGE
COIL side	YELLOW/RED and BLACK	10.5 to 13.5 Vdo
CONTACT side	RED/BLACK and BLUE/RED	00.0 to 0.10 Vdd

Continuity Test

Refer to RELAY R1 for procedure.

HEADLAMP

Bulb Replacement

If any headlamp bulb is burnt, proceed as follows. Remove air duct or protector if applicable. Unplug burnt bulb connector. Remove the rubber boot.

Turn bulb retainer ring counterclockwise to unlock. Detach the bulb and replace.



TYPICAL

CAUTION: Never touch glass portion of an halogen bulb with bare fingers, as it short-ens its operating life. If by mistake glass is touched, clean it with isopropyl alcohol which will not leave a film on the bulb. After lock-ing ring installation, ensure bulb is properly secured in place.

Properly reinstall removed parts.

Headlamp Test

If the new bulbs do not work correctly or if the headlamp is dimmed, proceed as follows.

440F, 550F and 600 Models

For proper operation, the AC system must be iso-lated from DC system. If for instance, an AC accessory was added and grounded to frame or to engine, the headlamp will be dimmed.

NOTE: For proper operation the AC accessory needs to be "grounded" to the YELLOW/GREEN. Use a digital multimeter and set it to ohms. Disconnect connector at headlamp.

Measure resistance as follows.

Section 09 ELECTRICAL SYSTEM

Subsection 09 (LIGHTS, INSTRUMENTS AND ACCESSORIES)






If any resistance value is found, there is an improp-er interconnection between AC and DC circuit. Disconnect one accessory at a time and recheck to find the faulty circuit.

If no resistance is found (open circuit), start engine

Read voltage at headlamp connector as follows. Refer to WIRING DIAGRAMS.




440F, 550F AND 600 MODELS - VAC

If voltage is inadequate, proceed as in ALL MOD-ELS below to find the source of the problem.

600 HO SDI and V800 Models

Install supply harness (P/N 529 035 869) to contin-uously feed electrical system. Refer to *LIGHTING AND* ACCESSORIES SYSTEM TESTING in this section for proper installation.

Read voltage at headlamp connector as follows. Refer to WIRING DIAGRAMS.



600 HO SDI AND V800 MODELS - VDO

If voltage is inadequate, proceed as in ALL MOD-ELS below to find the source of the problem.

All Models

Check appropriate fuse. Refer to FUSE in this section.

Check appropriate relay (if applicable). Refer to POWER DISTRIBUTION in this section. Check headlamp dimmer switch. Check wiring harness and connectors.

Check voltage regulator/rectifier. Refer to CHARGING SYSTEM. Check generator coils. Refer to CHARGING SYS-TEM.

Headlamp Beam Aiming

Beam aiming is correct when center of high beam is 25 mm (1 in) below the headlamp horizontal cen-ter line, scribed on a test surface, 381 cm (12 ft 6 in) away.

Place the vehicle on a flat surface perpendicular to test surface (wall or screen) and 381 cm (12 ft 6 in) away from it.

Rider or equivalent weight must be on the vehicle.

Subsection 09 (LIGHTS, INSTRUMENTS AND ACCESSORIES)

600 HO SDI and V800 Models

1. Mode button 2. Multifunction display

Mode Button

ELECTRONIC SPEEDOMETER

These models are equipped with an electronic speedometer.

Mode Button Depress mode button to change multifunction dis-play. Each time engine is started, display shows odometer. From that point depressing mode but-ton will change display for the trip meter. Depressing mode button again will change display for the resetable hourmeter. Push mode button again to return to odometer.

Push and hold mode button for 2 seconds to reset the tripmeter or the resetable hourmeter depend-ing on the one displayed.

Odometer records the total distance travelled and displays it either in miles or kilometers. Refer to CHANGE FROM ONE UNIT TO THE OTHER for changing units.


Multifunction Display

Odometer


Trip Meter

Select high beam.

Measure headlamp center distance from ground. Scribe a line at this height on test surface (wall or screen). Light beam center should be 25 mm (1 in) below scribed line.



np center line (12 ft 6 in) (1 in) below ce 1. Headlan A. 381 cm B. 25 mm



1. Headlamp horizonta 2. Light beam (high be 3. Light beam center A. 25 mm (1 in) m) (pr ted on the wall)

TAILLIGHT

Bulb Replacement

Unscrew lens screws to expose bulb. Push the bulb in and hold while turning counter-clockwise to release.

Install the new bulb by first pushing in while turn-ing clockwise.

Taillight Removal

Disconnect taillight connector. Remove the wires from connector. NOTE: Note the location of each wire.

Pull wires.

Taillight Installation

mmr2007-200

The installation is the reverse of the removal procedure.

Install wires in connector as noted previously.

Records distance travelled since it has been reset. Distance travelled is displayed either in miles or kilometers. Refer to CHANGE FROM ONE UNIT TO THE OTHER for changing units. Resetable Hourmeter

Records engine running time in hours and minutes since it has been reset.

Push and hold mode button for 2 seconds to reset the hourmeter.

Subsection 09 (LIGHTS, INSTRUMENTS AND ACCESSORIES)

Multifunction Display Code If your speedometer shows SCALE in the multi-function display, it means that the display selector button is stuck in the down position or depressed when the electrical system was activated.

Change from One Unit to the Other

NOTE: Speedometer, odometer and trip meter will have their units (kilometer or miles) changed all together. Stop engine and open engine compartment.

Remove air duct or protector if applicable. Choose the desired unit as follows.





FUNCTION	PIN
Power 12 Vdc (+)	8, 22
Ground	10, 11
Speed sensor signal	6
MPH/Km/h setting	5
Tachometer RPM signal	7
Tachometer control wires	18, 19, 20, 21
HI beam signal	15
Low injection oil level signal	14
Park brake pilot lamp	16
DESS pilot lamp	9
Temperature pilot lamp	2
Engine pilot lamp (EMS)	1
Battery pilot lamp	12

FUNCTION	PIN
Power 12 Vdc (+)	8, 22
Ground	10, 11
Speed sensor signal	6
MPH/Km/h setting	5
Tachometer RPM signal	7
Tachometer control wires	18, 19, 20, 21
HI beam signal	15
EMS signal	1
Engine overheat signal	2
Engine oil pressure signal	14
Low battery voltage signal	12
Park brake pilot lamp	16
DESS pilot lamp	9

Troubleshooting Speedometer

SCALE Appears in Multifunction Display The display selector button is stuck in the down position or was depressed while the speedometer initialized. Press/release button several times to unstick it.

Retry.

Section 09 ELECTRICAL SYSTEM Subsection 09 (LIGHTS, INSTRUMENTS AND ACCESSORIES) NO LIGHTS in Speedometer and Needle Does not Move QUICK CHECK 5 OBSERVATION POSSIBLE CAUSE No power from battery Fuse F3, relay 1 Speedometer does not turn on Wiring/connectors $\overline{\mathbb{V}}$ Defective speedometer Disconnect speedometer connector. Read voltage from vehicle harness as follows. SPEEDOMETER CONNECTOR (harness side) MEASUREMENT Pin 8 12 Vdc If voltage is not good, check/repair wiring/or con-nectors from magneto. If good, check generator coil. Pin 22 Pin 11 Pin 10 Close to 0 Ω E. LIGHTS ARE LIT in Speedometer and Needle Does not Move 3 Check speed sensor. See below. Reconnect connector. Calibration of a New Speedometer î 4 Proceed as follows: If there is voltage, replace speedometer Froceed as following illustrations are examples only. Enter the exact value required for the specific model you are working on. First count number of teeth on sprocket and note it. If there is no voltage, recheck voltage as follows. SPEEDOMETER CONNECTOR (harness side) VOLTAGE Pin 8 Engine ground 12 Vdc Pin 22




If voltage is good, check ground circuit (pin 10 and 11) wiring/connectors.

If speed sensor tests good, replace speedometer.

When installing a new speedometer, it is neces-sary to set it in accordance with the drive axle sprocket used on the vehicle.

CAUTION: If the following operation is not done right the first time, it cannot be repeated. Speedometer calibration can be set only once. Learn the procedure thoroughly before doing it.





Procedure is over.

NOTE: At some point, 0 - 0 will be displayed. Do not use, it is intended for manufacturer only. If in-advertently used, speedometer will exit program-ming mode without causing problems. Restart procedure.

Speedometer Calibration Information

Speedometer Calibration Information To know the actual calibration of a speedometer, proceed as follows. – Ensure speedometer connector is installed. – Install supply harness (P/N 529 035 869) to continuously feed electrical system. Refer to LIGHTING AND ACCESSORIES SYSTEM TESTING for proper installation. – Look at speedometer ► The calibration will be visible a brief moment.



NOTE: Speedometer calibration cannot be set to a different value.

Zeroing Needle on Electronic Speedometer or Tachometer

If needle is not pointing to zero on any electronic speedometer or tachometer, adjust it as follows.



UGNED NEEDLE

IMPORTANT: First ensure gauges are OFF.

Push and hold MODE button on speedometer while installing supply harness (P/N 529 035 869). Refer to LIGHTING AND ACCESSORIES SYSTEM TESTING for proper installation.

In a few seconds "SCALE" should be displayed on gauge



Release mode button then, SCALE will disappear. A set of brackets will be displayed along with a dash going in a circle clockwise then counterclock-



Then, the brackets and moving dash will revert their position. The moving dash will go clockwise then counterclockwise.



This cycle will repeat. To adjust the **speedometer** needle, push MODE button while the moving dash is on left side.



TO ADJUST SPEEDOMETER NEEDLE

To adjust the tachometer needle, push MODE button while the moving dash is on right side.



TO ADJUST TACHOMETER NEEDLE

To move needle clockwise, wait until the moving dash is going clockwise then push and hold mode button until needle is properly aligned.

To move needle counterclockwise, wait until the moving dash is going counterclockwise then push and hold mode button until needle is properly aligned.



Release mode button. After a few seconds, gauge will return to normal operation. The new needle position is now set. Remove supply harmess.

SPEED SENSOR 600 HO SDI and V800 Models

Sensor Static Test Locate speed sensor connector



TYPICAL

Install supply harness (P/N 529 035 869) to continuously feed electrical system. Refer to *LIGHTING AND ACCESSORIES SYSTEM TESTING* for proper installation. Use a multimeter and set it to Vdc.

Back-probe connector and read voltage as follows.

SPEED SENSOR CONNECTOR (sensor side)		VOLTAGE
YELLOW/RED	VIOLET/BLACK	Battery voltage


Subsection 09 (LIGHTS, INSTRUMENTS AND ACCESSORIES)

If voltage is not good, check fuses, relay and winna/connectors. wiring/co

If voltage is good, do the following test. Lift rear of vehicle and safely block.

Before starting engine, ensure track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle. Never rotate at high speed.

Start engine and slightly accelerate engine so that track rotates SLOWLY. Back-probe connector and read voltage.



NOTE: Since we measure pulsating voltage, the numeric display will continuously change. The analog display may be easier to follow. Carlo and and a FLUKE MULTIMETER П VDC



Analog disp

If voltage is appropriate, check/repair wiring/ connector between sensor and speedometer. If it is good, try a new speedometer. If voltage is wrong, try a new sensor.

TACHOMETER

Tachometer Pinout

600 Models

FUNCTION	WIRE
Power 12 Vac to bulb	NEW OWN
RPM signal from magneto	YELLOW
Grounds	YELLOW/GREEN

600 HO SDI and V800 Models

FUNCTION	PIN
Power 12 Vdc (+)	9
Ground	10
Control wires from speedometer	18, 19, 20, 21

Tachometer Test 600 Models

No Light but the Needle Moves

The tachometer light is supplied through the main wiring harness from magneto. Check the voltage between YELLOW and YELLOW/GREEN of bulb. The obtained value should be 12 Vac. Otherwise, check connections and wiring harness.

If the voltage is good, replace the bulb.

The Needle Does not Move

The tachometer is supplied through the main wring harmes from magneto. Check the voltage between YELLOW and YELLOW/GREEN of tachometer.

The obtained value should be 12 Vac. Otherwise, check connections and wiring harness.

If they test good, try a new tachometer. 600 HO SDI and V800 Models

No Light but the Needle Moves


The tachometer power is supplied through the main wiring harness. Check the voltage between pins 9 and 10 of tachometer.

The Needle Does not Move

The speedometer receives AC (RPM signal) from magneto, converts it to DC and then controls the tachometer.


No lights in tachometer: see above.

Lights in tachometer: check wire connections on pins 18, 19, 20 and 21.



If they test good, try a new tachometer. Crazy Needle

Check wire connections on pin 18, 19, 20 and 21



If they test good, try a new tachometer.

Zeroing Needle on Electronic Tachometer Refer to procedure in SPEEDOMETER.

ENGINE TEMPERATURE GAUGE Modèles 600, 600 HO SDI et V800

Gauge Test

Disconnect gauge connector and measure voltage as follows.



MODELS	10DELS GAUGE CC (harnes		VOLTAGE	
600	YELLOW	YELLOW/ GREEN	12 Vac	
600 HO SDI	YELLOW/ RED	VIOLET/	12 Vdc	
V800	GREEN/RED	BLACK		



If voltage is not good, check gauge supply. Refer to POWER SUPPLY in this section.

to POWER SUPPLY in this section. If voltage is good, check temperature sensor on engine as follows. Reconnect gauge connector. Jump VIOLET wire on gauge to ground. Pointer should move to "H" zone.



If so, ensure wiring/connectors going to sensor are good and if correct, replace sensor.
 Otherwise, replace temperature gauge.

HEATING ELEMENTS

NOTE: All measurements must be performed at 21°C (70°F).

Throttle Lever

Unplug the 3-pin connector (440F, 550F and 600) or the 12-pin connector (V800 and 600 HO SDI) under console.



Check heating element as follows RESISTANCE @ 20°C (68°F) INTENSITY ELEMENT TERMINAL BROWN/ YELLOW 18.5 Ω LOW YELLOW/ BLACK

BROWN



If readings are out of specifications, check/repair wining and if good, replace throttle lever. If readings are within specifications, check switch continuity as follows.

440F, 550F and 600 Models

SWITCH POSITION	3-PIN CONNECTOR		RESISTANCI @ 20°C (68°F)
LOW YELLOW		BROWN/ YELLOW	0.5 Ω max.
HIGH		BROWN	

600 HO SDI and V800 Models

SWITCH POSITION	12-PIN CO	ONNECTOR	RESISTANCE @ 20°C (68°F)
LOW	GREEN/	BROWN	
HIGH	RED	YELLOW/ BROWN	0.5 Ω max.



If switch is out of specifications, replace switch. If switch test good, refer to POWER SUPPLY. Reconnect connectors.

Handlebar Grip

Unplug the 15-pin connector (440F, 550F and 600) or the 12-pin connector (V800 and 600 HO SDI) under console.



Check heating element on each side as follows.

INTENSITY	WIRE OF ELEMENT CONNECTOR		@ 20°C (68°F)
LOW	ORANGE/ VIOLET	YELLOW/	15.2 Ω
HIGH	ORANGE	BLACK	7.6 Ω



If readings are out of specifications, check/repair wiring going to heating grip and if good, replace handlebar grip. If readings are within specifications, check switch continuity as follows. 440F, 550F and 600 Models

440F, 550F	and 600 Woders	
SWITCH POSITION	15-PIN CONNECTOR	RESISTANCE @ 20°C (68°F

LOW	YELLOW	ORANGE/ VIOLET	0.5 Ω max.
HIGH		ORANGE	

600 HO SDI and V800 Models SWITCH POSITION 12-PIN CONNECTOR





If switch is out of specifications, check wiring/ connectors going to switch. If they are good, re-place switch.

If switch test good, refer to POWER SUPPLY in this section.

Reconnect connectors.

Rear Passenger Grips

If so Equipped

Unplug connector. Check heating element on each side as follows.

INTENSITY	WIRE OF ELEMENT CONNECTOR		RESISTANCE @ 20°C (68°F
LOW	ORANGE/ BLUE BLACK		19 Ω
HIGH	ORANGE		9.5 Ω

If readings are out of specifications, check/repair wring going to heating grip and if good, replace grip. If readings are within specifications, check switch.

If switch tested good, refer to POWER SUPPLY in this section. Reconnect connectors.

12-VOLT POWER OUTLET All Models except 440F

Power Outlet Removal

Remove the console.

Remove connectors from the power outlet housing.

Unscrew the large nut then remove the 12-volt power outlet.

Power Outlet Test

First, try another accessory (DC current), if it does not work, check outlet supply. Remove power outlet.

Unplug the power outlet connectors. Turn ignition key to ON or install DESS key as per models.

Measure the voltage as follows.

MODELS WIRES VOLTAGE 550F RED/BLUE BLACK 12 - 14,5 Vdc All others YELLOW/RED BLACK 12 - 14,5 Vdc VOLTAGE

No voltage: • Check accessories fuse (20 A) and relay 1 (if applicable), connectors and wiring harness.

Voltage is good:
 After checking the accessories, change the power outlet.

Installation

The installation is the reverse of the removal pro-cedure.

12-VOLT REAR POWER OUTLET Skandic SWT V800 Models

Rear Power Outlet Test

First, try another accessory (DC current), if it does not work, check outlet supply. Unplug the power outlet connectors.

Turn on rear power outlet switch (test both positions)

Measure the voltage as follows.

WIRES VOLTAGE RED/BLACK BLACK 12 - 14.5 Vdc No voltage:

- Check fuse F9 and relay 4, connectors and wiring harness.
- Voltage is good:
 After checking the accessories, change the power outlet.

BEEPER

Beeper Test (reverse function) 440F, 600 HO SDI and V800 Models

NOTE: This beeper works with DC current. Disconnect connector from beeper.



Use a multimeter and set it to Vdc Set gearbox to reverse. Install DESS cap.

On 440F models, start engine.

Read voltage as follows.

MODEL	TER	MINAL	VOLTAGE
440F	GIBAY/ BLACK	BLACK	Battery
600 SDI and V800	YELLOW/ RED	WHITE (see photo)	voltage



Stop engine on 440F models

If voltage is as per specification, replace beeper. It vottage is as per specification, replace beeper, if voltage is out of specification, check reverse switch for mechanical and electrical operation. If switch is good, check fuse, relay 1 (if applicable) and wring/connectors. When everything else has been tested and voltage is still inappropriate, MPEM can be suspected on 440F models.

550F and 600 Models

NOTE: This beeper works with AC current from magneto. Wires can be installed in any position on beeper.

Dispaniect connectors from beeper Use a multimeter and set it to Vac.

Set gearbox to reverse. Start engine and read voltage as folio

WIRES		VOLTAGE	
YELLOW	REDNELLOW	Anorea 13	

Stop engine. If voltage is as per specification, replace besper.

If voltage is out of specification, check revenue awitch for mechanical and electrical operation, it switch is good, check wiring/connectors.

Beeper Test (EMS functions) 600 HO SDI and V800 Models

Disconnect connector from beeper. Install DESS cap Read voltage as follows.

TERM	INAL	VOLTAGE
YELLOW/RED	WHITE (see photo)	Pulseting bettery voltage according to beens



If woltage is as per specification, replace beeper If votage is so to specification, check fuse, re-lay 1 and wining/connectors. When everything else has been tested and voltage is still inappropriate, ECM can be suspected.

	ELT		
SERVICE TOOLS	3		
Description belt tension feature drive belt tension adjust driven pulley opening to APPPLICATION C	d	Pert Number 414 348 200 529 006 700 529 017 200	
MODEL	PIN	MINIMUM WIDTH	
107	414 633 800	(wear limit)	
850F	414 633 600	32.00 mm (1.260 m) 32.30 mm (1.272 m)	
600	417 300 155	34.5 mm (1.374 in)	
ICE OH 208	605 348 425	34.9 mm (1.374 ml	
VBOD	605 348 425	35.5 mm (1-13/32 m)	
Screw the driven pulley	opening tool (P/N 629 017		
	opening tool (PN 529 017 class of driven pullery and pulley. The pulley. The pulley.	Inclusion of the second	

Section 10 DRIVE SYSTEM AND BRAKE Subsection 01 (DRIVE BELT)

Drive Belt Inspection

Inspect belt mispection Inspect belt for cracks, fraying or abnormal wear (uneven wear, wear on one side, missing cogs, cracked fabric). If abnormal wear is noted, prob-able cause could be pulley misalignment, exces-sive RPM with frozen track, fast starts without warm-up period, burred or rusty sheave, oil on belt or distorted spare belt. Check drive helt with Banlace the drive helt

distorted spare belt.
 Check drive belt width. Replace the drive belt if width is under minimum recommended width (see APPLICATION CHART above).

Drive Belt Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. NOTE: The drive belt height and deflection must be checked each time a new drive belt is installed and should be rechecked after 50 km (30 miles).

The maximum drive belt life span is obtained when the drive belt is installed as shown. This will ensure that correct direction of rotation is respected.



Drive Belt Height Adjustment Before checking the belt height, ensure that a good-condition proper belt (refer to the APPLICA-TION CHART) is installed.

Check pulley alignment. Refer to PULLEY ALIGN-MENT.

To obtain maximum vehicle performance, the drive belt cord should be flush with driven pulley edge. Adjust as required.



TYPICAL 1 Flush

Adjust drive belt height using Allen screws. Loosen jam nuts then turn Allen screws.




LPV 27 DRIVEN PULLEY


CAUTION: Do not force or use tools to pry the belt in place, as this could cut or break the cords in the belt.

INCORRECT


1

Install the drive belt between drive pulley sheaves. Insert, by the top, the belt between driven pulley sheaves. Finish with the bottom. Adjust belt then install belt guard and close hood.





DRIVE PULLEY (COMET® 102)			
SERVICE TOOLS			
Description	Part Number	Page	
drive pulley holder	529 006 400	535	
tanered tool	529 000 400		
tripod tool			
SERVICE PRODUCTS			
Description	Part Number	Page	
Primer N	293 800 005		
pulley flange cleaner.	293 800 041 413 711 809	536-538	
	Carrier C. S. S. C. S. C. S. C. Starter		
The second second second second			
and the second			
and the second second second second			
		573	



GENERAL PROCEDURES NOTE: Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile drive pulley type. Sheave Removal (drive pulley) Never start engine when the pulley guard is removed. Some drive pulley components can be changed to improve vehicle performance in high altitude regions. A Service Bulletin will give information about calibration according to altitude. **CAUTION:** Such modifications should only be performed by experience mechanics since they can greatly affect vehicle performance. Any drive pulley repairs must be performed by an authorized BRP snowmobile dealer. Subcomponent installation and assembly tolerances require strict adherence to proce-dures detailed. 529 006 400 6 Never use an impact wrench to remove or in stall the drive pulley. The drive pulley assembly is a precisely bal-anced unit. Never replace parts with used parts from another drive pulley assembly.

During assembly/installation, use the torque values and the service products as in the exploded

view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENER and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed. newed.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 02 (DRIVE PULLEY (COMET® 102))

FIXED AND SLIDING SHEAVES

Never use an impact wrench to remove or in stall the drive pulley.

Unfasten center and rear bottom pan attachments on left hand side. Remove belt guard. Remove drive belt. Refer to DRIVE BELT for pro-cedure.

Use the drive pulley holder (P/N 529 006 400). Make sure holder hook is positioned on top of tow-





1. Holder hook on top of

Remove drive pulley screw no. 1 Install the drive pulley holder (P/N 529 006 400) in a way to limit pulley clockwise rotation.

Insert the drive pulley puller (P/N 529 025 000) then turn puller clockwise to free drive pulley from crankshaft taper.

Subsection 02 (DRIVE SYSTEM AND BRARE Subsection 02 (DRIVE PULLEY (COMET® 102))



Remove driven pulley to make room for drive pul-ley removal (refer to DRIVEN PULLEY). Remove drive pulley.

Sheave Disassembly (drive pulley) Mount tapered tool (P/N 529 035 826) in a vise.

Clean tool and inner pulley taper with pulley flange cleaner (PN 413 711 809). Install drive pulley over tapered tool then, fasten drive pulley screw no. 1 and torque to 68 N•m (50 Ibi+ft). Now drive pulley is locked on tapered tool.



Scribe pen marks on sliding sheave no. 10, gov-errior cup no. 5 and spring cover no. 3 for proper indexing at reassembly.

Hold spring cover no. 3 by hand then, unscrew drive pulley screw.

Scribe marks

Remove spring cover screws no. 2.

10



Remove spring cover. Heat governor cup no. 5 to melt threadlocker. Install the tripod tool (P/N 529 025 200) then, un-screw governor cup.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 02 (DRIVE PULLEY (COMET® 102))



Note shim no. 8 quantity.



1. Shim:

Lift sliding sheave to separate it from fixed sheave

Sheave Inspection

Check surfaces of fixed and sliding sheave for scratches, excessive wear or other damages. Replace as required. Check sliding sheave for excessive lateral play and fixed sheave shaft for scratches. Replace if nec-

essary.

Check spring cover bushing. Replace cover if bushing is completely bronze instead of the origi-nal teflon coating.

Check slider shoes no. 6 for proper sliding action. Replace as required. Check rollers no. 7 for free action. Replace as required.

Sheave Cleaning

Clean pulley faces and shaft with fine steel wool and clean dry cloth. Clean sliding sheave bushing and spring cover bushing with a clean dry cloth.

Remove grease or oil with pulley flange cleaner (P/N 413 711 809).

Sheave Assembly (drive pulley)

Clean governor cup and fixed sheave threads. Install shims no. 8 on fixed sheave shaft.

Apply Primer N (P/N 293 800 041) on fixed sheave threads and governor cup threads, allow to dry for 10 minutes. Apply Loctite 271 (red) IP/N 293 800 005) to threads.

Using the tripod tool (P/N 529 025 200), torque governor cup to 170 N•m (125 lbf•ft).

Install spring no. 4, and spring cover no. 3. Install the drive pulley screw to compress the spring and position spring cover on sliding sheave towers.

Tighten spring cover screws to 12 N•m (106 lbf•in). Proceed with one screw per tower in a criss-cross sequence then, remaining three screws.

Remove the drive pulley screw. Use the drive pulley puller (P/N 529 025 000) to unlock drive pulley from tapered tool.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 02 (DRIVE PULLEY (COMET® 102))



Sheave Installation (drive pulley)

Clean crankshaft taper and inner pulley taper with pulley flange cleaner (P/N 413 711 809). Install drive pulley on crankshaft.

Install the drive pulley screw with a new lock washer.

Torque drive pulley screw to 68 N•m (50 lbf•ft). Reinstall driven pulley, drive belt and belt guard. Refasten bottom pan center and rear attachments on left hand side.

Raise the rear of the vehicle and support it with a mechanical stand.

A WARNING

Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the vehicle.

Accelerate the vehicle at low speed (maximum 30 km/h (20 MPH)) and apply the brake, repeat 5 times.

Recheck the torque of 68 N•m (50 lbf•ft),

A WARNING

After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.

RAMPS

Ramp Replacement With drive pulley installed on vehicle, loosen one turn the spring cover screws no. 2.

Remove ramp no. 12 with washers no. 13 and bushing no. 14.

Check ramp and bushing for wear. Replace as re quired.

CAUTION: Always replace all ramps and bush ings at the same time and make sure to use identical ramps. Install ramp.

With square end facing sliding sheave, install a washer no. 13 on each side of ramp.




1. Square end facing sliding sheave

Tighten pivot bolt nut no. 15 to 5.6 N•m (50 lbf•in maximum. Make sure ramp can still move on piv ot bolt no. 11.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 02 (DRIVE PULLEY (COMET® 102))

539



Retighten cover screws to 12 N•m (106 lbf•in). Proceed with one screw per tower in a criss-cross sequence then, remaining three screws.

RING GEAR

Ring Gear Removal


Remove drive pulley from vehicle. Refer to FIXED AND SLIDING SHEAVES. Using a heat gun, heat ring gear screws no. 17 to melt threadlocker.

Remove ring gear screws, washers no. 18 and ring gear no. 19.

Ring Gear Installation

Ring Gear Installation The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Clean threaded holes of fixed sheave. Apply Loctite 271 (red) (P/N 293 800 005) on threads of ring gear screws and between screw heads and thick flat washers. Torque screws in a criss-cross sequence to 27 N=m (20 lbf+ft). NOTE: It is of the utmost importance to use thick flat washers with ring gear screws in oder not to pierce inner fixed sheave with the screws.

	Subsection 03 (DRIVE PULLEY (BON	
DRIVE PULLEY (BOMBARDIER LI	TE)
SERVICE TOOLS		
pulley holder	Part Number 529 027 600 529 022 400 529 035 826 529 035 826 529 027 300	543-546
SERVICE PRODUCTS		
Description	Part Number	Page
Loctite 271 (red) pulley flange cleaner	293 800 005	100 C 100 C 100 C 100 C 100 C 100 C
	413711000	



Section 10 DRIVE SYSTEM AND BRAKE Subsection 03 (DRIVE PULLEY (BOMBARDIER LITE))

GENERAL

NOTE: Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile drive pulley type.

Never start engine when the pulley guard is removed.

Some drive pulley components (return spring, cal-ibration disk) can be changed to improve vehicle performance in high altitude regions. A Service Bulletin gives information about calibration accord-ing to altitude.

CAUTION: Such modifications should only be performed by experience mechanics since they can greatly affect vehicle performance.

Any drive pulley repairs must be performed by an authorized Ski-Doo dealer. Subcompo-nent installation and assembly tolerances re-quire strict adherence to procedures detailed.

Never use an impact wrench to remove or in

stall the drive pulley.

The drive pulley assembly is a precisely bal-anced unit. Never replace parts with used parts from another drive pulley assembly.

During assembly/installation, use the torque v ues and the service products as in the explode view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENER and LOCITIE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

PROCEDURES FIXED AND SLIDING SHEAVES

Sheave Inspection

Check surface of sliding sheave and fixed sheave for scratches, excessive wear or other damages. Replace if necessary.



1. Sliding sheave 2. Fixed sheave

Check sliding half for excessive lateral play and fixed half shaft for scratches. Replace as required.

Sheave Removal (drive pulley)

Open the hood to remove the belt guard and the drive belt. Using the drive pulley holder (P/N 529 027 600), hold the drive pulley to remove the drive pulley bolt and its lock washer.





Hold the drive pulley and screw in the puller then remove drive pulley

Section 10 DRIVE SYSTEM AND BRAKE Subsection 03 (DRIVE PULLEY (BOMBARDIER LITE))

Sheave Cleaning

Clean pulley faces and shaft with fine steel wool and clean dry cloth. Clean sliding sheave bushing with clean dry cloth.

Remove grease or oil with pulley flange cleaner (P/N 413 711 809).

Sheave Installation (drive pulley)

Clean crankshaft taper and inner pulley taper with pulley flange cleaner (P/N 413 711 809).

Install the drive pulley bolt and its lock washer. Hold the drive pulley with the drive pulley holder (P/N 529 027 600) then torque bolt to 90 Nem (66 lbf+ft).

Install drive belt and belt guard.

Raise and block the rear of the vehicle and support it with a mechanical stand.

A WARNING

Make sure the track is free of particles that could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the ve-hicle.

Accelerate the vehicle at low speed (maximum 30 km/h (20 MPH)) and apply the brake, repeat 5 times.

Retorque bolt to 95 N•m (70 lbf•ft).

After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.

GOVERNOR CUP

Governor Cup Removal

Remove drive pulley from engine. Refer to FIXED AND SLIDING SHEAVES.

Remove governor cup nut. Two methods can be used to unscrew the nut.

With Pulley Holder: – Install the pulley holder (P/N 529 035 826) in a vice.



Install the drive pulley on it



Unscrew nut on the top of drive pulley. Re-move washer.



Governo Nut Washer

To remove the pulley holder from fixed sheave, use the drive pulley puller (P/N 529 022 400). Without Pulley Holder:

Install the governor cup nut in a vice.



Section 10 DRIVE SYSTEM AND BRAKE Subsection 03 (DRIVE PULLEY (BOMBARDIER LITE))



Remove the governor cup

Governor Cup Inspection


Check the hexagonal opening of governor cup for excessive wear or looseness.

Governor Cup Installation

NOTE: Even if two methods can be used to un-screw the governor cup nut, the following proce-dure is the only one (the one and only) method to tighten governor cup nut properly.

Install the pulley holder (P/N 529 035 826) in a vice. Clean pulley holder taper and the inner taper of fixed sheave with pulley flange cleaner (P/N 413 711 809).

Install fixed sheave on tool and sliding sheave on fixed sheave shaft. When assembling pulleys, align marks on gover-nor cup and pulley sheaves.



1. Alignment marks

Install washer and nut.

Tighten nut to 128 N•m (94 lbf•ft).

To remove the pulley holder from fixed sheave, use the drive pulley puller (P/N 529 022 400).

CENTRIFUGAL WEIGHT Centrifugal Weight Removal

Remove governor cup, see above for procedure. Identify blocks and their respective positive posi-tions for reassembly.




Remove blocks with their calibration weights. Centrifugal Weight Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Make sure to install blocks at their original position and with their curved end toward governor cup. See following illustration.



Centrifugal Weight Calibration Use the following table to calibrate this drive clutch properly.






	FACTOR	Y CALIBRATI	ON
ENGINE	CA	LIBRATION W	EIGHT
ENGINE	WASHERS BY BLOCK	WASHER P/N	WEIGHT PER WASHER
	1	417 120 400	21 gr
550F	4	417 114 400	3.4 gr

SPRING

Spring Removal

Remove governor cup and centrifugal weights. Install the spring cover tool (P/N 529 027 300) with the drive pulley puller (P/N 529 022 400) on spring



1. Drive pulley puller tool 2. Spring cover tool

Screw puller (hand tight) to hold spring cover and remove screws holding spring cover. Slowly unscrew puller to release spring pressure. Remove spring cover, spring and spring seat.

Spring Inspection

Check the free length of spring. Replace spring if it is out of specification.

SPRING FREE LENGTH	

	LENGTH

a second the second second second	04.01 4.5
SERVICE LIMIT	94.61 ± 1.5 mm
OLITIOL LIMIT	(3.725 ± .060 in)

(3.725 ± .060 in)


SERVICE LIMIT	(3.725 ± .060 in)
The second se	


Spring Installation
Install spring seat then the spring and its cover.

RING GEAR

Ring Gear Removal

Remove drive pulley from engine. Refer to FIXED AND SLIDING SHEAVES. To remove the ring gear, use a heat gun to break the threadlocker on ring gear screws before un-screwing.





GENERAL

NOTE: Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile drive pulley type.

Never start engine when the pulley guard is removed.

TRA drive pulley stands for Total Range Adjustable drive pulley

NOTE: This is a lubrication free drive pulleys. Al-ways refer to appropriate PARTS CATALOG for re-placement part. Most parts of TRA IV are not in-terchangeable with those of the other TRA pulley

type. Some drive pulley components (return spring, ramp) can be changed to improve vehicle perfor-mance in high altitude regions. A Service Bulletin will give information about calibration according

A WARNING

Any drive pulley repairs must be performed by an authorized BRP snowmobile dealer. Sub-component installation and assembly tolerances require strict adherence to proce-dures detailed.

CAUTION: Such modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance. Verify spring specifications before installation. Do not only refer to the spring color code.

Never use any type of impact wrench at drive pulley removal and installation.

The drive pulley assembly is a precisely bal-anced unit. Never replace parts with used parts from another drive pulley assembly.

During assembly/installation, use the torque val-ues and the service products as in the exploded view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENER and LOCTITE APPLICATION at the beginning of this manual for

complete procedure.

A WARNING

tightening ly be ad ed to

must strictly be adhered to. Locking devices (e.g.: locking table, eleastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with naw ones where specified. If the efficiency all a locking device is impaired, it must be re-recent newed

PROCEDURES

CALIBRATION SCREWS

Calibration Screw Adjustment

Calibration Screw Adjustments The drive pulley is factory calibrated to transmit maxmum engine power at a predefined RPM. Factors such as ambient temperature, altitude or surface condition may say this critical engine RPM thus affecting snowmobile efficiency.


This adjustable drive pulley allows setting maximum engine RPM in the vehicle to maintain maximum power.

NOTE: Use the digital inductive tachometer NOTE: Use the digital inductive tachometer. Calibration screws should be adjusted so that ac-tual maximum engine RPM in vehicle matches the maximum horsepower RPM given in TECHNICAL SPECIFICATIONS.

NOTE: The adjustment has an effect on high RPMI

To adjust, modify ramp and position by turning cal bration screws.

Calibration screw has a notch on top of its he



Governor cup has 6 positions numbered 1 to 8.



Each number modifies maximum engine RPM by about 200 RPM.

Lower numbers decrease engine RPM in steps of 200 RPM and higher numbers increase it in steps of 200 RPM.

Example: Calibration screw is set at position 3 and is changed to position 5. So maximum engine RPM is increased by about 400 RPM. See the following table for original setting.


CALIBRATI	ON SCREW
600	Position 3
600 HO SDI	Position 5

To Adjust:

To Adjust: Just loosen locking nut enough to pull calibration screw partially out and adjust to desired position. Do not completely remove the locking nut. Torque locking nuts to 10 Nem (89 lbf•in).


CAUTION: Do not completely remove calibra-tion screw otherwise its inside washer will fall off.

CAUTION: Always adjust all 3 calibration screws and make sure they are all set at the same number.



TYPICAL 1. Loosen just enough to pe mit rotating of calibration screw

Calibration Screw Replacement When installing calibration screw, make sure to install washer as shown.




TYPICAL 1. Washe

Torque locking nut to 10 Nom (89 lbfoin). FIXED AND SLIDING SHEAVES

Sheave Inspection

Check surface of sliding sheave and fixed sheave for scratches, excessive wear or other damages. Replace if necessary.



Sheave Cleaning

Clean pulley sheaves and shaft with fine steel wool and dry cloth.

Remove all hardened oil deposits that have baked on crankshaft and pulley tapered surfaces with coarse or medium steel wool and/or sand paper no. 600.

CAUTION: Do not use any other type of abra-

Sheave Assembly

The assembly is the reverse of the disassembly procedures. However pay attention to the following.

Make sure to align the sliding sheave mark with the fixed sheave mark.



Using a plastic hammer, strike hub firmly 2 or 3 times to ensure proper seating of cones.

Sheave Installation (drive pulley)

Do not apply antiseize or any lubricant on crankshaft and drive pulley tapers.

Parts must be at room temperature before cleaning.

Using a paper towel with pulley flange cleaner (P_N 413 711 809), clean crankshaft tapered end and the taper inside the fixed sheave of the drive pulley, crankshaft threads and retaining screw threads.

Before installation of drive pulley, clean also crank-shaft threads and retaining screw threads.

CAUTION: Avoid contact between cleaner and crankshaft seal because damage may occur. Reclean mounting surfaces with paper towel and cleaning solvent.

Wipe off the mounting surfaces with a clean, dry

CAUTION: Mounting surfaces must be free of any oil, cleaner or towel residue. Install drive pulley on crankshaft extension

Install a new conical spring washer with its con-cave side towards drive pulley then install screw.

Never substitute conical spring washer and/or screw with jobber ones. Always use BRP genuine parts for this particular case. Using the drive pulley holder (P/N 529 035 674), torque screw to 90 N•m (66 lbf•ft).

Install drive belt and guard.

Raise and block the rear of the vehicle and support it with a mechanical stand.

Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the ve-hicle.

Accelerate the vehicle at low speed (maximum 30 km/h (20 MPH)) and apply the brake, repeat 5 times

Retorque screw to 95 Nom (70 lbfoft).


After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.

GOVERNOR CUP

Governor Cup Removal

Remove drive pulley. Refer to FIXED AND SLID-ING SHEAVES at the beginning of this section. Carefully lift governor cup until slider shoes come to their highest position into guides. Hold a slider shoe set then carefully lift its housing and install a slider shoe fork (P/N 529 005 500). Proceed the same way for other housings lifting one at a time.

56	Subsection 04 (DRIVE PULLEY (TRA III))
1	Align governor cup mark with the one on the slid ing sheave.
2 ANDER	
1. Hold slider shoes 2. Lift one housing at a time	
Install a slider shoe fork (P/N 529 005 500). Pro- ceed the same way for other housings lifting one	RAMPS
at a time.	Ramp Removal
529 005 500	Remove the drive pulley. Refer to FIXED AI SLIDING SHEAVES.
	Remove governor cup from sliding sheave. Unscrew bolts holding ramps on governor cup
5	Ramp Inspection
A16801A	Check ramps for wear. Replace as required.
	Ramp Installation
(IS)	The installation is the reverse of the removal cedure. However, pay attention to the following
	CAUTION: Always replace all ramps and dowel tubes at the same time and make s to use identical ramps.
and an arts	Insert dowel tube from chamfered side. N sure ramp is centered on dowel tube.
mm(2007-113-008	
When all slider shoes are held with the forks, re- move the governor cup.	AIRCORA
Governor Cup Inspection	1. Chamfered side
Check the governor cup for cracks or other visible damages. Replace if necessary.	Position dowel tube split at the angle "A".
Check slider shoes for wear. Replace if groove is not apparent on top.	
Check if O-rings are cracked, cut or crushed. Replace as required.	
Governor Cup Installation	
The installation is the reverse of the removal pro- cedure. However, pay attention to the following.	



Lever Installation Always use the same roller pin as originally in-stalled when servicing. Different types have dif-ferent weights for calibration purpose. Refer to *TECHNICAL SPECIFICATIONS*. While installing levers, make sure that the curved sides of the levers are outwards as shown.

Spring Installation

For installation, reverse the removal procedure. To install spring cover, use the spring compressor (P/N 529 036 012).

Align balance marks before installing spring cover.



Tighten screws to proper torque as mentioned in exploded view.

CENTRIFUGAL LEVERS

Lever Removal Remove the drive pulley. Refer to FIXED AND SLIDING SHEAVES.

Remove governor cup from sliding sheave. Remove screws securing centrifugal levers on sliding sheave.



Lever Inspection Check centrifugal lever for crack, distortion or other damages.

Check roller for roundness of external diameter. Check if the roller turns freely.

Check thrust washers for wear (thickness).


Check lever screw heads for wear.

Check ramp bushings for wear.

Always install levers so that cotter pins are on the side shown here. Besides install cotter pin head on top when lever is sat at bottom of slid-ing sheave. Bend cotter pin ends to sit perfectly against lever.

557

Whenever replacing centrifugal levers, al-ways replace all 3 at the same time. Oth-erwise, the drive pulley will be unbalanced (because of lever differences).



3201XA 1. Head on top 2. All on the same side

~ 1

Lever Installation

CAUTION: Lever assemblies must be installed so that cotter pins are on the same side. Torque screws as per the exploded view.

CAUTION: Lever and rollers must move easily after installation.

BUSHINGS

Bushing Cleaning

Only use petroleum based cleaner when cleaning bushings.

CAUTION: Do not use acetone to clean bushng.

Bushing Inspection

Visually inspect coating. Replace if worn. Bushing Removal


Spring Cover Bushing

Under normal use there is no need to replace this bushing. In case of replacement, it's recommended to re-place spring cover.


Sliding Sheave Bushing

NOTE: In case of worn out bushing, it is advisable to replace complete whole sliding sheave assem-bly as replacing just the bushing may reduce the drive pulley performance.





Secure the spring compressor (P/N 529 036 012) in a vise, place the bushing installer (P/N 529 031 200) and the sliding sheave on it.



1. Spring compresso 2. Bushing installer 3. Sliding sheave


Use the large bushing extractor tool (P/N 529 035 931) to press out old bushing.

NOTE: Make sure to use the large bushing extrac-tor tool (P/N 529 035 931) as marked; to remove the bushing press using the side marked "OUT", as shown below in the picture.






Clean sliding sheave bushing mounting surface with pulley flange cleaner (P/N 413 711 809).



DRIVE PULLEY (1	RA IV)	
SERVICE TOOLS		
Description		
bushing installer	Part Number	Par
bushing installer digital inductive tachometer drive pulley holder	529 031 200	
slider shoe fork	529 005 500	
spring compressor		
SERVICE PRODUCTS		
Description	Part Number	Pag
Loctite 609 pulley flange cleaner		
	413 /11 809	



GENERAL

NOTE: Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile drive pulley type.

Never start engine when the pulley guard is removed.

TRA drive pulley stands for Total Range Adjustable drive pulley. NOTE: This is a lubrication free drive pulleys. Al-ways refer to appropriate PARTS CATALOG for re-placement part. Most parts of TRA IV are not in-terchangeable with those of the other TRA pulley to a standard to the other TRA pulley.

Some drive pulley components (return spring, ramp) can be changed to improve vehicle perfor-mance in high altitude regions. A Service Bulletin will give information about calibration according to altitude.

Any drive pulley repairs must be performed by an authorized BRP snowmobile dealer. Sub-component installation and assembly tolerances require strict adherence to proce-dures detailed.

CAUTION: Such modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance. Verify spring specifications before installation. Do not only refer to the spring color code.

Never use any type of impact wrench at drive pulley removal and installation.

The drive pulley assembly is a precisely bal-anced unit. Never replace parts with used parts from another drive pulley assembly.

During assembly/installation, use the torque val-ues and the service products as in the exploded view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENER and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Zas WARINUMG Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, sell-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed. newed.

PROCEDURES

CALIBRATION SCREWS

Calibration Screw Adjustment Calibration Screw Adjustment The drive pulley is factory calibrated to transmit maximum engine power at a predefined RPM. Factors such as ambient temperature, altitude or surface condition may vary this critical engine RPM thus affecting snowmobile efficiency. This adjustable drive pulley allows setting maxi-mum engine RPM in the vehicle to maintain max-imum power.

NOTE: Use the digital inductive tachometer (P/N 529 014 500) for engine RPM adjustment. Calibration screws should be adjusted so that ac-tual maximum engine RPM in vehicle matches the maximum horsepower RPM given in *TECHNICAL* SPECIFICATIONS.

NOTE: The adjustment has an effect on high RPM

To adjust, modify ramp end position by turning calibration screws

Calibration screw has a notch on top of its head.



Governor cup has 6 positions numbered 1 to 6.

563



1. Position

Each number modifies maximum engine RPM by about 200 RPM.

Lower numbers decrease engine RPM in steps of 200 RPM and higher numbers increase it in steps of 200 RPM.

Example:

Calibration screw is set at position 3 and is changed to position 5. So maximum engine RPM is increased by about 400 RPM.

See the following table for original setting.


V800	Position 3

To Adjust:


Just lossen locking nut enough to pull calibration screw partially out and adjust to desired position. Do not completely remove the locking nut. Torque locking nuts to 10 N+m (89 lbf=im).

CAUTION: Do not completely remove calibration screw otherwise its inside washer will fall off.

CAUTION: Always adjust all 3 calibration screws and make sure they are all set at the same number.



Calibration Screw Replacement When installing calibration screw, make sure to install washer as shown.




TYPICAL 1. Washer

Torque locking nut to 10 N•m (89 lbf•in).

FIXED AND SLIDING SHEAVES

Sheave Inspection Check surface of sliding sheave and fixed sheave for scratches, excessive wear or other damages. Replace if necessary.



1. Sliding sheave 2. Fixed sheave

Check fixed sheave shaft for scratches. Replace as required.

Sheave Removal (drive pulley) Open the hood to remove the belt guard and the drive belt.

Secure drive pulley holder (P/N 529 035 674) over a sliding sheave tower.



Remove the access cover on the LH side of bot-tom pan and unscrew the drive pulley screw.

Never use any type of impact wrench at drive pulley removal and installation. Install the drive pulley puller (P/N 529 022 400).






CAUTION: These pulleys have metric threads. Do not use imperial threads puller. Always tighten puller by hand to ensure that the drive pulley has the same type of threads (metric vs imperial) prior to fully tightening. Retain drive pulley with the drive pulley holder (P/N 529 035 674) and screw in the puller then re-move drive pulley.



Sheave Disassembly

To separate fixed sheave from sliding sheave, screw puller into fixed sheave shaft about 13 mm (1/2 in). Raise drive pulley and hold it by the sliding sheave while knocking on puller head to disengage fixed sheave.



TYPICAL 1. Puller 2. Holding sliding sheave

NOTE: If the separation of fixed sheave from slid-ing sheave is hard, use a heat gun and slightly heat the governor cup to expand its taper.

CAUTION: Never use any type of torch to heat governor cup.

Sheave Cleaning

Clean pulley sheaves and shaft with fine steel wool and dry cloth. Remove all hardened oil deposits that have baked on crankshaft and pulley tapered surfaces with coarse or medium steel wool and/or sand paper no. 600.

CAUTION: Do not use any other type of abra-

Sheave Assembly

The assembly is the reverse of the disassembly procedures. However pay attention to the following.

Make sure to align the sliding sheave mark with the fixed sheave mark.



Using a plastic hammer, strike hub firmly 2 or 3 times to ensure proper seating of cone

Sheave Installation (drive pulley)

Do not apply antiseize or any lubricant on crankshaft and drive pulley tapers.

Parts must be at room temperature before cleaning.

Using a paper towel with pulley flange cleaner (P/N 413 711 809), clean crankshaft tapered end and the taper inside the fixed sheave of the drive pulley, crankshaft threads and retaining screw threads.

Before installation of drive pulley, clean also crank-shaft threads and retaining screw threads.

CAUTION: Avoid contact between cleaner and crankshaft seal because damage may occur. Reclean mounting surfaces with paper towel and cleaning solvent.

Wipe off the mounting surfaces with a clean, dry paper towel.

CAUTION: Mounting surfaces must be free of any oil, cleaner or towel residue.

Install drive pulley on crankshaft extension.

Install a new conical spring washer with its con-cave side towards drive pulley then install screw.

A WARNING

Never substitute conical spring washer and/or screw with jobber ones. Always use BRP genuine parts for this particular case.

Using the drive pulley holder (P/N 529 035 674), torque screw to 90 N+m (66 lbf+ft). Install drive belt and guard.

Raise and block the rear of the vehicle and support it with a mechanical stand.

Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the ve-hicle.

Accelerate the vehicle at low speed (maximum 30 km/h (20 MPH)) and apply the brake, repeat 5 times.

Retorque screw to 95 Nom (70 lbfoft)

After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.


GOVERNOR CUP

Governor Cup Removal

Remove drive pulley. Refer to FIXED AND SLID-ING SHEAVES at the beginning of this section.

Carefully lift governor cup until slider shoes come to their highest position into guides. Hold a slider shoe set then carefully lift its housing

and



Hold slider shoes
 Lift one housing at a time

Install a slider shoe fork (P/N 529 005 500). Proceed the same way for other housings lifting one at a time.





When all slider shoes are held with the forks, re-move the governor cup.

Governor Cup Inspection

Check the governor cup for cracks or other visible damages. Replace if necessary. Check slider shoes for wear. Replace if groove is not apparent on top. Check if O-rings are cracked, cut or crushed. Re-place as required.

Governor Cup Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Align governor cup mark with the one on the slid-ing sheave.




RAMPS

Ramp Removal Remove the drive pulley. Refer to FIXED AND SLIDING SHEAVES. Remove governor cup from sliding sheave.

Unscrew bolts holding ramps on governor cup. Ramp Inspection


Check ramps for wear. Replace as required. Ramp Installation


Hamp Installation The installation is the reverse of the removal pro-cedure. However, pay attention to the following. **CAUTION:** Always replace all ramps and all dowel tubes at the same time and make sure to use identical ramps. Insert dowel tube from chamfered side. Make sure ramp is centered on dowel tube.



1. Chamfered side

Position dowel tube split at the angle "A"





CENTRIFUGAL LEVERS

Lever Removal

Remove the drive pulley. Refer to FIXED AND SLIDING SHEAVES

Remove governor cup from sliding sheave. Remove screws securing centrifugal levers on sliding sheave.



Lever Inspection

Check centrifugal lever for crack, distortion or other damages. Check roller for roundness of external diameter.

Check if the roller turns freely. Check thrust washers for wear (thickness).

Check lever screw heads for wear. Check ramp bushings for wear.

Lever Installation

Always use the same roller pin as originally installed when servicing. Different types have different weights for calibration purpose. Refer to *TECHNICAL SPECIFICATIONS*

While installing levers, make sure that the curved sides of the levers are outwards as shown.



Always install levers so that cotter pins are on the side shown here. Besides install cotter pin head on top when lever is sat at bottom of sliding sheave Bend cotter pin ends to sit perfectly against lever

Whenever replacing centrifugal levers, always replace all 3 at the same time. Otherwise, the drive pulley will be unbalanced (because of lever differences).



1. Head on top 2 All on the seme side

CAUTION: Lever assemblies must be installed so that cotter pins are on the same side. Torque screws as per the exploded view CAUTION: Lever and rollers must move easily after installation.

BUSHINGS

Bushing Cleaning Only use petroleum based cleaner when cleaning bushings CAUTION: Do not use acetone to clean bushing.

565

Bushing Inspection Visually inspect coating. Replace if wom

BRANING SO DRIVE SYSTEM AND BRAKE Submaction OF (DRIVE PULLEY (TRA IV))

Buahing Removal Spring Cover Bushing Under normalise Press

re annerro Nacion the











Clean sliding sheave bushing mounting surface with pulley fiange cleaner (P/N 413 711 808).

Sushing Installation To instal a new bushing, secure the spring com-pressor IPIN 529 036 012) in a vise and mount the islang sheave. Doet bushing outside diameter with Loctle 609 IPIN 413 703 1001. Insert the bushing from inner side of sliding sheave.

Mount the large bushing extractor tool (PN 529 035 931) with side marked "IN" to press in a new





Section 10 DRIVE SYSTEM AND BRAKE Subsection 06 (DRIVEN PULLEY(IBC 5100 AND IBC VSA 6000))

GENERAL

GENERAL NOTE: Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile driven pulley type. During assembly/installation, use the torque val-ues and the service products as in the exploded views. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed. ed.

VARNING Never start engine when the pulley guard is removed.

The driven pulley is a precisely balanced unit. Never replace parts with used parts from an-other driven pulley.

PROCEDURES

DRIVEN PULLEY

Driven Pulley Cleaning Use pulley flange cleaner (P/N 413 711 809) to clean pulley sheaves.

Driven Pulley Removal

Remove guard and drive belt from vehicle. 550F and 600 Models

Remove air intake silencer and carburetors.

600 HO SDI Models Remove air intake silencer and throttle body.

V800 Models

Unscrew and move the ECM/fuse box support on RH side.



1 ECM/fuse box supp 2 Muffler 3. Fuse box


Unscrew the top and the bottom nuts securing steering column. Move the steering column toward the RH side.


All Models

Remove driven pulley screw, lock washer and the shaft extension then pull the driven pulley from that



Driven Pulley Disassembly Using the clutch spring compressor (P/N 529 036 012), push the cam.





NOTE: For high altitude regions, a Service Bulletin will give information about calibration according to altitude.

CV

Spring


It is usual to experience spring setting during breaking period of a new spring. The factory spring preload is slightly higher (about 1 kg (2 bi)) to compensate for spring setting. Specifications in TECHNICAL SPECIFICATIONS are applicable after break-in period (about 10 hours of use).

To check spring preload adjustment, use the spring scale hook (P/N 529 030 900) and a spring

Section 10 DRIVE SYSTEM AND BRAKE Subsection 06 (DRIVEN PULLEY(IBC 5100 AND IBC VSA 6000))

Remove drive belt. Remove drive belt. Install the hook on the sliding sheave. Preventing fixed sheave from turning, pull sliding sheave with the spring scale perpendicularly with pulley axie. Take 1st measurement when sliding sheave be-gins to turn. Rotate sliding sheave to 10 mm (g/g) n/ of rotation. Hold fish scale at this position. Slowly release tension from fish scale at the position. Slowly release tension from fish scale at the position. Slowly release tension from fish scale and take 2nd measurement when sliding sheave begins to return. Spring preload is the average measure-ment between these 2. 1st 2nd measurement + measurement (when opening) (when closing) = preload 2 Example: 3.8 kg 3.4 kg 3.6 kg (8 lb) (8.4 lb) + (7.5 lb) = Actual spring (when opening) (when closing) 2 1 E=K/ TYPICAL Step 1: 1# measurement Step 2: 2nd measurement To adjust spring preload, relocate spring end in cam, moving it clockwise to increase the preload and counterclockwise to decrease it. Refer to TECHNICAL SPECIFICATIONS. NOTE: Always recheck torsional preload after adjusting. Driven Pulley Adjustment Refer to PULEY ALIGNMENT and DRIVE BELT to perform adjustments. CAUTION: Drive belt and pulley adjustments must always be checked whenever pulleys have been removed, replaced or disassem-bled. 577

Section 10 DRIVE SYSTEM AND BRAKE Subsection 07 (DRIVEN PULLEY (LPV 27))		
DRIVEN PULLEY	(LPV 27)	
SERVICE TOOLS		
Description	Part Number	Page
bushing extractor/installer		583
		581-585
crankshaft protector	420 876 552	
		582
large bushing extractor.		
SERVICE PRODUCTS		
Description	Part Number	Page
Loctite 380 (Black Max)		
Loctite 767 (antiseize lubricant)	293 800 070	585
pulley flange cleaner	413 /11 809	



GENERAL

NOTE: Refer to TECHNICAL SPECIFICATIONS to identify the snowmobile driven pulley type.

During assembly/installation, use the torque val-ues and the service products as in the exploded

Clean threads before applying a threadlocker. Re-ter to SELFLOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking flasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

Never start engine when the pulley guard is removed.

The driven pulley is a precisely balanced unit. Never replace parts with used parts from an-other driven pulley.

PROCEDURES

DRIVEN PULLEY

Driven Pulley Cleaning

Sheaves

Use pulley flange cleaner (P/N 413 711 809) to clean pulley sheaves.

Bushings

During break-in period (about 10 hours of use), tefion from bushing no, 7 and no. 8 moves to cam or shaft surface. A teriton over teriton running con-dition occurs, leading to low friction. So it is nor-mal to see gray teriton deposit on cam or shaft. Do not remove that deposit, it is not dust.

When a dust deposit has to be removed from the cam or the shaft, use dry cloth to avoid removing transferred teflon.

Driven Pulley Removal Remove guard and drive belt from sethicle. Remove pulley retaining screw red. 1 and should dered washer no. 2 then pull the driven guiley from the countershelt. Take care not to lose spacer no. 3.

Driven Pulley Disassembly

Sheaves Use clutch spring compressor IP/N 529 036 0121



Driven pulley cam is spring loaded, use above mentioned tool. Make sure the cam follows the compressor while unscreeving. If cam gets stuck, leave 1 mm (1122 in) gap between cam and compressor and carefully free up cam by rotating the aliding sheave back and forth. Resume unscreeving encou-the cam is free to follow the compressor.

Remove half keys no. 4 and spacer no. 5 to disate semble the carn no. 6 and pulley sheaves. Large Bushing

19821

Remove circlip no. 10. Remove two slider shoes.

Subsection 07 (DRIVEN PULLEY (LPV 27))



Install the support plate included in the large bushing extractor (P/N 529 031 100) inside sliding



Place the large bushing extractor (P/N 529 035 575) below bushing and screw the threaded rod of the clutch spring compressor (P/N 529 036 012) in the large bushing extractor hole until the end of threaded rod reaches against the support plate.



Mount the clutch spring compressor head in a vise.

Using a heat gun, heat bushing to break the adhe-sive product.

Turn pulley sheave by hand to extract old bushing. Clean residues of adhesive product by using pulley flange cleaner (P/N 413 711 809). Small Bushing

Remove circlip no. 11.

Remove circlip no. 11. Using a press, extract the small bushing. Push the bushing out of its location by using a pipe with proper diameter. Clean residues of adhesive product by using pulley flange cleaner (P/N 413 711 809).

Driven Pulley Inspection

Sheaves Inspect sheaves for abnormal wear or cracks. Slider Shoe

BLACK slider shoe = forward.

RED slider shoe = reverse. Check cam slider shoes no. 9 for wear. Replace when inside edge thickness of cam slider shoe slope base is worn to 1 mm (.039 in) or less.

-2 . 1 + 3 .

Measure thickness of slope base here
 Sliding pulley side
 Slope base

Bushings

Check the bushings no. 7 and no. 8 for cracks, scratch and for free movement when assembled to fixed sheave no. 12. Using a dial bore gauge measure bushing diame-ter. Measuring point must be at least 6 mm (1/4 in) from bushing edge.



Replace bushing(s) if worn more than specified.

DRIVEN PULLEY BUSHING WEAR LIMIT Small bushing 38.30 (1.508)

Large bushing 108.2 (4.260) Driven Pulley Assembly

Large Bushing On threaded rod install both sleeves and one spacer included with the clutch spring compres-sor (P/N 529 036 012).



Coat bushing outside diameter with Loctite 380 (Black Max) (P/N 413 408 300). Place new bushing on sliding sheave and slightly tap to engage squarely the bushing in the sliding.

Install the sliding pulley on threaded rod and screw in the large bushing extractor (P/N 529 035 575).



Turn pulley sheave by hand to insert the new bush-

IMPORTANT: Change the position of extractor of-ten to push the bushing straight. Install circlip.

Small Bushing

Coat bushing outside diameter with Loctite 380 (Black Max) (P/N 413 408 300).

Using a press and the bushing extractor/installer (P/N 529 031 300) with crankshaft protector (P/N 420 876 552), insert small bushing in its location



Install circlip

Slider Shoe

When replacing slider shoes no. 9, always install a new set (3 shoes) to maintain equal pressure on the cam.

Install slider shoes as per following photo. RED slider shoes are being used for reverse and BLACK ones for forward.





1. BLACK slider shoe 2. RED slider shoe

Cam and Spring

Make sure to install proper cam. Refer to TECH-NICAL SPECIFICATIONS. Cam angle is identified on cam




Install the recommended spring.

Single-Stud Spring If a single-stud spring is used, the stud must be inserted in one of the 3 sliding sheave's holes.

Enter the other end of the spring in the sliding sheave location hole.

Compress cam using the clutch spring compressor (P/N 529 036 012).

Install spacer no. 5 then secure cam with half keys no. 4, as shown in the next photo.



Double Opened Ends Spring

If a spring opened at both ends is used, do the following: 1. Select the appropriate spring locating hole on the cam to enter one end of the spring.



NOTE: When no preload is required, use hole no. 6 and DO NOT rotate the sheave (skip operation no. 3). When applying 6.8 kg (15 lib) of preload on a PINK spring, use hole no. 4 and DO rotate the sheave (perform operation no. 3). 2. Enter the other end of the spring in the sliding sheave location hole.




When torsion preload is required, turn the sliding sheave exactly 120° (1/3 turn) counter-clockwise. 3.



Insert cam in driven pulley while still holding preload, using the clutch spring compressor (P/N 529 036 012). 4.

Install spacer no. 5 then secure cam with half keys no. 4, as shown in the next photo. 5,



1. Half keys inserted into shaft groove 2. Spacer recess facing half keys

6. Using a fish scale hooked to a sliding sheave balancing hole, measure the force required to turn the sliding sheave counterclockwise. Al-so measure the force required by the sheave to return to its original position. Calculate the average of both forces.

If preload is too low, use a higher number. If preload is too high, use a smaller number.

Driven Pulley Installation Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) on countershaft splines. Reinstall the pulley on the countershaft by revers-ing the removal procedure.

Torque pulley retaining screw no. 1 to 22 Nem (16 lbf=ft).

Driven Pulley Adjustment Refer to PULLEY ALIGNMENT and DRIVE BELT to perform adjustments.

CAUTION: Drive belt and pulley alignment must always be checked whenever pulleys have been removed, replaced or disassem-bled.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 08 (PULLEY ALIGNMENT)

PULLEY ALIGNMENT

SERVICE TOOLS

Description universal alignment tool.

Page 588 Part Number 529 035 831

GENERAL

Both pulley distance adjustment and pulley alignment must be carried out to ensure the highest effi-ciency of the transmission system. Furthermore, optimum drive belt operation and minimal wear will be obtained only with proper pulley alignment. This basic distance is provided as an assembly guide and indicates the dimensions between which satis-factory belt deflection will be obtained. The pulley distance we will refer to in this section, is the space separating the drive and driven pulley outside diameters (Z measurement).

A WARNING Failure to correctly perform pulley alignment may cause the vehicle to creep forward at idle.

All pulley alignment specifications refer to

- X = Distance between straight bar and drive pulley fixed half edge, measured between pulleys.
- Y = Distance between straight bar and drive pulley fixed half edge, measured at the end of straight bar.

Z = Distance between outside diameter of pulleys.

PULLEY ALIGNMENT SPECIFICATIONS

	PULLEY DISTANCE	OFFSET	
MODEL	Z	X	Y - X
440F	39.0 ± 0.75 mm	37.0 ± 0.75 mm	0.75 to 1.5 mm
	(1.535 ± .030 in)	(1.457 ± .030 in)	(.030 to .060 in)
550F	41.8 ± 0.75 mm	35.0 ± 0.75 mm	0.75 to 1.5 mm
	(1.647 ± .030 in)	(1.380 ± .030 in)	(.030 to .060 in)
600	35.5 ± 0.75 mm	37.0 ± 0.50 mm	0.75 to 1.5 mm
	(1.398 ± .030 in)	(1.456 ± 020 in)	(.030 to .060 in)
600 HO SDI	67.0 ± 0.75 mm	37.0 ± 0.50 mm	0.75 to 1.5 mm
V800	(2.638 ± 030 in)	(1.456 ± .020 in)	(.030 to .060 in)

NOTE: When pulley distance and alignment are adjusted to specifications, refer to DRIVE BELT to adjust drive belt height.

	587

Section 10 DRIVE SYSTEM AND BRAKE Subsection 08 (PULLEY ALIGNMENT)

PROCEDURES


Preparation

Remove drive belt guard.

Remove drive belt. Insert the universal alignment tool (P/N 529 035 831) into the opened driven pulley.

Measuring Procedure


Always measure distances X and Y from the far-ther straight bar side (including its thickness to the fixed half edge).




1. Straight bar 2. Front of vehicle

The distance Y must exceed distance X to com-pensate for the twist due to the engine torque.

Pulley Distance Adjustment



NOTE: Prior to performing pulley distance adjust-ment, loosen torque rod nut to allow engine move-ment. Engine supports have tendency to stick to frame, work engine loose prior to aligning.



Engine Movement

The engine support has slotted mounting holes. Move engine to obtain specified distance be-tween pulleys.

Skandic WT/SWT/SUV/Expedition TUV

Driven Pulley Movement Loosen gearbox retaining screws and move gear-box accordingly. Retighten screws.

Pulley Alignment

SKkandic LT 440F

When engine slotted mounting holes do not allow to set proper pulley offset X, adjust with shims (P/N 504 108 200) between pulley and counter-shaft bearing support (pulley pushed toward brake disc).


Engine Movement

Loosen the 4 bolts retaining engine support to the frame. Position engine to obtain the specified alignment.

NOTE: After alignment, adjust torque rod so it slightly contacts stopper plate. Do not over tight-en, it will disalign pulleys.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 08 (PULLEY ALIGNMENT) 9 NEVER TOTOTAL 0 0 ADED07 Retigh Skandic WT/SWT/SUV/Expedition TUV Driven Pulley Movement Loosen gearbox retaining screws. Install or remove shims accordingly. Retighten screws.

		Section 10 DRIVE SYSTEM Subsection 09 (BRAKE (WT/S		
B	BRAKE (WT/SWT/SUV/TUV)			
SE	RVICE PRODUCTS	AUVAUV.		
Dee	cription	Part Number	- This -	
Lor	tite 609	Pert Number 293 600 062 293 800 060 413 703 100 293 800 070	5	
		Service Contract		
	Contraction of the second			
	te observite leatest brake due of put			
	Children sales it with the second			
	and the start of the	and anternational	Augerran	
	AURIE CALLER THE A	And the second s		
		The second s		
	and company and	Starts was been and	a straight	
		and the second states		
		Construction of the second sec		
	Person in the Party of the Part	PLACE PADE		
	and the second			
	Carl of the second second second			



Section 10 DRIVE SYSTEM AND BRAK Subsection 09 (BRAKE (WT/SWT/SUV/TUV)

GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, solf-locking fasteners, coatter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

A WARNING

A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean contaminated disc with a high qual-ity brake degreasing agent.

CAUTION: Avoid spilling brake fluid on plas-tic, rubber or painted parts. Protect these parts with a rag when servicing brake system.

CAUTION: To avoid serious damage to the brake system, use only DOT 4 brake fluid from a sealed container. Do not use brake fluid taken from old or already opened containers, nor mix different fluids for topping off.

CAUTION: Sealing washers must be discarded and replaced with new ones every time a Banjo fitting is unscrewed.

PROCEDURES

BRAKE FLUID

The brake fluid must be changed in accordance with the maintenance chart.

Recommended Fluid

Always use brake fluid meeting the specification DOT 4 such as DOT 4 brake fluid GTLMA (P/N 293 600 062) sold by BRP.

Fluid Level Verification

With the vehicle on a level surface, position steer-ing in straight-ahead position to ensure reservoir is level. Check brake fluid level, the reservoir is full when the fluid reaches the top of window.

Draining

Brake Fluid Replacement

Remove reservoir cover with its diaphragm. Connect a clear hose to caliper bleeding screw Loosen bleeding screw and pump brake lever unti-no more fluid flows out of bleeding screw.



TYPICAL 1 Open bleeding screw 2 Clear hose to catch us

Filling and Bleeding

Close bleeding scre Fill reservoir with DOT 4 brake fluid.

In itsel a clean out who both a base hold. Install a clean base to bleeding screw. Route this hose to acontainer. Unscrew bleeding screw until brake fluid freely flows out of hose. Close bleed-ing screw. Refil reservoir when the fluid level is low to prevent air into system.

Pump up system pressure with brake lever until resistance is felt.


resistance is reit. Squeeze brake lever and open bleeding screw. When lever touches the handlebar, do not release lever and close bleeding screw. Repeat the procedure until no more air bubbles appear in the hose and brake lever is not spongy.

BRAKE PADS

Pad Inspection

Brake pads must be replaced when lining is 1 mm (1/32 in) thick or less or if the groove, on lining pad,

CAUTION: Brake pads must always be replaced in pairs.



Remove brake disc

Brake Disc Installation

Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) on shaft. Apply Loctite 243 (blue) (P/N 293 800 060) on threads of brake disc screw and torque it to 22 N•m (16 lbf+ft).

Reinstall all removed parts.

CALIPER

Caliper Removal

Procedure to Remove Caliper from Disc Brake Unscrew M10 Allen screws that attach caliper to gearbox. Pull caliper.

Hang the caliper with a piece of wire to take the weight off the brake hose after removing M10 Allen screws that attach caliper to gearbox. CAUTION: Do not let the caliper hang by the hose and do not stretch or twist the hose.

Procedure to Replace Caliper

Drain brake system (refer to BRAKE FLUID RE-PLACEMENT).

Loosen bolt and disconnect brake hose. Discard sealing washers. Catch spilled fluid with a rag. Attach the brake hose in a position to prevent the remaining fluid from flowing out.

Unscrew M10 Allen screws that attach caliper to gearbox.

Remove caliper

Caliper Inspection

Check pistons for scratches , rust or other dam-ages. If so, replace the caliper as an assembly. NOTE: Only brake pads are available as spare

Caliper Installation

Push pistons all the way in to allow caliper instal-lation over brake disc. Install the Banjo fitting with two new sealing

washers. Fasten caliper on gearbox.

Fill the brake system and bleed it. Refer to BRAKE FLUID REPLACEMENT in this section.

585

Brake Disc Removal Apply parking brake and remove the brake disc screw.

Remove caliper. Refer to CALIPER.

TYPICAL 1. Brake pad Pad Installation

Install:

new brake pads pad spring and push 2 pins to lock the brake pads

both clips in the pin holes.

A WARNING Avoid getting fluid, oil or grease on brake pads. Contaminated brake pads can affect stopping capacities.

Press the brake lever until both new pads are touching the brake disc. Center the brake disc into the caliper, Refer to *CALIPER*.

BRAKE DISC

Brake Disc Inspection


The brake disc can be inspected without removing it from the vehicle.

Check for scoring, cracking or bending, replace as required.

Measure brake disc thickness. The minimum thickness should be 4.3 mm (169 in). If the brake disc is out of specification, replace it with a new one

CAUTION: Brake disc should never be machi

The brake disc must be centered in caliper. Apply brake then check for proper brake disc positioning. Push on appropriate caliper piston in order to move pad inward allowing proper brake disc positioning.



TYPICAL
1. Brake disc not centered
2. Brake disc centered
3. Apply brake before checking

3. Apply brake before checking Apply brake then recheck.

Apply blace then recircles

MASTER CYLINDER

Master Cylinder Removal The master cylinder is located on the LH side of handlebar.

Empty the master cylinder reservoir. Refer to DRAINING in BRAKE FLUID REPLACEMENT. Place a container under master cylinder Banjo fitting then unscrew it. Discard the sealing washers.

ting then unscrew it. Discard the sealing washers. Catch spilled fluid with a rag. Attach the brake hose in a position to prevent the remaining fluid from flowing out.

To remove master cylinder, unscrew both screws retaining the brake lever to the handlebar.

Master Cylinder Installation

596

The installation is the reverse of removal procedure. Pay attention to the following. Always use new sealing washers during installa-

tion. Install clamp with its arrow pointing at front of vehicle. Tighten to 8 N•m (71 lbf•in) front screw before rear one.



TYPICAL
1. Arrow on upper clamp pointing at the front of vehicle
2. Tighten front screw first

Bleed the brake system. Refer to BRAKE FLUID REPLACEMENT in this section.

BRAKE LIGHT SWITCH

Switch Resistance Test

Disconnect steering connector. Validate switch operation with an ohmmeter.

SWITCH	TERMINAL		RESISTANCE
Released	1200	WHITE/RED	Infinite (OL)
Pushed and held	WHITE	(small terminal)	0.2 Ω (closed)

If readings do not correspond to the above specifications, check wiring/connectors going to switch. If they are good, replace switch.


Switch Removal


The brake light switch is located near the brake lever. To remove the switch, do the following. Disconnect the switch.

Take out the master cylinder from the handlebar. Fix the master cylinder in a rigid way preferably in a vise.

Pull out the switch wire and rubber cover. Activate the parking brake.

Unscrew the switch body pay attention to apply a torque in axial direction with steps of little torque angles and pay attention to not apply a force in radial direction (flexion). The switch is delicate and can be easily snapped.





Section 10 DRIVE SYSTEM AND BRAKE Subsection 10 (COUNTERSHAFT AND BRAKE (LT 440F))

GENERAL

During assembly/installation, use torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITE APPLICATION at the beginning of this manual for complete procedure.

A WARNING Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean contaminated disc with a high qual-ity brake degreasing agent.


PROCEDURES

BRAKE PADS

Pad Inspection

Brake pads must be replaced when fixed pad no. 1 projects only 1 mm (1/32 in) from caliper.

CAUTION: Brake pads must always be replaced



TYPICAL 1. Fixed pad 2. Inner caliper A. 1 mm (1/32 in) mi

Pad Removal

Moving Pad

Remove caliper no. 2 from vehicle. Using long nose pliers, hold the ratchet wheel lock and screw the ratchet wheel to release spring ten-sion.



Pull pin no. 3 out of caliper and remove caliper lever no. 4.

Unscrew the ratchet wheel no. 5 to remove the moving pad no. 6.

Fixed Pad With caliper removed, unscrew nut no. 7 retaining fixed pad no. 2 to chaincase. Pry brake disc no. 8 in order to free fixed pad.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 10 (COUNTERSHAFT AND BRAKE (LT 440F))

Pad Installation

Moving Pad

Moving Pad Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) on threads of moving pad. Install moving pad no. 6 in the caliper and screw the ratchet wheel no. 5 completely.

Install caliper lever no. 5 completely. Install caliper lever no. 4, ratchet wheel lock no. 9 and pin no. 3. Make sure that lock is positioned correctly. Install pin so that it can only be removed upward and ensure it is properly locked. Press the lever 2 or 3 times to test the mecha-

Install caliper after replacing fixed pad.

Fixed Pad

Reverse removal procedure.

CALIPER

Caliper Removal

Remove air intake silencer and injection oil reservoir.

Unlock ends of locking plate no. 10 then unscrew nuts no. 11 securing caliper no. 2 to chaincase.

Remove caliper from chaincase. NOTE: If the caliper is being removed for replace-ment, remove brake cable no. 12 from the caliper lever.

Caliper Installation

Reverse the removal procedure. However, pay at-tention to the following.

Torque caliper nuts no. 11 to 24 N•m (18 lbf•ft). Bend locking plate over a flat of each nut.

BRAKE CABLE

Cable Removal

Unscrew the cable end from caliper lever no. 4. Remove E-clip no. 13 retaining cable no. 12 to caliper no. 2.

Cut all locking ties.

Disconnect cable from the brake handle. Remove cable from vehicle. Note routing for in-stallation.


Cable Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following.

Insert brake cable in the upper hole in brake lever and in caliper lever. Install spring no. 14 and cable nut no. 15. Tighten nut until 5 to 7 threads exceed.

Cable Adjustment

Fully depress the brake handle several times to obtain a gap of 13 mm (1/2 in) between the end of brake handle and handlebar grip when brake is fully applied.



If this measurement is hard to reach, retighten cable nut no. 15 as needed.


BRAKE DISC

Disc Removal

Remove caliper. Remove guard, belt and driven pulley. Unscrew bearing support bolts no. 16 then re-move both bearing supports no. 17 and bearing no. 18.

Open chaincase and remove upper sprocket. Pull countershaft no. 19 toward driven pulley side to gain access to clip no. 20.

Remove clip on countershaft.



Section 10 DRIVE SYSTEM AND BRAKE Subsection 10 (COUNTERSHAFT AND BRAKE (LT 440F))

Pull countershaft toward driven pulley side to free from chaincase and disc no. 8.

Remove disc. Disc Inspection

Check for scoring, cracking or heat discoloration, replace as required.


CAUTION: Brake disc should never be ma-

Disc Installation

The brake disc must be floating on countershaft for efficient operation of brake.

Apply Loctite 767 (antiseize lubricant) (P/N 293 800 070) on shaft and check that disc slides freely. The disc hub exceeds the disc more from one side than from the other. Install disc with the longer exceeding portion toward driven pulley.

Push O-rings no. 21 inside disc hub.



Install all other removed parts

BRAKE LIGHT SWITCH

Switch Adjustment

Brake light should light up before brake pads touch brake disc. To adjust, unscrew nut no. 15 until brake light goes on.

At least one full thread must exceed the elas-tic stop nut.

Check brake adjustment as described above. NOTE: If brake light adjustment is unattainable while respecting brake adjustment, ratchet wheel may be too far out. If so, tighten ratchet wheel.

COUNTERSHAFT

Countershaft Removal To remove countershaft no. 19, use the same pro-cedure as for brake disc. Refer to BRAKE DISC. Pull the countershaft by the LH side of vehicle.

Countershaft Inspection

Check countershaft for bending, rust or other damages. Replace if necessary. Check condition of countershaft splines and threads. Replace countershaft if necessary. Check the Woodruff key and its location for wear or other damages. Replace key or countershaft if necessary.

Countershaft Installation The installation is the reverse of removal proce-dure.

NOTE: Always install a new bearing when coun-tershaft is removed.

COUNTERSHAFT BEARING

Bearing Removal


Remove the driven pulley, refer to DRIVEN PUL-LEY.

Unscrew bearing support bolts no. 16 then re-move both bearing supports no. 17 and bearing no. 18.


Bearing Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Ensure that countershaft is properly aligned, then tighten the 3 retaining bolts no. 16 to 15 N•m (133 lbf•in).

NOTE: A misaligned countershaft will result in dif-ficulty to center the bearing in its support.



CHAINCASE (LT 440F)			
	44VF)		
SERVICE TOOLS			
Description drive axle holder oil seal pusher	Part Number 529 007 200 529 035 584	Pag 60 60	
		53	
SERVICE PRODUCTS			
Description	Part Number	Pag	
Loctite 271 (red) Loctite 609. ThermoLube synthetic grease XP-S synthetic chaincase oil	413 703 100		



Section 10 DRIVE SYSTEM AND BRAKE Subsection 11 (CHAINCASE (LT 440F))

GENERAL

During assembly/installation, use the torque val-ues and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITTE APPL/CATION at the beginning of this manual for complete procedure.

A WARNING Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

MAINTENANCE

CHAINCASE OIL


Recommended Oil

NOTE: Do not mix different oil (mineral and synthetic) for topping off.

Use XP-S synthetic chaincase oil (P/N 413 803 300).

Oil Level Verification

With the vehicle on a level surface, check the oil level by removing dipstick no. 1. Oil level must be between lower and upper marks.



NOTE: It is normal to find metallic particles stuck to dipstick magnet. If bigger pieces of metal are found, remove the chaincase cover and inspect the chaincase parts. Remove metal particles from magnet.

Check O-rings no. 2. If the O-rings are brittle, hard or otherwise damaged, replace them.

Draining Procedure

Place a drain pan under chaincase area. Remove tuned pipe and muffler. Refer to EX-HAUST SYSTEM.

Remove the chaincase cover no. 3 to drain chaincase.

Filling Procedure

Place the vehicle on a level surface. Using a funnel, pour 250 mL (8.5 U.S. oz) of chain-case oil.

Refill to upper mark. See RECOMMENDED OIL for the proper chaincase oil to use.

CAUTION: Use only the recommended types of oil when servicing. Do not mix synthetic oil with other types of oil.

DRIVE CHAIN ADJUSTMENT

NOTE: Brake disc key must be in good condition before checking if chain no. 4 is loose.

Before performing the drive chain adjustment, check the tensioner adjustment screw O-rings no. 5 and replace if necessary. Fully tighten tensioner adjustment screw no. 6 BY HAND. The tensioner adjustment screw shoulder and the washer no. 7 must be in contact with the chaincase housing.



1. Shoulder 2. Washer

When done, back off only far enough for hair pin no. 8 to engage in locking hole.

605

Section 10 DRIVE SYSTEM AND BRAKE Subsection 11 (CHAINCASE (LT 440F))

This initial adjustment should provide 3 - 5 mm (1/8 - 13/64 in) free-play when measured at the outer circumference of the brake disc.

CAUTION: Free-play must not exceed 5 mm (13/64 in), readjust if necessary.

If the specified free-play is not reached with the tensioner screw fully tightened, replace chain and check the condition of sprockets.

PROCEDURES

CHAINCASE

Chaincase Removal

Apply parking brake.

Remove exhaust pipe and muffler. Refer to EX-HAUST SYSTEM.

Place a drain pan under chaincase area and re-move chaincase cover.

Remove the lower sprocket bolt no. 9.

Remove cotter pin no. 10.

Upper sprocket nut no. 11, conical spring washer no. 12 and washer no. 13. Remove hair pin no. 8 from tensioner adjustment screw

Release drive chain tension by unscrewing ten-sioner adjustment screw no. 6.

Remove the upper socket no. 14 and the lower sprocket no. 15 as well as chain no. 4 simultane-

Remove the countershaft spacer no. 16.


Then remove the drive axle spacer no. 17.

Near drive axle, remove the circlip no. 18 from chaincase housing. Release parking brake.

Remove nuts no. 19 that retain chaincase to frame.

Remove caliper from chaincase. Refer to COUN-TERSHAFT AND BRAKE.

Release track tension, use drive axle holder (P/N 529 007 200).



Pry out drive axle oil seal no. 20 from chaincase. Pull chaincase from drive axle and countershaft. Using 2 prybars inserted between chaincase hous-ing no. 21 and frame, pry complete assembly from vehicle

Chaincase Inspection

Visually inspect the chain and sprockets for wear, cracked, damaged or missing links. If a problem is detected, replace drive chain and sprockets as an assembly.

Check the drive chain deflection. If the deflection is greater than 38 mm (1-1/2 in) without the chain tensioner, replace the chain.

Check for worn or defective bearings. Check chain tensioner roller no. 22 for wear or oth-er damages. If the roller does not turn smoothly, replace the needle bearing no. 23.

Chaincase Installation

Reverse removal procedure and pay attention to the following.

At the bottom of chaincase, clean the oil seal lo-cation with a cleaning solvent.

Apply Loctite 609 (P/N 413 703 100) on mounting surface (outside) of oil seal no. 20.

Using the oil seal pusher (P/N 529 035 584), press the oil seal no. 20 into chaincase hole. Oil seal must fit flush with the chaincase edge.

Install chaincase housing and torque nuts no. 19 to 42 N•m (31 lbf•ft).

CAUTION: Take care not damaging oil seal when inserting drive shaft splines. Install the circlip no. 18 in chaincase housing.

CAUTION: It is of the utmost importance to in-stall the circlip otherwise damage to the chain-case components may occur.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 11 (CHAINCASE (LT 440F))

Position the sprockets no. 14 and no. 15 with the backside of writing facing the chaincase cover. Sprocket hub faces toward chaincase.

Install the washer no. 13 and the conical spring washer no. 12 on countershaft. Install the coni-cal spring washer with its concave side towards sprocket.



install the castellated nut no. 11 and torque to 60 N•m (44 lbf•ft).

Install new cotter pin no. 10 in the position shown CAUTION: When removing a cotter pin always replace with a new one. Cotter pin will rub on chaincase cover if installed otherwise.



1. New 2. Fold cotter pin over castellated nut flats only

Apply Loctite 271 (red) (P/N 293 800 005) on threads of lower sprocket screw no. 9 and torque to 48 N•m (35 lbf•ft).

Check if chain tensioner screw is screwed correct-

Install chaincase cover and torque its screws to 6 Nem (53 lbfein).

Adjust drive chain. Refer to DRIVE CHAIN AD-JUSTMENT at the beginning of this section.

CHAIN TENSIONER

Chain Tensioner Removal Remove chaincase cover no. 3.

Remove hair pin no. 8. Unscrew tensioner adjustment screw no. 6 com-

pletely.

Pull the tensioner adjustment screw to separate it from tensioner.



Chain Tensioner Inspection

Check chain tensioner roller no. 22 for wear or oth-er damages. If the roller does not turn smooth-by replace the needle bearing no. 23. See CHAIN TENSIONER ROLLER BEARING.

Check O-rings no. 5 on tensioner adjustment screw. Replace them if necessary.

Check threads of tensioner adjustment screw for damages or wear. Replace the screw if necessary and check chaincase housing for damages.

Chain Tensioner Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. Apply ThermoLube synthetic grease (P/N 293 700 417) on threads and O-rings of tensioner adjust-ment screw.

Check if chain tensioner screw is screwed correct-Adjust drive chain tension. Refer to DRIVE CHAIN ADJUSTMENT at the beginning of this section.

Install all removed parts.

CHAIN TENSIONER ROLLER BEARING

Roller Bearing Removal

Remove the chain tensioner, see procedure above.


Heat the roller screw no. 24 to break the threadlocker.


Remove the needle bearing from the roller


Roller Bearing Installation val pro-The installation is the reverse of the remove cedure. However, pay attention to the follow ving.


607


Section 10 DRIVE SYSTEM AND BRAKE Subsection 11 (CHAINCASE (LT 440F)) Clean and remove grease on screw then apply Loctite 271 (red) (P/N 293 800 005) under the screw head only, none on threads Torque screw to 16 N•m (142 lbf•in).











GENERAL

During assembly/installation, use the torque val-ues and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

A WARNING Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pin, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

MAINTENANCE


GEARBOX OIL

Recommended Oil

NOTE: Do not mix different oil (mineral and synthetic) for topping off. Use XP-S synthetic chaincase oil (P/N 413 803 300).

Oil Level Verification

With the vehicle on a level surface, check the oil level by removing dipstick. Oil level should reach the upper level mark.



TYPICAL 1. Upper level mark (full) 2. Lower level mark (add)

Draining Procedure

Place the vehicle on a level surface. Place a drain pan under gearbox drain plug area. Remove dipstick.

Remove the drain plug located at the bottom of gearbox.

Wait a while to allow oil to flow out of gearbox. Install drain plug and torque it to 6 N•m (53 lbf•in).

Filling Procedure



Using a funnel, pour 400 mL (13.5 U.S. oz) of rec-ommended oil.

mmr2007-212

CAUTION: Use only the recommended type of oil when servicing. Do not mix synthetic oil with other types of oil. Check oil level with the dipstick and add oil if nec-essary. The level must reach the upper level dip-stick's mark.

NOTE: After first outing, oil level will decrease as the upper oil cavity fills with oil. Recheck oil level and refill as required.

PROCEDURES

GEARBOX

Gearbox Removal

Drain gearbox oil. Refer to DRAINING PROCE-DURE.

Remove driven pulley. Refer to DRIVEN PULLEY (IBC 5100 AND IBC VSA 6000). Remove brake caliper, brake disc. Unfasten shift-ing rod and unplug reverse switch.





WT/SWT/SUV 550F AND SWT V800 1. Driven pulley 2. Brake disc 3. Galiper 4. Shifting rod 5. Reverse switch



10 0 4 22 33 10

----dtm IT108... WT/SUV 600, TUV 600 HO SDI AND TUV V800 1 Driven pulley 2 Brake dac 3 Caliper 4 Shifting rod 5 Reverse switch

Remove rear suspension. Refer to the appropri-ate *REAR SUSPENSION* section. On 550F models with a speedometer, remove an-gle drive and square pin from bottom of gearbox.




550F MODELS WITH SPEEDOMETER 1 Angle drive

Remove muffler. Refer to EXHAUST SYSTEM. Depending on model, unbolt RH end bearing or speedometer sensor cover then pull drive axle to-ward right side.



615







NOTE: Brake shaft gears and sleeve remain in gearbox housing. Remove bearing no. 14 from brake shaft using a press.




Make sure gears mesh.



Push sliding sleeve against gear to lock it in place (reverse gear). This will allow the driven pulley shaft no. 16 to be pushed out enough for bearing removal and sliding sleeve dog will not touch the RH gear of driven pulley shaft. Drive reverse shaft no. 17 out until its LH side bearing no. 18 is free.

CAUTION: Make sure loose gears do not inter-




 Sleeve dog not touching right gear
 Brake shaft gears are still in gearbox Use a 3 jaws puller to extract LH reverse shaft bearing.











Apply ThermoLube synthetic grease (P/N 219 700 417) on intermediate shaft O-rings no. 41.

Install intermediate gears no. 31 with their shoul-der towards LH side. Position spacers no. 33 as illustrated in removal procedure. Beveled side of spacers goes against gearbox wall.

Skandic WT/SWT/SUV 550F and WT/SUV 600 Install screws no. 29 retaining intermediate gears.

Skandic SWT V800, Expedition TUV 600 HO SDI and TUV V800

HO SDI and TUV V800 Install bolts no. 29 retaining intermediate gears with washer, locking washers and nuts. Tighten nut to 12 Nem (106 liden) then back of the nut until he locking washer is losse. Retighten the nut until locking washer stops moving (very slight pressure on it). Turn gear, a slight drag should be felt.

Fold locking washer against a flat side of nut to lock the assembly. NOTE: Make sure the tab of locking washer is inserted in intermediate shaft hole.

All Models

2007-212

•


Install new caps. Install the appropriate premarked shims no. 11.

Using a pusher, install RH side bearing of brake and reverse shafts no. 22 and no. 28.




1 Bearings installed


Partially assemble brake shaft gears no. 42 and no. 43 with shoulder facing recess.



1. Shoulder 2. Recess

Install sleeve no. 44 on brake shaft no. 13 then, slide gears and sleeve until end of sleeve is flush with shaft end.





Section 10 DRIVE SYSTEM AND BRAKE Subsection 12 (GEARBOX (WT/SWT/SUV/TUV))



Push on ball with a screwdriver then move sliding sleeve to the right

Finalize driven pulley shaft insertion. Make sure that gears mesh during insertion. Install circlip no. 25.



mmr2007-212

Install RH side bearings no. 46, no. 22 and no. 28, shims no. 11, circlip no. 10 then, plugs no. 7 and oil seal no. 8.





READY TO INSTALL BEARINGS, SHIMS, CIRCLIPS, OIL SEAL AND PLUGS


CAUTION: Make sure that gearbox is well supported before inserting driven pulley shaft bearing, see photo.




Gearbox Installation GearDox Installation Reverse removal procedure. However pay atten-tion to the following. Make sure drain plug is installed. Fill gearbox. Refer to *FILLING PROCEDURE*. Check pulley alignment.









Section 10 DRIVE SYSTEM AND BRAKE Subsection 13 (DRIVE AXLE)

GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

Sprocket/Track Alignment

CAUTION: Do not tamper with sprocket/track alignment if frame or suspension is damaged. Sprockets may be repositioned to fit lugs without removing drive axle.

Use drive axle sprocket adjuster kit (P/N 861 725 700).



PROCEDURES

DRIVE AXLE

Drive Axle Removal 440F Models

Drain oil from chaincase. Raise and block rear of vehicle off the ground. Remove erar suspension. Remove driven pulley. Remove plastic cover no. 1, the large washer no. 2 and the bearing outer flange no. 3. Apply parking brake.

Remove chaincase cover, chain and sprockets then the circlip on drive axle. Refer to CHAIN-CASE.

Release drive axle sprockets from track and at the same time, push the drive axle assembly toward the right side. Drive axle bearing in chaincase will fall off.

Move the drive axle towards the left side to remove it from vehicle.

Remove bearing no. 5 and sprockets. See procedures further in this section.

550F and 600 Models

Drain gearbox.

Remove angle drive **no. 6** and square pin **no. 7**. Raise and block rear of vehicle off the ground. Remove rear suspension.

Remove muffler.

Unfasten screw no. 8 from drive axle end. Remove 3 screws no. 9 retaining bearing outer

flange no. 3. Release drive axie sprockets from track and at the same time, pull the drive axie assembly towards the end bearing housing side to remove it.

Remove bearing no. 5 and sprockets. See procedures further in this section. 600 HO SDI and V800 Models

Drain gearbox.

Remove the speedometer sensor $\mathbf{no.}\ \mathbf{1}$ and the speedometer adaptor $\mathbf{no.}\ \mathbf{12}$

Remove the large washer no. 2 and the bearing outer flange no. 3.

Raise and block rear of vehicle off the ground. Remove rear suspension.

Release sprockets from track and at the same time, pull the drive axle assembly towards the end bearing housing side to remove it.

Remove bearing no. 5 and sprockets. See procedures further in this section.

Drive Axle Inspection

Check drive axle no. 14 for bending, wear or other damages. Replace as required. Check if bearings turn smoothly and freely. Replace if necessary.

Section 10 DRIVE SYSTEM AND BRAKE Subsection 13 (DRIVE AXLE)

Drive Axle Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. 440F Models


The drive axle bearing in chaincase must have its seal facing cover.

Fill chaincase or gearbox with recommended oil. Install all other removed parts.

Torque plastic cover nuts no. 16 to 12 N•m (106 lbf•in).

550F, 600, 600 HO SDI and V800 Models

When installing drive axle, always position a new seal on each end of drive axle (if applicable). Locate seal lip as illustrated.



1. Grease seal type 2. Oil seal type

On models with a speedometer, index speedome-ter magnetic adapter no. 12 in drive axle and push it until it is completely inserted in its hole. Install all other removed parts.

550F and 600 Models

Apply Loctite 243 (blue) (P/N 293 800 060) on threads of screw no. 8.

Torque bearing flange bolts no. 9 and screw no. 8 to 22 N•m (16 lbf•ft).

600 HO SDI and V800 Models


Torque plastic cover nuts no. 17 to 11 Nom (97 lbfoin).

Drive Axle Lubrication

440F and V800 Models

632

Lubricate the end housing bearing with ThermoLube synthetic grease (P/N 219 700 417). Continue lubricating until grease flows out of the pilot hole on speedometer sensor or plastic cover.



SPEEDOMETER SENSOR SHOWN

DRIVE AXLE BEARING

Drive Axle Bearing Inspection Before removing the drive axle bearing no. 5 from drive axle no. 14, check if it turns smoothly and freely. Replace if necessary.

Drive Axle Bearing Removal

Remove drive axle from

550F and 600 Models

Unlock bearing by unscrewing the Allen set screw no. 15.

Using a suitable puller, remove the drive axle bear-ing no. 5, the bearing inner flange no. 10 and the inner plate no. 11.


440F, 600 HO SDI and V800 Models

Remove circlip no. 4. Using a suitable puller, remove the drive axle bear-ing no. 5, the bearing inner flange no. 10 and the bearing protector no. 13.

Drive Axle Bearing Installation

Drive Axie Bearing installation Install bearing protector no. 13 or inner plate no. 11 and the bearing inner flange no. 10 on drive axie. Install bearing protector so that its flat side is against bearing. Using a press and a suitable pipe, push the bear-ing. Always push bearing by inner race. Push bearing until it leans on its protector.

mm/2007-213






CAUTION: The same sprocket must not be pressed twice on the axle. To assemble press fit sprockets, use a press and a suitable pipe as illustrated.

lain. Sprocket Installation

Section 10 DRIVE SYSTEM AND BRAKE Subsection 13 (DRIVE AXLE)



Section 10 DRIVE SYSTEM AND BRAKE Subsection 14 (TRACK) TRACK SERVICE TOOLS Description belt tension tester cleat installer..... Part Number 414 348 200 529 036 044 Page .636 .635 TRACK Track Inspection Visually inspect track for: - cuts and abnormal wear - broken rods proken rods broken or missing track cleats. if track is damaged or rods are broken, replace track. For damaged or missing cleats, replace by new ones. WARNING WARNING Atteur TYPICAL 1. Poston cleat 2. Push tabs into rubber Do not operate a snowmobile with a cut, torn or damaged track. Track Cleat Replacement Raise rear of vehicle off the ground and lift snow guard then hand rotate track to expose a cleat to be replaced. Track Removal Remove the following parts: - rear suspension (refer to SUSPENSION) - drive axle (refer to DRIVE AXLE) Remove the defective cleat. - track Place new cleat in position on the track and using the cleat installer (P/N 529 036 044) bend cleat then push tabs into rubber. Track Installation Reverse the removal procedure. Re-open installer, then position cleat tabs on open end of tool and squeeze tabs until they are indent-ed in rubber. NOTE: When installing the track, respect rotation direction indicated by an arrow on track thread. Check sprocket/track alignment as described in DRIVE AXLE. Track Adjustment Track tension and alignment are interrelated. Do not adjust one without checking the other. Track tension procedure must be carried out prior to track alignment. Track Tension


NOTE: Ride the snowmobile in snow about 15 tr 20 minutes prior to adjusting track tension. Lift snowmobile by a rope, chain or lift straj hooked to rear bumper.


Section 10 DRIVE SYSTEM AND BRAKE Subsection 14 (TRACK)

Allow the rear suspension to fully extend and check gap halfway between front and rear idler wheels. Measure between slider shoe bottom and inside of track. The gap should be as given in the following table. If the track tension is too loose, track will have a tendency to thump.

TRACK ADJUSTMENT		
MODELS	FORCE	DEFLECTION
440 550F	7.3 kgf (16 lbf)	Minimum 30.00 mm (1.181 in)
		Maximum 35.00 mm (1.378 in)
600 600 HO SDI V800	7.3 kgf (16 lbf)	Minimum 40.00 mm (1.575 in)
		Maximum 50.00 mm (1.969 in)

The belt tension tester (P/N 414 348 200) may be used to measure deflection as well as force applied.





1. Tool top O-ring positioned at 7.3 kgf (16 lbf) 2. Apply pressure on tool until it contacts the upper O-ring 3. Measured track deflection

CAUTION: Too much tension will result in pow-er loss and excessive stresses on suspension components.

To adjust tension, do the following: - Remove wheel caps.


- Turn adjustment screws to adjust. 2 TYPICAL 1. Adjustment screw 2. Retaining screw 3. Wheel cap removal

Track Alignment


Before checking track alignment, ensure that the track is free of all particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle. Never rotate at high speed.


Start the engine and accelerate slightly so that track barely turns. This must be done in a short period of time (1 to 2 minutes).

Check that the track is well centered; equal distance on both sides between edges of track guides and slider shoes.



To correct, stop engine, loosen rear wheel screws, then tighten the adjustment screw on side where the slider shoe is the farthest from the track insert guides.





GENERAL

The procedure explained below is the same for the RH and LH sides unless otherwise noted. During assembly/installation, use torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.


Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.


PROCEDURES

SHOCK ABSORBER AND SPRING


Shock Absorber and Spring Removal Lift front of vehicle and support off the ground. Remove ski bolt and nut.

Remove steel bushing from ski using a pusher. See pusher dimensions below.








Unfasten rod nut then pull out shock from bottom. Check shock as described below in *INSPECTION*. At installation, make sure bushings are in place.



Unscrew 3 Allen screws retaining shock absorber cover no. 3, then remove stopper no. 5, washers no. 6 and large washer no. 7.







Section 11 SUSPENSION

Subsection 02 (FRONT SUSPENSION (SUV/TUV))

GENERAL

The procedure explained below is the same for the RH and LH sides unless otherwise noted.

During assembly/installation, use the torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCITTE APPL/CATION at the beginning of this manual for complete procedure.

A WARNING Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

PROCEDURES

SHOCK ABSORBER

Shock Absorber Removal

Lift front of vehicle and support it off the ground. Reduce spring preload by turning adjusting ring accordingly.

Remove lower bolt then upper bolt of shock ab-sorber no. 1.


For shock absorber disassembly and check, refer to SHOCK ABSORBER INSPECTION AND SER-VICING.

Shock Absorber Installation Reverse the removal procedure.

SWING ARM

Swing Arm Removal

Lift front of vehicle and support it off the ground. On steering arm, remove cap no. 2, and circlip no. 3.



1. Cap 2. Steering arm 3. Swing arm

Scribe marks on the steering arm and ski leg no. 4 before disassembly.



Loosen steering arm bolt and pull up steering arm. Ski leg may fall off from swing arm no. 5. Unbolt lower end of shock from swing arm Unbolt upper and lower arms no. 6 and no. 7. Unbolt rear of swing arm from frame Pull swing arm off the vehicle.

Swing Arm Inspection

Check all rubber cushions no. 8 for crack and wear. Replace as required. Check for straightness of swing arm. Replace as required.

Check for clogged grease fittings. Clean or re-place as required.

Swing Arm Installation

For assembly, reverse the disassembly procedure. However, pay attention to the following. Install steering stopper no. 9 as per following pho-to.



Then loosen steering arm bolt. Ski leg may fall off from swing arm no. 5. Check straightness of ski leg no. 4 and make sure that splines are properly interlocking with steering arm. Replace as required.


645






Section 11 SUSPENSION Subsection 02 (FRONT SUSPENSION (SUV/TUV))

Section 11 SUSPENSION Subsection 02 (FRONT SUSPENSION (SUV/TUV)) 3 1 1. Swing arm 2. Lower arm 3. Upper arm Arm Installation Position arms and tie rods horizontally before tight-ening nuts. Bent portion of lower arm no. 7 must face down.





GENERAL

During assembly/installation, use torque values and service products as in the exploded view(s).

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with new ones where specified. If the efficiency of a locking device is impaired, it must be re-newed.

Suspension Adjustment

To adjust the rear suspension, refer to the appro-priate OPERATOR'S GUIDE.

PROCEDURES

NOTE: The following components can be re-moved with suspension in place. For suspension assembly removal, refer to SUSPENSION AS-SEMBLY further in this section.

REAR AXLE

Rear Axle Removal


Lift rear of vehicle and support it off the ground. Completely loosen track tension by unscrewing both adjustment screws.



Remove rear idler wheel screws on rear axle Pull out rear axle from RH side of vehicle.

Rear Axle Installation Installation is the reverse of removal procedure. Pay attention to the following details.

Hole of outer bushing must face adjustment screw.



NG POSIT Adjust track tension. Refer to TRACK section.

EXTENSION ARM

Extension Arm Removal Lift rear of vehicle and support it off the ground. Completely loosen track tension.

Remove nuts and conical washers from the eye bolt adjuster. Remove bolt retaining eye bolt ad-juster to rear support.



1. Conical was 2. Nuts 3. Rear support support

Remove rear idler wheel on appropriate side. Remove idler wheel from rear support. Unbolt extension arm from its support.



1. RH extension arm 2. Rear support

Extension Arm Installation

The installation is the reverse of the removal procedure. However, pay attention to the following. At installation, position conical washers as shown.



NASHER QUANTITY AND MOUNTING POSITION



Tighten nut 3/4 turn after contacting washers for better deep snow performance. Maximum preload is 3 turns after nut touching washers. This last adjustment is for trail riding with or without a load and for pulling a load.

Horse-Shoe Washer

For deep snow riding, do not install washer. For trail riding with passenger and/or weight, install 1 washer under each rubber stoppers. For trail riding with heavy load and/or pulling a load, use 2 washers under each rubber stoppers.

REAR SHOCK ABSORBER

Rear Shock Absorber Removal Lift rear of vehicle and support it off the ground. Remove shock upper and lower bolt and nut. NOTE: If necessary, to ease shock removal, release stopper strap tension to release shock pressure.

Remove rear shock absorber.

Rear Shock Absorber Inspection Refer to SHOCK ABSORBER INSPECTION AND SERVICING.

Rear Shock Absorber Installation Installation is the reverse of removal procedure.

REAR SPRING

Rear Spring Removal

Lift rear of vehicle and support it off the ground. Decrease spring preload by turning cams accordingly. Unbolt rear arm top axle from chassis.

Unbolt rear arm top axle from chassis. Remove spring supports.



Loosen set screw from locking rings. Remove the following on both sides: – locking ring

- top idler wheel

- spring.

Rear Spring Installation


Installation is the reverse of removal procedure. Pay attention to the following details. At assembly, respect THIS SIDE OUT inscription on top idler wheels.

At assembly, make sure that spring end is in cam adjuster.



H SIDE SHOWN Spring end Top idler wheel Cam adjuster

CAUTION: To avoid track damage, spring supports must be mounted upward.



TYPICAL — RIGHT SIDE SHOWN 1. Right position: upward 2. Wrong position

REAR ARM

mmr2007-217

Rear Arm Removal

Lift rear of vehicle and support it off the ground. Completely loosen track tension.

Remove upper bolt securing shock absorber to rear arm. Remove rear springs. Remove bolts holding rear arm to pivot arms.



Pivot arm Rear arm Remove the rear arm

Rear Arm Installation

Installation is reverse of removal procedure. FRONT SHOCK ABSORBER

Skandic LT 440F

Front Shock Absorber Removal Lift rear of vehicle and support it off the ground. Remove upper and lower bolts securing shock ab-sorber.

Remove shock absorber from vehicle

Front Shock Absorber Inspection Refer to SHOCK ABSORBER INSPECTION AND SERVICING.

Front Shock Absorber Installation The installation is the reverse of the removal pro-cedure.

FRONT SPRING WT/SWT 550F, WT 600 and SWT V800

Front Spring Removal Holding spring end, remove bolt of the top spring support then the bottom support bolt. Unbolt front idler wheel axle.

Remove idler wheel on side where axle retaining plate is not welded.





TYPICAL - PUSH ON SLIDER SHOE

Using locking pliers, pull slider shoe through track window to remove.



TYPICAL - PULL ON SLIDER SHOE TO REMOVE

Slider Shoe Installation Installation is reverse of removal procedure. Pay attention to the following details. Make sure to insert slider shoe end with hole first.

SUSPENSION ASSEMBLY

Suspension Removal Lift rear of vehicle and support it off the ground. Completely loosen track tension. Remove both track stoppers.

mmr2007-21



Remove rear arm top axle bolts from chassis, us-ing the following procedure. – Unscrew one of the socket screws securing the rear arm top axle to frame.




Replace this socket screw with an hexagonal bolt (longer than socket screw) and a nut.
 Screw the hexagonal bolt completely and lock it with the nut.



Unscrew the socket screw on the other side then unlock nut and remove the hexagonal bolt.
 Remove bolts retaining front arm to tunnel.





Section 11 SUSPENSION Subsection 04 (REAR SUSPENSION (SUV/TUV))

SUSPENSION REMOVAL

Release track tension

Lift rear of vehicle and support it off the ground. Unbolt front arm then rear arm.

Self-Locking Screws

CAUTION: These self-locking screws must al-ways be replaced by new ones every time they are removed.

are removed. NOTE: To prevent axle from turning when un-screwing self-locking screws, proceed as follows: - Remove one self-locking screw then install a 10 mm shorter non-self-locking one in place. Torque as specified in exploded view. - Remove the opposite self-locking screw. - Remove the temporary installed non-self-locking screw.

- If it doesn't work, heat bolt head to melt thread-

locker.

Remove suspension assembly.



SUSPENSION DISASSEMBLY AND ASSEMBLY

Extension Arms

Remove nuts and conical washers from the eye bolt adjuster. Remove bolt retaining eye bolt ad-juster to support.

Remove rear idler wheel on appropriate side. Remove idler wheel from rear support.

Unbolt extension arm no. 1 from its support.







Tighten nut 3/4 turn after contacting washer for better deep snow performance. Maximun preload is 3 turns after nut touching washers This last adjustment is for trail riding with or with out a load and for pulling a load.

Rear Shock Absorber

Unbolt top and bottom ends of rear shock at sorber no. 8.







Section 11 SUSPENSION Subsection 05 (SHOCK ABSORBER INSPECTION AND SERVICING)

Check the following conditions that will denote a defective shock:

- a skip or a hang back when reversing stroke at mid travel
- seizing or binding condition except at extreme end of either stroke
- oil leakage
- a gurgling noise, after completing one full compression and extension strokes.
- If suspecting a shock is freezing, proceed as follows:
- Place shock in a freezer (temperature below $0^{\circ}C$ (32°F)) for 4 hours.

Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition. Renew if any faults are present.

nonew if any faults are present.

Gas Shock Absorber (HPG type)

Because of gas pressure, strong resistance is felt when compressing shock.

To inspect shock operation, or if suspecting an internal leak between oil chamber and gas chamber, check shock as follows:

Install shock in a vise clamping on its bottom eyelet with its rod upward. Verify the compression stroke when the rod is fully extended.

Completely push down the shock rod then release.


The shock should extend unassisted. Rod must come out at a steady speed. If speed suddenly increases particularly at end of extension, replace shock.


If suspecting a shock is freezing, proceed as follows:


Place shock in a freezer (temperature below 0°C (32°F)) for 4 hours.


Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.


Shock Absorber/Spring Assembly Refer to disassembly procedure.














Subsection 01 (STEERING AND HANDLEBAR)

GENERAL

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be installed or replaced with a new ones where specified. If the efficiency of a locking device is impaired, it must be renewed.

PROCEDURES

HANDLEBAR GRIP

NOTE: To verify heating elements, refer to LIGHTS, INSTRUMENTS AND ACCESSORIES

Grip Removal

Grips no. 1 must be carefully removed to prevent damaging the heating elements. Remove rivet no. 2.

Heat grip with a heat gun.

Apply tape to handlebar no. 3 near the grip to protect paint.

Inject compressed air into the handlebar and twist grip while pulling it out.



The grips might not be removable as explained above; in this case, carefully proceed as follows to prevent damaging the heating elements. Start cutting and immediately peel it open to lo-

Start cutting and immediately peel it open to locate the gap in the heating element, as shown.



TYPICAL 1. Gap in the heating element opposite the wires

Continue cutting along the gap and remove the grip.

If required, disconnect heating element connector. Remove wires from connector and pull wires by the end of handlebar. Slowly peel heating element from handlebar and remove it.

Grip Installation

Installation is the opposite procedure of the removal but pay attention to the following.

Clean handlebar ends and inside of grip with isopropyl alcohol. Let dry before installation. CAUTION: Handlebar end and inside of grip

CAUTION: Handlebar end and inside of grip must be clean and dry before installing grip to ensure proper adhesion. To install stick the heating element to the han-

To install, stick the heating element to the handlebar and route wires into handlebar and through handlebar hole.

Never use lubricants (e.g. oil, grease, etc.) to install the handlebar grip. Only use a mix of soap and water, Mix 40 parts of water with one part of dish washing soap (recommended: Ultra Joy, Sunlight or Palmolive).

Heat the grip with a heater gun or a spot light to ease installation. Insert new grip with compressed air.

Section 12 STEERING Subsection 01 (STEERING AND HANDLEBAR)



Install rivet no. 2.

HANDLEBAR

Handlebar Removal

NOTE: If the handlebar no. 3 must be changed, remove all components (handlebar grip, throttle lever housing, etc.) before removing it from ve-hicle.

Remove steering padding no. 4.

Remove handlebar bolts no. 5 and handlebar clamps no. 6. Cut locking ties retaining harness to handlebar.

Handlebar Inspection

Inspect the handlebar for damage, cracks or bend-ing, replace if any of these problems is detected. Check handlebar clamps no. 6 for cracks or distor-tion, replace if necessary.

Handlebar Installation

The installation is the reverse of the removal pro-cedure. However pay attention to the following. Install all handlebar bolts no. 5 before torquing them. Adjust the handlebar to the desired position. Torque to 24 N•m (18 lbf+ft).

HANDLEBAR EXTENSION Skandic LT 440F and SWT V800

Handlebar Extension Removal

Remove handlebar no. 3 from handlebar extension no. 7. Unscrew bolts no. 8 retaining the extension to steering column no. 9.

Remove handlebar extension from vehicle.

Handlebar Extension Inspection Check handlebar extension for cracks, bend c other damages. Replace defective parts.

Do not try to repair a defective handlebar ex-tension.

Handlebar Extension Installation

The installation is the reverse of the removal pro cedure.

TIE-ROD

NOTE: Use same procedure for RH and LH side. Tie-Rod Inspection

Check tie-rod ends for looseness. If play is excessive, replace tie-rod. Check if the tie-rod is bent, cracked or otherwise damaged. Replace if necessary.

Tie-Rod Removal

NOTE: When removing a tie-rod, note its position. Check the location and the number of hardened washers no. 10.


LH or RH Tie-Rods

Skandic LT 440F, WT and SWT Unscrew the outer tie-rod end no. 11 from steer-ing arm no. 12.

Unscrew the inner tie-rod end no. 13 from steer-ing column no. 9.

Remove tie-rod no. 14 from vehicle.

Skandic SUV and Expedition TUV Separate the outer tie-rod end no. 11 from steer-ing arm no. 12.



Then separate the inner tie-rod end from pivot arm.

Section 12 STEERING Subsection 01 (STEERING AND HANDLEBAR)

Central Tie-Rod

Skandic SUV and Expedition TUV

Skalloc SoV and Expedition (JV) The central tie-rod no. 16 links the LH pivot arm no. 15 to the RH pivot arm no. 17. To remove the central tie-rod, unscrew both tie-rod ends from pivot arms.

Short Tie-Rod Skandic SUV

The short tie-rod no. 18 links the steering column with the RH pivot arm no. 17.


Unscrew tie-rod nuts no. 19 from steering column and pivot arm then remove it.

Expedition TUV

The short tie-rod no. 18 links the steering column with the LH pivot arm no. 15. Unscrew tie-rod nuts no. 19 from steering column and pivot arm then remove it.

Tie-Rod Installation

The installation is the reverse of the removal pro-cedure. However, pay attention to the following. The maximum external threaded length not en-gaged in the tie-rod must not exceed 20 mm (25/32 in).



Install tie-rod with the groove on steering arm side. Do not forget to place hardened washer (s) where required.

Install nuts no. 19 retaining tie-rod. Torque them to 52 N•m (38 lbf•ft).

Complete the procedure by performing the steer-ing alignment, refer to SKI AND STEERING ALIGNMENT.

STEERING ARM

Steering Arm Removal

Skandic LT 440F, WT and SWT Remove tie-rod no. 14 from steering arm no. 12. Remove bolts securing steering arm to steering arm reinforcement.

Unscrew bolts holding shock cover. Unscrew shock absorber nut then lift the front of vehicle and remove shock absorber.



Steering arm Steering arm reinforce Shock absorber nut Shock cover bolts

Remove shock cover. Remove steering arm

Skandic SUV and Expedition TUV

Separate tie-rod no. 14 from steering arm no. 12 Remove ski leg cap.



To maintain correct steering alignment when re-assembly, scribe a mark on the steering arm and ski leg before disassembly. Remove steering arm from ski leg.

Steering Arm Inspection

Check if steering arm is bent, crack or otherwise damage. Replace if necessary.

Check splines on steering arm and on ski leg. If a worn spline is found, replace the part with a new one.

Section 12 STEERING Subsection 01 (STEERING AND HANDLEBAR)

Steering Arm Installation The installation is the reverse of the removal procedure. However, pay attention to the following. Skandie LT 440F. WT and SWT

Install steering arm at mid-travel position when handlebar and skis are facing straight ahead. Skandic SUV and Expedition TUV

Steering arm must be installed parallel to ski.

Torque steering arm bolt no. 20 to 24 N•m (18 lbf•ft).

STEERING COLUMN

Steering Column Removal

Remove handlebar no. 3 and handlebar extension no. 7.

Lift console to allow room and reach upper attachment.

Upper Side Skandic LT 440F

Remove nuts no. 21, U-clamp no. 22 and bushing no. 23.

Skandic WT/SWT/SUV 550F and Skandic WT/SUV 600

Remove bolts no. 27, stopper plates no. 24, half housings no. 25, bushings no. 26 and nuts no. 21.

Skandic SWT V800 and Expedition TUV Remove nuts no. 21, throttle cable plate no. 28, half housings no. 25 and bushings no. 26.

Lower Side Skandic LT 440F

Separate both tie-rods from steering column. Remove nuts, U-clamp and bushing.

Remove steering arm from vehicle.

Skandic WT and SWT

Separate both tie-rods from steering column. Remove nuts, stopper plates, half housings, bushings and bolts.

NOTE: On SWT V800, the removal of driven pulley is necessary to reach the bottom of steering column.

Remove steering column from vehicle.

Skandic SUV and Expedition TUV Separate short tie-rod no. 18 from steering col-

umn.

Remove nuts, stopper plate(s), half housings and bushings. Remove steering column from vehicle.


Steering Column Inspection

Check steering column for crack, bend or other damage.

Steering Column Installation

The installation is the reverse of the removal procedure. However, pay attention to the following. Apply ThermoLube synthetic grease (P/N 219 700 417) on steering column before installing half housings no. 25.

Torque nuts no. 21 to 24 N•m (18 lbf•ft). Install tie-rod(s).



Section 12 STEERING Subsection 02 (SKIS AND STEERING ALIGNMENT)

GENERAL

During assembly/installation, use the torque val-ues and service products as in the exploded view(s).

Clean threads before applying a threadlocker. Re-fer to SELF-LOCKING FASTENERS and LOCTITE APPLICATION at the beginning of this manual for complete procedure.


Torque wench tightening specifications must strictly be adhered to. Looking devices (e.g.: looking tabs, elastic stop nuts, self-looking fasteners, cotter pins, etc.) must be installed or replaced with a new ones where specified. If the efficiency of a looking device is impaired, it must be renewed.

ADJUSTMENT

STEERING ALIGNMENT

A WARNING


Never lengthen tie-rod making threaded por-tion of ball joint exceed 20 mm (25/32 in).





Definitions

Toe-Out: A difference measured between the front edge of the skis "A" and rear edge "B" as viewed from the top. It is adjustable.



Camber:

A specific inward or outward tilt angle of ski leg compared to a vertical line when viewing the vehi-cle from front. This angle is not adjustable on any models

Adjustments

Skandic SUV and Expedition TUV Adjustments should be performed following this sequence:

- Handlebar/pivot arm positioning.

- Set toe-out adjustment.

Handlebar and Pivot Arms Positioning First make sure pivot arms are parallel. To adjust, use the tie-rod located between them. Turn handlebar until pivot arms are pointing straight forward.

Check if handlebar is horizontal. To adjust, loosen lock nuts of short tie-rod and turn it accordingly.

Restrain short tie-rod while torquing nuts so that ball joint sockets run parallel with steering arms and pivot arms.


Ensure that pivot arms are still pointing straight forward and check ski toe-out.

With this adjustment properly done, turning radius will be the same on both sides.

Toe-Out Adjustment

With the handlebar in straight ahead position, turn left and right tie-rods or tie-rods adjuster to obtain specified toe-out. – Loosen jam nuts of both tie-rods.

NOTE: On models with tie-rod adjuster, only loosen adjuster jam nut.



Subsection 12 STEERING Subsection 02 (SKIS AND STEERING ALIGNMENT)

PROCEDURES

SKI RUNNER

Ski Runner Inspection Lift the front of vehicle and check ski runners for wear or damages (missing or broken carbide). Re-place if necessary.

Ski Runner Removal Lift the front of vehicle and support it off ground. Unscrew the ski runner nuts then remove ski run-



TYPICAL — SUV MODEL SHOWN 1. Ski runner nuts 2. Ski leg


The installation is the reverse of the removal pro-cedure. On models equipped with the following type of ski runner, make sure to install the carbide inside.



Ski Inspection Check skis and runners for wear, replace as nec-essary. Check condition of ski stopper. Replace it when deteriorated.

Ski Removal Skandic LT, WT and SWT

Lift front of vehicle and support off the ground. Remove ski bolt and nut. Remove steel bushing from ski using a pusher. See pusher dimensions below.





Skandic SUV and Expedition TUV Lift front of vehicle and support it off ground. Unscrew nut then pull ski bolt out. Remove ski from vehicle.

Ski Installation Skandic LT, WT and SWT Install the ski stopper on skis with its highest por-tion toward front then the support plate.

Section 12 STEERING Subsection 02 (SKIS AND STEERING ALIGNMENT) Skandic SUV and Expedition TUV 1. Ski stopper 2. Ski bolt 3. Front of vehicle 4. Elastic stop nut 5. Ski leg bushing 6. Ski leg 7. Ski 1 Ski stoppe Install the ski to shock absorber. Secure the ski to shock absorber with the ski bolt. NOTE: Make sure that the bolt head is toward the outside of the vehicle. Ensure the ski leg bushing is still on the ski leg. Ensure the skileg bushing is still on the skileg. Insert the ski stopper into the ski. Place its higher side toward the front of vehicle. Install the skileg. Secure the skileg with the skilbolt. NOTE: Make sure that the bolt head is toward the outside of the vehicle. Torque nut to 45 Nem (33 lbf=ft). On SWT models, install a conical spring washers on both side of ski leg (concave surface inside). 6 100 3 Hubber bushings Conical spring was Ski bolt hers (SWT only) 56 stop nut Torque ski leg nuts to 45 N•m (33 lbf•ft). 675

BODY

SERVICE TOOLS

Description fuel reservoir nut wrench ...

PARTS REPLACEMENT

DECAL

To remove a decal; heat old decal with a heat gun and peel off slowly. Using isopropyl alcohol, clean the surface and dry thoroughly.

thoroughly. Apply liquid scap to new decal and carefully po-sition the decal. Using a sponge or a squeege, remove the air bubbles and surplus water work-ing from the center toward the edges. Allow to air dry.

CAUTION: Do not apply isopropyl alcohol or solvent directly on decals. Use only in a well ventilated area.



Hood Removal

Remove bolts retaining both hinges to front bumper.



TYPICAL — EXPEDITION TUV SHOWN 1. Hinge bolt 2. Hood 3. Front bumper 4. Bottom pan

Open hood and detach retaining wire from hood.



Disconnect wiring harness.



TYPICAL Remove hood.

Hood Installation The installation is the reverse of the removal pro-cedure.

FRONT BUMPER Front Bumper Removal Remove all bolts and/or rivets retaining the front bumper to bottom pan. Remove bumper.

Front Bumper Installation

677

Reverse the removal procedure.

BOTTOM PAN

Bottom Pan Removal

Remove hood. Remove front bumper.

Skandic LT, WT and SWT Remove skis.

Drill all rivets holding bottom pan to frame. Skandic SUV

Remove front shock absorbers and front suspen-sion arms.

Drill all rivets holding bottom pan to frame. Remove bottom pan.

Expedition TUV

To remove the central part of bottom pan, drill all rivets then remove the piece. To remove the side parts of bottom pan, lift front of vehicle and remove appropriate suspension arm. Drill rivets holding central and side parts then re-move them.

Bottom Pan Installation Reverse the removal procedure.

WINDSHIELD

Windshield Removal

Open hood. Remove rubber latches securing windshield then remove it.



Windshield Installation Reverse the removal procedure.

CONSOLE Console Removal

Open hood.

The console can be retained by rivets or darts. Drill all rivets or remove all darts.



IVETS - SKANDIC SUV



DARTS - EXPEDITION TUV 600

Remove fuel tank cap. Using the fuel reservoir nut wrench (P/N 529 035 891), unscrew the fuel tank nut.



Remove handlebar and handlebar extension. Re-fer to STEERING. Remove rewind handle and transmission lever (if applicable).

Lift up the console and unplug all connectors. Install fuel tank cap.

=2=2

TYPICAL — EXPEDITION TUV 1. Backrest arm 2. Knob 3. Rear rack

Remove backrest from vehicle.

For installation, reverse the removal procedure.

It is recommended to clean the seat with a solution of warm soapy water, using a soft clean cloth.

CAUTION: Avoid use of harsh detergents such as strong soaps, degreasing solvents, abrasive cleaners, paint thinners, etc. that may cause damage to the seat cover.

Clean the vehicle thoroughly, removing all dirt and grease accumulation. To clean use a soft clean cloth and either soapy water or isopropyl alcohol.

To remove grease, oil or glue use isopropyl alco-

CAUTION: Do not apply isopropyl alcohol or acetone directly on decals.

CAUTION: The following products must not be used to clean or wax any of the plastic components used on the vehicles: - gasoline - brake fluid

Backrest Installation

CLEANING

SEAT

PLASTIC

Console Installation The installation is the reverse of the removal procedure.

SEAT

Seat Removal Open seat.

Remove screws holding hinges to seat or carefully drill rivets.

Detach retaining wire from seat. Remove seat.

Seat Installation Reverse the removal procedure.

BACKREST

Backrest Removal Fixed Backrest Model On both sides, remove screws securing backrest to seat.



TYPICAL — SKANDIC SUV 1. Backrest support screws Remove backrest from vehicle.

Adjustable Backrest Model On both sides, unscrew knobs securing the backrest arms to rear rack.

grint and the total of the

and parts

varsor
naphtha
acetone
strong detergents

kerosene
diesel fuel
lighter fluid
Varsol

679

abrasive cleaners

waxes containing an abrasive or a cleaning agent in their formula.

Apply wax on glossy finish only. Protect the ve-hicle with a cover to prevent dust accumulation during storage.

CAUTION: If for some reason the snowmobile has to be stored outside, it is preferable to cov-er it with an opaque tarpaulin. This will prevent the sun rays from affecting the plastic compo-nents and the vehicle finish.

REPAIR

The very first step before repairing plastic materials is to find out exactly which type of material is involved. Refer to following chart.

DADT	MATTOIAL	REPAIL	RABLE
PART	MATERIAL	YES	NO
Bottom pan	High density polyethylene (HDPE)		*
Hood	R.R.I.M.	~	
Windshield	Polycarbonate		*

CAUTION: Consult chart and repair kit instruc-tions carefully, some repair products are not tions carefully, some repair pro compatible with certain plastics

Polycarbonate windshields must never be repaired by welding or otherwise.

REPAIR PROCEDURE FOR R.R.I.M.

R.R.I.M. is light colored (tan) on the inside with a smooth surface.

A WARNING

Material should be repaired and repainted in a well-ventilated area only.

CAUTION: Clean R.R.I.M. with isopropyl alco-hol or Crest Hi-Solv product. Never use clean-ers or products that contain chlorine.

CAUTION: R.R.I.M. should never be exposed to temperatures exceeding 93°C (200°F).

NOTE: When working on a R.R.I.M. surface, never use a grinder or a high revolution tool such as an air or electric buffer. Use of such tools could over-heat material and liberate agents in it thus causing a bad adhesion.

Small Scratches

Sand and scuff area.
Feather out edges.
Paint with a matching acrylic auto touch-up paint.

Deep Scratches

- Sand and scuff area. Make a "V" groove using a knife or a rough round file.
- Clean surface with isopropyl alcohol or Crest Hi-Solv stock no. AH-S product. Cover with TP-E epoxy mixed in equal quanti-
- ties
- Heat the surface with a heater lamp placed at 38 cm (15 in) for a period of 15 minutes. Sand the surface using a smooth dry sand pa-
- per Use the same product if a final finish is required.
- Clean surface with Crest Hi-Solv product.
 Apply a flexible primer such as Crest Prima Flex stock no. AP-F.
- Wait 10 minutes.
- Repaint (air dry during 72 hours (approximately)).

Large Crack

- Sand and scuff outside and inside area by ex-ceeding it 31.7 mm (1-1/4 in) on each side and 12.7 mm (1/2 in) at each end.
- Make a "V" groove (appr. 90°) on both sides of hood using a knife or a rough round file. Enlarge the crack to 2.4 mm (3/32 in) 3.2 mm (1/8 in) using a sharp knife.
- Clean outside and inside surface with isopropyl
- alcohol or Crest Hi-Solv product. Repair inside surface first.
- Cover inside area with Crest TP-E epoxy. Apply a 50 mm x 30 mm (2 in x 1-1/4 in) patch. If no room for the patch, use tape.
- Cover exterior surface with same product. Damaged area should be slightly higher.
- Heat surface with a heater lamp placed at 38 mm (15 in) for a period of 15 minutes.
- Sand outside surface using a smooth dry sand paper
- Use same product if a final finish is required. - Apply a flexible primer.
- Wait 10 minutes
- Repaint (air dry during 72 hours approximately).

	Section 13 BODY/FRAMI Subsection 01 (BODY
NOTE: R.R.I.M. materials are high static plastics, painting must be done in a dust free area such as a paint booth. Crest products used in R.R.I.M. repair procedure are available from following locatione.	Subsection of (BOD)
CREST MAIN OFFICE AND MANUFACTURING PLANT	
CREST INDUSTRIES INC. 1337 King Road Trenton, Michigan, U.S.A. 48183	
Phone: 734-479-4141 Toll free: 1 800 822-4100 Fax: 734-479-4040 E-mail: info@crestauto.com www.crestauto.com	
The second se	

Section 13 BODY/FRAME Subsection 02 (FRAME) FRAME SERVICE TOOLS Description Supertanium drill bit.... Part Number 529 031 800 SERVICE PRODUCTS Description XP-S synthetic chaincase oil... Part Number 413 803 300 PROCEDURES FRAME Frame Cleaning SELF-PIERCING RIVETS Clean frame and tunnel with appropriate cleaners and nose with high pressure hose. Rivet Drilling Procedure When drilling self-piercing rivets, use the Superta-nium drill bit (P/N 529 031 800), available in a 5 mm (3/16 in) size and shipped in packs of 2. CAUTION: Never direct high-pressure water jet towards decals. They would peel off. Touch up all metal spots where paint has been scratched off. Spray all bare metal parts of vehicle with metal protector. For proper drilling instructions and to prevent pre-mature wear, follow the procedure below. mature Wear, ronow the procedure beaw. Always use a variable speed drill. Maintain a slow to medium speed at all times when drilling. The proper speed is attained when a constant chip is ejected. NOTE: To increase bit life, use XPS synthetic chaincase oil (P/N 413 803 300) as a cuting oil. Frame Welding - electric welding - amperage: 70-110 A - voltage: 20-24 V - electrode: E-7014 (3/32 in).

CAUTION: High speed drilling will cause excessive heat which may destroy the cutting day of the bit; therefore, avoid using pneumatic drills. - Cut rivet using a chisel. - Remove riveted part. - Drive out remaining rivet head using a punch.

POP RIVETS

mm/2007-223

Rivet Drilling Procedure

- Always drill rivet head
 When rivet is located on plastic part, use pliers
 to avoid rivet turning and heating plastic
 Use a small punch to push the rivet end.

CAUTION: Before performing electrical weld-ing anywhere on the vehicle, unplug the multi-ple connector at the electronic box. On models equipped with a battery, also unplug the nega-tive cable. This will protect the electronic box and battery against damage caused by flowing current when welding.

Page

683



			tion 14 TECHNICAL SPECIFICATION Subsection 01 (440F AND 550F MODEL
440F AND	550F	MO	DELS
			SKANDE
MODE	1		U
			6455
ENGINE			
Engine type			40
Number of cylinder			1
Born		ALL (M)	87.5 (2.858)
Stroke		mm (iv)	61.00 (2.4021)
Displacement		(10)2 [(1)]	456.5 (25.54)
Compression ratio Maximum power engine speed			14 x 15 (90)
Combustion chamber volume		s 100 RPM	24.4 to 28.4
Computation channels where		10	Seni trabectidal
Piston ring type		24	Rectangular
	New	nes (all	0.2 (0079)
ting and gap	Wear limit	no jej	1.0 (.00%)
	New	net (e)	0.04 (0015)
Ring/piston groove clearance	Wear limit	mm (m)	0.2 (0079)
	Neu	no let	0.070 (.0031)
Piston/cylinder wall clearance	Wear Imit	mm (m)	0.2 (.007%)
Piaton skirt wear	Wear limit	nn (ei	0.15 (.006)
Cylinder head worpage	Wear limit	en (n)	0.5 (62)
Change and a lot	New (max.)	nm (n)	0.05 (0020)
Cylinder taper	Wear limit	nın (iri)	8.10 (0039)
	New (max.)	nm (in)	0.01 (.0004)
Cylinder out of round	Wear limit	nm lini	0.06 (.0031)
Maximum crankshaft and play	New (max.)	nn (ri	0.3 (.012)
Maximum crankshaft deflection	Wear linit	nn (r)	PTD: 0.06 (.0004) Center: 0.08 (.0001) MAG: 0.00 (.001)
	New	ne (ei)	0.20 to 0.527 (2079 to 15257)
Connecting rod big end axial paly	Wear limit	nn (n)	1.2 (5472)
Crankshaft end-play	New	nn (ri	0.10 to 0.30 (1004 to 012)
COOLING SYSTEM	-	a state of the state of the	
Type			Fan
	Ceffection	nn (n)	85 x 15 (37 x 380)
Axial fan beit adjustment	Face	ligt libit	5.0 (11.0)

		0.30	SKANDIC				
THE STREET	MODEL		LT				
			440F				
LUBRICATION SYSTEM	12-0		XP-S mineral injection oil				
Injection oil	Type Quantity	L (U.S. oz)	2.5 (84.5)				
FUEL SYSTEM	Countity	E (0.5. 02)	2.0 (04.0)				
Carburetor type			1 x VM32				
Main jet			180				
Needle jet			159				
Pilot jet			50				
Jet needle identification and	Lelia position		6DGY12 - 3				
Side cut-away	reite position		3				
Idle throttle slilde height			1.4 ± 0.1 (.055 ± .004)				
Float adjustment		mm (in)	35.5 ± 1 (1.392 ± .040)				
Air or pilot screw adjustment		± 1/16 turn	15				
die speed		± 200 RPM	1650				
Sas type		Unleaded					
ump octane number	Inside North Al ((R+M)/2)	merica	87 or higher				
	Outside North A	America (RON)	92 or higher				
uel tank capacity		L (U.S. gal)	37 (9.77)				
ias/oil ratio	Contraction of the		Injection				
LECTRICAL SYSTEM		and the second second					
lagneto generator output			240 W Ø 6000 RPM				
nition type			CDI				
park plug	Make and type		NGK BR9ES				
	Gap	mm (in)	0.40 to 0.60 (.016 to .024)				
nition timing BTDC		mm (in)	2.79 (.110) @ 3500 RPM				
gger coil		Ω	160 to 180				
merating coil	Low speed	Ω	5.1				
	High speed	Ω	6.2				
inting coil		Ω	0.17 to 0.21				
tension coil	Primary	Ω					
	Secondary	kΩ	-				
adlamp	and the second second	W	60/55 (H4)				
llight and stoplight	a the second second	W	8/27				

	MODEL	SKANDIC
		u
DRIVE SYSTEM		440F
Chaincase oil	Type	
Citation Contraction Citation Citatio Citation Citation Citation Citation Citation C	Quantity mL (U.S. oz)	XP-S synthetic chaincase oil
Chain drive ratio	mL (U.S. 02)	250 (8.5)
Chain	Pitch	17/44
Gridin	in Type/links qty/plate qty	3/8
Drive pulley type	reasoning downaria dty	Silent 70/13
Sector Sector Sector	Clutch	COMET 102
	lengagement = 100 RPM Spring color	3200
Drive pulley calibration	Spring color Spring free	Silver/Black
	length mm (in)	79 (3.110)
		417 003 900
	Туре	LPV 27
Driven pulley	Spring color	White
	Spring preload	0
Pulley distance	Cam angle	40°
runey distance	2 mm (in)	39 ± 0.75 (1.535 ± .030)
Offset	(n) mm (x	37 ± 0.75 (1.457 ± .030)
D	Y-X mm (in)	0.75 to 1.5 (.030 to .060)
Drive belt part number	P/N	414 633 800
Drive belt	Width mm (in)	34.60 (1.362)
	Wear limit mm (in)	32.00 (1.260)
Drive belt adjustment	Deflection mm (in)	32 ± 5 (1.260 ± .197)
	Force kgt (lbt)	11.34 (25)
	Width mm (in)	381 (15)
irack	Length m (in)	3.97 (156)
	Profile height mm (in)	25.4 (1)
rack adjustment	Deflection mm (in)	30 to 35 (1.181 to 1.378)
	Force kgf (lbf)	7.3 (16)
RAKE SYSTEM		
rake lining thickness	Service limit mm (in)	1 (.839)
rake fluid	Туре	DOT 4
and had	Quantity mL (U.S. oz)	60 (2.0)

Section 14 TECHNICAL SPECIFICATIONS Subsection 01 (440F AND 550F MODELS)

		SKANDIC	
MODEL		LT	
		440F	
SUSPENSION		and the second second second	
FRONT			
Suspension type		LTS	
Suspension maximum travel	mm (in)	150 (5.9)	
Shock absorber type		Hydraulic	
REAR		and and the second	
Suspension type		LS	
Suspension maximum travel	mm (in)	150 (5.9)	
Shock absorber type	Center	Hydraulic	
Shock absorber type	Rear	HPG	1
Stroke limiter standard position		Middle position	
STEERING SYSTEM		The second second second second second	See.
Ski type		ADJ	
Toe-out	mm (in)	5 (.197)	
Camber		0°	
VEHICLE INFORMATIONS			
Mass (dry)	kg (lb)	231 (509.3)	
ength	m (in)	3.04 (119.7)	
Vidth	m (in)	1.01 (39.6)	
leight	m (in)	1.30 (51.2)	
iki stance (carbide to carbide)	mm (in)	820 (32)	
MATERIAL			34
rame		Steel	
lottom pan		Polypropylene	
bood		RRIM	5

MOD	EI		1	SKANDIC	
	····		WT	SWT	SU
ENGINE	Constant of		550F		
Engine type					
Number of cylinder				552	
Bore		mm (in)		76 (2.992)	-
Stroke		mm (in)		61.00 (2.402)	
Displacement		cm ³ (in ³)		553.40 (33.771)	
Compression ratio	(10,)			9.6 ± 0.5	
Maximum power engine speed	im power engine speed ± 100 RPM			7000	
Combustion chamber volume				35.54	-
Diston ring hang	1.1.1.1.1.1.1	1=		Semi-trapezoidal	
Piston ring type		200		Rectangular	
Discondina	New	mm (in)	-	0.40 (.0157	
Ring end gap	Wear limit	mm (in)	in the second	1.0 (.039)	
Ring/piston groove clearance	New	mm (in)	1 (K.)	0.037 (.0015)	
	Wear limit	mm (in)		0.2 (.0079)	
and the state	New	mm (in)	and the second	0.147 (.0058)	
Piston/cylinder wall clearance	Wear limit	mm (in)		0.2 (.0079)	
Piston skirt wear	Wear limit	mm (in)	10000	0.15 (.006)	-
Cylinder head warpage	Wear limit	mm (in)		0.5 (.02)	
a la da barra	New (max.)	mm (in)	1000000	0.05 (.0020)	100
Cylinder taper	Wear limit	(in) mm		0.10 (.0039)	
O l'ale and ale and	New (max.)	mm (in)	and the second	0.01 (.0004)	21270
Cylinder out of round	Wear limit	mm (in)		0.08 (.0031)	
Maximum crankshaft end play	New (max.)	mm (in)	1	0.3 (012)	
Maximum crankshaft deflection	Wear limit	mm (in)	1-	PTO: 0.06 (.0024) Center: 0.08 (.0031) MAG: 0.03 (.001)	
	New	mm (in)		0.20 to 0.527 (.0079 to .0207	1
Connecting rod big end axial paly	Wear limit	mm (in)		1.2 (.0472)	
Crankshaft end-play	New	mm (in)		0.10 to 0.30 (.004 to .012)	
COOLING SYSTEM	1 Salar	The state of	2		1
Type				Fan	
	Deflection	mm (in)		9.5 ± 1.5 (37 ± .06)	
Axial fan belt adjustment	Force	kgf (lbf)		5.0 (11.0)	

				SKANDIC	C. A. C.		
	MODEL		WT	SWT	SUV		
			10.10	550F	and and a second		
LUBRICATION SYSTEM			2 Contraction		1		
Injection oil	Туре		XP-S mineral injection oil				
	Quantity L (U	I.S. oz)		2.5 (84.5)			
FUEL SYSTEM		-					
Carburetor type				2 x VM34 with choke			
Main jet			-	190			
Needle jet				159			
Pilot jet				40			
Jet needle identification and	I clip position			6DH4 - 2			
Slide cut-away			25				
Idle throttle slide height			1.6 ± 0.1 (.063 ± .004)				
Float adjustment		m (in)	23.90 ± 1 (.941 ± 040)				
Air or pilot screw adjustmen				1/2			
Idle speed ± 200 RPM Gas type				1700 Unleaded			
ump octane number	Inside North America ((R+M)/2)		87 or higher				
and the second second	Outside North America (R		92 or higher				
uel tank capacity	L (U.S.	gal)	42 (11.1)				
as/oil ratio				Injection			
LECTRICAL SYSTEM		-	100				
lagneto generator output			340 W @ 6000 RPM				
nition type			CDI by Denso				
bark plug	Make and type		NGK. BR9ES				
here prog	Gap mm	n (in)	0.40 to 0.60 (.016 to .024)				
nition timing BTDC	mm	n (in)		2.77 (.109) @ 3500 RPM			
gger coil		Ω	1 and a second	160 to 180	As the cost		
	Low speed	Ω		6.3			
nerating coil	High speed	Ω		7.7			
hting coil		Ω		0.145 to 0.175	PROVIDE AND AND A		
	Primary			-	Le Caller		
tension coil	Secondary		1	-			
Itery	1001900			12 V, 18 A•h			
adlamp		W		60/55 (H4)			
light and stoplight		W		8/27			
a	Starter solenoid	A		30			

102	100	SKANDIC				
M	DDEL	12.14	WT SWT SUV			
RIVE SYSTEM		-	550F			
and the second s		-		18425.5	1992 14.4	
Searbox oil	Type		XP-S sy	nthetic chaincase pi	1	
Charles and the	Quantity mL (US)	וא	manel	500 (17)	138 1. V.C.	
Gear ratio	2nd	-		1:293		
	R			1:204		
Drive pulley type	<u>I^</u>	-		1:357		
Charles and a second	Clutch	-		Bombardier Lite		
	engagement ± 100 F	IPM	2500			
	Spring color	1 3	Yellow/Green			
Drive pulley calibration	Spring free min	(in)	94 61 ± 15 (3 725 ± 060)			
Store -	Weight 417 120 400 = 21 g 417 114 400 = 3 4 g		1	x 21 g + 4 x 34 g		
	Block	-		3 x 417 118 100	Carl Contract	
	Сар			1 x 417 126 696	22.6.85	
The second second	Type	1	155 5 6 1455	IBC 5100	200	
	Spring color		Orange/Blue/Blue			
Driven pulley	Spring pretoad	lig (1b)	7 5 (16 5)			
a set of spin of the	Cam angle	201	40%	35°	35°/30	
Pulley distance	Z	nm (in)	41	8 ± 0 75 (1.647 ± 0	(30)	
Offset	X	nm (in)	3	5 ± 0 75 (1 380 ± .00	30)	
Unset	Y·X	mm (in)	0	75 to 1.5 (030 to .0	60)	
Drive belt part number	12 1 2 2 2 2	P/N		414 633 800		
Drive belt	Width	mm (in)		34.60 (1.362)	St. 1.	
Drive Delt	Wearlimit	mm (in)	Sat Vel	32 30 (1 272)	Charles .	
Drive belt adjustment	Deflection	mm (in)	1 1 1 2 2 L	32 ± 5 (1.260 ± .19	71	
Cine ben bajostinent	Force	kgi (ibn	1222	11.34 (25)		
Constant Cast of	Width	mm (in)	500 (20)	600 (24)	500 (2	
Track	Length	m (in)		3 968 (156)		
	Profile height	mm (in)	1997	235 (925)	1048	
Track adjustment	Deflection	mm (in)	Contraction of the second	30 to 35 (1.18) to 1. 7.3 (16)	310]	
State State State	Force	101 (161)		1.3 (10)		

				SKANDIC		
	MODEL		WT	SKANDIC	SUV	
	MODEL		WI	550F	-	
BRAKE SYSTEM						
Brake lining thickness	Service limit	mm (in)		1 (.039)		
	Туре			DOT 4		
Brake fluid	Quantity	mL (U.S. oz)		60 (2.0)		
SUSPENSION	Res Chicken		The second second	and the second	Carlo Carlos	
FRONT	A CONTRACTOR OF THE		1	Mar State State	and the second second	
Suspension type	and the second se			LTS	and the second	
Suspension maximum travel		mm (in)	151 (5.95)			
Shock absorber type			Hydraulic			
Sway bar type	The second second					
REAR		1000	and the second	AND DECK		
Suspension type	Mary Carton			WLS	SUV	
Suspension maximum travel	Seato Seato	mm (in)	210 (8.23)		290 (11.42)	
shock absorber type		Center			Gas	
		Rear		Gas	HPG	
Stroke limiter standard position	and the street of		man man			
STEERING SYSTEM	and a share and the	page and a	and have shared		All Carlo Carlos	
Ski type				ADJ		
Toe-out		mm (in)		5 (197)		
Camber		~~~~~	and the second second	0°		
VEHICLE INFORMATIONS		and the second	The state of the		with the series	
Mass (dry)		kg (lb)	266 (586.4)	286 (630.5)	277 (610.7)	
ength	and the second	m (in)	3.05 (120)	3.02 (119)	3.05 (120)	
Vidth	and the second second	(in) m	and the second second	1.08 (42.5)		
leight	and the second second	m (in)	1.3 (51)			
ki stance (carbide to carbide)		mm (in)	and the second second	900 (35.4)		
MATERIAL	and a set of the set		and and the		and a star	
rame				Steel		
lottom pan			Polypropylene			
lood	April 1 and 1 and 1	and the second	- marking	RRIM		

			Sul	osection 02	(600 MODELS
600 MOD	ELS				
MO) EI			SKANDIC	
mor	nu -	-	WT	600	SUV
ENGINE	Rest Street	20.07		000	Contraction of the
Engine type			12.12. 4.21	593	
Number of cylinder				2	
Bore		mm (in)		76 (2.992)	
Stroke		mm (in)		65.8 (2.591)	
Displacement		cm3 (in2)		597 (36.43)	
Compression ratio				12.00 ± 0.5	
Maximum power engine speed		± 100 RPM		7000	
Combustion chamber volume	las	20	25.49 to 27.96		
	Color			Orange/Blue/Blue	se
RAVE spring	Wire diameter Minimum free	mm (in)		0.90 (0.035)	
	Minimum free length	mm (in)	1919-1919-19-19-19-19-19-19-19-19-19-19-	48.50 (1.909)	
Piston ring type	A NOT	1=		Semi-trapezoid	al
i loton mig tipe	-	2nd		-	
Ring end gap	New	mm (in)	0.40 to 0.55 (.0157 to .0217)		
	Wear limit	mm (in)			
Ring/piston groove clearance	New	mm (in) 0.040 to 0.090 (.0016 to .0035)			
	Wear limit	mm (in)		0.20 (.0079)	
Piston/cylinder wall clearance	New	mm (in)	0.1	20 ± 0.02 (.0047	± .0008)
Thatany cynniadr fran cloarance	Wear limit	mm (in)		0.20 (.0079)	
Piston skirt wear	Wear limit	mm (in)		0.15 (.006)	
Cylinder head warpage	Wear limit	mm (in)		0.5 (.02)	
Cylinder taper	New (max.)	mm (in)		0.05 (.0020)	
Cynnider (aper	Wear limit	mm (in)		0.1 (.0039)	
Cylinder out of round	New (max.)	mm (in)		0.010 (.0004	1
Cynnael dur or round	Wear limit	mm (in)		0.08 (.0031)	
Maximum crankshaft end play	New (max.)	mm (in)		0.3 (.012)	
Maximum crankshaft deflection	Wear limit	mm (in)		PTO: 0.06 (.00 Center: 0.08 (.) MAG: 0.05 (.00	0031)
	New	mm (in)	0.3	10 to 0.677 (.012	to .027)
Connecting rod big end axial play	Wear limit	mm (in)	1. 1. 1. 1. 1. 1.	1.2 (.0472)	
Crankshaft end-play	New	mm (in)	0.	10 to 0.30 (.004	
COOLING SYSTEM	-		Participan for the second	14/1-1-1-12	200 200 200
Coolant	Туре		coolant from BRP		%/ 50%). Use prem 2) or coolant specifical um engines
	Quantity	L (U.S. gal.)	4.9 (1.29)		5.17 (1.37)
hermostat opening temperature		°C (°F)		42 (108)	
adiator cap opening pressure		kPa (PSI)		90 (13)	

			_		SKANDIC	SUV		
Maket Ing Street	MODEL		-	WT	600	304		
LUBRICATION SYSTEM		No. Colores						
Injection oil	Ty	pe		XP-S mineral injection oil				
injection on	Qu	antity L (U	.S. oz)	3.5 (118)				
FUEL SYSTEM			12 12					
Carburetor type	New Contraction			2	x VM38 with choke			
Main jet		1212.010 Lan		Sherry and a	330			
Needle jet				All and a second	P.9			
Pilot jet					40			
Jet needle identification	Call Call	Carlo and a second			6DFHL24			
Clip position number					3			
Slide cut-away					2.5			
dle throttle slide height				1.5 ± 0.1 (.059 ± .004)				
Roat adjustment		mm	(in)	18.1 ± 1 (710 ± .039)				
Air or pilot screw adjustment		± 1/16 t	tum	2				
dle speed		± 200 R		and the second second	1700			
Sas type					Unleaded			
ump octane number	Inside North America ((R+M)/2)				87 or higher			
anp octario namboi	Outsid	le North America (ROI	N)	5	2 or higher			
uel tank capacity	2	L (U.S. g		a farmer and	42 (11.1)			
as/oil ratio				Injection				
LECTRICAL SYSTEM		and the second of the	12000	the second days	State State State	State State		
lagneto generator output		1	N	290	@ 6000 RPM			
nition type	and and		100. J.C	C.D	I. by Denso			
	Make a	ind type		N	GK BR9ECS			
lark plug	Gap	mm (in)	0.85 (.033)				
nition timing BTDC		mm (in)	3.0 (118) @ 3500 RPM				
gger coil		Ω	2	15	10 to 300			
hting coil	201 19 1 16 2 - 21	Ω		0	1 to 0.4			
h tension coil	Primary	Ω		0.	3 to 0.7			
In tension coll	Seconda	ry KΩ		18 to 2	6 (with caps)	13 43 M 24 2		
tery	Real Property and the			12 V, 18 A•h	with electric starter)			
idlamp	The state of	W		60	/55 (H4)			
light and stoplight	101.55	W	Section 1	334534.7	8/27			
	Starter s	olenoid A		30 (if	applicable)			

		A CONTRACTOR OF THE OWNER	SKANDIC
MODEL		WT	SUV
			600
SUSPENSION			
FRONT		1.	SUV
Suspension type		LTS	185 (7.3)
Suspension maximum travel	mm (in)	151 (6)	
Shock absorber type			Hydraulic
REAR			SIN
Suspension type		WLS	SUV
Suspension maximum travel	mm (in)	210 (8.3)	290 (11.4)
Shock absorber type	Center		-
	Rear	and an and the second	HPG
Stroke limiter standard position			-
STEERING SYSTEM	and the second second	and the second s	and the second
iki type	- my second region for	and the second s	ADJ
oe-out	mm (in)	5	(.197)
amber			0°
EHICLE INFORMATIONS	adarda harris	and the second	and the second
lass (dry)	kg (lb)	275 (606)	291 (641.5)
ength	m (in)		5 (120)
lidth	m (in)		8 (42 5)
eight	m (in)		10 (51)
i stance (carbide to carbide)	mm (in)	900 (35.4)	985 (38.8)
ATERIAL	No. State of the	and the second	
ime	Same and the second second	S	teel
ttom pan and side panels	a start and the second	Н	PPE
bd	Barn - San and and	R	RIM
		strang and and and	

600 HO S	DI MO	DELS		
	(A.).		EXPEDITION	
M	ODEL		τυν	
ENGINE	The section of the		600 HO SDI	
Engine type			593 HO SDI	
Number of cylinder			2	
Bore		mm (in)	72 (2.835)	
Stroke		mm (in)	73 (2.874)	
Displacement		cm ³ (in ³)	594.40 (36.273)	
Compression ratio			6.4	
Maximum power engine speed	1	± 100 RPM	8000	
Combustion chamber volume		20	26.40 to 28.40	
RAVE spring	Color		Black	
	Wire diameter	mm (in)	0.80 (0.031)	
	Minimum free length	mm (in)	42.5 (1.673)	
Piston ring type		1st	Semi-trapezoidal	
	New	2nd mm (in)	0.40 to 0.55 (.016 to .022)	
Ring end gap	Wear limit	mm (in)	1.0 (.039)	
Ring/piston groove clearance	New	mm (in)	0.05 to 0.1 (.0020 to .0039)	
	Wear limit mm (in)		0.2 (0079)	
	New mm (in)		0.105 ± 0.013 (.0041 ± .0005)	
Piston/cylinder wall clearance	Wear limit mm (in)		0.18 (.0071)	
Piston skirt wear	Wear limit	mm (in)	0.15 (.006)	
Cylinder head warpage	Wear limit	mm (in)	0.5 (.02)	
Cylinder taper	New (max.)	mm (in)	0.05 (.0020)	
	Wear limit	mm (in)	0.1 (0039)	
	New (max.)	mm (in)	0.012 (.0005)	
Cylinder out of round	Wear limit	mm (in)	0.08 (.0031)	
Maximum crankshaft end play	New (max.)	mm (in)	0.3 (.012)	
Maximum crankshaft deflection	Wear limit	mm (in)	PTO: 0.06 (.0024) Center: 0.08 (.0031) MAG: 0.05 (.0020)	
	New	mm (in)	0.310 to 0.677 (.012 to .027)	
connecting rod big end axial play	Wear limit	mm (in)	1.2 (.0472)	
rankshaft end-play	New	mm (in)	0.10 to 0.30 (.004 to .012)	

		EXPEDITION
N	NODEL	TUV
		600 HO SDI
COOLING SYSTEM		
Coolant	Туре	Ethyl glycol and distilled water (50%/ 50%). Use premix coolant from BRP (P/N 219 700 362) or coolant specifically formulated for aluminum engines
	Quantity L (U.S. gal.	4.5 (1.2)
Thermostat opening temperature	°C (°F	42 (108)
Radiator cap opening pressure	kPa (PSI)	90 (13)
LUBRICATION SYSTEM		
Inighting all	Туре	XP-S 2-stroke synthetic blend
Injection oil	Quantity L (U.S. oz)	2.5 (84.5)
FUEL SYSTEM	Long the second second second	
Throttle body type		Dell'Orto
Idle speed	± 200 RPM	1700
Gas type	State of the second second	Unleaded
Pump octane number	Inside North America ((R+M)/2)	87 or higher
	Outside North America (RON)	92 or higher
Fuel tank capacity	L (U.S. gal)	42 (11.1)
Gas/oil ratio		Injection
ELECTRICAL SYSTEM		
Magneto generator output	W	480 @ 6000 RPM
gnition type		Inductive by BOSH
Spark plug	Make and type	NGK BR8ECS
Brown Brown Brown	Gap mm (in)	0.85 (.033)
gnition timing BTDC	mm (in)	5.39 (.2122) @ 3500 RPM
ingger coil	Ω	190 to 290
ighting coil	Ω	0.175 to 0.180
lattery		12 V. 18 A•h
leadlamp	W	60/55 (H4)
aillight and stoplight	W	8/27
use	Starter solenoid A	5
	Starting system A	30

Section 14 TECHNICAL SPECIFICATIONS

	MODEL	EXPEDITION	
	IN COLL	TUV	
DRIVE SYSTEM		600 HO SDI	
Gearbox oil	Туре		
	Quantity mL (U.S. oz)	XP-S synthetic chaincase oil	
	1#	500 (17)	
Gear ratio	2nd	1 2.82	
	R	1 1.70	
Drive pulley type	- Marine	TRA III	
	Clutch engagement ± 100 RPM	3000	
	Spring color	Blue/Yellow/Green	
Drive pulley calibration	Spring length mm (in)	115 (4.53)	
	Pin	Solid (P/N 417 004 308)	
	Ramp	410	
	Screw position	5	
Driven pulley type	Туре	IBC VSA 6000	
	Spring preload kg (Ib)	8 to 9	
	Cam angle	35°/30°	
Pulley distance	2 mm (in)	67 ± 0.75 (2.638 ± .030)	
Offset	X mm (in)	37.0 ± 0.5 (1.457 ± 0.020)	
Onser	Y-X mm (in)	0.75 to 1.5 (030 to 060)	
Drive belt part number	P/N	605 348 425	
Drive half	Width mm (in)	37.3 (1.469)	
Drive belt	Wear limit mm (in)	34.9 (1 374)	
Drive belt adjustment	Deflection mm (in)	32 ± 5 (1.260 ± .197)	
	Force kgf (lbf)	11.30 (24.91)	
	Width mm (in)	500 (20)	
Track	Length m (in)	3.968 (156)	
	Profile height mm (in)	31.8 (1.25)	
A REAL PROPERTY AND INC.	Deflection mm (in)	40 to 50 (1.575 to 1.969)	
Track adjustment	Force kgf (lbf)	7.3 (16)	
BRAKE SYSTEM			
Brake lining thickness	mm (in)	1 (.039)	
and another a	Тура	DOT 4	
Irake fluid	Quantity mL (U.S. oz)	500 (17)	

MODEL TUV 600 H0 SDI 600 H0 SDI FRONT Suspension hype Suspension maximum travel mm (in) 200 (7.9) Shock absorber hype H.PG. REAR Suspension maximum travel mm (in) 200 (1.4) Suspension maximum travel mm (in) 290 (11.4) Shock absorber hype Center H.PG. Stock absorber hype A.D.J Center G.D.J Servet M.D.J Center G.P. Stricks limiter standard position — G.P. G.P. Street limiter standard position — G.P. G.P. Street limiter standard position — G.P. G.P. G.P.	
SUSPENSION FRONT Suspension maximum travel Suspension maximum travel mm (in) 200 (7.9) Shock absorber type REAR Suspension maximum travel Suspension maximum travel mm (in) Suspension maximum travel mm (in) Suspension maximum travel mm (in) Stock absorber type Center H.PG. Rear H.PG. Rear H.PG. Rear H.PG. Rear H.PG. Stroke limiter standard position — TEEERING SYSTEM bit type exout mber 0° EHICLE INFORMATIONS ass (dry) kg (lb) 320 (705.5)	
FRONT Suspension type SUV Suspension maximum travel mm (in) 200 (7.9) Shock absorber type H.P.G. Suspension maximum travel mm (in) 290 (11.4) Suspension type SUV Suspension type SUV Suspension type Center H.P.G. Rear Shock absorber type Center H.P.G. Rear Stroke limiter standard position	
Suspension type SUV Suspension maximum travel mm (in) 200 (7.9) Shock absorber type H.PG. REAR SUV Suspension type SUV Suspension type SUV Suspension type SUV Suspension maximum travel mm (in) 290 (11.4) Shock absorber type Center H.PG. Stock absorber type Rear H.PG. Stock absorber type Rear H.PG. Ttroke limiter standard position TEEEING SYSTEM ADJ e-out mm (in) 5 (137) mber 0° HICLE INFORMATIONS sas (dry) kg (lb) 320 (705.5)	
construction region 200 (7.9) Shock absorber type M.PG. REAR SUV Suspension maximum travel mm (in) Suspension maximum travel MIC Suspension maximum travel mm (in) Suspension maximum travel MPG. Travel imiter standard position	
Shock absorber type H.P.6. REAR SUvenision type Suspension maximum travel mm (m) 290 (11.4) Subsension maximum travel mm (m) 290 (11.4) shock absorber type Center H.P.6. Shock absorber type Center H.P.6. Totke limiter standard position TEENING SYSTEM of type ADJ e-out mm (m) 5 (197) mber 0° HICLE INFORMATIONS std(ry) kg (tb) 320 (705.5)	
REAR Suspension type Suspension type Suspension maximum travel mm (in) Suspension maximum travel mm (in) Suspension maximum travel mm (in) Suspension TEERING SYSTEM Supple ADJ e-out supple ADJ e-out supple ADJ e-out supple ADJ supp	
Suspension type SUV Suspension maximum travel mm (in) 290 (11.4) Shock absorber type Center H.P.G. Stroke limiter standard position TEERING SYSTEM at type ADJ eout mm (in) 5 (197) mber 0° HICLE INFORMATIONS 320 (705.5)	
Suspension maximum travel mm (in) 290 (11.4) Shock absorber type Center H.P.G. Shock absorber type Rear H.P.G. Troke limiter standard position TEEEING SYSTEM di type ADJ e-out mm (in) 5 (197) mber 0° HICLE INFORMATIONS ss (dry) kg (tb)	
Center H.PG. Rear H.PG. troke limiter standard position TEERING SYSTEM ai bype ADJ e-out mm (in) 5 (197) mber 0° HICLE INFORMATIONS ss (dry) kg (lb) 320 (705.5)	
Above Rear H PG. troke limiter standard position TEERING SYSTEM at type ADJ e-out mm (in) b (197) 0° HICLE INFORMATIONS 320 (705.5)	
Rear H PG. troke limiter standard position — TEERING SYSTEM — a type ADJ e-out mm (in) 5 (197) mber mber 0° HICLE INFORMATIONS ass (dry) kg (b) 320 (705.5)	
TEERING SYSTEM id type ADJ e-out mm (in) 5 (197) mber 0° HICLE INFORMATIONS sss (dry) kg (lb) 320 (705.5)	
a type ADJ e-out mm (in) 5 (.197) mber 0° HICLE INFORMATIONS ass (dry) kg (b) 320 (705.5)	
e-out mm (in) 5 (.197) mber 0° HICLE INFORMATIONS ass (dry) kg (b) 320 (705.5)	and the second
mber 0° HICLE INFORMATIONS ass (dry) kg (b) 320 (705.5)	
HICLE INFORMATIONS sss (dry) kg (lb) 320 (705.5)	a management and
iss (dry) kg (lb) 320 (705.5)	
ngth m (in) 3.06 (120.5)	
tth m (in) 1.17 (46)	
ght m (in) 1.31 (52)	
stance (carbide to carbide) mm (in) 985 (38.8)	
TERIAL	
le Steel	an and a summer
om pan and side panels HDPE	
RRIM	
om pan and side panels HDPE	

V800	MO	DELS				
	MODEL		SKANDIC	EXPEDITION		
			V800			
ENGINE		and the second s		in the second second		
Engine type				ROT	AX V810	
				4-stroke, Single Over Head	Camshaft (SOHC), liquid cool	
Number of cylinders					2	
Number of valves Bore				the second s	hanical adjustment)	
Stroke			(in) mm (in)		1 (3.58) 5 (2.42)	
Displacement			mm (in)		5 (2.42) P ³ (48.82 in ³)	
Compression ratio					10.3:1	
Decompressor type	-				-	
Maximum HP RPM	-		RPM		7250	
Intake valve opening	11	1. 1. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		15	* BTDC	
Intake valve closing	in the second	20.5		45	* ABDC	
Exhaust valve openin	g	10000		50	° 880C	
Exhaust valve closing		Self- Self-		10	° ATDC	
Valve clearance	Intake	a free	mm (in)	0.04 to 0.10	(.0016 to .0039)	
	Exhaust	14.	mm (in)	0.04 to 0.15	5 (.0016 to .0059)	
Valve stem diameter	Intake	New	mm (in)	4.966 to 4.98	30 (.1955 to .1960)	
		Service limit	mm (in)	4.93	10 (.1941)	
	Exhaust	New	mm (in)	4.956 to 4.97	70 (.1951 to .1957)	
		Service limit	mm (in)		0 (.1941)	
Valve guide diameter		New	mm (in)	5.006 to 5.018 (.1971 to .1976)		
		Service limit	mm (in)		5.050 (.1988)	
Valve spring free lengt	Valve spring free length		mm (in)	40.81 (1.607)		
opring noo lengt		Service limit	mm (in)		39.00 (1.535)	
	Intake	New	mm (in)		5 (.041 to (.053)	
Valve seat contact		Service limit	mm (in)		B (.070)	
width	Exhaust	New	mm (in)	and the second se	1.25 to 1.55 (.049 to .061)	
		Service limit	mm (in)		(.078)	
Rocker arm bore diamet	er	New	mm (in)		50 (4739 to .4744)	
	7	Service limit	mm (in)		50 (.4748)	
Rocker arm shaft diame	er	New	mm (in)		18 (.4724 to .4731)	
	(Dise)	Service limit	mm (in)		11 990 (.4720)	
Piston measurement	CALCUS	New	mm (in)		90.950 to 90.966 (3.5807 to 3.5813)	
Piston/cylinder clearance	184.02	New	mm (in)		0.027 to 0.057 (.0011 to .0023)	
iston/cylinder clearance		Service limit	mm (in)	0.100 (.0040)		


				SKANDIC		EXPEDITION	
1 million mark	MOI	DEL	121.021	SWT	V800	TUV	
ENGINE (cont'd)	ALCON DO			Concernance of the	¥300		
	1.	14		Upper compr	ession ring,	rectangular	
Piston ring type		2nd		Lower compre		And and a second se	
		34		Oil	scraper ring	1	
-	Rectangula	r		0.20 to 0.40 (.008 to .016)			
	Taper-face	New	mm (in)	0.20 to 0.40 (.008 to .016)			
Ring end gap	Oil scraper			0.20 to 0.70 (.008 to .028)			
	ring	Service limit		1.5 (059)			
	All	New	mm (in)	0.03 to 0.070 (0012 to 0028)			
	Rectangular	Service limit	mm (in)	and the second se		0020)	
Day In June 1	-	New	mm (in) mm (in)	0.15 (0059)			
Ring/piston groove clearance	Taper-face	Service limit	mm (in)	0.02 to 0.060 (.0008 to .0024) 0.15 (.0059)			
	Oil scraper	New	mm (in)		80 (.0004 to	00711	
	ring	Service limit	mm (in)		250 (.0098)		
Cylinder bore		New	mm (in)	90.993 to 91.0		to 3 5829)	
	1.5.9.14.1	Maximum New	mm (in)		38 (0015)		
Cylinder taper		Service limit	mm (in)		190 (0035)		
		Maximum New	mm (in)	0.0	15 (0006)		
Cylinder out of round		Service limit	mm (in)		20 (0008)		
	Timing chain	New	mm (in)	34.959 to 34.9		to 1.3770)	
Camshaft main bearing	side	Service limit	mm (in)		150 (1.3760)		
ournal	Spark plug	New	mm (in)	21.959 to 21.980 (.8645 to .8654)			
	side	Service limit	mm (in)	21.	950 (.8642)		
	Timing chain	New	mm (in)	35.000 to 35.0	25 (1.3780	to 1.3789)	
amshaft main bearing	side	Service limit	mm (in)	35.0	40 (1.3795)		
ournal bore	Spark plug	New	mm (in)	22.000 to 22	021 (.8661 1	to .8670)	
	side	Wear limit	mm (in)	22	040 (.8677)		
	Intake valve	New	mm (in)	32.11 to 32.3	11 (1.2642 to	1.2721)	
amshaft lobe	KILOKE VOIVE	Service limit	(in) mm	32	09 (1.2634)		
BIIISINGIT TODE		New	mm (in)	31.94 to 32.1	14 (1.2575 to	0 1 2654	
	valve	Service limit	mm (in)	31.1	32 (1.2567)		
ankshaft main journal	diameter	New	mm (in)	42.024 to 42.0	40 (1.6545 1	to 1.6551)	
AG/PTO side		Service limit	mm (in)	42.00	10 (1.6535 in	1	
ankshaft radial play M	AG/PTO side	Service limit	mm (in)	0.1	07 (.0031)		
ankshaft main journal o	diameter PTO	New	mm (in)	34.000 to 34.0	16 (1.3386 1	to 1.3392)	
pport bearing		Service limit	mm (in)	33.9	80 (1.3378)		
ankshaft radial play P1 aring	0 support	Service limit	mm (in)	0.	(0039)		


	MODEL	10.0		SKANDIC		EXPEDITION	
	a state	1	F	2001	V800	TUV	-
ENGINE (cont'd)	-	3000	STANK!	C. C	1000	No. of Concession, Name	1000
Crankshaft pin diameter		New	mm (in)	40.009 to 40	025 (1.5	5752 to 1.5758)	
		Service limit	mm (in)	39.990 (1.5744)			
	MAG/PTO	New	mm (in)		0.050 (.0	02)	
Crankcase plain bearing	A contract of the local data was to be a second data was a second data was a second data was a second data was	Service limit	mm (in)	42	2.070 (1.	6563)	
PTO cover plain bearing		Service limit	mm (in)		.080 (1		
Connecting rod big end		Service limit	mm (in)	40.100 (1.579)			
Connecting rod big end	radial play	Service limit	mm (in)	0.09 (.0035)		_	
Connecting rod big end axial p		New mm (in)		0.200 to 0.500 (.008 to .020)		-	
		Service limit New	mm (in) mm (in)		0.600 (.0		
Connecting rod small end diameter		Service limit	mm (in) mm (in)	20.010 to 20.020 (7878 to .7882) 20.060 (.7898)		-	
		New	mm (in) mm (in)	and the second		7898) 7872 to .7874)	-
Piston pin diameter		Service limit	mm (in)	the second s	9.980 (and the second se	
Connecting rod small en	nd radial play		mm (in)		0.080 (.0		
COOLING SYSTEM			and the second second				
Coolant	115 Conc. 115	Туре		Ethyl glycol and distilled water (50%/ 50%). Use premix coolant from BRP (P/N 219 700 362) or coolant specifically formulated for aluminum engines		ix İy	
		Quantity	L (U.S. gal.)	4.00 (1.06)		4.5 (1.2)	
Thermostat opening te	mperature		°C (°F)		45 (11	3)	
Radiator cap opening p		ant stores	kPa (PSI)	AND DESCRIPTION OF	110 (1		
LUBRICATION SYST		Section States	San Dan Barr	State State	10-0	and service and an inter	
	Туре			Wet sump	Replan	ceable oil filter	
	Oil filter	and the second		BRP Rotax paper type, replaceable		_	
Lubrication	Engine oil pressure	Capacity (oil change with		550 kPa (80 PSI) at 7000 RPM		_	
-	Engine oil			2.3 L (2.4 quarts) XP-S 0W40 synthetic oil or an equivalent		_	
FUEL SYSTEM	Contraction of	Recommended		XI-3 01140 3	Indiana Contra		Charles .
Throttle body type		10.7 C 17			VDC	Lor - Alter - Alter	
Idle speed		Estimate	± 200 RPM	1400			
Gas type	101800	STATISTICS.		Unleaded			
Pump octane number		Inside North America ((R+M)/Z)		87 or higher		_	
	1000	Outside North A		92 or higher		-	
	Store weeks		L (U.S. gal)	and the second	41 (10	.8)	


			SKANDIC	EXPEDITION	
- Company	MODEL		SWT		
ELECTRICAL SYSTEM		Concession in the			
Magneto generator output	Contraction of the	W	460 @ 60	00 RPM	
Ignition type	at a fill of the fill		CDI (Capacity Discharg	e Ignition) by DENSO	
Spark plug	Make and ty	pe	NGK DO	PR8E	
	Gap	mm (in)	0.75 (.0	and the second se	
Ignition timing	and such			and the second se	
Crankshaft position sensor (CPS)	Ω		A series where the series were as a series where the seri	
		Vac			
Battery					
Headlamp		W			
Taillight and stoplight	W				
Fuse	Starter solence				
DRIVE SYSTEM	Starting syste	m A	30		
UNITESTOTEM	Type		VD C contratio o	haincasa oil	
Gearbox oil	Quantity	mL (U.S. oz)		the second s	
	1st	mL (U.S. 02)		the second se	
Sear ratio	Znd				
jear rauu	B				
Drive pulley type					
	Clutch engagement	± 100 RPM		The second s	
	Spring color		Red/Re	d	
rive pulley calibration	Spring length	mm (in)	97 (3.8	2)	
	Pin		Hollow (P/N 41)	222 594)	
	Ramp		614		
	Screw position	and marked and a	Not adjustable 700 to \$00 @ 20°C (68°F) 2.3 @ 20°C (68°F) 12 V. 18 A ● h 60/55 (H4) 8/27 5 30 XP-S synthetic chancase oil 500 (17) 1: 2 82 1: 2 04 1: 3 44 TRA IV 2500 Rad/Red 97 (3 82) Hollow (P/N 417 222 594) 614 3 1BC VSA 6000		
and the second second	Туре	Contraction of the	IBC VSA E	000	
iven pulley type	Spring preload kg (lb)		7.5 to 9.0		
	Cam angle		40°/30°		
	Z	mm (in)	67 ± 0.75 (2.63	8 ± .030)	
Iley distance Offset	X	mm (in)	37.0 ± 0.75 (1.45	7 ± 0.030)	
	Y-Z	mm (in)	0.75 to 2.25 (.03	0 to .090)	
ive belt part number		P/N	605 348 4		
ve belt	Width	mm (in)	37.3 (1.48	(9)	
VE DER	Wear limit	mm (in)	35.5 (1.39		
ve beit adjustment	Deflection	mm (in)	32 ± 5 (1.260		
AG DEIT BOJOSTINEIL	Force	kgf (lbf)	11.30 (24.)	91)	


	MODEL	-	SWT	TUV
DRIVE SYSTEM (con'd)	1		VI	800
	Width	mm (in)	600 (24)	500 (20)
Track	Length	m (in)		3 (156)
C Star Grant Star	Profile height	mm (in)		(1.25)
Track adjustment	tment Deflection mm (in)		40 to 50 (1.575 to 1.969)	
	Force	kgf (lbf)	7.3	3 (16)
BRAKE SYSTEM	12 16 25 272 161			
Brake lining thickness		mm (in)		(.039)
Brake fluid	Type	1010		OT 4
CHERT HOUSE	Quantity	mL (U.S. oz)	50	0 (17)
SUSPENSION FRONT	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1			
Suspension type			LTS	SUV
Suspension maximum travel		mm (in)	150 (6)	200 (8)
Shock absorber type		1000 10-9		on control
REAR			and a start of the	
Suspension type			WLS	SUV
Suspension maximum travel		mm (in)	210 (8.3)	293 (11.5)
		Center	Mot	tion control
Shock absorber type		Rear	A Thick Man	H.P.G
Stroke limiter standard posi	tion			-
STEERING SYSTEM	C. C. Carrowski			
Ski type				ADJ
Toe-out		mm (in)		5 (.197) 0°
Camber				U
VEHICLE INFORMATIONS	i la companya da companya d	1	and the second	220 (20E E)
Mass (dry)		kg (lb)	320 (705.5) 3.09 (121.7)	
Length		m (in)	1.08 (42.5)	1.22 (4
Width		m (in)		1.36 (53.5)
Height		m (in)		985 (38.8)
Ski stance (carbide to carbin	de)	m (in)		000 (00 0)
MATERIAL				Steel
Frame				HDPE
Bottom pan				RRIM
Hood				


	higher trans	and an and an an
ELECTRICAL CO	NNECTORS	
SERVICE TOOLS	Fail Hundrar	Contract Page
Description	Part Number	Page
connector crimping tool	529 035 909	716
crimp pliers	529 035 730	
crimper die		
APRILIE THEN APPEND		
SERVICE TOOLS - OTHER	SUPPLIER	Constant Proverty
Description	Part Number	Page
Snap-on screwdriver		
Snap-on screwdriver	TT600-5	
tool AMP	755430-2	712-713
SERVICE PRODUCTS		ever word and
SERVICE PRODUCTS		
Description	Part Number	Pag
dielectric grease	293 550 004	





















Section 15 ELECTRICAL CONNECTORS AND WIRING DIAGRAMS Subsection 01 (ELECTRICAL CONNECTORS)



The locking tab on the connector may have to be bent out a little so it will lock in the housing when it's re-inserted.



If the wire is in good condition but the terminal is rusted or corroded, remove defective terminal and crimp a new one. If wire and terminal are defec-tive, acquire a new genuine wire and new terminal and crimp them together as explained below. IMPORTANT: Use genuine wires only. Otherwise wires will not fit properly. When re-inserting the connector, the locking tab must be installed facing the smaller cutout of the connector cavity.



Insert the connector, ensuring the locking tab snaps into the housing. Re-install the lock, attach the 2 tie raps, and close the housing cover.


Terminal Crimping (Kostal and AMP multilock) To crimp a new connector terminal, use the con-nector crimping tool (P/N 529 035 909) and the crimper die (P/N 529 035 906).



CRIMPING TOOL

To properly crimp the wires, strictly follow this pro-cedure. Strip the wire to a maximum of 3 mm (1/8 in).





<text><text><text><section-header><text><text><text><text>

