


Foreword

FOREWORD

This handbook contains information on the Triumph Daytona 675 and Street Triple motorcycles. Always store this owner's handbook with the motorcycle and refer to it for information whenever necessary.



Warnings, Cautions and Notes

Throughout this owner's handbook particularly important information is presented in the following form:

Warning

This warning symbol identifies special instructions or procedures, which if not correctly followed could result in personal injury, or loss of life.

Caution


This caution symbol identifies special instructions or procedures, which, if not strictly observed, could result in damage to, or destruction of, equipment.

NOTE

- **This note symbol indicates points of particular interest for more efficient and convenient operation.**

Foreword

Warning Labels



At certain areas of the motorcycle, the symbol (left) can be seen. The symbol means 'CAUTION: REFER TO THE HANDBOOK' and will be followed by a pictorial representation of the subject concerned.

Never attempt to ride the motorcycle or make any adjustments without reference to the relevant instructions contained in this handbook.

See "Warning Labels" on page 12 for the location of all labels bearing this symbol. Where necessary, this symbol will also appear on the pages containing the relevant information.

Maintenance

To ensure a long, safe and trouble free life for your motorcycle, maintenance should only be carried out by an authorized Triumph dealer. Only an authorized Triumph dealer will have the necessary knowledge, equipment and skills to maintain your Triumph motorcycle correctly.

To locate your nearest Triumph dealer, visit the Triumph web-site at www.triumph.co.uk or telephone Triumph Motorcycles America Limited on (678) 854 2010.

Noise Control System

Tampering with the Noise Control System is prohibited.

Owners are warned that the law may prohibit:

- The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use and,
- the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Owner's Handbook

Thank you for choosing a Triumph motorcycle. This motorcycle is the product of Triumph's use of proven engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Please read this owner's handbook before riding in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations.

This handbook includes safe riding tips, but does not contain all the techniques and skills necessary to ride a motorcycle safely.

Triumph strongly recommends that all riders undertake a safety course approved by the Motorcycle Safety Foundation to ensure safe operation of this motorcycle. Information about the nearest Motorcycle Safety Foundation course to you can be obtained by calling the following nationwide toll free number: 800-447-4700, or by writing to the Motorcycle Safety Foundation at: 2, Jenner Street, Irvine, California 92718.

To ensure a long and trouble free life for your motorcycle, maintenance should be carried out as described in this manual by an authorized Triumph dealer.

Warning

This owner's handbook, and all other instructions that are supplied with your motorcycle, should be considered a permanent part of your motorcycle and should remain with it even if your motorcycle is subsequently sold.

All riders must read this owner's handbook and all other instructions which are supplied with your motorcycle, before riding, in order to become thoroughly familiar with the correct operation of your motorcycle's controls, its features, capabilities and limitations. Do not lend your motorcycle to others as riding when not familiar with your motorcycle's controls, features, capabilities and limitations can lead to an accident.

Foreword

Information

The information contained in this publication is based on the latest information available at the time of printing. Triumph reserves the right to make changes at any time without prior notice, or obligation.

Not to be reproduced wholly or in part without the written permission of Triumph Motorcycles Limited.

© Copyright 2008 Triumph Motorcycles America Limited.

Publication part number 3852806 issue 2.

Table of Contents

This handbook contains a number of different sections. The table of contents below will help you find the beginning of each section where, in the case of the major sections, a further table of contents will help you find the specific subject required.

Foreword	1
Warning Labels	12
Parts Identification	16
Serial Numbers	21
General Information	23
How to Ride the Motorcycle	53
Accessories, Loading and Passengers.	63
Maintenance and Adjustment	67
Storage	121
Specifications	123

FOREWORD - SAFETY FIRST

The Motorcycle

Warning

This motorcycle is designed for on-road use only. It is not suitable for off-road use.
Off-road operation could lead to loss of control of the motorcycle resulting in an accident causing injury or loss of life.

Warning

This motorcycle is not designed to tow a trailer or be fitted with a sidecar. Fitting a sidecar and/or a trailer may result in loss of control and an accident.

Warning

This motorcycle is designed for use as a two-wheeled vehicle capable of carrying a rider on his/her own, or a rider and one passenger (subject to a passenger seat being fitted).
The total weight of the rider, and any passenger, accessories and luggage must not exceed the maximum load limit of 429 lbs (195 kg).

Fuel and Exhaust Fumes

Warning

GASOLINE IS HIGHLY FLAMMABLE:

Always turn off the engine when refuelling.
Do not refuel or open the fuel filler cap while smoking or in the vicinity of any open (naked) flame.
Take care not to spill any gasoline on the engine, exhaust pipes or mufflers when refuelling.
If gasoline is swallowed, inhaled or allowed to get into the eyes, seek immediate medical attention.
Spillage on the skin should be immediately washed off with soap and water and clothing contaminated with gasoline should immediately be removed.
Burns and other serious skin conditions may result from contact with gasoline.

Warning

Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and may cause loss of consciousness and death within a short time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

Foreword - Safety First

Helmet and Clothing

Warning

When riding the motorcycle, both rider and passenger must always wear a motorcycle helmet, eye protection, gloves, trousers (close fitting around the knee and ankle) and a brightly colored jacket. Brightly colored clothing will considerably increase a rider's (or passenger's) visibility to other operators of road vehicles. Although full protection is not possible, wearing correct protective clothing can reduce the risk of injury when riding.

Warning

A helmet is one of the most important pieces of riding gear as it offers protection against head injuries. You and your passenger's helmet should be carefully chosen and should fit you or your passenger's head comfortably and securely. A brightly colored helmet will increase a rider's (or passenger's) visibility to other operators of road vehicles. An open face helmet offers some protection in an accident though a full face helmet will offer more.

/continued

Warning

/continued

Always wear a visor or approved goggles to help vision and to protect your eyes.



When choosing a helmet, always look for a DOT (Department of Transport) sticker indicating that the helmet has DOT approval. Do not buy a helmet without DOT approval.

Foreword - Safety First

Parking

Warning

Always turn off the engine and remove the ignition key before leaving the motorcycle unattended. By removing the key, the risk of use of the motorcycle by unauthorized or untrained persons is reduced.

When parking the motorcycle, always remember the following:
Engage first gear to help prevent the motorcycle from rolling off the stand.

The engine and exhaust system will be hot after riding. DO NOT park where pedestrians, animals and/or children are likely to touch the motorcycle.

Do not park on soft ground or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over.

For further details, please refer to the 'How to Ride the Motorcycle' section of this owner's handbook.

Parts and Accessories

Warning

Owners should be aware that the only approved parts, accessories and conversions for any Triumph motorcycle are those which carry official Triumph approval and are fitted to the motorcycle by an authorized dealer.

In particular, it is extremely hazardous to fit or replace parts or accessories whose fitting requires the dismantling of, or addition to, either the electrical or fuel systems and any such modification could cause a safety hazard.

The fitting of any non-approved parts, accessories or conversions may adversely affect the handling, stability or other aspect of the motorcycle operation that may result in an accident causing injury or death.

Triumph does not accept any liability whatsoever for defects caused by the fitting of non-approved parts, accessories or conversions or the fitting of any approved parts, accessories or conversions by non-approved personnel.

Foreword - Safety First


Maintenance/ Equipment

Warning

Consult your authorized Triumph dealer whenever there is doubt as to the correct or safe operation of this Triumph motorcycle. Remember that continued operation of an incorrectly performing motorcycle may aggravate a fault and may also compromise safety.

Warning

Use of a motorcycle with bank angle indicators worn beyond the maximum limit (when 0.20 in (5 mm) of the bank indicator remains) will allow the motorcycle to be banked to an unsafe angle. Banking to an unsafe angle may cause instability, loss of motorcycle control and an accident.



1 Bank angle indicator

Warning

Ensure all equipment that is required by law is installed and functioning correctly. The removal or alteration of the motorcycle's lights, mufflers, emission or noise control systems can violate the law. Incorrect or improper modification may adversely affect the handling, stability or other aspect of the motorcycle operation, which may result in an accident causing injury or death.

Warning

If the motorcycle is involved in an accident, collision or fall, it must be taken to an authorized Triumph dealer for inspection and repair. Any accident can cause damage to the motorcycle that, if not correctly repaired, may cause a second accident that may result in injury or death.

Foreword - Safety First

Riding

Warning

Never ride the motorcycle when fatigued or under the influence of alcohol or other drugs. Riding when under the influence of alcohol or other drugs is illegal. Riding when fatigued or under the influence of alcohol or other drugs reduces the rider's ability to maintain control of motorcycle and may lead to loss of control and an accident.

Warning

All riders must be licensed to operate the motorcycle. Operation of the motorcycle without a license is illegal and could lead to prosecution. Operation of the motorcycle without formal training in the correct riding techniques that are necessary to become licensed is dangerous and may lead to loss of motorcycle control and an accident.

Warning

Always ride defensively and wear the protective equipment mentioned elsewhere in this foreword. Remember, in an accident, a motorcycle does not give the same impact protection as a car.

Warning

This Triumph motorcycle should be operated within the legal speed limits for the particular road travelled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases. Always reduce speed in potentially hazardous driving conditions such as bad weather or heavy traffic.

Warning

Continually observe and react to changes in road surface, traffic and wind conditions. All two-wheeled vehicles are subject to external forces which may cause an accident. These forces include but are not limited to:

- Wind draft from passing vehicles;
- Potholes, uneven or damaged road surfaces;
- Bad weather;
- Rider error.

Always operate the motorcycle at moderate speed and away from heavy traffic until you have become thoroughly familiar with its handling and operating characteristics. Never exceed the legal speed limit.

Foreword - Safety First

Warning

Ensure that you know and respect the rules of the road. Read and observe publications such as 'MOTORCYCLE SAFETY', 'YOU AND YOUR MOTORCYCLE, RIDING TIPS' and also read and become familiar with the contents of the MOTORCYCLE HANDBOOK for your state.

Caution

This Triumph motorcycle is not fitted with spark arresters. Operation in forests, brush or grass areas may violate state and local laws and regulations.

NOTE

Wobble/Weave

A weave is a relatively slow oscillation of the rear of the motorcycle, while a wobble is a rapid, possibly strong shaking of the handlebar. These are related but distinct stability problems usually caused by excessive weight in the wrong place, or by a mechanical problem such as worn or loose bearings or under-inflated or unevenly worn tires.

Your solution to both situations is the same. Keep a firm hold on the handlebars without locking arms or fighting the steering. Smoothly ease off the throttle to slow gradually. Do not apply the brakes, and do not accelerate to try to stop the wobble or weave. In some cases, it helps to shift your body weight forward by leaning over the tank.

Copyright © 2005 Motorcycle Safety Foundation. All rights reserved. Used with permission.

Foreword - Safety First

Handlebars and Footrests

Warning

The rider must maintain control of the vehicle by keeping hands on the handlebars at all times. The handling and stability of a motorcycle will be adversely affected if the rider removes his hands from the handlebars, resulting in loss of motorcycle control and an accident.

Warning


The rider and passenger must always use the footrests provided, during operation of the vehicle. By using the footrests, both rider and passenger will reduce the risk of inadvertent contact with any motorcycle components and will also reduce the risk of injury from entrapment of clothing.

Warning Labels

WARNING LABELS


The labels detailed on this and the following pages draw your attention to important safety information in this handbook. Before riding, ensure that all riders have understood and complied with all the information to which these labels relate.

Warning Label Locations - Daytona 675




Warning Labels

Warning Label Locations - Daytona 675 (continued)




Warning Labels

Warning Label Locations - Street Triple



Warning Labels


Warning Labels Location - Street Triple (continued)



Parts Identification

PARTS IDENTIFICATION


Daytona 675



- | | |
|---------------------------------|---------------------------|
| 1 Front turn signal | 8 Gearshift pedal |
| 2 Headlight | 9 Front brake disc |
| 3 Brake/tail light | 10 Front brake caliper |
| 4 Radiator/coolant pressure cap | 11 Fuel tank |
| 5 Oil cooler/heat exchanger | 12 Fuel filler cap |
| 6 Drive chain | 13 Seat lock |
| 7 Side stand | 14 Coolant expansion tank |

Parts Identification


Daytona 675 (continued)



- | | |
|-------------------------------|---------------------|
| 15 Battery | 21 Oil filler cap |
| 16 Tool kit | 22 Clutch cable |
| 17 Rear brake disc | 23 Front fork |
| 18 Rear brake caliper | 24 Rear brake pedal |
| 19 Rear brake fluid reservoir | 25 Dipstick |
| 20 Rear suspension unit | 26 Muffler |

Parts Identification


Street Triple



- | | |
|---------------------------------|---------------------------|
| 1 Front turn signal | 8 Gearshift pedal |
| 2 Headlight | 9 Front brake disc |
| 3 Brake/tail light | 10 Front brake caliper |
| 4 Radiator/coolant pressure cap | 11 Fuel tank |
| 5 Oil cooler/heat exchanger | 12 Fuel filler cap |
| 6 Drive chain | 13 Seat lock |
| 7 Side stand | 14 Coolant expansion tank |

Parts Identification


Street Triple (continued)



- | | |
|-------------------------------|---------------------|
| 15 Battery | 21 Oil filler cap |
| 16 Tool kit | 22 Clutch cable |
| 17 Rear brake disc | 23 Front fork |
| 18 Rear brake caliper | 24 Rear brake pedal |
| 19 Rear brake fluid reservoir | 25 Dipstick |
| 20 Rear suspension unit | 26 Muffler |

Parts Identification


Both Models (Daytona 675 shown)



- | | |
|-------------------------------|--------------------------|
| 1 Clutch lever | 8 Front brake lever |
| 2 Passing button | 9 Engine stop switch |
| 3 Headlight dimmer switch | 10 Starter button |
| 4 Horn button | 11 Tachometer |
| 5 Turn signal switch | 12 Speedometer |
| 6 Ignition switch | 13 Warning lights |
| 7 Front brake fluid reservoir | 14 Trip computer display |

SERIAL NUMBERS

Vehicle Identification Number (V.I.N.)




1 V.I.N number
(Daytona 675 shown)

The Vehicle Identification Number (V.I.N) is stamped into the steering head area of the frame. In addition, it is displayed on a label which is also adjacent to the steering head.

Record the vehicle identification number in the space below.

Engine Serial Number



1 Engine serial number
(Daytona 675 shown)

The engine serial number is stamped on the engine crankcase, immediately above the clutch cover.

Record the engine serial number in the space provided below.

Serial Numbers

This page intentionally left blank

GENERAL INFORMATION

Table of Contents

Instrument Panel Layout.....	25
Speedometer and Odometer.....	26
Tachometer.....	26
Odometer/Trip Meter.....	26
Clock/Trip Computer.....	27
Trip Computer Operation.....	28
Clock Adjustment.....	28
Trip Computer Reset.....	29
Lap Timer.....	29
Data Recording Mode.....	30
Data Retrieval Mode.....	31
Gear Shift Lights.....	33
Adjusting Gear Shift light Modes.....	34
Setting Gear Shift Light Limits.....	35
Gear Position Display.....	37
Coolant Temperature Gauge.....	38
Warning Lights.....	39
Turn Signals.....	39
High Beam.....	39
Low Fuel.....	39
Neutral.....	39
Low Oil Pressure Warning Light.....	39
High Coolant Temperature Warning Light.....	39
Engine Management System Malfunction Indicator Light.....	40
Alarm Indicator Light.....	40
Ignition Key.....	41
Ignition Switch/Steering Lock.....	41
Ignition Switch Positions.....	41
Brake Lever Adjuster.....	42
Right Handlebar Switches.....	43
Engine Stop Switch.....	43
Starter Button.....	43


General Information

Left Handlebar Switches	44
Headlight Dimmer Switch	44
Turn Signal Switch	44
Horn Button	44
Pass Button	44
Fuel Requirement/Refuelling	45
Fuel Grade	45
Oxygenated Gasoline	45
Ethanol	45
MTBE (Methyl Tertiary Butyl Ether)	46
Methanol	46
Fuel Tank Cap	47
Filling the Fuel Tank	47
Tool Kit and Handbook	48
Stand	48
Side Stand	48
Seat Lock	49
Seat Care	49
Rider's Seat	49
Rear Seat/Seat Cover	50
Breaking In	50
Safe Operation	51
Daily Safety Checks	51

General Information

Instrument Panel Layout

(Daytona 675 shown)



- | | |
|--|---|
| 1 Tachometer | 10 Engine management malfunction indicator light |
| 2 Tachometer 'red zone' | 11 Low fuel level indicator light |
| 3 Speedometer | 12 Neutral indicator light |
| 4 Odometer/trip meters | 13 High beam indicator light |
| 5 Clock/trip computer display | 14 Turn signal indicator light |
| 6 Scroll/set/trip buttons | 15 Gearshift lights |
| 7 Coolant temperature display | 16 Alarm status indicator light (alarm is an accessory) |
| 8 Low oil pressure warning light | 17 Gear position indicator |
| 9 High coolant temperature warning light | |

General Information

Speedometer and Odometer

The digital speedometer indicates the road speed of the motorcycle. The read-out displays the motorcycle road speed in increments of one mile (or kilometer) per hour.

In the speedometer face is the electronic odometer and two trip meters. For details of the operation of the odometer and trip meters, please refer to the following pages.


Tachometer

The tachometer shows the engine speed in revolutions per minute - rpm (r/min). On the right side of the tachometer face is the 'red zone'. Engine rpm (r/min) in the red zone is above maximum recommended engine speed and is also above the range for best performance.



Caution

Never allow engine RPM to enter the 'red zone' as severe engine damage may result.



- 1 Odometer/trip meter display
- 2 Set button
- 3 Trip button
- 4 Trip meter 1 display
- 5 Trip meter 2 display

The odometer shows the total distance that the motorcycle has travelled.

The odometer and two trip meters are located in the same display frame as the speedometer. Either trip meter shows the distance that the motorcycle has travelled since the meter on display was last reset to zero.

General Information

Warning


Do not attempt to switch between odometer and trip meter display modes or reset the trip meter with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.

Use the 'Trip' button to switch between the odometer and trip meter display modes. Press the 'Trip' button repeatedly until the desired display is visible. The display will Scroll through in the order:

- Odometer
- Trip meter 1
- Trip meter 2

To reset either of the trip meters, select and display the trip meter to be zeroed then press the 'Trip' and 'Set' buttons together for 2 seconds. After 2 seconds, the trip meter on display will reset to zero.

Clock/Trip Computer



- 1 Clock/trip computer display
- 2 Scroll button

The clock and trip computer information appear on the same display.

The trip computer provides an indication of fuel consumption, speed, lap time, time and distance, all recorded and calculated since the last reset.

Each display provides the following information:

Instantaneous Fuel Consumption

An indication of the fuel consumption at an instant in time.

Average Fuel Consumption

An indication of the average fuel consumption, calculated from when the trip computer was last reset. After a reset the display will show dashes until 0.1 miles/kilometer has been covered.

General Information

Trip Distance

The total distance travelled, since the last reset.

Trip Time

The total time elapsed, since the last reset.

Average Speed

The average speed is calculated from when the trip computer was last reset. After a reset the display will show dashes until 1 mile/kilometer has been covered.

Maximum Speed

The maximum speed achieved since the last reset is displayed.

Lap Timer

Provides information on lap time, maximum speed, average speed, and distance travelled for up to 99 laps.

Trip Computer Operation

Display Section

When the ignition is switched on the clock display is shown. To access the trip computer information press the 'Scroll' button.

Press the 'Scroll' button repeatedly until the desired display is visible. The trip display will scroll through in the order:


- Clock
- Lap Timer
- Average Speed
- Maximum Speed

- Trip Distance
- Trip Time
- Average Fuel Consumption
- Instantaneous Fuel Consumption

Clock Adjustment

Warning

Do not attempt to adjust the clock with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.



- 1 Clock display
- 2 Hours read-out
- 3 Minutes read-out
- 4 Scroll button
- 5 Set button

To reset the clock, select the clock display and press both 'Scroll' and 'Set' buttons together. After a short time, the clock's hour display will start to flash.


General Information

To reset the hour display, ensure that the hour display is still flashing then depress the 'Scroll' button to change the setting. Each individual press will change the setting by one digit.

When the correct hour display is shown, press the 'Set' button. The minutes display will begin to flash. The minutes display is adjusted in the same way as for the hours.

Once both hours and minutes are correctly set, press the 'Set' button to confirm the setting. The display will cease to flash.

Trip Computer Reset




- 1 Trip computer display
- 2 Scroll button
- 3 Set button

Warning

Do not attempt to switch between the trip computer display modes or reset the trip computer with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.

To reset the trip computer only, select one of the trip computer displays, press the 'Scroll' and 'Set' buttons simultaneously for 2 seconds. After 2 seconds, the trip computer, not the clock, will reset.

Lap Timer



- 1 Lap timer display

The lap timer will provide the following information: Lap time, number of laps, maximum speed, average speed and distance travelled. Each display provides the following information:

General Information

Lap Time

The elapsed time of the lap (the lap number will be displayed in the speedometer display position). Information is recorded for each lap since the last reset.

NOTE

- **The lap timer will record up to 99 minutes, 59 seconds and 9 tenths of a second. After this time, the display will reset to zero.**

Number of Laps

The number of recorded laps since the last reset is displayed. Up to a maximum of 99 laps can be stored by the lap timer.

Maximum Speed

The maximum speed achieved per lap (the lap number will be displayed in the speedometer display position) or the maximum speed achieved during all recorded laps.

Average Speed

The average speed per lap (the lap number will be displayed in the speedometer display position) or the average speed during all recorded laps.

Distance Travelled


The distance travelled per lap (the lap number will be displayed in the speedometer display position) or the distance travelled for all recorded laps.

The lap timer has two modes; Data Recording Mode and Data Retrieval Mode.

Warning

Do not attempt to switch between lap timer display modes with the motorcycle in motion as this may lead to loss of motorcycle control and an accident.

Data Recording Mode



- 1 Lap time display (during a lap)
- 2 Stop watch icon
- 3 Scroll button

After pressing the 'Scroll' button to select the lap timer, the word 'LAP' will appear in the clock display.


Pressing the starter button (with the engine running only) will start the lap timer. The display will show the lap time in minutes, seconds and tenths of a second, and the stop

General Information

watch icon will flash.

At the end of the lap, pressing the starter button again will register the start of a new lap. The display will show the last lap time for 15 seconds. After this time, the display will show the current lap number for 5 seconds before returning to the time for the current lap.


New lap recording



1 Starter button

Each new lap is recorded by a brief press of the starter button (with the engine running only). Whilst in the data recording mode, pressing the starter button for 2 seconds will return the display to the lap timer. From the lap timer display, press the 'Set' button to enter the Data Retrieval Mode.

Data Retrieval Mode



- 1 Lap time
- 2 Lap number
- 3 Set button
- 4 Trip button

Accessing the Data Retrieval Mode

The Data Retrieval Mode can be accessed in one of two ways:


- With the ignition in the 'ON' position, from the lap timer display, press the 'Set' button.
- From the Data Recording Mode, with the engine running and the motorcycle stationary, press the starter button for 2 seconds. This will return the display to the 'LAP' display. From here press the 'Set' button.

The Data Retrieval Mode cannot be accessed whilst the motorcycle is in motion.

General Information

Data Retrieval Mode

When the Data Retrieval Mode is accessed, the lap time for the first lap will be displayed. The lap number will be displayed in the speedometer display position. The stop watch Icon will no longer flash.




- 1 Data Retrieval Mode (lap time shown)
- 2 Lap number
- 3 Scroll button
- 4 Trip button

Press the 'Trip' button repeatedly until the desired lap (up to a maximum of 99 laps) is displayed.

Press the 'Scroll' button repeatedly until the desired data is visible for the lap number displayed.

The lap timer display will scroll through in the order:

- Lap time
- Maximum speed (per lap or maximum speed achieved)
- Average speed (per lap or total of all laps)
- Distance travelled (per lap or total of all laps)



- 1 Data Retrieval Mode (maximum speed shown)
- 2 Lap number
- 3 Scroll button
- 4 Trip button

The speed and distance will be displayed in kilometers or miles, according to the units displayed by the speedometer.


After the last lap is displayed, the total time for all laps, from the last reset will be displayed.

The letters 'Ltt' will appear in the speedometer display.

General Information

pressing the 'Scroll' button repeatedly will display the following:

- Total time for all laps
- Maximum speed achieved
- Average speed of all laps
- Total distance travelled




- 1 Data Retrieval Mode - total time display
- 2 Lap timer 'total time' indication
- 3 Scroll button

Lap Timer Reset

To reset the lap timer, press the 'Scroll' and 'Set' buttons simultaneously for 2 seconds. After 2 seconds, the lap timer will reset. This will delete the stored data for all stored laps.

To exit the Data Retrieval Mode, press the 'Set' button.

Gearshift Lights



- 1 Gearshift lights
- 2 Display screen
- 3 Scroll button
- 4 Set button
- 5 Trip button

The gearshift lights provide a visual indication of when to shift gear. The set shift-up speed at which the lights operate can be adjusted for rider preference. The gearshift lights are all colored blue.

Gearshift Light Modes

The gearshift lights have four programmable operating modes as described below:

- **SCALE mode:** The lights will illuminate in sequence 3,000 rpm before the set shift-up speed in the following order:

General Information

LED	RPM
1 st LED	3,000 rpm before set shift-up speed
2 nd LED	2,250 rpm before set shift-up speed
3 rd LED	1,500 rpm before set shift-up speed
4 th LED	750 rpm before set shift-up speed
5 th , 6 th and 7 th LEDs	At set shift-up speed


The gearshift lights will go out in the reverse of the order in which they illuminate.

- **3 LED mode:** The three middle lights illuminate when the set limit is reached, and remain illuminated until the engine speed drops below the set limit.
- **7 LED mode:** All seven lights illuminate when the set limit is reached, and remain illuminated until the engine speed drops below the set limit.
- **OFF mode:** The gearshift lights can be set to OFF.

The gearshift lights will not operate below 4,000 rpm to avoid the lights operating at idle, and will not operate above 14,000 rpm.

Adjusting Gearshift Light Modes


To adjust the gearshift light modes, turn the ignition to the 'ON' position. Press the 'Trip' and 'Scroll' buttons simultaneously for 4 seconds, after 4 seconds the current mode will be displayed.



- 1 Gearshift lights
- 2 Display screen (3 LED mode shown)
- 3 Scroll button
- 4 Set button
- 5 Trip button

General Information


The corresponding lights for the current mode will be illuminated and the clock will display the selected mode - either 'SCALE' 'LEd 3', 'LEd 7', or 'OFF'. If the 'OFF' mode has been selected, no lights will be illuminated. See 'Gearshift Light Modes' on page 26.



- 1 Gearshift lights
- 2 Display screen (SCALE mode shown)

To scroll through the four modes press the 'Set' button. To set the gearshift lights to the displayed mode, press the 'Trip' and 'Scroll' buttons simultaneously for 4 seconds.

If the 'OFF' mode is selected at this point, the instruments will return to their normal mode of operation, otherwise the gearshift lights limits can now be adjusted as described below:




- 1 Gearshift lights
- 2 Display screen (OFF mode shown)

Setting Gearshift Light Limits

Select the desired gearshift light mode as described above. Press the 'Trip' and 'Scroll' buttons simultaneously for 4 seconds. After 4 seconds, the tachometer needle will move round to the last set position and the word 'tAcHo' will appear in the clock display. The corresponding lights for the current mode will also remain illuminated.


General Information



- 1 Gearshift lights
- 2 Display screen
- 3 Scroll button
- 4 Set button
- 5 Trip button

Pressing the 'Set' button at this point will return the instruments to their normal mode of operation, without adjusting the gearshift lights limits.

To change the setting, press the 'Scroll' button. The clock display will now show 'A1000'.




- 1 Gearshift lights
- 2 Display screen
- 3 Scroll button
- 4 Set button
- 5 Trip button

To change the setting in increments of 1,000 rpm, press the 'Scroll' button again. Each individual press will then increase the setting in increments of 1,000 rpm, up to a limit of 14,000 rpm. As the limit cannot exceed 14,000rpm, when 14,000 rpm is reached the limit will return to 4,000 rpm.

When the correct setting is shown press the 'set' button to confirm. The clock display will now show 'A100'.

General Information



- 1 Gearshift lights
- 2 Display screen
- 3 Scroll button
- 4 Set button
- 5 Trip button


The setting can now be changed in increments of 100 rpm, again up to a limit of 14,000 rpm.

Each individual press of the 'Scroll' button will increase the setting in increments of 100 rpm, up to a limit of 14,000 rpm. As the limit cannot exceed 14,000, when 14,000 rpm is reached the limit will return to 4,000 rpm.

When the correct setting is shown, pressing the 'set' button will confirm the setting.


When the gearshift lights settings are exited in any mode except 'OFF', the tachometer needle will quickly sweep from zero to maximum and then return to zero, and the gearshift lights will illuminate according to their set mode.

Gear Position Display



- 1 Gear position display (neutral position shown)

The gear position display indicates the gear position. When the transmission is in neutral (no gear selected), the display will show 'n'.




- 1 Gear position display (fifth gear shown)

When the transmission is in gear the relevant gear number '1' to '6' will be displayed.

General Information

Coolant Temperature Gauge



1 Coolant temperature gauge

The coolant temperature gauge indicates the temperature of the engine coolant.

When the ignition is switched on, all 10 bars of the display will be shown. When the engine is started from cold the display will show 1 bar. As the temperature increases more bars will be shown in the display. When the engine is started from hot the display will show the relevant number of bars, dependant on engine temperature.

The normal temperature range is between 3 and 6 bars.

If the coolant temperature becomes too high the display will show 9 bars and will start to flash. The high coolant temperature warning light in the tachometer will also be illuminated.

If the coolant temperature increases further, all 10 bars of the display will flash. The high temperature warning light in the tachometer will remain illuminated.

Caution

Do not continue to run the engine if either of the high temperature warnings are displayed as severe engine damage may result.

General Information

Warning Lights

Turn Signals



When the turn signal switch is pushed to left or right, the turn signal indicator light will flash on and off at the same speed as the turn signals.

High Beam



When the ignition is switched on and the headlight dimmer switch is set to 'high beam', the high beam warning light will illuminate.

Low Fuel



tank.

The low fuel indicator will illuminate when there are approximately 0.79 US gal (3.0 liters) of fuel remaining in the

Neutral



The neutral indicator light will illuminate when the transmission is in neutral (no gear selected). The indicator light will illuminate when the transmission is in neutral with the ignition switch in the 'ON' position.

Low Oil Pressure Warning Light



light in the tachometer will illuminate.

With the engine running, if the engine oil pressure becomes dangerously low, the low oil pressure warning

Caution

Stop the engine immediately if the low oil pressure warning light illuminates. Do not restart the engine until the fault has been rectified. Severe engine damage will result from running the engine when the low oil pressure warning light is illuminated.

The low oil pressure warning light in the tachometer will illuminate if the ignition is switched on without running the engine.

High Coolant Temperature Warning Light



With the engine running, if the engine coolant temperature becomes dangerously high, the high coolant temperature warning light in the tachometer will illuminate.

General Information

Caution

Stop the engine immediately if the high coolant temperature warning light illuminates. Do not restart the engine until the fault has been rectified.

Severe engine damage will result from running the engine when the high coolant temperature warning light is illuminated.

The high coolant temperature warning light in the tachometer will illuminate if the ignition is switched on without running the engine.

Engine Management System Malfunction Indicator Light



The malfunction indicator light for the engine management system illuminates when the ignition is switched on (to indicate that it is working), but should not become illuminated when the engine is running.

If the malfunction indicator light becomes illuminated when the engine is running, this indicates that a fault has occurred in one or more of the systems controlled by the engine management system. In such circumstances, the engine management system will switch to 'limp-home' mode so that the journey may be completed, if the

fault is not so severe that the engine will not run.

Warning

Reduce speed and do not continue to ride for longer than is necessary with the malfunction indicator light illuminated. The fault may adversely affect engine performance, exhaust emissions and fuel consumption. Reduced engine performance could cause a dangerous riding condition, leading to loss of control and an accident. Contact an authorized Triumph dealer as soon as possible to have the fault checked and rectified.

NOTE

- **If the malfunction indicator light flashes when the ignition is switched on contact an authorized Triumph dealer as soon as possible to have the situation rectified. In these circumstances the engine will not start.**

Alarm Indicator Light




The alarm light will illuminate when the conditions described in the accessory alarm instructions are met.

The light does not function unless an alarm is fitted.

General Information

Ignition Key



1 Key number tag

In addition to operating the steering lock/ignition switch, the ignition key is required to operate the seat lock and fuel tank cap.

When the motorcycle is delivered from the factory, two keys are supplied together with a small tag bearing the key number. Make a note of the key number and store the spare key and key number tag in a safe place away from the motorcycle.


Your authorized Triumph dealer can supply a replacement key cut from details of the key number or can cut a new key using the original as a master.



Caution

Do not store the spare key with the motorcycle as this will reduce all aspects of security.

Ignition Switch/Steering Lock



- 1 Ignition switch/steering lock
- 2 On position
- 3 Off position
- 4 Lock position
- 5 Park position

Ignition Switch Positions

This is a four position, key operated switch. The key can be removed from the switch only when it is in the OFF, LOCK or P (PARK) position.

TO LOCK: Turn the key to the 'OFF' position, push and fully release the key, then rotate it to the 'LOCK' position.

'PARKING': Turn the key from the 'LOCK' position to the 'P' position. The steering will remain locked.

General Information

NOTE

- Do not leave the steering lock in the 'P' position for long periods of time as this will cause the battery to discharge.

Warning

For reasons of security and safety, always move the ignition switch to the 'OFF' position and remove the key when leaving the motorcycle unattended.


Any unauthorized use of the motorcycle may cause injury to the rider, other road users and pedestrians and may also cause damage to the motorcycle.

Warning

With the key in the 'LOCK' or 'P' position the steering will become locked.

Never turn the key to the 'LOCK' or 'P' positions while the motorcycle is moving as this will cause the steering to lock. Locked steering will cause loss of motorcycle control and an accident.

Brake Lever Adjuster



- 1 Lever (Daytona 675 shown)
- 2 Adjuster wheel
- 3 Triangular mark

An adjuster is fitted to the front brake lever. The adjuster allows the distance from the handlebar to the lever to be changed to one of six positions for Daytona 675 or four positions for Street Triple, to suit the span of the operator's hands.

To adjust the lever, push the lever forward and turn the adjuster wheel to align one of the numbered positions with the triangular mark on the lever holder.


The distance from the handlebar grip to the released lever is shortest when set to number six (Daytona 675), or four (Street Triple), and longest when set to number one.

General Information

Warning

Do not attempt to adjust the lever with the motorcycle in motion as this may lead to loss of motorcycle control and an accident. After adjusting the lever, operate the motorcycle in an area free from traffic to gain familiarity with the new lever setting. Do not loan your motorcycle to anyone as they may change the lever setting from the one you are familiar with causing loss of control or an accident.

Right Handlebar Switches



- 1 Engine stop switch
- 2 Starter button

Engine Stop Switch

In addition to the ignition switch being turned to the 'ON' position, the

engine stop switch must be in the 'RUN' position for the motorcycle to operate.

The engine stop switch is for emergency use. If an emergency arises which requires the engine to be stopped, move the engine stop switch to the stop position.

NOTE

- **Although the engine stop switch stops the engine, it does not turn off all the electrical circuits and may cause difficulty in restarting the engine due to a discharged battery. Ordinarily, only the ignition switch should be used to stop the engine.**

Caution

Do not leave the ignition switch in the 'ON' position unless the engine is running as this may cause damage to electrical components and will discharge the battery.

Starter Button

The starter button operates the electric starter. For the starter to operate, the clutch lever must be pulled to the handlebar.


NOTE

- **Even if the clutch lever is pulled to the handlebar, the starter will not operate if the side stand is down and a gear is engaged.**

General Information

With the engine running, the starter button functions as the lap timer 'trigger' button. Momentarily pressing the starter button will start the lap timer recording the next lap.

Left Handlebar Switches



- 1 Headlight dimmer switch
- 2 Turn signal switch
- 3 Horn button
- 4 Pass button

Headlight Dimmer Switch

High or low beam can be selected with the headlight dimmer switch. To select high beam, push the switch forward. To select low beam, push the switch rearwards. When the high beam is turned on, the high beam indicator light will illuminate.

NOTE

- A lighting ON/OFF switch is not fitted to this model. The headlight, brake/tail light and license plate light all function automatically when the ignition is turned to the ON position.

Turn Signal Switch

When the turn signal switch is pushed to the left or right and released, the corresponding turn signals will flash on and off. To turn off the turn signals, press and release the switch.

Horn Button

When the horn button is pushed, with the ignition switch turned to the 'ON' position, the horn will sound.

Pass Button

When the pass button is pressed the headlight main beam will be switched on. It will remain on as long as the button is held in and will turn off as soon as the button is released.

General Information

Fuel Requirement/Refuelling

Fuel Grade



This Triumph motorcycle is designed to run on unleaded gasoline with a CLC or AKI octane rating (R+M)/2 of 89 or higher for Daytona 675 models, or a CLC or AKI octane rating (R+M)/2 of 87 or higher for Street Triple models. Federal regulations require that pumps delivering unleaded gasoline are marked 'UNLEADED' and that the Cost of Living Council (CLC) or Anti-Knock Index (AKI) octane rating is also displayed. These ratings are an average of the Research Octane Number (RON) and the Motor Octane Number (MON).

Caution

The exhaust system is fitted with a catalytic converter to help reduce exhaust emission levels. The catalytic converter can be permanently damaged if the motorcycle is allowed to run out of fuel or if the fuel level is allowed to get very low. Always ensure you have adequate fuel for your journey.

Caution

The use of leaded fuel is illegal in most countries, states or territories. Use of leaded fuel will damage the catalytic converter.

NOTE

- If 'knocking' or 'pinging' occurs at a steady engine speed under normal load, use a different brand of gasoline or gasoline which has a higher octane rating.

Oxygenated Gasoline

To help in meeting clean air standards, some areas of the U.S. use oxygenated gasoline to help reduce harmful emissions. These gasolines are a blend of conventional gasoline and another compound such as alcohol. This Triumph motorcycle will give its best performance when using unleaded gasoline. However, the following should be used as a guide if you use any oxygenated fuels.

Ethanol

Ethanol fuel is a mixture of 10% Ethanol and 90% gasoline and is often described under the names 'gasohol', 'Ethanol enhanced', or 'contains Ethanol'. This fuel may be used in your Triumph motorcycle.

General Information

MTBE (Methyl Tertiary Butyl Ether)

The use of gasolines containing up to 15% MTBE (Methyl Tertiary Butyl Ether) is permitted in this Triumph motorcycle.

Methanol

Caution

Fuels containing methanol should not be used as damage to components in the fuel system can be caused by contact with methanol.

Caution

Because of the generally higher volatility of oxygenated fuels, starting, engine response and fuel consumption may be adversely affected by their use. Should any of these difficulties be experienced, run the motorcycle on normal unleaded gasoline.

Warning

To help reduce hazards associated with refuelling, always observe the following fuel safety instructions: Gasoline (fuel) is highly flammable and can be explosive under certain conditions. When refuelling, turn the ignition switch to the 'OFF' position.

Do not smoke.

Do not use a mobile telephone.

Make sure the refuelling area is well ventilated and free from any source of flame or sparks. This includes any appliance with a pilot light.


Never fill the tank until the fuel level rises into the filler neck. Heat from sunlight or other sources may cause the fuel to expand and overflow creating a fire hazard.

After refuelling always check that the fuel filler cap is correctly closed and locked.

Because gasoline (fuel) is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above will lead to a fire hazard, which could cause damage to property, injury to persons or death.

General Information

Fuel Tank Cap



- 1 Fuel tank cap
- 2 Key

To open the fuel tank cap, lift up the flap covering the lock itself. Insert the key into the lock and turn the key clockwise.

To close and lock the cap, push the cap down into place with the key inserted, until the lock 'clicks' into place. Withdraw the key and close the key cover.

Caution

Closing the cap without the key inserted will damage the cap, tank and lock mechanism.


Filling the Fuel Tank

Avoid filling the tank in rainy or dusty conditions where airborne material can contaminate the fuel.

Caution

Contaminated fuel may cause damage to fuel system components.

Fill the fuel tank slowly to help prevent spillage. Do not fill the tank to a level above the bottom of the filler neck. This will ensure there is enough air space to allow for fuel expansion if the fuel inside the tank expands through absorption of heat from the engine or from direct sunlight.



- 1 Maximum fuel level
- 2 Fuel filler neck
- 3 Air space

General Information

Warning

Overfilling the tank can lead to fuel spillage.

If fuel is spilled, thoroughly clean up the spillage immediately and dispose of the materials used safely.

Take care not to spill any fuel on the engine, exhaust pipes, tires or any other part of the motorcycle. Because fuel is highly flammable, any fuel leak or spillage, or any failure to observe the safety advice given above may lead to a fire hazard, which could cause damage to property and injury or death to persons.

Fuel spilled near to, or onto the tires will reduce the tire's ability to grip the road. This will result in a dangerous riding condition potentially causing loss of motorcycle control and an accident.

After refuelling always check that the fuel filler cap is correctly closed and locked.


Tool Kit and Handbook

The tool kit is located beneath the seat(s).

The handbook is located beneath the seat (rear seat on Daytona 675).

Stand

Side Stand



1 Side stand

The motorcycle is equipped with a side stand on which the motorcycle can be parked.

Warning

The motorcycle is fitted with an interlock system to prevent it from being ridden with the side stand in the down position.

Never attempt to ride with the side stand down or interfere with the interlock mechanism as this will cause a dangerous riding condition leading to loss of motorcycle control and an accident.

NOTE

- **When using the side stand, always turn the handlebars fully to the left and leave the motorcycle in first gear.**

General Information

Whenever the side stand is used, before riding, always ensure that the side stand is fully up after first sitting on the motorcycle.

For instructions on safe parking, refer to the 'How to Ride the Motorcycle' section.

Seat Lock

Seat Care

To prevent damage to the seat or seat cover, care must be taken not to drop or lean the seat against any surface which may damage the seat or seat cover.




Caution

To prevent damage to the seat or seat cover, care must be taken not to drop the seat. Do not lean the seat against the motorcycle or any surface which may damage the seat or seat cover. Instead, place the seat, with the seat cover facing upwards, on a clean, flat surface which is covered with a soft cloth. Do not place any item on the seat which may cause damage or staining to the seat cover.

Rider's Seat

Both models



1 Seat lock (Daytona 675 shown)

The seat lock is located on the left hand side of the battery tray, in line with the footrest mounting rail. To remove the seat, insert the ignition key into the seat lock and turn it counter-clockwise while pressing down on the rear of the seat. This will release the seat from its lock and allow it to be slid rearwards for complete removal from the motorcycle.


General Information

To install the seat, engage the seat's tongue under the fuel tank and press down at the rear to engage in the seat lock.

Warning

To prevent detachment of the seat during riding, after fitting always grasp the seat and pull firmly upwards. If the seat is not correctly secured it will detach from the lock. A loose or detached seat could cause loss of motorcycle control and an accident.

Rear Seat/Seat Cover Daytona 675 only



1 Rear seat fastener

To remove the rear seat cover or rear seat (where fitted): Remove the fastener located beneath the padding. This will allow the rear seat/seat cover to be slid forwards for complete removal from the motorcycle.

Breaking-In



Breaking-In is the name given to the

process that occurs during the first hours of a new vehicle's operation.

In particular, internal friction in the engine will be higher when components are new. Later on, when continued operation of the engine has ensured that the components have 'bedded in', this internal friction will be greatly reduced.

A period of careful breaking-in will ensure lower exhaust emissions, and will optimize performance, fuel economy and longevity of the engine and other motorcycle components.

During the first 500 miles (800 kilometers):

- Do not use full throttle.
- Avoid high engine speeds at all times.
- Avoid riding at one constant engine speed, whether fast or slow, for a long period of time.
- Avoid aggressive starts, stops, and rapid accelerations, except in an emergency.
- Do not ride at speeds greater than 3/4 of maximum engine speed.

From 500 to 1000 miles (800 to 1500 kilometers):

- Engine speed can gradually be increased to the rev limit for short periods.

General Information

Both during and after breaking in has been completed:

- Do not over-rev the engine when cold.
- Do not lug engine. Always downshift before the engine begins to 'struggle'.
- Do not ride with engine speeds unnecessarily high. Shifting up a gear helps reduce fuel consumption, reduces noise and helps to protect the environment.

Safe Operation

Daily Safety Checks



Check the following items each day before you ride.

The time required is minimal, and these checks will help ensure a safe, reliable ride.

If any irregularities are found during these checks, refer to the Maintenance and Adjustment section or see your authorized Triumph dealer for the action required to return the motorcycle to a safe operating condition.

Warning

Failure to perform these checks every day before you ride may result in serious motorcycle damage or an accident causing serious injury or death.

Check:

Fuel: Adequate supply in tank, no fuel leaks (page 45).

Engine oil: Correct level on dipstick. Add correct specification oil as required. No leaks from the engine or oil cooler (page 73).

Drive chain: Correct adjustment (page 84).

General Information

Tires/Wheels: Correct inflation pressures (when cold). Tread depth/wear, tire/wheel damage, punctures etc. (page 99).

Nuts, bolts, fasteners: Visually check that steering and suspension components, axles, and all controls are properly tightened or fastened. Inspect all areas for loose/damaged fasteners.

Steering Action: Smooth but not loose from lock to lock. No binding of any of the control cables (page 93).

Brakes: Pull the brake lever and push the brake pedal to check for correct resistance. Investigate any lever/pedal where the travel is excessive before meeting resistance, or if either control feels spongy in operation (page 88).

Brake pads: There should be more than 0.06 in (1.5 mm) of friction material remaining on all the pads (page 88).

Brake Fluid Levels: No brake fluid leakage. Brake fluid levels must be between the 'MAX' and 'MIN' marks on both reservoirs (page 88).

Front Forks: Smooth action. No leaks from fork seals (page 95).

Throttle: Throttle grip free-play 0.8-0.12 in (2-3 mm). Ensure that the throttle grip returns to the idle position without sticking (page 80).

Clutch: Smooth operation and correct cable free-play (page 83).

Coolant: No coolant leakage. Check the coolant level in the expansion tank (when the engine is cold) (page 77).

Electrical equipment: All lights and the horn function correctly (page 41).

Engine stop: Stop switch turns the engine off (page 54).

Stands: Returns to the fully up position by spring tension. Return springs not weak or damaged (page 48).

How to Ride the Motorcycle


HOW TO RIDE THE MOTORCYCLE

Table of Contents

To Stop the Engine.....	54
To Start the Engine	55
Moving Off	56
Shifting Gears	56
Braking	57
Parking.....	59
Considerations for High Speed Operation	61
General	61
Steering	61
Luggage	61
Brakes.....	62
Tires	62
Fuel	62
Engine Oil	62
Coolant.....	62
Electrical Equipment.....	62
Miscellaneous	62

How to Ride the Motorcycle

To Stop the Engine



- 1 Engine stop switch
- 2 Starter button
- 3 Neutral indicator light
- 4 'ON' position
- 5 Ignition switch

Close the throttle completely.

Select neutral.

Turn the ignition switch off.

Select first gear.

Support the motorcycle on a firm, level surface with the side stand.

Lock the steering.

Caution

The engine should normally be stopped by turning the ignition switch to the 'OFF' position. The engine stop switch is for emergency use only. Do not leave the ignition switched on with the engine stopped. Electrical damage may result.

How to Ride the Motorcycle

To Start the Engine

Check that the engine stop switch is in the 'RUN' position.

Ensure the transmission is in neutral.

Turn the ignition switch on.

NOTE

- When the ignition is switched on, the tachometer needle will quickly sweep from zero to maximum and then return to zero. The instrument warning lights will illuminate and will then go off (except those which normally remain on until the engine starts - see 'Warning Lights' on page 39. It is not necessary to wait for the needle to return to zero before starting the engine.
- In very cold conditions, part open the throttle to aid cold starting. Return it to the closed position once the engine has started.

Pull the clutch lever fully into the handlebar.

Leaving the throttle fully closed, push the starter button until the engine starts.

Warning

Never start the engine or run the engine in a confined area. Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

Caution

Do not operate the starter continuously for more than 5 seconds as the starter motor will overheat and the battery will become discharged. Wait 15 seconds between each operation of the starter to allow for cooling and recovery of battery power.

Do not let the engine idle for long periods as this may lead to overheating which will cause damage to the engine.

How to Ride the Motorcycle

Caution

The low oil pressure warning light should go out shortly after the engine starts.


If the low oil pressure warning light stays on after starting the engine, stop the engine immediately and investigate the cause. Running the engine with low oil pressure will cause severe engine damage.

- The motorcycle is equipped with starter lockout switches. The switches prevent the electric starter from operating when the transmission is not in neutral with the side stand down.
- If the side stand is extended whilst the engine is running, and the transmission is not in neutral then the engine will stop regardless of clutch position.

Moving Off

Pull in the clutch lever and select first gear. Open the throttle a little and let out the clutch lever slowly. As the clutch starts to engage, open the throttle a little more, allowing enough engine speed to avoid stalling.

Shifting Gears



1 Gearshift pedal

Close the throttle while pulling in the clutch lever. Shift into the next higher or lower gear. Open the throttle part way, while releasing the clutch lever. Always use the clutch when shifting gear.

Warning

Take care to avoid opening the throttle too far or too fast in any of the lower gears as this can lead to the front wheel lifting from the ground (pulling a 'wheelie') and to the rear tire breaking traction (wheel spin).

Always open the throttle cautiously, particularly if you are unfamiliar with the motorcycle, as a 'wheelie' or loss of traction will cause loss of motorcycle control and an accident.

How to Ride the Motorcycle


NOTE

- The gearshift mechanism is the 'positive stop' type. This means that, for each movement of the gearshift pedal, you can only select each gear, one after the other, in ascending or descending order.

Warning

Do not shift to a lower gear at speeds that will cause excessive engine rpm (r/min). This can lock the rear wheel causing loss of control and an accident. Engine damage may also be caused. Down-shifting should be done such that low engine speeds will be ensured.

Braking



1 Front brake lever (Daytona 675 shown)

Warning

WHEN BRAKING, OBSERVE THE FOLLOWING:


Close the throttle completely, leaving the clutch engaged to allow the engine to help slow down the motorcycle.

Downshift one gear at a time such that the transmission is in first gear when the motorcycle comes to a complete stop.

When stopping, always apply both brakes at the same time. Normally the front brake should be applied a little more than the rear.

Downshift or fully disengage the clutch as necessary to keep the engine from stalling.

Never lock the brakes, as this may cause loss of control of the motorcycle and an accident.



1 Rear brake pedal (Daytona 675 shown)

How to Ride the Motorcycle

Warning

For emergency braking, disregard down-shifting, and concentrate on applying the front and rear brakes as hard as possible without skidding. Riders should practice emergency braking in a traffic-free area.
Incorrect brake technique could result in loss of control and an accident.

Triumph strongly recommends that all riders take a course of instruction, which includes advice on safe brake operation.

Warning

For your safety, always exercise extreme caution when braking, accelerating or turning as any improper action can cause loss of control and an accident. Independent use of the front or rear brakes reduces overall braking performance. Extreme braking may cause either wheel to lock, reducing control of the motorcycle and causing an accident.

When possible, reduce speed or brake before entering a turn as closing the throttle or braking in mid-turn may cause wheel slip leading to loss of control and an accident.

When riding in wet or rainy conditions, or on loose surfaces, the ability to maneuver and stop will be reduced. All of your actions should be smooth under these conditions. Sudden acceleration, braking or turning may cause loss of control and an accident.

How to Ride the Motorcycle


Warning

When descending a long steep gradient, use engine braking by down-shifting and use the brakes intermittently. Continuous brake application can overheat the brakes and reduce their effectiveness.

Riding with your foot on the brake pedal or your hands on the brake lever may actuate the brake light, giving a false indication to other road users. It may also overheat the brake, reducing braking effectiveness.

Do not coast with the engine switched off, and do not tow the motorcycle. The transmission is pressure-lubricated only when the engine is running. Inadequate lubrication may cause damage or seizure of the transmission, which can lead to sudden loss of motorcycle control and an accident.

Parking



Select neutral and turn the ignition switch to the 'OFF' position.

Lock the steering to help prevent theft.

Always park on a firm, level surface to prevent the motorcycle from falling.

When parking on a hill, always park facing uphill to prevent the motorcycle from rolling off the side stand. Engage first gear to prevent the motorcycle from moving.

On a lateral (sideways) incline, always park such that the incline naturally pushes the motorcycle towards the side stand.

Do not park on a lateral (sideways) incline of greater than 6° and never park facing downhill.

How to Ride the Motorcycle

NOTE

- **When parking near traffic at night, or when parking in a location where parking lights are required by law, leave the tail, license plate and position lights on by turning the ignition switch to P (Park).**

Do not leave the switch in the 'P' position for long periods-of-time as this will discharge the battery.

Warning

The engine and exhaust system will be hot after riding. DO NOT park where pedestrians and children are likely to touch the motorcycle.

Touching any part of the engine or exhaust system when hot may cause unprotected skin to become burnt.

Warning

Do not park on a soft or on a steeply inclined surface. Parking under these conditions may cause the motorcycle to fall over causing damage to property and personal injury.

Warning

Gasoline is extremely flammable and can be explosive under certain conditions. If parking inside a garage or other structure, be sure it is well ventilated and the motorcycle is not close to any source of flame or sparks. This includes any appliance with a pilot light.

Failure to follow the above advice may cause a fire resulting in damage to property or personal injury.

How to Ride the Motorcycle

Considerations for High Speed Operation

Warning

This Triumph motorcycle should be operated within the legal speed limits for the particular road travelled. Operating a motorcycle at high speeds can be potentially dangerous since the time available to react to given traffic situations is greatly reduced as road speed increases. Always reduce speed in consideration of weather and traffic conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed course racetracks. High-speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions. High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

The handling characteristics of a motorcycle at high speed may vary from those you are familiar with at legal road speeds. Do not attempt high-speed operation unless you have received sufficient training and have the required skills as a serious accident may result from incorrect operation.

Warning

The items listed are extremely important and must never be neglected. A problem, which may not be noticed at normal operating speeds, may be greatly exaggerated at high speeds.

General

Ensure the motorcycle has been maintained according to the scheduled maintenance chart.

Steering

Check that the handlebar turns smoothly without excessive free play or tight spots. Ensure that the control cables do not restrict the steering in any way.

Luggage

Make certain that any luggage containers are closed, locked and securely fitted to the motorcycle.

How to Ride the Motorcycle

Brakes

Check that the front and rear brakes are functioning properly.

Tires

High-speed operation is hard on tires, and tires that are in good condition are crucial to riding safely. Examine their overall condition, inflate to the correct pressure (when the tires are cold), and check the wheel balance. Securely install the valve caps after checking tire pressures. Observe the information given in the maintenance and specification sections on tire checking and tire safety.

Fuel

Have sufficient fuel for the increased fuel consumption that will result from high-speed operation.

Engine Oil

Make certain that the engine oil level is correct. Ensure that the correct grade and type of oil is used when topping-off.

Coolant

Check that the coolant level is at the upper level line in the expansion tank. (Always check the level with the engine cold).

Electrical Equipment

Make certain that the headlight, brake/tail light, turn signals, horn etc., all work properly.

Miscellaneous

Visually check that all fasteners are tight.



Caution

The exhaust system is fitted with a catalytic converter to help reduce exhaust emission levels. The catalytic converter can be permanently damaged if the motorcycle is allowed to run out of fuel or if the fuel level is allowed to get very low. Always ensure you have adequate fuel for your journey.

Accessories and Loading

ACCESSORIES AND LOADING

The addition of accessories and carrying of additional weight can affect the motorcycle's handling characteristics causing changes in stability and necessitating a reduction in speed. The following information has been prepared as a guide to the potential hazards of adding accessories to a motorcycle and carrying passengers and additional loads.

Warning

Incorrect loading may result in an unsafe riding condition leading to an accident.

Always ensure any loads carried are evenly distributed on both sides of the motorcycle. Ensure that the load is correctly secured such that it will not move around while the motorcycle is in motion.

Always check the load security regularly (though not while the motorcycle is in motion) and ensure that the load does not extend beyond the rear of the motorcycle.

Never exceed the maximum vehicle loading weight of 429 lbs (195 kg).

This maximum loading weight is made up from the combined weight of the rider, passenger, any accessories fitted and any load carried.

Warning

Do not install accessories or carry luggage that impairs the control of the motorcycle. Make sure that you have not adversely affected the visibility of any lighting component, road clearance, banking capability (i.e. lean angle), control operation, wheel travel, front fork movement, visibility in any direction, or any other aspect of the motorcycle's operation.

Warning

This motorcycle must not be operated above the legal road speed limit except in authorized closed course conditions.

Accessories and Loading

Warning

Only operate this Triumph motorcycle at high speed in closed-course on-road competition or on closed course racetracks. High-speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions. High-speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

Your passenger should be instructed that he or she can cause loss of motorcycle control by making sudden movements or by adopting an incorrect seated position.

The rider should instruct the passenger as follows:

- It is important that the passenger sits still while the motorcycle is in motion and does not interfere with the operation of the motorcycle.
- To keep his or her feet on the passenger footrests and to firmly hold onto the seat strap or the rider's waist or hips.
- Advise the passenger to lean with the rider when travelling around corners and not to lean unless the rider does so.

Warning

Do not carry animals on your motorcycle.

An animal could make sudden and unpredictable movements that could lead to loss of motorcycle control and an accident.

Accessories and Loading

Warning


The handling and braking capabilities of a motorcycle will be affected by the presence of a passenger. The rider must make allowances for these changes when operating the motorcycle with a passenger and should not attempt such operation unless trained to do so and without becoming familiar and comfortable with the changes in motorcycle operating characteristics that this brings about.

Motorcycle operation without making allowances for the presence of a passenger could lead to loss of motorcycle control and an accident.

Warning

Never attempt to store any items between the frame and the fuel tank. This can restrict the steering and will cause loss of control leading to an accident.

Weight attached to the handlebar or front fork will increase the mass of the steering assembly and can result in loss of steering control leading to an accident.



Warning

Do not carry a passenger unless he or she is tall enough to reach the footrests provided.

A passenger who is not tall enough to reach the footrests will be unable to sit securely on the motorcycle and may cause instability leading to loss of control and an accident.

Warning

Never ride an accessory equipped motorcycle, or a motorcycle carrying a payload of any kind, at speeds above 80 mph (130 km/h). In either/both of these conditions, speeds in excess of 80 mph (130 km/h) should not be attempted even where the legal speed limit permits this.

The presence of accessories and/or payload will cause changes in the stability and handling of the motorcycle.

Failure to allow for changes in motorcycle stability may lead to loss of control or an accident.

Remember that the 80 mph (130 km/h) absolute limit will reduce by the fitting of non-approved accessories, incorrect loading, worn tires, overall motorcycle condition and poor road or weather conditions.

Accessories and Loading



Warning

If the passenger seat is used to carry small objects, they must not exceed 11lb (5 kg) in weight, must not impair control of the motorcycle, must be securely attached and must not extend beyond the rear or sides of the motorcycle.

Carrying of objects in excess of 11 lb (5 kg) in weight, that are insecure, impair control or extend beyond the rear or sides of the motorcycle may lead to loss of motorcycle control and an accident.

Even if small objects are correctly loaded onto the rear seat, the maximum speed of the motorcycle must be reduced to 80 mph (130 km/h).



Caution

Do not allow luggage to rest on or against the upper portion of the rear bodywork.

Allowing luggage to rest on or against the upper portion of the rear bodywork could close the airgap between the bodywork and the exhaust potentially causing the bodywork to become damaged by overheating.

Maintenance and Adjustment

MAINTENANCE AND ADJUSTMENT

Table of Contents

Scheduled Maintenance	70
Engine Oil	73
Oil Level Inspection	74
Oil and Oil Filter Change	75
Disposal of Used Engine Oil and Oil Filters	76
Oil Specification and Grade.....	76
Cooling System	77
Corrosion Inhibitors.....	77
Coolant Level Inspection	78
Coolant Level Adjustment.....	79
Coolant Change	79
Radiator Hoses	79
Throttle Control	80
Inspection.....	81
Adjustment	82
Clutch	83
Inspection.....	84
Adjustment	84
Drive Chain	84
Chain Lubrication	85
Chain Free – Movement Inspection	85
Chain Free – Movement Adjustment	86
Chain and Sprocket Wear Inspection.....	87
Brakes	88
Brake Wear Inspection	88
Brake Pad Wear Compensation.....	88
Disc Brake Fluid	89
Front Brake Fluid Level Inspection and Adjustment - Daytona 675 ..	90
Front Brake Fluid Level Inspection and Adjustment - Street Triple...	90
Rear Brake Fluid Inspection and Adjustment	91
Brake Light Switches	91
Windshield Cleaning	92

Maintenance and Adjustment

Steering/Wheel Bearings.....	93
Steering Inspection	93
Inspecting the Steering (steering head) Bearings for Free-Play.....	93
Wheel Bearings Inspection	94
Front Suspension	95
Front Fork Inspection.....	95
Suspension Setting Chart - Daytona 675 only	96
Front Suspension Settings.....	96
Spring Pre-Load Adjustment.....	97
Rebound Damping Adjustment	97
Compression Damping Adjustment	97
Rear Suspension Adjustment	98
Rebound Damping Adjustment.....	98
Compression Damping Adjustment	98
Tires	99
Tire Inflation Pressures	99
Tire Wear.....	99
Minimum Recommended Tread Depth	100
Tire Replacement	101
Battery.....	103
Battery Removal	104
Battery Disposal	104
Battery Maintenance.....	104
Battery Discharge	105
Battery Maintenance During Motorcycle Storage.....	105
Battery Charging.....	106
Battery Installation	107
Fuse Box	107
Fuse Identification.....	109
Headlights	110
Headlights	110
Headlight Adjustment Daytona 675	111
Headlight Adjustment Street Triple	112
Headlight Bulb Replacement	113
Headlight Bulb Replacement	114
Brake/Tail Light	115
Brake/Tail Light Replacement.....	115
Turn Signal Lights	115
License Plate Light	116
Bulb Replacement	116

Maintenance and Adjustment

Cleaning	116
Preparation for Washing	117
Where to be Careful	117
After Washing	118
Unpainted aluminum Items	118
Cleaning of the Exhaust System	118
Washing	118
Drying	118
Protecting	119

Maintenance and Adjustment

Scheduled Maintenance

To maintain the motorcycle in a safe and reliable condition, the maintenance and adjustments outlined in this section must be carried out as specified in the schedule of daily checks, and also in line with the scheduled maintenance chart. The information that follows describes the procedures to follow when carrying out the daily checks and some simple maintenance and adjustment items.

Warning

Special tools, knowledge and training are required in order to correctly carry out the maintenance items listed in the scheduled maintenance chart. Only an authorized Triumph dealer will have this knowledge and equipment.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorized Triumph dealer carry out the scheduled maintenance of this motorcycle.

Warning

All maintenance is vitally important and must not be neglected. Incorrect maintenance or adjustment may cause one or more parts of the motorcycle to malfunction. A malfunctioning motorcycle may lead to loss of control and an accident.

Weather, terrain and geographical location affects maintenance. The maintenance schedule should be adjusted to match the particular environment in which the vehicle is used and the demands of the individual owner.

Since incorrect or neglected maintenance can lead to a dangerous riding condition, always have an authorized Triumph dealer carry out the scheduled maintenance of this motorcycle.

Triumph Motorcycles cannot accept any responsibility for damage or injury resulting from incorrect maintenance or improper adjustment carried out by the owner.

Maintenance and Adjustment

Scheduled Maintenance Chart							
Operation Description	Odometer Reading in Miles (Kms) or time period, whichever comes first						
		First Service	A Service	B Service	C Service	D Service	A Service
	Every	500 (800) 1 month	6,000 (10,000) 1 year	12,000 (20,000) 2 years	18,000 (30,000) 3 years	24,000 (40,000) 4 years	30,000 (50,000) 5 years
Engine oil cooler - check for leaks	Day	•	•	•	•	•	•
Engine oil - replace	-	•	•	•	•	•	•
Engine and oil filter - replace	-	•	•	•	•	•	•
Valve clearances - check/adjust	-			•		•	
Air cleaner - replace	-			•		•	
Engine ECM - check for stored DTCs	-	•	•	•	•	•	•
Spark plugs - check	-		•		•		•
Spark plugs - replace	-			•		•	
Throttle bodies - balance	-		•	•	•	•	•
Throttle cables - check/adjust	Day	•	•	•	•	•	•
Cooling system - check for leaks	Day	•	•	•	•	•	•
Coolant level - check/adjust	Day	•	•		•		•
Coolant - replace	-			•		•	
Fuel system - check for leaks, chafing etc.	Day	•	•	•	•	•	•
Lights, instruments & electrical systems - check	Day	•	•	•	•	•	•
Steering - check for free operation	Day	•	•	•	•	•	•
Steering Head bearings - check/adjust	-		•	•	•	•	•
Steering Head bearings - lubricate	-			•		•	
Forks - check for leaks/smooth operation	Day	•	•	•	•	•	•
Fork oil - replace	-						•
Brake fluid levels - check	Day	•	•	•	•	•	•
Brake fluid - replace		Every 2 years					
Brake pad - check wear levels	Day	•	•	•	•	•	•
Brake master cylinders - check for fluid leaks	Day	•	•	•	•	•	•
Brake calipers - check for fluid leaks and seized pistons	Day	•	•	•	•	•	•

Maintenance and Adjustment

Scheduled Maintenance Chart (continued)							
Operation Description	Odometer Reading in Miles (Kms) or time period, whichever comes first						
		First Service	A Service	B Service	C Service	D Service	A Service
	Every	500 (800) 1 month	6,000 (10,000) 1 year	12,000 (20,000) 2 years	18,000 (30,000) 3 years	24,000 (40,000) 4 years	30,000 (50,000) 5 years
Drive Chain - lubricate	Every 200 miles (300 kms)						
Drive Chain - wear check	Every 500miles (800kms)						
Drive chain slack - check/adjust	Day	•	•	•	•	•	•
Drive chain rubbing strip - check	-		•	•	•	•	•
Fasteners - inspect visually for security	Day	•	•	•	•	•	•
Wheels - inspect for damage	Day	•	•	•	•	•	•
Tire wear/tire damage - check	Day	•	•	•	•	•	•
Tire pressures - check/adjust	Day	•	•	•	•	•	•
Clutch cable - check/adjust	Day	•	•	•	•	•	•
Secondary air injection system - check/clean	-			•		•	
Stand - check operation	Day	•	•	•	•	•	•
Exhaust butterfly valve cables - check/adjust (Daytona 675 only)	-				•		
Secondary exhaust clamp bolts - check/adjust	-	•	•	•	•	•	•
Fuel and evaporative loss* hoses - replace	-					•	

*Evaporative system fitted to California models only.

Maintenance and Adjustment

Engine Oil



cbnz


In order for the engine, transmission, and clutch to function correctly, maintain the engine oil at the correct level, and change the oil and oil filter in accordance with scheduled maintenance requirements.

Warning

Motorcycle operation with insufficient, deteriorated, or contaminated engine oil will cause accelerated engine wear and may result in engine or transmission seizure. Seizure of the engine or transmission may lead to sudden loss of control and an accident.

Maintenance and Adjustment

Oil Level Inspection



- 1 Filler
- 2 Dipstick location in crankcase
- 3 Dipstick
- 4 Upper marking
- 5 Lower marking

Warning

Never start the engine or run the engine in a confined area. Exhaust fumes are poisonous and can cause loss of consciousness and death within a short period of time. Always operate your motorcycle in the open-air or in an area with adequate ventilation.

Caution

Running the engine with insufficient oil will cause engine damage. If the low oil pressure indicator remains on, stop the engine immediately and investigate the cause.

Start the engine and run at idle for approximately five minutes.

Stop the engine, then wait for at least three minutes for the oil to settle.

Remove the dipstick, wipe the blade clean, install and fully tighten.

NOTE

- An accurate indication of the level of oil in the engine is only shown when the engine is at normal operating temperature, the motorcycle is upright (not on the side stand) and when the dipstick has been fully tightened.
- Do not add oil through the dipstick hole in the crankcase.

Remove the dipstick.


The oil level is indicated by lines on the dipstick. When full, the indicated oil level must be level with the upper marking on the dipstick.

If the oil level is below the lower marking, remove the filler plug and add oil a little at a time through the filler plug hole in the clutch cover until the correct level is reached.

Once the correct level is reached, install the dipstick and the filler plug.

Maintenance and Adjustment

Oil and Oil Filter Change



- 1 Oil drain plug
- 2 Oil filter

The engine oil and filter must be replaced in accordance with scheduled maintenance requirements.

Warning

Prolonged or repeated contact with engine oil can lead to skin dryness, irritation and dermatitis. In addition, used engine oil contains harmful contamination that can lead to skin cancer. Always wear suitable protective clothing and avoid skin contact with used oil.

Warm up the engine thoroughly, and then stop the engine and secure the motorcycle in an upright position on level ground.

Remove the lower fairing (Daytona 675 only).

Place an oil drain pan beneath the engine.

Remove the oil drain plug.

Warning

The oil may be hot to the touch. Avoid contact with the hot oil by wearing suitable protective clothing, gloves, eye protection, etc. Contact with hot oil may cause the skin to be scalded or burned.

Unscrew and remove the oil filter using Triumph service tool T3880313. Dispose of the old filter in an environmentally friendly way.

Apply a thin smear of clean engine oil to the sealing ring of the new oil filter. Install the oil filter and tighten to **7 lbf ft (10 Nm)**.

Install the oil drain plug and tighten to **18 lbf ft (25 Nm)**.

Fill the engine with a 10W/40 or 15W/50 semi or fully synthetic motorcycle engine oil that meets specification API SH (or higher) AND JASO MA.

Maintenance and Adjustment

Start the engine and allow it to idle for a minimum of 30 seconds.

Caution

Raising the engine speed above idle, before the oil reaches all parts of the engine can cause engine damage or seizure. Only raise engine speed after running the engine for 30 seconds to allow the oil to circulate fully.

Caution

If the engine oil pressure is too low, the low oil pressure warning light will illuminate. If this light stays on when the engine is running, stop the engine immediately and investigate the cause. Running the engine with low oil pressure will cause engine damage.

Ensure that the low oil pressure warning light extinguishes shortly after starting.

Turn off the ignition, check the oil level using the method previously described, and top-off to between the minimum and maximum level lines on the dipstick.

Install the lower fairing (Daytona 675 only).

Disposal of Used Engine Oil and Oil Filters

To protect the environment, do not pour oil on the ground, down sewers or drains, or into groundwater courses. Do not place used oil filters in with general waste. If in doubt contact your local authority.

Oil Specification and Grade


Triumph high performance fuel injected engines are designed to use 10W/40 or 15W/50 semi or fully synthetic motorcycle engine oil that meets specification API SH (or higher) AND JASO MA.

Do not add any chemical additives to the engine oil. The engine oil also lubricates the clutch and any additives could cause the clutch to slip.

Do not use mineral, vegetable, non-detergent oil, castor based oils or any oil not conforming to the required specification. The use of these oils may cause instant, severe engine damage.

Maintenance and Adjustment

Cooling System



To ensure efficient engine cooling, check the coolant level each day before riding the motorcycle, and top-off the coolant if the level is low.

Caution

A year-round type of anti-freeze is installed in the cooling system when the motorcycle leaves the factory. It is colored green, contains a 50% solution of ethylene glycol, and has a freezing point of -31°F (-35°C).

Corrosion Inhibitors

To protect the cooling system from corrosion, the use of corrosion inhibitor chemicals in the coolant is essential.

If coolant containing a corrosion inhibitor is not used, the cooling system will accumulate rust and scale in the water jacket and radiator. This will block the coolant passages, and considerably reduce the efficiency of the cooling system.

The anti-freeze recommended in the Specification Section, mixed 50/50 with distilled water will provide the necessary corrosion inhibition.

Warning

Always use the anti-freeze in accordance with the instructions of the manufacturer.

Coolant mixture that contains anti-freeze and corrosion inhibitors contains toxic chemicals that are harmful to the human body. Never swallow anti-freeze or any of the motorcycle coolant.

Distilled water must be used to dilute coolant to the correct mixture ratio.

In an emergency, tap water can be added to the cooling system. However, the coolant must then be changed and returned to the correct mixture ratio using distilled water and new coolant as soon as possible.


Caution

Distilled water must be used to dilute coolant to the correct mixture ratio. If hard water is used in the cooling system, it will cause scale accumulation in the engine and radiator and considerably reduces the efficiency of the cooling system. Reduced cooling system efficiency may cause the engine to overheat and suffer severe damage.

Maintenance and Adjustment

Coolant Level Inspection

Daytona 675



- 1 Expansion tank
- 2 Tank cap
- 3 MAX mark
- 4 MIN mark


NOTE

- The coolant level should be checked when the engine is cold (at room or ambient temperature).

Position the motorcycle on level ground and in an upright position. The expansion tank can be viewed from the left hand of the motorcycle, between the rear of the lower fairing and the frame.

Check the coolant level in the expansion tank. The coolant level must be between the 'MAX' and 'MIN' marks. If the coolant is below the minimum level, the coolant level must be adjusted.

Street Triple



- 1 Expansion tank
- 2 Tank cap
- 3 MAX mark
- 4 MIN mark

NOTE

- The coolant level should be checked when the engine is cold (at room or ambient temperature).

Position the motorcycle on level ground and in an upright position.

Remove the seat. The expansion tank is positioned between the frame rails beneath the seat.

Check the coolant level in the expansion tank. The coolant level must be between the 'MAX' and 'MIN' marks. If the coolant is below the minimum level, the coolant level must be adjusted.

Maintenance and Adjustment

Coolant Level Adjustment

Warning

Do not remove the expansion tank or radiator pressure cap when the engine is hot. When the engine is hot, the coolant inside the expansion tank will be hot and also under pressure. Contact with this hot, pressurized coolant will cause scalds and skin damage.

Allow the engine to cool.

Daytona 675

The expansion tank cap can be removed from the left hand of the motorcycle, between the rear of the lower fairing and the frame.

Street Triple

Remove the seat to gain access to the expansion tank.

Remove the cap from the expansion tank, and add coolant mixture through the filler opening until the level reaches the 'MAX' mark. Install the cap.

NOTE

- **If the coolant level is being checked because the coolant has overheated, also check the level in the radiator and top-off if necessary.**

- **In an emergency, water alone can be added to the cooling system. However, the coolant must then be changed and returned to the correct mixture ratio using distilled water and new coolant as soon as possible.**

Coolant Change

Have the coolant changed by an authorized Triumph dealer in accordance with scheduled maintenance requirements.

Radiator and Hoses

Check the radiator hoses for cracks or deterioration, and hose clips for tightness in accordance with scheduled maintenance requirements. Have your authorized Triumph dealer replace any defective items.

Check the radiator grille and fins for obstructions by insects, leaves or mud. Clean off any obstructions with a stream of low-pressure water.

Warning

The fan operates automatically when the engine is running. Always keep hands and clothing away from the fan as contact with the rotating fan can cause injury.


Maintenance and Adjustment

Caution

Using high-pressure water sprays, such as from a car wash facility or household pressure washer, can damage the radiator fins, cause leaks and impair the radiator's efficiency.

Do not obstruct or deflect airflow through the radiator by installing unauthorized accessories, either in front of the radiator or behind the cooling fan. Interference with the radiator airflow can cause overheating, potentially resulting in engine damage.

Throttle Control



- 1 Throttle grip (Daytona 675 shown)
- 2 Correct setting 0.08-0.12 in (2-3 mm)

Warning

The throttle grip controls the throttle valves in the throttle bodies. If the throttle cables are incorrectly adjusted, either too tight or too loose, the throttle may be difficult to control and performance will be adversely affected.

Check the throttle grip free-play in accordance with scheduled maintenance requirements and make adjustments as necessary.

Maintenance and Adjustment

Warning

Always be alert for changes in the 'feel' of the throttle and have the throttle system checked by an authorized Triumph dealer if any changes are detected. Changes can be due to wear in the mechanism, which could lead to a sticking throttle.

An incorrectly adjusted, sticking or stuck throttle will lead to loss of motorcycle control and an accident.

Inspection

Warning

Use of the motorcycle with incorrectly adjusted, incorrectly routed, sticking or damaged throttle cables will interfere with the throttle function resulting in loss of motorcycle control and an accident.

To avoid incorrect adjustment, incorrect routing, or continued use of a sticking or damaged throttle, always have your throttle checked and adjusted by your authorized Triumph dealer.


Check that the throttle opens smoothly, without undue force and that it closes without sticking. Have your authorized Triumph dealer check the throttle system if a problem is detected or any doubt exists.

Check that there is 0.08-0.12 in (2-3 mm) of throttle grip free-play when lightly turning the throttle grip back and forth.

If there is an incorrect amount of free-play, Triumph recommends that you have adjustments made by your authorized Triumph dealer. However, in an emergency, throttle adjustment may be made as follows:

Maintenance and Adjustment

Adjustment



- 1 Opening cable adjuster
- 2 Closing cable adjuster
- 3 Closing cable - free play measurement point
- 4 Throttle grip (Daytona 675 shown)
- 5 Opening cable - free play measurement point

Remove the seat.

Disconnect the battery, negative (black) lead first.

Remove the fuel tank.

Remove the airbox.

Release the locknuts on the 'opening' cable adjusters.

Rotate the 'opening' cable adjuster at the throttle grip end such that it has an equal amount of adjustment in each direction.

Rotate the 'opening' cable adjuster at the throttle body end of the cable to give 0.08-0.12 in (2-3 mm) of play at the throttle grip. Tighten the locknut.

Make any minor adjustments as necessary to give 0.08-0.12 in (2-3 mm) of play using the adjuster near the throttle grip end of the cable. Tighten the adjuster locknut.

With the throttle fully closed, ensure that there is 0.08-0.12 in (2-3 mm) of free play in the 'closing' cable at the throttle cam attached to the throttle bodies. If necessary, adjust at the throttle body end in the same way as the 'opening' cable, until 0.08-0.12 in (2-3 mm) of play is present.

Tighten the adjuster locknuts.

Maintenance and Adjustment

Warning

Ensure that all the adjuster locknuts of all cables are tightened, as a loose locknut could result in a sticking throttle. An incorrectly adjusted, sticking or stuck throttle can lead to loss of motorcycle control and an accident.

Install the airbox.

Install the fuel tank.


Reconnect the battery, positive (red) lead first.

Install the seat.

Check that the throttle opens smoothly, without undue force and that it closes without sticking.

Ride carefully to your nearest authorized Triumph dealer and have them check the throttle system thoroughly before riding again.

Clutch



1 Clutch lever

2 0.08-0.12 in (2-3 mm)

The motorcycle is equipped with a cable-operated clutch.

If the clutch lever has excessive free-play, the clutch may not disengage fully. This will cause difficulty in shifting gear and selecting neutral. This may cause the engine to stall and make the motorcycle difficult to control.

Conversely, if the clutch lever has insufficient free-play the clutch may not engage fully, causing the clutch to slip, which will reduce performance and cause premature clutch wear.

Clutch lever free-play must be checked in accordance with scheduled maintenance requirements.

Maintenance and Adjustment

Inspection

Check that there is 0.08-0.12 in (2-3 mm) clutch lever free-play at the lever.

If there is an incorrect amount of free-play, adjustments must be made.

Adjustment

Loosen the knurled locknut at the lever end of the clutch cable and turn the adjuster sleeve until the correct amount of clutch lever free-play is achieved.

Tighten the knurled locknut against the clutch lever assembly.

If correct adjustment cannot be made using the lever adjuster, use the cable adjuster at the lower end of the cable.

Loosen the adjuster locknut.

Turn the outer cable adjuster to give 0.08-0.12 in (2-3 mm) of free-play at the clutch lever.

Tighten the locknut.

Drive Chain



For safety and to prevent excessive

wear the drive chain must be checked, adjusted and lubricated in accordance with scheduled maintenance requirements. Checking, adjustment and lubrication must be carried out more frequently for extreme conditions such as salty or heavily gritted roads.

If the chain is badly worn or incorrectly adjusted (either too loose or too tight) the chain could jump off the sprockets or break. Therefore, always replace worn or damaged chains using genuine Triumph parts supplied by an authorized Triumph dealer.

Warning

A loose or worn chain, or a chain that breaks or jumps off the sprockets could catch on the engine sprocket or lock the rear wheel.

A chain that snags on the engine sprocket will injure the rider and lead to loss of motorcycle control and an accident.

Similarly, locking the rear wheel will lead to loss of motorcycle control and an accident.

Maintenance and Adjustment

Chain Lubrication

Lubrication is necessary every 200 miles (300 kms) and also after riding in wet weather, on wet roads, or any time that the chain appears dry.

Use the special chain lubricant as recommended in the specification section.

Apply lubricant to the sides of the rollers then allow the motorcycle to stand unused for at least 8 hours (overnight is ideal). This will allow the oil to penetrate to the chain O-rings etc.


Before riding, wipe off any excess oil.

If the chain is especially dirty, clean first and then apply oil as mentioned above.

Caution

Do not use a pressure washer to clean the chain as this may cause damage to the chain components.

Chain Free – Movement Inspection



1 Maximum movement position

Warning

Before starting work, ensure the motorcycle is stabilized and adequately supported. This will help prevent injury to the operator or damage to the motorcycle.

Place the motorcycle on a level surface and hold it in an upright position with no weight on it.


Rotate the rear wheel by pushing the motorcycle to find the position where the chain is tightest, and measure the vertical movement of the chain midway between the sprockets.

Maintenance and Adjustment

Chain Free - Movement Adjustment

For Daytona 675 the vertical movement of the drive chain must be in the range 1.37-1.57 in (35-40 mm).

For Street Triple the vertical movement of the drive chain must be in the range 0.80-1.00 in (20-25 mm).



- 1 Adjuster bolt
- 2 Adjuster bolt locknut
- 3 Rear wheel spindle nut

Loosen the wheel spindle nut.

Release the locknuts on both the left hand and right hand chain adjuster bolts.

Moving both adjusters by an equal amount, turn the adjuster bolts clockwise to increase chain free movement and counter-clockwise to reduce chain free movement.

When the correct amount of chain free movement has been set, push

the wheel into firm contact with the adjuster. Tighten both adjuster locknuts to **20 lbf ft (27 Nm)** and the rear wheel spindle nut to **81 lbf ft (110 Nm)**.

Repeat the chain adjustment check. Re-adjust if necessary.

Warning

Operation of the motorcycle with insecure adjuster locknuts or a loose wheel spindle may result in impaired stability and handling of the motorcycle. This impaired stability and handling may lead to loss of control or an accident.


Check the rear brake effectiveness. Rectify if necessary.

Warning

It is dangerous to operate the motorcycle with defective brakes and you must have your authorized Triumph dealer take remedial action before you attempt to ride the motorcycle again. Failure to take remedial action may reduce braking efficiency leading to loss of control or an accident.

Maintenance and Adjustment

Chain and Sprocket Wear Inspection



- 1 Measure across 20 links
- 2 Weight

Remove the chain guard.


Stretch the chain taut by hanging a 20-40 lb (10-20 Kg) weight on the chain.

Measure the length of 20 links on the straight part of the chain from pin center of the 1st pin to the pin center of the 21st pin. Since the chain may wear unevenly, take measurements in several places.

If the length exceeds the maximum service limit of 12.56 in (319 mm), the chain must be replaced.

Rotate the rear wheel and inspect the drive chain for damaged rollers, and loose pins and links.

Also inspect the sprockets for unevenly or excessively worn or damaged teeth.



If there is any irregularity, have the drive chain and/or the sprockets replaced by an authorized Triumph dealer.

Install the chain guard.

Warning

The use of non-approved chains may result in a broken chain or may cause the chain to jump off the sprockets.

Use a genuine Triumph supplied chain as specified in the Triumph Parts Catalog.

Never neglect chain maintenance and always have chains installed by an authorized Triumph dealer.

Caution


If the sprockets are found to be worn, always replace the sprockets and drive chain together.

Replacing worn sprockets without also replacing the chain will lead to premature wear of the new sprockets.

Maintenance and Adjustment

Brakes

Brake Wear Inspection



- 1 Brake pads
- 2 Minimum thickness line

Brake pads must be inspected in accordance with scheduled requirements and replaced if worn to, or beyond the minimum service thickness.

If the lining thickness of any pad (front or rear brakes) is less than 0.06 in (1.5 mm), that is, if the pad has worn down to the bottom of the grooves, replace all the pads on the wheel.

Warning

Brake pads must always be replaced as a wheel set. At the front, where two calipers are fitted on the same wheel, replace all the brake pads in both calipers.

Replacing individual pads will reduce braking efficiency and may cause an accident.

After replacement brake pads have been fitted, ride with extreme caution until the new pads have 'broken in'.

Brake Pad Wear Compensation

Disc and brake pad wear is automatically compensated for and has no effect on the brake lever or pedal action. There are no parts that require adjustment on the front and rear brakes.

Maintenance and Adjustment

Warning

If the brake lever or pedal feels soft when it is applied, or if the lever/pedal travel becomes excessive, there may be air in the brake lines and hoses or the brakes may be defective.

It is dangerous to operate the motorcycle under such conditions and your authorized Triumph dealer must rectify the fault before riding.

Riding with defective brakes may lead to loss of motorcycle control and an accident.

Disc Brake Fluid

Inspect the level of brake fluid in both reservoirs and change the brake fluid in accordance with scheduled maintenance requirements. Use only DOT 4 fluid as recommended in the specification section. The brake fluid must also be changed if it becomes, or is suspected of having become contaminated with moisture or any other contaminants.

Warning

Brake fluid is hygroscopic which means it will absorb moisture from the air.

Any absorbed moisture will greatly reduce the boiling point of the brake fluid causing a reduction in braking efficiency.

Because of this, always replace brake fluid in accordance with scheduled maintenance requirements.

Always use new brake fluid from a sealed container and never use fluid from an unsealed container or from one which has been previously opened.

Do not mix different brands or grades of brake fluid.


Check for fluid leakage around brake fittings, seals and joints and also check the brake hoses for splits, deterioration and damage.

Always rectify any faults before riding.

Failure to observe and act upon any of these items may cause a dangerous riding condition leading to loss of control and an accident.

Maintenance and Adjustment

Front Brake Fluid Level Inspection and Adjustment - Daytona 675



- 1 Front brake fluid reservoir, upper level line
- 2 Lower level line
- 3 Safety clip

The brake fluid level in the reservoirs must be kept between the upper and lower level lines (reservoir held horizontal).

Remove the safety clip.


Remove the reservoir cover.

Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.

Install the reservoir cover ensuring that the diaphragm seal is correctly installed.

Install the safety clip.

Front Brake Fluid Level Inspection and Adjustment - Street Triple



- 1 Front brake fluid reservoir, upper level line
- 2 Lower level line

The brake fluid level in the reservoirs must be kept between the upper and lower level lines (reservoir held horizontal).

To inspect the fluid level, check the level of fluid visible in the window at the front of the reservoir body.

To adjust the fluid level, loosen the cap screws and detach the cover noting the position of the sealing diaphragm.


Fill the reservoir to the upper level line using new DOT 4 fluid from a sealed container.

Install the cover, ensuring that the diaphragm seal is correctly positioned between the cap and reservoir body. Tighten the cap fasteners.

Maintenance and Adjustment

Rear Brake Fluid Inspection and Adjustment

Both models



- 1 Rear brake fluid reservoir, upper level line
- 2 Lower level line

Brake Light Switches

The brake light is activated independently by either the front or rear brake. If, with the ignition in the 'ON' position, the brake light does not work when the front brake lever is pulled or the rear brake pedal is pressed, have your authorized Triumph dealer investigate and rectify the fault.

Warning

Riding the motorcycle with defective brake lights is illegal and dangerous.

An accident causing injury to the rider and other road users may result from use of a motorcycle with defective brake lights.


Warning

If there has been an appreciable drop in the level of the fluid in either fluid reservoir, consult your authorized Triumph dealer for advice before riding. Riding with depleted brake fluid levels, or with a brake fluid leak is dangerous and will cause reduced brake performance potentially leading to loss of motorcycle control and an accident.

Maintenance and Adjustment

Windshield Cleaning

Daytona 675 only



Clean the windshield with a solution of mild soap or detergent and lukewarm water. After cleaning, rinse well and then dry with a soft, lint free cloth.

Caution

Products such as window cleaning fluids, insect remover, rain repellent, scouring compounds, gasoline or strong solvents such as alcohol, acetone, carbon tetrachloride, etc. will damage the windshield. Never allow these products to contact the screen.

If the transparency of the windshield is reduced by scratches or oxidation which cannot be removed, the windshield must be replaced.

Warning

Never attempt to clean the windshield while the motorcycle is in motion as releasing the handlebars may cause loss of vehicle control and an accident. Operation of the motorcycle with a damaged or scratched windshield will reduce the rider's forward vision. Any such reduction in forward vision is dangerous and may lead to an accident causing injury or death.

Caution

Corrosive chemicals such as battery acid will damage the windshield. Never allow corrosive chemicals to contact the windshield.

Maintenance and Adjustment

Steering/Wheel Bearings

Caution

To prevent risk of injury from the motorcycle falling during the inspection, ensure that the motorcycle is stabilized and secured on a suitable support. Do not exert extreme force against each wheel or rock each wheel vigorously as this may cause the motorcycle to become unstable and cause injury by falling from its support.

Ensure that the position of the support block will not cause damage to the sump.


Steering Inspection

Lubricate and inspect the condition of the steering (steering head) bearings in accordance with scheduled maintenance requirements.

NOTE

- **Always inspect the wheel bearings at the same time as the steering bearings.**

Inspecting the Steering (steering head) Bearings for Free-Play



Inspecting the steering for free-play (Daytona 675 shown)

Inspection

Position the motorcycle on level ground, in an upright position.

Raise the front wheel above the ground and support the motorcycle.

Standing at the front of the motorcycle, hold the lower end of the front forks and try to move them forward and backward.

If any free-play can be detected in the steering (steering head) bearings, ask your authorized Triumph dealer to inspect and rectify any faults before riding.

Maintenance and Adjustment

Warning

Riding the motorcycle with incorrectly adjusted or defective steering (steering head) bearings is dangerous and may cause loss of motorcycle control and an accident.

Remove the support and place the motorcycle on the side stand.

Wheel Bearings Inspection

If the wheel bearings in the front or rear wheel allow play in the wheel hub, are noisy, or if the wheel does not turn smoothly, have your authorized Triumph dealer inspect the wheel bearings.

The wheel bearings must be inspected at the intervals specified in the scheduled maintenance chart.

Position the motorcycle on level ground, in an upright position.

Raise the front wheel above the ground and support the motorcycle.

Standing at the side of the motorcycle, gently rock the top of the front wheel from side to side.

If any free-play can be detected, ask your authorized Triumph dealer to inspect and rectify any faults before riding.

Reposition the lifting device and repeat the procedure for the rear wheel.

Warning

Operation with worn or damaged front or rear wheel bearings is dangerous and may cause impaired handling and instability leading to an accident. If in doubt, have the motorcycle inspected by an authorized Triumph dealer before riding.

Remove the support and place the motorcycle on the side stand.

Maintenance and Adjustment

Front Suspension

Front Fork Inspection

Examine each fork for any sign of damage, scratching of the slider surface, or for oil leaks.

If any damage or leakage is found consult an authorized Triumph dealer.

To check that the forks operate smoothly:

- Position the motorcycle on level ground.
- While holding the handlebars and applying the front brake, pump the forks up and down several times.
- If roughness or excessive stiffness is detected, consult your authorized Triumph dealer.
- The suspension movement will be affected by adjustment settings (Daytona 675 only).

Warning

Riding the motorcycle with defective or damaged suspension is dangerous and may lead to loss of control and an accident.

Warning

Never attempt to dismantle any part of the suspension units, as all units contain pressurized oil. Skin and eye damage can result from contact with the pressurized oil.

Maintenance and Adjustment

Suspension Setting Chart - Daytona 675 only

NOTE

- The Street Triple model has no front suspension adjustment.

LOADING		FRONT			REAR	
		Spring Pre-Load*	Rebound Damping*	Compression Damping*	Rebound Damping*	Compression Damping*
Solo Riding	Standard	5	6	7	6	11
	Softer	6	7	8	7	12
	Firmer	4	5	6	5	10
Rider and Passenger		4	5	6	5	10

* Number of adjuster turns out from the fully screwed in position.

NOTE

- This chart is only a guide. Setting requirements may vary for rider weight and personal preferences. See the following pages for information regarding suspension adjustment.

The standard suspension settings provide a comfortable ride and good handling characteristics for general, solo riding. The chart shows suggested settings for the front and rear suspension.


Warning

Ensure that the correct balance between front and rear suspension is maintained. Suspension imbalance could significantly change handling characteristics leading to loss of control and an accident. Refer to the chart above for further information or consult your dealer.

Warning

Ensure that the adjusters are set to the same setting on both forks. Settings which vary from left to right could significantly change handling characteristics leading to loss of control and an accident.

Front Suspension Settings Daytona 675 only



- 1 Spring pre-load adjuster
- 2 Rebound damping force adjuster

Maintenance and Adjustment

Spring Pre-Load Adjustment

The spring pre-load adjusters are located at the top of each fork.

To change the spring pre-load, rotate the adjuster clockwise to increase pre-load, or counter-clockwise to decrease pre-load. Always set the pre-load adjusters such that there are an equal number of graduation lines visible on both forks.

NOTE

- The motorcycle is delivered from the factory with the spring pre-load set at position 5.

Rebound Damping Adjustment

The rebound damping adjusters are located at the top of each fork.


To change the rebound damping force, rotate the slotted adjuster clockwise to increase, or counter-clockwise to decrease. Always count the turns out from the screwed fully in position and set both forks to the same setting.

NOTE

- The motorcycle is delivered from the factory with the rebound set at position 6.

Compression Damping Adjustment

The compression damping adjuster is located near the bottom of both forks, adjacent to the wheel spindle.



1 Compression damping force adjuster

To change the compression damping force rotate the slotted adjuster clockwise to increase, or counter-clockwise to decrease. Always count the number of turns out from the fully screwed in position and set both forks to the same setting.

NOTE

- The motorcycle is delivered from the factory with the compression damping set at position 7.

Maintenance and Adjustment

Rear Suspension Adjustment


NOTE

- The Street Triple model has no rear suspension adjustment.

Daytona 675 only

The rear suspension unit is adjustable for both rebound and compression damping.

Rebound Damping Adjustment



1 Rebound damping adjuster


The rebound damping adjuster is located at the bottom of the rear suspension unit on the left hand side of the motorcycle.

To adjust the rebound damping setting, rotate the adjuster clockwise to increase rebound damping and counter-clockwise to decrease.

NOTE

- The motorcycle is delivered from the factory with the rebound adjuster set at position 6.

Compression Damping Adjustment



1 Compression damping adjuster

The compression damping adjuster is situated adjacent to the rear suspension unit reservoir.

To adjust the compression damping setting rotate the slotted adjuster clockwise to increase, or counter-clockwise to decrease.

NOTE


- The motorcycle is delivered from the factory with the compression damping set at position 11.

Warning

The rear suspension unit spring pre-load is not rider adjustable. Any attempt to adjust the spring pre-load could result in a dangerous riding condition leading to loss of control and an accident.

Maintenance and Adjustment

Tires



Tire marking




This motorcycle is equipped with

tubeless tires, valves and wheel rims. Use only tires marked 'TUBELESS' and tubeless valves on rims marked 'SUITABLE FOR TUBELESS TYRES'.

Tire Inflation Pressures

Correct inflation pressure will provide maximum stability, rider comfort and tire life. Always check tire pressures before riding when the tires are cold. Check tire pressures daily and adjust if necessary. See the specification section for details of the correct inflation pressures.



Wheel marking

Warning

Incorrect tire inflation will cause abnormal tread wear and instability problems that may lead to loss of control and an accident. Under-inflation may result in the tire slipping on, or coming off the rim. Over-inflation will cause instability and accelerated tread wear. Both conditions are dangerous as they may cause loss of control leading to an accident.

Tire Wear

As the tire tread wears down, the tire becomes more susceptible to punctures and failure. It is estimated that 90% of all tire problems occur during the last 10% of tread life (90% worn). It is therefore not recommended to use tires until they are worn to their minimum.

Maintenance and Adjustment

Minimum Tread Depth Recommended

In accordance with the periodic maintenance chart, measure the depth of the tread with a depth gauge, and replace any tire that has worn to, or beyond the minimum allowable tread depth specified in the table below:

Under 80 mph (130 km/h)	0.08 in (2 mm)
Over 80 mph (130 km/h)	Rear 0.12 in (3 mm) Front 0.08 in (2 mm)

Warning

This motorcycle must not be operated above the legal road speed limit except in authorized closed course conditions.

Warning

Only operate this Triumph motorcycle at high speed in closed course on-road competition or on closed course race tracks. High speed operation should only then be attempted by riders who have been instructed in the techniques necessary for high speed riding and are familiar with the motorcycle's characteristics in all conditions. High speed operation in any other circumstances is dangerous and will lead to loss of motorcycle control and an accident.

Warning

Operation with excessively worn tires is hazardous and will adversely affect traction, stability and handling which may lead to loss of control and an accident. When tubeless tires become punctured, leakage is often very slow. Always inspect tires very closely for punctures. Check the tires for cuts, embedded nails or other sharp objects. Operation with punctured or damaged tires will adversely affect motorcycle stability and handling which may lead to loss of control or an accident.
/continued

Maintenance and Adjustment

Warning

/continued

Check the rims for dents or deformation. Operation with damaged or defective wheels or tires is dangerous and loss of motorcycle control or an accident could result.

Always consult your authorized Triumph dealer for tire replacement, or for a safety inspection of the tires.

Tire Replacement

All Triumph motorcycles are carefully and extensively tested in a range of riding conditions to ensure that the most effective tire combinations are approved for use on each model. It is essential that approved tires, fitted in approved combinations, are used when purchasing replacement tires. The use of non-approved tires, or approved tires in non-approved combinations, may lead to motorcycle instability and an accident. See the specification section for details of approved tire combinations. Always have tires installed and balanced by your authorized Triumph dealer who has the necessary training and skills to ensure safe, effective installation.

Warning

If a tire sustains a puncture, the tire must be replaced. Failure to replace a punctured tire, or operation with a repaired tire can lead to instability, loss of control or an accident.

Warning

Do not install tube-type tires on tubeless rims. The bead will not seat and the tires could slip on the rims, causing rapid tire deflation that may result in a loss of vehicle control and an accident. Never install an inner tube inside a tubeless tire. This will cause friction inside the tire and the resulting heat build-up may cause the tube to burst resulting in rapid tire deflation, loss of vehicle control and an accident.

Warning

If tire damage is suspected, such as after striking the curb, ask your authorized Triumph dealer to inspect the tire both internally and externally. Remember, tire damage may not always be visible from the outside. Operation of the motorcycle with damaged tires could lead to loss of control and an accident.

Maintenance and Adjustment

Warning

When replacement tires are required, consult your authorized Triumph dealer who will arrange for the tires to be selected, in a correct combination, from the approved list and fitted according to the tire manufacturer's instructions.

When tires are replaced, allow time for the tires to seat to the rim (approximately 24 hours). During this seating period, ride cautiously as an incorrectly seated tire could cause loss of control or an accident.

Initially, the new tires will not produce the same handling characteristics as the worn tires and the rider must allow adequate riding distance (approximately 100 miles) to become accustomed to the new handling characteristics.

24 hours after fitting, the tire pressures must be checked and adjusted, and the tires examined for correct seating. Rectification must be carried out as necessary. The same checks and adjustments must also be carried out when 100 miles have been travelled after fitting.

Use of a motorcycle with incorrectly seated tires, incorrectly adjusted tire pressures, or when not accustomed to its handling characteristics may lead to loss of control and an accident.

Warning

Tires that have been used on a rolling road dynamometer may become damaged. In some cases, the damage may not be visible on the external surface of the tire. Tires must be replaced after such use as continued use of a damaged tire may lead to instability, loss of control and an accident.

Warning

Accurate wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any wheel balance weights. Incorrect wheel balance may cause instability leading to loss of control and an accident.

When wheel balancing is required, such as after tire replacement, see your authorized Triumph dealer.

Only use self-adhesive weights. Clip on weights may damage the wheel and tire resulting in tire deflation, loss of control and an accident.

Maintenance and Adjustment

Battery

Warning

Under some circumstances, the battery can give off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space. The battery contains sulphuric acid (battery acid). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield. If battery acid gets on your skin, flush with water immediately. If battery acid gets in your eyes, flush with water for at least 15 minutes and SEEK MEDICAL ATTENTION IMMEDIATELY. If battery acid is swallowed, drink large quantities of water and SEEK MEDICAL ATTENTION IMMEDIATELY. KEEP BATTERY ACID OUT OF THE REACH OF CHILDREN.


Warning

The battery contains harmful materials. Always keep children away from the battery whether or not it is fitted in the motorcycle. Do not attach jump leads to the battery, touch the battery cables together or reverse the polarity of the cables as any of these actions may cause a spark which would ignite battery gases causing a risk of personal injury.

Maintenance and Adjustment

Battery Removal

Daytona 675



- 1 Battery
- 2 Negative (black) terminal
- 3 Positive (red) terminal
- 4 Battery strap

Disconnect the battery leads, negative (black) lead first.

Take the battery out of the case.


Warning

Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark, which would ignite battery gases causing a risk of personal injury.

Battery Disposal

Should the battery ever require replacement, the original battery must be handed to a recycling agent who will ensure that the dangerous substances from which the battery is manufactured do not pollute the environment.

Street Triple



- 1 Battery
- 2 Negative (black) terminal
- 3 Positive (red) terminal
- 4 Battery strap

Battery Maintenance

Clean the battery using a clean, dry, cloth. Be sure that the cable connections are clean.

Warning

The battery acid is corrosive and poisonous and will cause damage to unprotected skin. Never swallow battery acid or allow it to come into contact with the skin. To prevent injury, always wear eye and skin protection when handling the battery.

Remove the rider's seat.

Remove the battery strap.

Maintenance and Adjustment

The battery is a sealed type and does not require any maintenance other than checking the voltage and routine recharging when required, such as during storage.

It is not possible to adjust the battery acid level in the battery; the sealing strip must not be removed.

Battery Discharge



Caution

The charge level in the battery must be maintained to maximize battery life.

Failure to maintain the battery charge level could cause serious internal damage to the battery.

Under normal conditions, the motorcycle charging system will keep the battery fully charged. However, if the motorcycle is unused, the battery will gradually discharge due to a normal process called self discharge; the clock, engine control module (ECM) memory, high ambient temperatures, or the addition of electrical security systems or other electrical accessories will all increase this rate of battery discharge. Disconnecting the battery from the motorcycle during storage will reduce the rate of discharge.

Battery Maintenance During Motorcycle Storage

During storage or infrequent use of the motorcycle, inspect the battery voltage weekly using a digital multimeter. Follow the manufacturer's instructions supplied with the meter.

Should the battery voltage fall below 12.7 Volts, the battery should be charged (see page 106).

Allowing a battery to discharge or leaving it discharged for even a short period of time causes sulphation of the lead plates. Sulphation is a normal part of the chemical reaction inside the battery, however over time the sulphate can crystallize on the plates making recovery difficult or impossible. This permanent damage is not covered by the motorcycle warranty, as it is not due to a manufacturing defect.

Keeping the battery fully charged reduces the likelihood of it freezing in cold conditions. Allowing a battery to freeze will cause serious internal damage to the battery.

Maintenance and Adjustment

Battery Charging

For help with selecting a battery charger, checking the battery voltage or battery charging, contact your local authorized Triumph dealer.

Warning

The battery gives off explosive gases; keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using the battery in an enclosed space. The battery contains sulphuric acid (battery acid). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.

If battery acid gets on your skin, flush with water immediately.

If battery acid gets in your eyes, flush with water for at least 15 minutes and SEEK MEDICAL ATTENTION IMMEDIATELY.

If battery acid is swallowed, drink large quantities of water and SEEK MEDICAL ATTENTION IMMEDIATELY.

KEEP BATTERY ACID OUT OF THE REACH OF CHILDREN

Caution

Do not use an automotive quick charger as it may overcharge and damage the battery.

Should the battery voltage fall below 12.7 Volts, the battery should be charged using a Triumph approved battery charger. Always follow the instructions supplied with the battery charger.

For extended periods of storage (beyond two weeks) the battery should be removed from the motorcycle and kept charged using a Triumph approved maintenance charger.

Similarly, should the battery charge fall to a level where it will not start the motorcycle, remove the battery from the motorcycle before charging.

Maintenance and Adjustment

Battery Installation

Warning

Ensure that the battery terminals do not touch the motorcycle frame as this may cause a short circuit or spark, which would ignite battery gases causing a risk of personal injury.

Place the battery in the battery case.
Reconnect the battery, positive (red) lead first.

Apply a light coat of grease to the terminals to prevent corrosion.


Cover the positive terminal with the protective cap.

Install the battery strap.

Install the rider's seat.

Fuse Box

Daytona 675



Arrowed: Fuse box

The fuse box is located beneath the left hand cockpit infill panel.


To allow access to the fuse box, the cockpit infill panel must be removed.

Warning

Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating. Use of an incorrect fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.

Maintenance and Adjustment

Street Triple




Arrowed: Fuse box

The fuse box is located beneath the fuel tank.


To access the fuse box, remove the seat.

Remove the fuel tank support from its location in the seat base.



- 1 Fuel tank support
- 2 Seat

Remove the front fuel tank fasteners and pivot the fuel tank upwards at the front. While holding the fuel tank in the raised position, locate the fuel tank support into the fuel tank fastener points on the frame and fuel tank.



- 1 Fuel tank support
- 2 Fuel tank
- 3 Fastener point, fuel tank
- 4 Fastener point, frame

Warning

Always replace blown fuses with new ones of the correct rating (as specified on the fuse box cover) and never use a fuse of higher rating. Use of an incorrect fuse could lead to an electrical problem, resulting in motorcycle damage, loss of motorcycle control and an accident.

Maintenance and Adjustment


Fuse Identification

A blown fuse is indicated when all of the systems protected by that fuse become inoperative. When checking for a blown fuse, use the tables to establish which fuse has blown.

The fuse identification numbers listed in the tables correspond with those printed on the fuse box cover, as shown. Spare fuses are located at right angles to the main fuses and should be replaced if used.

Daytona 675


Circuit Protected	Position	Rating (Amps)
Dip and main beam headlights, starter relay	1	15
Ignition switch, starter circuit	2	10
Auxiliary lighting	3	5
Horn, turn signals, alarm	4	10
Cooling fan	5	15
Engine management	6	20



- 1 Fuse box
- 2 Fuse box cover
- 3 Spare fuses

Street Triple

Circuit Protected	Position	Rating (Amps)
Dip and main beam headlights, starter relay	1	20
Ignition switch, starter circuit	2	10
Auxiliary lighting	3	5
Horn, turn signals, alarm	4	10
Cooling fan	5	15
Engine management	6	20



- 1 Fuse box
- 2 Fuse box cover
- 3 Spare fuses

NOTE:

- The starter solenoid has an additional 30 Amp fuse, attached directly to the solenoid, beneath the rider's seat.

Maintenance and Adjustment

Headlights

Headlights

Warning

Adjust road speed to suit the visibility and weather conditions in which the motorcycle is being operated.
Ensure that the beams are adjusted to illuminate the road surface sufficiently far ahead without blinding oncoming traffic. An incorrectly adjusted headlight may impair visibility causing an accident.

Warning

Never attempt to adjust a headlight beam when the motorcycle is in motion. Any attempt to adjust a headlight beam when the motorcycle is in motion may result in loss of control and an accident.


Caution

If the motorcycle is to be used under closed-course conditions, you may be asked to tape the visible outer surface of the headlight.
When taped, the headlight will overheat and distort the outer surface. Therefore, to avoid headlight distortion, always disconnect the headlights when they are taped for use under closed course-conditions.

Maintenance and Adjustment

Headlight Adjustment Daytona 675

Each headlight can be adjusted by means of vertical and horizontal adjustment screws located on the rear of each headlight.



- 1 Horizontal adjustment screw (Left hand)
- 2 Vertical adjustment screw (Left hand)
- 3 Horizontal adjustment screw (Right hand)
- 4 Vertical adjustment screw (Right hand)
- 5 Pivot screws (**DO NOT adjust these screws**)

Switch the headlight dipped beam on.

Caution

Do not adjust the pivot screws as this will cause the headlight reflector to become detached from the pivot screw, leading to irreparable damage to the headlight.

Turn the vertical adjustment screws on each headlight clockwise to raise the beam or counter-clockwise to lower the beam.

On the right hand headlight turn the horizontal adjustment screw clockwise to move the beam to the left or counter-clockwise to move the beam to the right.

On the left hand headlight turn the horizontal adjustment screw clockwise to move the beam to the right or counter-clockwise to move the beam to the left.

Switch the headlights off when the beam settings are satisfactory.

Maintenance and Adjustment

Headlight Adjustment Street Triple

Vertical Adjustment



1 Vertical beam adjuster cover fasteners

The vertical beams of the left hand and right hand headlights can only be adjusted together. Independent adjustment is not possible.

Switch the headlight dipped beam on.

Remove the adjuster cover.

Loosen the clamp bolt sufficient to allow restricted movement of the headlights.

Adjust the position of the headlights to give the required beam setting.


Tighten the clamp bolt to **11 lbf ft (15 Nm)**.

Re-check the headlight beam settings.

Switch the headlights off when both beam settings are satisfactorily set.

Install the adjuster cover.

Horizontal Adjustment



1 Horizontal beam adjusters

The horizontal beams of both headlights can be adjusted individually. The same procedure is used to adjust either headlight.

Switch the headlight dipped beam on.

Loosen the headlight bowl fastener.

Adjust the horizontal position of the headlight to give the required beam setting.

Tighten the clamp bolt to **11 lbf ft (15 Nm)**.

Repeat for the second headlight.

Re-check the headlight beam settings.

Switch the headlights off when both beam settings are satisfactorily set.


Maintenance and Adjustment

Headlight Bulb Replacement Daytona 675

Caution

The use of non-approved headlight bulbs may result in damage to the headlight lens.
Use a genuine Triumph supplied headlight bulb as specified in the Triumph Parts Catalog.
Always have replacement headlight bulbs installed by an authorized Triumph dealer.

It is not necessary to remove the headlight when bulb replacement becomes necessary.



- 1 Headlight unit
- 2 Bulb retainer (right hand shown)

Warning

The bulbs become hot during use. Always allow sufficient time for the bulb to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before reuse.

To replace a bulb:

Remove the rider's seat.

Disconnect the battery, negative (black) lead first.

Remove the four screws and remove the bulb cover from the bulb to be replaced.

Disconnect the multi-plug from the bulb retainer.


Detach the bulb retainer from the headlight assembly by rotating it counter-clockwise.

Remove the bulb from the bulb retainer.

Installation is the reverse of the removal procedure.

Maintenance and Adjustment

Position Lamp Bulb Replacement




- 1 Bulb holder
- 2 Position lamp bulb

The position lamps are fitted to the left and right of each headlight. To replace a bulb, remove the two screws and remove the bulb cover, detach the rubber retainer from the headlight and pull out the bulb.

Installation is the reverse of the removal procedure.

Headlight Bulb Replacement Street Triple



- 1 Headlight bulb
- 2 Bulb clip
- 3 Position lamp bulb

Warning

The bulbs become hot during use. Always allow sufficient time for the bulbs to cool before handling. Avoid touching the glass part of the bulb. If the glass is touched or gets dirty, clean with alcohol before re-use.

Remove the seat.

Disconnect the battery, negative (black) lead first.

Undo the fastener securing the headlight clamp to the headlight body.

Support the headlight while removing the clamp.

Maintenance and Adjustment

Remove the headlight from its bowl while supporting it to prevent the cables from being over extended.

Disconnect the multi-pin electrical connector from the bulb to be replaced and remove the rubber cover.

Detach the wire retainer from its clip (do not remove the screw) then remove the bulb from the light unit.

Position Lamp Bulb Replacement

To remove the position lamp bulb:

Without pulling the wires, ease the bulb holder from its socket. The bulb is removed from its holder by pulling gently upwards.

Installation for both bulbs is the reverse of the removal procedure. Tighten the headlight clamp to **35 lbf in (4 Nm)**.

Warning

Do not reconnect the battery until the assembly process has been completed. Premature battery reconnection could result in ignition of the battery gases causing risk of injury.

Caution

When reconnecting the battery, connect the positive (red) lead first.

Brake/Tail Light


Both models

Brake/Tail Light Replacement

The brake/tail light unit is a sealed, maintenance free LED unit.

Turn Signal Lights

Bulb Replacement - Daytona 675




- 1 Turn signal lens
- 2 Securing screw

The lens on each turn signal light is held in place by a securing screw located in the body of the light.

Release the screw and remove the lens to gain access to the bulb for replacement.

Maintenance and Adjustment

Bulb Replacement - Street Triple



- 1 Turn signal lens
- 2 Securing screw

The lens on each turn signal light is held in place by a securing screw located in the lens of the light.

Release the screw and remove the lens to gain access to the bulb for replacement.

License Plate Light

Both models

Bulb Replacement

Carefully remove the rubber bulb retainer from the back of the license plate light unit and detach the bulb.

Caution

To avoid cable damage, do not pull the bulb retainer using the cables.

Installation is the reverse of the removal procedure.

Cleaning

Frequent, regular cleaning is an essential part of the maintenance of your motorcycle. If regularly cleaned, the appearance will be preserved for many years. Cleaning with cold water containing an automotive cleaner is essential at all times but particularly so after exposure to sea breezes, sea water, dusty or muddy roads and in winter when roads are treated for ice and snow. Do not use household detergent, as the use of such products will lead to premature corrosion.

Although, under the terms of your motorcycle warranty, cover is provided against the corrosion of certain items, the owner is expected to observe this reasonable advice which will safeguard against corrosion and enhance the appearance of the motorcycle.

Maintenance and Adjustment

Preparation for Washing

Before washing, precautions must be taken to keep water off the following places.

Rear opening of the exhausts: Cover with a plastic bag secured with rubber bands.

Clutch and brake levers, switch housings on the handlebar: Cover with plastic bags.

Ignition switch and steering lock: Cover the keyhole with tape.

Remove any items of jewelry such as rings, watches, zips or belt buckles, which may scratch or otherwise damage painted or polished surfaces.

Use separate cleaning sponges or cleaning cloths for washing painted/polished surfaces and chassis areas. Chassis areas (such as wheels and under mudguards) will be exposed to more abrasive road grime and dust, which may then scratch painted or polished surfaces, if the same sponge or cleaning cloths are used.

Where to be Careful

Avoid spraying water with any great force near the following places:

- Instruments.
- Brake cylinders and brake calipers.
- Under the fuel tank.
- Steering Head bearings.
- Air intake duct above the headlights.

Caution

Any water sprayed around the air intake duct could enter the airbox and engine, causing damage to both items.

Caution

Use of high-pressure spray washers is not recommended. When using pressure washers, water may be forced into bearings and other components causing premature wear from corrosion and loss of lubrication.

NOTE

- **Use of soaps that are highly alkaline will leave a residue on painted surfaces, and may also cause water spotting. Always use a low alkaline soap to aid the cleaning process.**

Maintenance and Adjustment

After Washing

Remove the plastic bags and tape, and clear the air intakes.

Lubricate the pivots, bolts and nuts.

Test the brakes before motorcycle operation.

Start the engine and run it for 5 minutes. Ensure adequate ventilation for the exhaust fumes.

Use a dry cloth to absorb water residue. Do not allow water to stand on the machine as this will lead to corrosion.



Warning

Never wax or lubricate the brake discs. Loss of braking power and an accident could result. Clean the disc with a proprietary brand of oil free brake disc cleaner.

Unpainted aluminum Items

Items such as brake and clutch levers must be correctly cleaned to preserve their appearance.

Use a proprietary brand of aluminum cleaner which does not contain abrasive or caustic elements.

Clean aluminum items regularly, in particular after use in inclement weather, where the components must be hand washed and dried each time the machine is used.

Warranty claims due to inadequate maintenance will not be allowed.

Cleaning of the Exhaust System

All parts of the exhaust system of your motorcycle must be cleaned regularly to avoid a deterioration of its appearance.

NOTE

- **The exhaust system must be cool before washing to prevent water spotting.**

Washing

Prepare a mixture of cold water and mild automotive cleaner. Do not use a highly alkaline soap as commonly found at commercial car washes because it leaves a residue.

Wash the exhaust system with a soft cloth. Do not use an abrasive scouring pad or steel wool. They will damage the finish.

Rinse the exhaust system thoroughly.

Ensure no soap or water enters the mufflers.

Drying

Dry the exhaust system as far as possible with a soft cloth. Do not run the engine to dry the system or spotting will occur.

Maintenance and Adjustment

Protecting

When the exhaust system is dry, rub 'Motorex 645 Clean and Protect' into the surface.

It is recommended that regular protection be applied to the system as this will both protect and enhance the system's appearance.



Caution

The use of products containing silicone will cause discoloration of the chrome and must not be used. Similarly, the use of abrasive cleaners and polishes will damage the system and must not be used.

Maintenance and Adjustment

This page intentionally left blank

STORAGE

Preparation for Storage

Clean and dry the entire vehicle thoroughly.

Fill the fuel tank with the correct grade of unleaded fuel and add a fuel stabilizer (if available), following the fuel stabilizer manufacturer's instructions.

Warning

Gasoline is extremely flammable and can be explosive under certain conditions. Turn the ignition switch OFF. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

Remove the spark plug from each cylinder and put several drops (0.16 fl oz (5 ml)) of engine oil into each cylinder. Cover the spark plug holes with a piece of cloth or rag. With the engine stop switch in the 'RUN' position, push the starter button for a few seconds to coat the cylinder walls with oil. Install the spark plugs, tightening to **9 lbf ft (12 Nm)**.

Change the engine oil and filter (see page [75](#)).

Check and if necessary correct the tire pressures (see page [125](#)).

Set the motorcycle on stand so that both wheels are raised off the ground. (If this cannot be done, put boards under the front and rear wheels to keep dampness away from the tires).

Spray rust inhibiting oil (there are a host of products on the market and your dealer will be able to offer you local advice) on all unpainted metal surfaces to prevent rusting. Prevent oil from getting on rubber parts, brake discs or in the brake calipers.

Lubricate and if necessary adjust the drive chain (see page [85](#)).

Make sure the cooling system is filled with a 50% mixture of anti-freeze and distilled water solution (see page [77](#)).

Remove the battery, and store it where it will not be exposed to direct sunlight, moisture, or freezing temperatures. During storage it should be given a slow charge (one ampere or less) about once every two weeks (see page [103](#)).

Storage

Store the motorcycle in a cool, dry area, away from sunlight, and with a minimum daily temperature variation.

Put a suitable porous cover over the motorcycle to keep dust and dirt from collecting on it. Avoid using plastic or similar non-breathable, coated materials that restrict air flow and allow heat and moisture to accumulate.

Preparation after Storage

Install the battery (if removed) (see page [107](#)).

If the motorcycle has been stored for more than four months, change the engine oil (see page [75](#)).

Check all the points listed in the daily safety checks section.

Before starting the engine, remove the spark plugs from each cylinder.

Put the side stand down.

Crank the engine on the starter motor several times until the oil pressure light goes out.

Replace the spark plugs, tightening to **9 lbf ft (12 Nm)**, and start the engine.

Check and if necessary correct the tire pressures (see page [125](#)).

Clean the entire vehicle thoroughly.

Check the brakes for correct operation.

Test ride the motorcycle at low speeds.

Specifications

SPECIFICATIONS

Daytona 675

Street Triple

Dimensions

Overall length	79.1 in (2010 mm)	. . .	78.7 in (2000 mm)
Overall width	27.5 in (700 mm)	. . .	29.5 in (750 mm)
Overall height	44.1 in (1120 mm)	. . .	45.8 in (1165 mm)
Wheelbase	54.9 in (1395 mm)	. . .	54.7 in (1390 mm)
Seat height	32.5 in (825 mm)	. . .	31.8 in (810 mm)

Weights

Dry Weight	363.7 lb (165 kg)	. . .	368.2 lb (167 kg)
Maximum Payload	430 lb (195 kg)	. . .	430 lb (195 kg)

Engine

Type	In-line 3 cylinder	. . .	In-line 3 cylinder
Displacement	41.2 cu in (674.8 cc)	. . .	41.2 cu in (674.8 cc)
Bore x Stroke	2.91 in x 2.06 in	. . .	2.91 in x 2.06 in
.	(74 x 52.3 mm)	. . .	(74 x 52.3 mm)
Compression Ratio	12.65:1	12.65:1
Cylinder Numbering	Left to Right	Left to Right
Cylinder Sequence	1 at left	1 at left
Firing Order	1-2-3	1-2-3
Starting System	Electric Starter	Electric Starter

Performance

Maximum Power (DIN 70020) . .	123 HP (125 PS)	. . .	106.7 HP (108.2 PS)
	at 12,500 rpm	at 11,700 rpm
Maximum Torque	53.3 lbf.ft (72 Nm)	. . .	50.1 lbf.ft (68 Nm)
	at 11,750 rpm		at 9,200 rpm

Lubrication

Lubrication	Pressure Lubrication	. . .	Pressure Lubrication
	(wet sump)		(wet sump)
Engine Oil Capacities			
Dry Fill	0.79 US gal (3.0 liters)	. .	0.79 US gal (3.0 liters)
Oil/Filter Change	0.68 US gal (2.6 liters)		0.68 US gal (2.6 liters)
Oil Change Only	0.63 US gal (2.4 liters)	. .	0.63 US gal (2.4 liters)



Specifications

	Daytona 675	Street Triple
Cooling		
Coolant Type	Mobil Antifreeze	Mobil Antifreeze
Water/anti-freeze ratio	50/50	50/50
Coolant Capacity	0.63 US gal (2.4 liters)	0.63 US gal (2.4 liters)
Thermostat Opens (nominal)	158°F (71°C)	158°F (71°C)
Fuel System		
Type	Electronic Fuel Injection	Electronic Fuel Injection
Injectors	Solenoid Operated	Solenoid Operated
Fuel Pump	Submerged Electric	Submerged Electric
Fuel Pressure (nominal)	43.5 psi (3 Bar)	43.5 psi (3 Bar)
Fuel		
Type	.89 (R+M)/2	.87 (R+M)/2
Tank Capacity	4.6 US gal (17.4 liters)	4.6 US gal (17.4 liters)
Ignition		
Ignition System	Digital Inductive	Digital Inductive
Electronic Rev Limiter (r/min)	14,000 (r/min)	13,000 (r/min)
Spark Plug	NGK CR9EK	NGK CR9EK
Spark Plug Gap	0.028 in (0.7 mm)	0.028 in (0.7 mm)
Gap Tolerance	+0.001/-0.003 in (+0.05/-0.1mm)	+0.001/-0.003 in (+0.05/-0.1mm)
Transmission		
Transmission Type	6 Speed, Constant Mesh	6 Speed, Constant Mesh
Clutch Type	Wet, Multi-Plate	Wet, Multi-Plate
Final Drive Chain	RK O-ring	RK O-ring
Primary Drive Ratio	1.848:1 (46/85)	1.848:1 (46/85)
Gear Ratios:		
Final Drive Ratio	2.937:1 (16/47)	2.937:1 (16/47)
1st	2.615:1 (13/34)	2.615:1 (13/34)
2nd	1.857:1 (21/39)	1.857:1 (21/39)
3rd	1.565:1 (23/36)	1.565:1 (23/36)
4th	1.350:1 (20/27)	1.350:1 (20/27)
5th	1.238:1 (21/26)	1.238:1 (21/26)
6th	1.136:1 (22/25)	1.136:1 (22/25)

Specifications

	Daytona 675	Street Triple
Tires		
Tire Pressures (Cold):		
Front	34 lb/in ² (2.35 Bar)	34 lb/in ² (2.35 Bar)
Rear	36 lb/in ² (2.50 Bar)	42 lb/in ² (2.90 Bar)
Front Size	120/70 ZR 17	120/70 ZR 17
Rear Size	180/55 ZR 17	180/55 ZR 17
Approved tires:		
Option 1, Front and Rear	Pirelli Dragon Supercorsa Pro	Dunlop Sportmax Qualifier
Option 2, Front and Rear	Michelin Pilot Power B	Pirelli Dragon Supercorsa Pro
Option 3, Front and Rear	Bridgestone BT014 G	Bridgestone BT014 G

Warning

Use the recommended tires ONLY in the combinations given. Do not mix tires from different manufacturers or mix different specification tires from the same manufacturers as this may result in loss of motorcycle control and an accident.

Electrical Equipment

Battery Type	YT7B - BS	YTX9 - BS
Battery Rating	12 volt, 7 Ah	12 VOLT
Alternator	12 volt, 33.5 Amp at 4,000 rpm	12 volt, 33.5 Amp at 4,000 rpm
Headlight	1 x 12 volt, 55-watt, H7 Halogen (left hand side) 1 x 12 volt, 65-watt, H9 Halogen (right hand side)	2 x 12 volt, 55/60 watt, H4 Halogen
Tail/Brake Light	LED	LED
Turn Signal Lights	12 volt, 10 watt	12 volt, 10 watt

Frame

Rake	23.9°	24.3°
Trail	3.51 in (89.1 mm)	3.75 in (95.3 mm)

Specifications

Tightening Torques - All Models

Oil Filter	7 lbf ft (10 Nm)
Oil Drain Plug	18 lbf ft (25 Nm)
Spark Plug	9 lbf ft (12 Nm)
Rear Wheel Spindle	81 lbf ft (110 Nm)
Chain Adjuster Locknut	20 lbf ft (27 Nm)

Fluids and Lubricants - All Models

Engine Oil	Semi or fully synthetic 10W/40 or 15W/50 motorcycle engine oil which meets specification API SH (or higher) and JASO MA, such as Mobil 1 Racing 4T.
Brake and Clutch Fluid	Mobil Universal Brake & Clutch Fluid DOT4
Coolant	Mobil Antifreeze
Bearings and Pivots	Mobil Grease HP 222
Drive Chain	Mobil Chain Spray or Mobilube HD 80

Index

INDEX

A		Level Inspection,	77
Accessories,	63	D	
B		Dimensions,	123
Battery,	103	Drive Chain,	84
Disposal,	104	Lubrication,	85
Installation,	105	Movement Adjustment, . . .	86
Maintenance,	104	Movement Inspection,	85
Removal,	104	Wear Inspection,	87
Brake/Tail Light,	115	E	
Brakes,	88	Electrical Equipment,	125
Brake and Clutch Lever		Engine	
Adjusters,	42	Serial Number,	21
Braking,	57	Specifications,	123
Disc Brake Fluid,	89	To Start the Engine,	55
Fluid Level,	90	To Stop the Engine,	54
Light Switches,	91	Engine Oil,	73
Pad Wear Compensation, . .	88	Disposal of Oil and Filters, .	76
Wear Inspection,	88	Grade and Specification, . .	76
Breaking-In,	50	Oil Level Inspection,	74
C		F	
Cleaning,	116	Fluids and Lubricants,	126
After Washing,	118	Frame,	125
Drying,	118	Front Suspension,	95
Exhaust System,	118	Compression Damping	
Preparation,	117	Adjustment,	97
Protecting,	119	Fork Inspection,	95
Unpainted Aluminum		Rebound Damping	
Items,	118	Adjustment,	97
Washing,	118	Setting Chart,	96
Where to be Careful, . . .	117	Spring Pre-Load Adjustment, .	97
Clock/Trip Computer,	27	Fuel,	124
Clutch,	83	Fuel Requirement,	45
Adjustment,	84	Filling the Fuel Tank,	47
Inspection,	84	Fuel Grade,	45
Coolant Temperature Gauge, . .	29	Fuel Tank Cap,	47
Cooling System,	77, 124	Fuel System,	124
Change,	79	Fuse Box,	107
Corrosion Inhibitors, . . .	77	G	
Level Adjustment,	79	Gearshift Lights,	33

TRIUMPH

Index

H		
Headlights,	110	
Adjustment,	111	
Bulb Replacement,	113	
Position Lamp,	115	
I		
Ignition,	124	
Key,	41	
Switch/Steering Lock,	41	
Instrument Panel Layout,	25	
L		
Lap Timer,	29	
Left Handlebar Switches,	44	
Headlight Dimmer Switch,	44	
Horn Button,	44	
Pass Button,	44	
Turn Signal Switch,	44	
License Plate Light,	116	
Lubrication,	123	
O		
Odometer/Trip Meter,	26	
P		
Performance,	123	
R		
Rear Seat,	50	
Rider's Seat,	49	
Right Handlebar Switches,	43	
Engine Stop Switch,	43	
Starter Button,	43	
S		
Safety,	5	
Daily Checks,	51	
Fuel and Exhaust Fumes,	5	
Handlebars and Footrests,	11	
Helmet and Clothing,	6	
Maintenance/Equipment,	8	
Motorcycle,	5	
Parking,	7	
Parts and Accessories,	7	
Riding,	9	
Seat Lock,	49	
Shifting Gears,	56	
Speedometer,	26	
Stand,	48	
Side Stand,	48	
Steering/Wheel Bearings,	93	
Inspection,	93	
Storage		
Preparation after Storage,	122	
Preparation for Storage,	121	
T		
Tachometer,	26	
Throttle Control,	80	
Tightening Torques,	126	
Tires,	99, 125	
Inflation Pressures,	99	
Minimum Tread Depth,	100	
Replacement,	101	
Tool Kit,	48	
Transmission,	124	
Turn Signal Lights,	115	
V		
Vehicle Identification Number,	21	
W		
Warning Lights,	39	
Warnings		
Warning Label Locations,	12	
Warning Labels,	2	
Warnings, Cautions and Notes,	1	
Weights,	123	
Windshield Cleaning,	92	

Daytona 675 Additional Information

DAYTONA 675 ADDITIONAL INFORMATION

Part Number: 3856461 08/08



1 of 8

Daytona 675 Additional Information


Daytona 675

This addendum contains information for the ignition key, suspension, tyres, direction indicators and specifications for the Daytona 675 and must be read in conjunction with the owner's handbook.

All other details are as described for the Daytona 675 in the accompanying owner's handbook.

Always keep this addendum with the owner's handbook, store them with the motorcycle and refer to them whenever necessary.

Ignition Key



1. Key number tag
2. Third key for alarm system

For Daytona 675 there is a third key that does not have a fob. This is for the accessory alarm system.

Suspension

Low Stroke Speed and High Stroke Speed Compression Damping

The front forks and rear suspension unit are equipped with low stroke and high stroke speed compression damping adjusters.

Low stroke speed compression damping is for something in the road that produces a low speed compression of the front forks and rear suspension unit.

High stroke speed compression damping is for something in the road that produces a high speed compression of the front forks and rear suspension unit.

Suspension Settings

Warning

Ensure that the correct balance between front and rear suspension is maintained. Suspension imbalance could significantly change handling characteristics leading to loss of control and an accident. Refer to the chart below for further information or consult your dealer.

Warning

Ensure that the adjusters are set to the same settings on both forks. Settings which vary from left to right could significantly change handling characteristics leading to loss of control and an accident.

Daytona 675 Additional Information

The standard suspension settings provide a comfortable ride and good handling characteristics for general, solo riding. The following charts show the suggested settings for the front and rear suspension.

Note:

- The suspension setting charts are only a guide for the Daytona 675, not any other model.
- Setting requirements may vary for rider weight and personal preferences.

Front Suspension Setting Chart

LOADING		Spring Pre-Load ¹	Rebound Damping ²	Low Stroke Speed Compression Damping ²	High Stroke Speed Compression Damping ³
Solo Riding	Standard - Sport	5	9	9	3
	Softer	5	14	14	5
Rider and Passenger		5	11	11	4
¹ Number of visible rings. ² Number of clicks out from the fully screwed in position. ³ Number of turns out from the fully screwed in position.					

Spring Pre-Load Adjustment and Rebound Damping Adjustment

The method to adjust the front suspension spring pre-load and rebound damping is the same as described for the Daytona 675 in the accompanying handbook, with the exception of the following:


- Front suspension rebound damping - count the number of clicks out from the fully screwed in position.

Note:

- The motorcycle is delivered from the factory with the front suspension set at the standard - sport settings, as shown in the table above.

Daytona 675 Additional Information

The front fork adjusters for the low stroke speed and high stroke speed compression damping are located near the bottom of each fork.



1. Low stroke speed adjuster
2. High stroke speed adjuster

Low Stroke Speed Compression Damping Adjustment

To adjust the low stroke speed compression damping force, rotate the slotted adjuster clockwise to increase the damping force, or anti-clockwise to decrease. Always count the number of clicks out from the fully screwed in position and set both forks to the same setting.

High Stroke Speed Compression Damping Adjustment

To adjust the high stroke speed compression damping force, rotate the adjuster clockwise to increase the damping force, or anti-clockwise to decrease. Always count the number of turns out from the fully screwed in position and set both forks to the same setting.

Note:

- The low stroke speed adjuster will turn with the high speed stroke adjuster. This will not affect the low speed stroke compression damping adjustment.

Daytona 675 Additional Information

Rear Suspension Setting Chart

LOADING		Rebound Damping ²	Low Stroke Speed Compression Damping ²	High Stroke Speed Compression Damping ¹
Solo Riding	Standard - Sport	9	9	3
	Softer	13	14	5
Rider and Passenger		11	9	4
¹ Number of turns out from the fully screwed in position.				
² Number of clicks out from the fully screwed in position.				

Rebound Damping Adjustment

The method to adjust the rear suspension rebound damping adjustment is the same as described for the Daytona 675 in the accompanying handbook, with the exception of the following:


- Rear suspension rebound damping - count the number of clicks out from the fully screwed in position.

Note:

- The motorcycle is delivered from the factory with the rear suspension set at the standard - sport settings, as shown in the table above.

Low Stroke Speed and High Stroke Speed Compression Damping

The adjusters for the low stroke speed and high stroke speed compression damping are located adjacent the rear suspension reservoir.



1. Low stroke speed adjuster
2. High stroke speed adjuster

Daytona 675 Additional Information

Low Stroke Speed Compression Damping Adjustment

To adjust the low stroke speed compression damping force, rotate the slotted adjuster clockwise to increase the damping force, or anti-clockwise to decrease. Count the number of clicks out from the fully screwed in position.

High Stroke Speed Compression Damping Adjustment

To adjust the high stroke speed compression damping force, rotate the adjuster clockwise to increase the damping force, or anti-clockwise to decrease. Count the number of turns out from the fully screwed in position.

Note:

- **The low stroke speed adjuster will turn with the high speed stroke adjuster. This will not affect the low speed stroke compression damping adjustment.**

Warning

The rear suspension unit spring pre-load is not rider adjustable.

Any attempt to adjust the spring pre-load could result in a dangerous riding condition leading to loss of control and an accident.

Direction Indicator Lights

The method to replace the direction indicator light bulb is the same as the Street Triple. Refer to the Maintenance section in the accompanying handbook.

Daytona 675 Additional Information

Tyre Options

Option	Front	Rear	Front Size	Rear Size
1	Pirelli Diablo Super Corsa SP		120/70 ZR 17	180/55 ZR 17
2	Dunlop Qualifier		120/70 ZR 17	180/55 ZR 17
3	Metzeler M3 C	Metzeler M3	120/70 ZR 17	180/55 ZR 17

Warning

Use the recommended tyre options ONLY in the combinations given. Do not mix tyres from different manufacturers or mix different specification tyres from the same manufacturers as this may result in loss motorcycle control and an accident.

Tyre Pressures

Front	2.35 Bar (34 lb/in ²)
Rear	2.50 Bar (36 lb/in ²)

Warning

Incorrect tyre inflation will cause abnormal tread wear and instability problems that may lead to loss of control and an accident. Under-inflation may result in the tyre slipping on, or coming off the rim. Over inflation will cause instability and accelerated tread wear.

Both conditions are dangerous as they may cause loss of control leading to an accident.

Daytona 675 Additional Information

Specifications

The specifications for the Daytona 675 are the same as described in the accompanying handbook with the exception of the following listed below.

Dimensions

Overall Length	2010 mm (79.1 in)
Overall Width	700mm (27.5 in)
Overall Height.....	1121 mm (44.1 in)
Wheelbase.....	1395 mm (54.9 in)
Seat Height	825 mm (32.5 in)

Frame

Rake.....	23.9°
Trail	89.1 mm

Performance

Maximum Power (DIN 70020)	128 PS (126 bhp) at 12,600 rpm
Maximum Torque.....	73 Nm (53.3 ft.lbf) at 11,900 rpm

Engine Oil Capacities

Dry Fill	3.5 litres
Oil/Filter Change	3.1 litres
Oil Change Only.....	2.9 litres

Ignition

Electronic Rev Limiter (r/min).....	14000 (r/min)
-------------------------------------	---------------

Gear Ratios

1st	2.313 (16/37)
-----------	---------------