




OWNER'S MANUAL



YZF-R1

5JJ-28199-E0



INTRODUCTION

Welcome to the Yamaha world of motorcycling!

As the owner of a YZF-R1, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your YZF-R1. The owner's manual does not only instruct you in how to operate, inspect and maintain your motorcycle, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your motorcycle in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following notations:



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the motorcycle operator, a bystander, or a person inspecting or repairing the motorcycle.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the motorcycle.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

NOTE:

- This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.
- Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If you have any questions concerning this manual, please consult your Yamaha dealer.

IMPORTANT MANUAL INFORMATION

EW000002



WARNING

PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE.

IMPORTANT MANUAL INFORMATION


EAU00008

**YZF-R1
OWNER'S MANUAL
©1999 by Yamaha Motor Co., Ltd.
1st Edition, December 1999
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.**

EAU00009

TABLE OF CONTENTS

1 GIVE SAFETY THE RIGHT OF WAY	1
2 DESCRIPTION	2
3 INSTRUMENT AND CONTROL FUNCTIONS	3
4 PRE-OPERATION CHECKS	4
5 OPERATION AND IMPORTANT RIDING POINTS	5
6 PERIODIC MAINTENANCE AND MINOR REPAIR	6
7 MOTORCYCLE CARE AND STORAGE	7
8 SPECIFICATIONS	8
9 CONSUMER INFORMATION	9
INDEX	





GIVE SAFETY THE RIGHT OF WAY

GIVE SAFETY THE RIGHT OF WAY 1-1

GIVE SAFETY THE RIGHT OF WAY

EAU00021

Motorcycles are fascinating vehicles, which can give you an unsurpassed feeling of power and freedom. However, they also impose certain limits, which you must accept; even the best motorcycle does not ignore the laws of physics.

Regular care and maintenance are essential for preserving value and operating condition of your motorcycle. Moreover, what is true for the motorcycle is also true for the rider: good performance depends on being in good shape. Riding under the influence of medication, drugs and alcohol is, of course, out of the question. Motorcycle riders—more than car drivers—must always be at their mental and physical best. Under the influence of even small amounts of alcohol, there is a tendency to take dangerous risks.

Protective clothing is as essential for the motorcycle rider as seat belts are for car drivers and passengers. Always wear a complete motorcycle suit (whether made of leather or tear-resistant synthetic materials with protectors), sturdy boots, motorcycle gloves and a properly fitting helmet. Optimum protective wear, however, should not encourage carelessness. Although full-coverage helmets and suits, in particular, create an illusion of total safety and protection, motorcyclists will always be vulnerable. Riders who lack critical self-control run the risk of going too fast and are apt to take chances. This is even more dangerous in wet weather. The good motorcyclist rides safely, predictably and defensively—avoiding all dangers, including those caused by others.

Enjoy your ride!


DESCRIPTION

Left view	2-1
Right view	2-2
Controls and instruments	2-3

DESCRIPTION

EAU00026


Left view



- | | |
|---|-------------|
| 1. Front fork compression damping force adjusting screw | (page 3-17) |
| 2. Front fork rebound damping force adjusting screw | (page 3-17) |
| 3. Front fork spring preload adjusting bolt | (page 3-16) |
| 4. Air filter | (page 6-15) |
| 5. Shift pedal | (page 3-10) |
| 6. Shock absorber compression damping force adjusting screw | (page 3-19) |
| 7. Passenger seat lock | (page 3-14) |
| 8. Shock absorber rebound damping force adjusting screw | (page 3-19) |
| 9. Luggage strap holders | (page 3-22) |
| 10. Helmet holders | (page 3-15) |

DESCRIPTION


Right view



11. Owner's tool kit	(page 6-1)	16. Radiator and coolant reservoir	(page 6-11)
12. Fuses	(page 6-34)	17. Front brake fluid reservoir	(page 6-25)
13. Rear brake fluid reservoir	(page 6-26)	18. Oil filter cartridge	(page 6-9)
14. Battery	(page 6-33)	19. Oil level check window	(page 6-8)
15. Shock absorber spring preload adjusting ring	(page 3-18)	20. Brake pedal	(page 3-11)

DESCRIPTION

Controls and instruments



1. Clutch lever
2. Left handlebar switches
3. Starter (choke) lever
4. Speedometer unit
5. Main switch/steering lock

(page 3-10)
(page 3-9)
(page 3-13)
(page 3-6)
(page 3-1)

6. Tachometer
7. Right handlebar switches
8. Throttle grip
9. Brake lever




(page 3-7)
(page 3-9)
(page 6-18)
(page 3-11)

INSTRUMENT AND CONTROL FUNCTIONS

Main switch/steering lock.....	3-1	Fuel tank breather hose	3-13
Indicator lights	3-2	Starter (choke) lever.....	3-13
Speedometer unit	3-6	Seats.....	3-14
Tachometer	3-7	Helmet holders	3-15
Self-diagnosis devices	3-7	Storage compartment	3-16
Anti-theft alarm (optional)	3-8	Adjusting the front fork	3-16
Handlebar switches	3-9	Adjusting the shock absorber assembly	3-18
Clutch lever	3-10	Matching the front and rear suspension settings	3-21
Shift pedal.....	3-10	Luggage strap holders	3-22
Brake lever	3-11	EXUP system.....	3-22
Brake pedal.....	3-11	Sidestand	3-23
Fuel tank cap	3-11	Ignition circuit cut-off system.....	3-23
Fuel.....	3-12		

INSTRUMENT AND CONTROL FUNCTIONS

EAU00027



1. Push
2. Turn

Main switch/steering lock

EAU00029

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

ON

EAU00036

All electrical systems are supplied with power, and the engine can be started. The key cannot be removed.

OFF

EAU00038

All electrical systems are off. The key can be removed.

LOCK

EAU00040

The steering is locked, and all electrical systems are off. The key can be removed.

To lock the steering

1. Turn the handlebars all the way to the left.
2. Push the key in from the "OFF" position, and then turn it to "LOCK" while still pushing it.
3. Remove the key.

To unlock the steering

Push the key in, and then turn it to "OFF" while still pushing it.

! WARNING

EW000016

Never turn the key to "OFF" or "LOCK" while the motorcycle is moving, otherwise the electrical systems will be switched off, which may result in loss of control or an accident. Make sure that the motorcycle is stopped before turning the key to "OFF" or "LOCK".

INSTRUMENT AND CONTROL FUNCTIONS

P_R (Parking)

The steering is locked, and the taillights and auxiliary lights are on, but all other electrical systems are off. The key can be removed.


The steering must be locked before the key can be turned to "P_R".

CAUTION:

Do not use the parking position for an extended length of time, otherwise the battery may discharge.

EAU01574

ECA00043



1. Neutral indicator light "N"
2. High beam indicator light "≡"
3. Turn signal indicator light "↔"
4. Fuel level warning light "⛽"
5. Oil level warning light "⛑"

Indicator lights

EAU00056

Neutral indicator light "N"

EAU00061

This indicator light comes on when the transmission is in the neutral position.

High beam indicator light "≡"

EAU00063

This indicator comes on when the headlight high beam is used.

Turn signal indicator light "↔"

EAU00057

This indicator light flashes when the turn signal switch is pushed to the left or right.

Fuel level warning light "⛽"


EAU01666

This warning light comes on when the fuel level drops below approximately 3.8 L. When this occurs, refuel as soon as possible.

The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to "⊗" and turn the key to "ON".
2. Shift the transmission into the neutral position or pull the clutch lever.
3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

INSTRUMENT AND CONTROL FUNCTIONS



1. Neutral indicator light "N"
2. High beam indicator light "≡O"
3. Turn signal indicator light "◁ ▷"
4. Fuel level warning light "⛢"
5. Oil level warning light "⛢"

Oil level warning light "⛢"

EAU03155

This warning light comes on when the engine oil level is low.


The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to "⛢" and turn the key to "ON".
2. Shift the transmission into the neutral position or pull the clutch lever.

3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

NOTE:

- Even if the oil level is sufficient, the warning light may flicker when riding on a slope or during sudden acceleration or deceleration, but this is not a malfunction.
- This model is equipped with a self-diagnosis device for the oil level warning light circuit. (See page 3-8 for an explanation of the self-diagnosis device.)



1. Coolant temperature gauge
2. Coolant temperature warning light "⛢"

EAU03156

Coolant temperature warning light "⛢"

This warning light comes on when the engine overheats. When this occurs, stop the engine immediately and allow the engine to cool.

The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to "⛢" and turn the key to "ON".
2. Shift the transmission into the neutral position or pull the clutch lever.

INSTRUMENT AND CONTROL FUNCTIONS





3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

EC000002


CAUTION:

Do not operate the engine if it is overheated.

INSTRUMENT AND CONTROL FUNCTIONS

Coolant temperature	Display	Conditions	What to do
0–39 °C		Message “LO” is displayed.	OK. Go ahead with riding.
40–116 °C		Temperature is displayed.	OK. Go ahead with riding.
117–139 °C		Temperature flashes. Warning light comes on.	Stop the motorcycle and allow it to idle until the coolant temperature goes down. If the temperature does not go down, stop the engine. (See the “Engine overheating” section on page 6-44 for further instructions.)
Above 140 °C		Message “HI” flashes. Warning light comes on.	Stop the engine and allow it to cool. (See the “Engine overheating” section on page 6-44 for further instructions.)

INSTRUMENT AND CONTROL FUNCTIONS



1. Speedometer
2. Odometer/tripmeter/fuel reserve tripmeter/clock
3. "RESET" button
4. "SELECT" button

Speedometer unit

EAU03157

The speedometer unit is equipped with the following:

- a digital speedometer (which shows riding speed)
- an odometer (which shows the total distance traveled)
- two tripmeters (which show the distance traveled since they were last set to zero)

- a fuel reserve tripmeter (which shows the distance traveled on the fuel reserve)
- a clock

Odometer and tripmeter modes

Pushing the "SELECT" button switches the display between the odometer mode "ODO" and the tripmeter modes "TRIP 1" and "TRIP 2" in the following order:

ODO → TRIP 1 → TRIP 2 → ODO

If the fuel level warning light comes on (see page 3-2), the odometer display will automatically change to the fuel reserve tripmeter mode "TRIP F" and start counting the distance traveled from that point. In that case, pushing the "SELECT" button switches the display between the various tripmeter and odometer modes in the following order: TRIP F → TRIP 1 → TRIP 2 → ODO → TRIP F

To reset a tripmeter, select it by pushing the "SELECT" button, and then push the "RESET" button for at least one second. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to "TRIP 1" after refueling and traveling 5 km.

NOTE:

After resetting the fuel reserve tripmeter, the display will return to "TRIP 1", unless a different mode had been previously selected; in that case, the display automatically returns to the prior mode.

Clock mode


To change the display to the clock mode, push the "SELECT" button for at least one second.

To change the display back to the odometer modes, push the "SELECT" button.

INSTRUMENT AND CONTROL FUNCTIONS

To set the clock:

1. Push the "SELECT" button and "RESET" button together for at least two seconds.
2. When the hour digits start flashing, push the "RESET" button to set the hours.
3. Push the "SELECT" button, and the minute digits will start flashing.
4. Push the "RESET" button to set the minutes.
5. Push the "SELECT" button and then release it to start the clock.



1. Tachometer
2. Red zone

EAU00101

Tachometer

The electric tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.

EC000003

CAUTION:

Do not operate the engine in the tachometer red zone.

Red zone: 11,750 r/min and above


EAU03158

Self-diagnosis devices

This model is equipped with a self-diagnosis device for the following electrical circuits:

- Throttle position sensor
- Speed sensor
- EXUP system

If any of those circuits are defective, the tachometer will repeatedly display the following error code:



INSTRUMENT AND CONTROL FUNCTIONS

Use the chart below to identify the faulty electrical circuit.

Specific r/min	Faulty electrical circuit
3,000 r/min	Throttle position sensor
4,000 r/min	Speed sensor
7,000 r/min	EXUP system

If the tachometer displays such an error code, note the circuit-specific number of r/min, and then have a Yamaha dealer check the motorcycle.

EC000004

CAUTION:

When the tachometer displays an error code, the motorcycle should be checked as soon as possible in order to avoid engine damage.


This model is also equipped with a self-diagnosis device for the oil level warning light circuit. If the oil level warning light circuit is defective, the following cycle will be repeated until the malfunction is corrected: The warning light will flash eight times, then go off for three seconds. If this occurs, have a Yamaha dealer check the motorcycle.

EAU00109

Anti-theft alarm (optional)

This motorcycle can be equipped with an optional anti-theft alarm by a Yamaha dealer. Contact a Yamaha dealer for more information.

INSTRUMENT AND CONTROL FUNCTIONS



1. Pass switch "PASS"
2. Dimmer switch
3. Turn signal switch
4. Horn switch "🔊"

Handlebar switches

Pass switch "PASS"

Press this switch to flash the headlight.

Dimmer switch


Set this switch to "☰" for the high beam and to "☷" for the low beam.

Turn signal switch

To signal a right-hand turn, push this switch to "➡". To signal a left-hand turn, push this switch to "⬅". When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

Horn switch "🔊"

Press this switch to sound the horn.



1. Engine stop switch
2. Light switch
3. Start switch "🔌"

Engine stop switch

Set this switch to "☒" to stop the engine in case of an emergency, such as when the motorcycle overturns or when the throttle cable is stuck.

Light switch

Set this switch to "☰ ☷" to turn on the auxiliary lights, meter lighting and tail-lights. Set the switch to "☀" to turn on the headlight also.

INSTRUMENT AND CONTROL FUNCTIONS

Start switch “ ”


Push this switch to crank the engine with the starter.

EAU00143

EC000005

CAUTION:

See page 5-1 for starting instructions prior to starting the engine.




1. Clutch lever

EAU00152

Clutch lever

The clutch lever is located at the left handlebar grip. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 3-23 for an explanation of the ignition circuit cut-off system.)




1. Shift pedal

EAU00157

Shift pedal

The shift pedal is located on the left side of the engine and is used in combination with the clutch lever when shifting the gears of the 6-speed constant-mesh transmission equipped on this motorcycle.

INSTRUMENT AND CONTROL FUNCTIONS




1. Brake lever position adjusting dial
2. Arrow mark
- a. Distance between brake lever and handlebar grip

EAU00161

Brake lever

The brake lever is located at the right handlebar grip. To apply the front brake, pull the lever toward the handlebar grip.

The brake lever is equipped with a position adjusting dial. To adjust the distance between the brake lever and the handlebar grip, turn the adjusting dial while holding the lever pushed away from the handlebar grip. Make sure that the appropriate setting on the adjusting dial is aligned with the arrow mark on the brake lever.




1. Brake pedal

EAU00162

Brake pedal

The brake pedal is on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.



1. Lock cover
2. Unlock

EAU02935

Fuel tank cap

To open the fuel tank cap

Open the fuel tank cap lock cover, insert the key into the lock, and then turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be opened.

To close the fuel tank cap

1. Push the fuel tank cap into position with the key inserted in the lock.

INSTRUMENT AND CONTROL FUNCTIONS

- Turn the key counterclockwise to the original position, remove it, and then close the lock cover.


NOTE:

The fuel tank cap cannot be closed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly closed and locked.

EWA00025

WARNING

Make sure that the fuel tank cap is properly closed before riding.



- Filler tube
- Fuel level

EAU01183

Fuel

Make sure that there is sufficient fuel in the tank. Fill the fuel tank to the bottom of the filler tube as shown in the illustration.

EW000130

WARNING

- Do not overfill the fuel tank, otherwise it may overflow when the fuel warms up and expands.
- Avoid spilling fuel on the hot engine.

EAU00185

CAUTION:

Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.

EAU00191

Recommended fuel:

Regular unleaded gasoline with a research octane number of 91 or higher

Fuel tank capacity:

Total amount:

18 L


Reserve amount:

3.8 L

NOTE:

If knocking (or pinging) occurs, use gasoline of a different brand or with a higher octane grade.

INSTRUMENT AND CONTROL FUNCTIONS




1. Fuel tank breather hose

Fuel tank breather hose

EAU02955

Before operating the motorcycle:

- Check the fuel tank breather hose connection.
- Check the fuel tank breather hose for cracks or damage, and replace it if damaged.
- Make sure that the end of the fuel tank breather hose is not blocked, and clean it if necessary.



1. Starter (choke) lever

EAU02976


Starter (choke) lever

Starting a cold engine requires a richer air-fuel mixture, which is supplied by the starter (choke).

Move the lever in direction ① to turn on the starter (choke).

Move the lever in direction ② to turn off the starter (choke).

INSTRUMENT AND CONTROL FUNCTIONS



1. Bolt (× 2)


EAU01890

Seats

Rider seat

To remove the rider seat


Lift up the rear corners of the rider seat as shown, remove the bolts, and then pull the seat off.



1. Projection
2. Seat holder

To install the rider seat

Insert the projection on the front of the rider seat into the seat holder as shown, place the seat in the original position, and then install the bolts.




1. Passenger seat lock
2. Unlock

Passenger seat

To remove the passenger seat

1. Insert the key into the seat lock, and then turn it counterclockwise.
2. While holding the key in that position, lift the front of the passenger seat and pull it forward.

INSTRUMENT AND CONTROL FUNCTIONS




1. Projection
2. Seat holder

To install the passenger seat

1. Insert the projection on the rear of the passenger seat into the seat holder as shown, and then push the front of the seat down to lock it in place.
2. Remove the key.

NOTE:

Make sure that the seats are properly secured before riding.



1. Helmet holder (× 2)

EAU03159

Helmet holders

The helmet holders are located on the bottom of the passenger seat.

To secure a helmet to a helmet holder

1. Remove the passenger seat. (See page 3-14 for removal and installation procedures.)
2. Attach the helmet to a helmet holder, and then securely install the passenger seat.

WARNING


Never ride with a helmet attached to a helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident.

To release the helmet from a helmet holder

Remove the passenger seat, remove the helmet from the helmet holder, and then install the seat.

EWA00015

INSTRUMENT AND CONTROL FUNCTIONS



1. Storage compartment

Storage compartment

The storage compartment is located under the passenger seat. (See page 3-14 for passenger seat removal and installation procedures.)

EAU01242

EWA00005

WARNING

- Do not exceed the load limit of 3 kg for the storage compartment.
- Do not exceed the maximum load of 201 kg for the vehicle.

Adjusting the front fork


This front fork is equipped with spring preload adjusting bolts, rebound damping force adjusting screws and compression damping force adjusting screws.

EAU01862

EW000035

WARNING

Always adjust both fork legs equally, otherwise poor handling and loss of stability may result.




1. Spring preload adjusting bolt

Spring preload

To increase the spring preload and thereby harden the suspension, turn the adjusting bolt on each fork leg in direction ①. To decrease the spring preload and thereby soften the suspension, turn the adjusting bolt on each fork leg in direction ②.

INSTRUMENT AND CONTROL FUNCTIONS




1. Current setting
2. Front fork cap bolt

NOTE:

Align the appropriate groove on the adjusting mechanism with the top of the front fork cap bolt.

	Minimum (soft)		Standard	Maximum (hard)				
Setting	8	7	6	5	4	3	2	1




1. Rebound damping force adjusting screw

Rebound damping force

To increase the rebound damping force and thereby harden the rebound damping, turn the adjusting screw on each fork leg in direction ①. To decrease the rebound damping force and thereby soften the rebound damping, turn the adjusting screw on each fork leg in direction ②.

Minimum (soft)	11 clicks in direction ②*
Standard	5 clicks in direction ②*
Maximum (hard)	1 click in direction ②*

* With the adjusting screw fully turned in direction ①



1. Compression damping force adjusting screw

Compression damping force

To increase the compression damping force and thereby harden the compression damping, turn the adjusting screw on each fork leg in direction ①. To decrease the compression damping force and thereby soften the compression damping, turn the adjusting screw on each fork leg in direction ②.

Minimum (soft)	9 clicks in direction ②*
Standard	5 clicks in direction ②*
Maximum (hard)	1 click in direction ②*

* With the adjusting screw fully turned in direction ①

INSTRUMENT AND CONTROL FUNCTIONS

CAUTION:

Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.

NOTE:


Although the total number of clicks of a damping force adjusting mechanism may not exactly match the above specifications due to small differences in production, the actual number of clicks always represents the entire adjusting range. To obtain a precise adjustment, it would be advisable to check the number of clicks of each damping force adjusting mechanism and to modify the specifications as necessary.

Adjusting the shock absorber assembly

This shock absorber assembly is equipped with a spring preload adjusting ring and rebound and compression damping force adjusting screws.

CAUTION:

Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.



1. Spring preload adjusting ring
2. Special wrench
3. Position indicator

Spring preload


To increase the spring preload and thereby harden the suspension, turn the adjusting ring in direction ①. To decrease the spring preload and thereby soften the suspension, turn the adjusting ring in direction ②.

NOTE:

Align the appropriate notch in the adjusting ring with the position indicator on the shock absorber.

	Minimum (soft)			Standard	Maximum (hard)				
Setting	1	2	3	4	5	6	7	8	9

INSTRUMENT AND CONTROL FUNCTIONS




1. Rebound damping force adjusting screw

Rebound damping force

To increase the rebound damping force and thereby harden the rebound damping, turn the adjusting screw in direction ①. To decrease the rebound damping force and thereby soften the rebound damping, turn the adjusting screw in direction ②.

Minimum (soft)	11 clicks in direction ②*
Standard	7 clicks in direction ②*
Maximum (hard)	1 click in direction ②*

* With the adjusting screw fully turned in direction ①



1. Compression damping force adjusting screw

Compression damping force

To increase the compression damping force and thereby harden the compression damping, turn the adjusting screw in direction ①. To decrease the compression damping force and thereby soften the compression damping, turn the adjusting screw in direction ②.

Minimum (soft)	11 clicks in direction ②*
Standard	9 clicks in direction ②*
Maximum (hard)	1 click in direction ②*

* With the adjusting screw fully turned in direction ①

NOTE:

Although the total number of clicks of a damping force adjusting mechanism may not exactly match the above specifications due to small differences in production, the actual number of clicks always represents the entire adjusting range. To obtain a precise adjustment, it would be advisable to check the number of clicks of each damping force adjusting mechanism and to modify the specifications as necessary.

INSTRUMENT AND CONTROL FUNCTIONS

WARNING

EAU00315

This shock absorber contains highly pressurized nitrogen gas. For proper handling, read and understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling.

- Do not tamper with or attempt to open the gas cylinder.
- Do not subject the shock absorber to an open flame or other high heat sources, otherwise it may explode due to excessive gas pressure.
- Do not deform or damage the gas cylinder in any way, as this will result in poor damping performance.
- Always have a Yamaha dealer service the shock absorber.

INSTRUMENT AND CONTROL FUNCTIONS

EAU01580

Matching the front and rear suspension settings

Use this table as a guide to match the suspension and damping adjustments of the front fork and shock absorber assembly according to various load conditions.


Load condition	Front fork adjustment			Shock absorber assembly adjustment		
	Spring preload	Compression damping force	Rebound damping force	Spring preload	Compression damping force	Rebound damping force
Rider only	1-8	1-9	1-11	1-7	4-11	3-11
With passenger	1-8	1-9	1-11	4-9	1-9	1-7

EC000015

CAUTION:

Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.

INSTRUMENT AND CONTROL FUNCTIONS



1. Luggage strap holder (× 4)
2. Hook (× 4)

EAU03170

Luggage strap holders

There are four luggage strap holders on the bottom of the passenger seat. To use the strap holders, remove the passenger seat, unhook the straps, and then install the seat with the straps hanging out from under the passenger seat. (See page 3-14 for passenger seat removal and installation procedures.)

EAU01571

EXUP system

This motorcycle is equipped with Yamaha's EXUP (EXhaust Ultimate Power valve) system. This system boosts engine power by means of a valve that regulates the diameter of the exhaust pipe. The EXUP system valve is constantly adjusted in accordance with the engine speed by a computer-controlled servomotor.

EC000027

CAUTION:

- The EXUP system has been set and extensively tested at the Yamaha factory. Changing these settings without sufficient technical knowledge may result in poor performance of or damage to the engine.
- If the EXUP system does not operate, have a Yamaha dealer check it.

INSTRUMENT AND CONTROL FUNCTIONS

Sidestand

EAU00330

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the motorcycle upright.

NOTE:

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See further down for an explanation of the ignition circuit cut-off system.)

WARNING

The motorcycle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly as described below and have a Yamaha dealer repair it if it does not function properly.

EW000044

Ignition circuit cut-off system

EAU00331

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the sidestand is moved down.


Periodically check the operation of the ignition circuit cut-off system according to the following procedure.


EW000045

WARNING

If a malfunction is noted, have a Yamaha dealer check the system before riding.

INSTRUMENT AND CONTROL FUNCTIONS





PRE-OPERATION CHECKS

Pre-operation check list..... 4-1

PRE-OPERATION CHECKS

EAU01114

The condition of a vehicle is the owner's responsibility. Vital components can start to deteriorate quickly and unexpectedly, even if the vehicle remains unused (for example, as a result of exposure to the elements). Any damage, fluid leakage or loss of tire air pressure could have serious consequences. Therefore, it is very important, in addition to a thorough visual inspection, to check the following points before each ride.

EAU00340

PRE-OPERATION CHECK LIST

ITEM	CHECKS	PAGE
Front brake	• Check operation, free play, fluid level and for fluid leakage.	6-24–6-26
Rear brake	• Fill with DOT 4 brake fluid if necessary.	6-23–6-26
Clutch	• Check operation, condition and free play. • Adjust if necessary.	6-22–6-23
Throttle grip and housing	• Check smooth operation. • Lubricate if necessary.	6-18, 6-29
Engine oil	• Check oil level. • Add oil if necessary.	6-8
Coolant	• Check coolant level. • Add coolant if necessary.	6-11–6-12
Drive chain	• Check chain slack and condition. • Adjust if necessary.	6-27–6-28
Wheels and tires	• Check tire air pressure, for wear and damage.	6-19–6-22
Control cables	• Check smooth operation. • Lubricate if necessary.	6-29
Brake pedal shaft	• Check smooth operation. • Lubricate if necessary.	6-30
Brake and clutch lever pivots	• Check smooth operation. • Lubricate if necessary.	6-30

PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Sidestand pivot	<ul style="list-style-type: none">• Check smooth operation.• Lubricate if necessary.	6-30
Chassis fasteners	<ul style="list-style-type: none">• Make sure that all nuts, bolts and screws are properly tightened.• Tighten if necessary.	—
Fuel	<ul style="list-style-type: none">• Check fuel level.• Add fuel if necessary.	3-12
Lights, signals and switches	<ul style="list-style-type: none">• Check proper operation.	—

NOTE:

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be thoroughly accomplished in a very short time; and the added safety it assures is more than worth the time involved.

⚠ WARNING

If any item in the PRE-OPERATION CHECK is not working properly, have it inspected and repaired before operating the motorcycle.



OPERATION AND IMPORTANT RIDING POINTS

Starting a cold engine	5-1
Starting a warm engine	5-3
Shifting	5-3
Recommended shift points (for Switzerland only)	5-4
Tips for reducing fuel consumption	5-4
Engine break-in	5-4
Parking	5-5

OPERATION AND IMPORTANT RIDING POINTS

EAU00372

EAU00373

EAU03160

EC000035

WARNING

- Become thoroughly familiar with all operating controls and their functions before riding. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.
- Never start the engine or operate it in a closed area for any length of time. Exhaust fumes are poisonous, and inhaling them can cause loss of consciousness and death within a short time. Always make sure that there is adequate ventilation.
- Before starting out, make sure that the sidestand is up. If the sidestand is not raised completely, it could contact the ground and distract the operator, resulting in a possible loss of control.

Starting a cold engine

In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met:

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.

EW000054

WARNING

- Before starting the engine, check the function of the ignition circuit cut-off system according to the procedure described on page 3-24.
- Never ride with the sidestand down.

1. Turn the key to "ON" and make sure that the engine stop switch is set to "○".

CAUTION:

If the fuel level warning light comes on, check the fuel level, and, if necessary, refuel as soon as possible.

2. Shift the transmission into the neutral position.

NOTE:

When the transmission is in the neutral position, the neutral indicator light should be on, otherwise have a Yamaha dealer check the electrical circuit.

3. Turn the starter (choke) on and completely close the throttle. (See page 3-13 for starter (choke) operation.)
4. Start the engine by pushing the start switch.

OPERATION AND IMPORTANT RIDING POINTS

NOTE:

If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.

EC000038

CAUTION:

- The oil level warning light and fuel level warning light should come on when the start switch is pushed, and they should go off when the start switch is released.
- If the oil level warning light flickers or remains on after starting, immediately stop the engine, and then check the engine oil level and the vehicle for oil leakage. If necessary, add engine oil, and then check the warning light again. If the warning light does not come on when pushing the start switch, or if it does

not go off after starting with sufficient engine oil, have a Yamaha dealer check the electrical circuit.

- If the fuel level warning light remains on after starting, stop the engine, and then check the fuel level. If necessary, refuel as soon as possible, and then check the warning light again. If the warning light does not come on when pushing the start switch, or if it does not go off after starting with sufficient fuel, have a Yamaha dealer check the electrical circuit.

5. After starting the engine, move the starter (choke) lever back halfway.

ECA00045

CAUTION:

For maximum engine life, never accelerate hard when the engine is cold!

6. When the engine is warm, turn the starter (choke) off.

NOTE:


- The engine is warm when it responds normally to the throttle with the starter (choke) turned off.
- When the engine is idling with the starter (choke) turned on, the radiator fan will automatically be switched on and off regardless of the coolant temperature. As a result, the engine idling speed will vary, but this does not indicate a malfunction.

OPERATION AND IMPORTANT RIDING POINTS

Starting a warm engine

Follow the same procedure as for starting a cold engine with the exception that the starter (choke) is not required when the engine is warm.

EAU01258



1. Shift pedal
N. Neutral position

EAU00423

Shifting

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.

The gear positions are shown in the illustration.

NOTE:

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

EC000048

CAUTION:

- Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.
- Always use the clutch while changing gears to avoid damaging the engine, transmission, and drive train, which are not designed to withstand the shock of forced shifting.

OPERATION AND IMPORTANT RIDING POINTS

Recommended shift points (for Switzerland only)

EAU02937

The recommended shift points during acceleration are shown in the table below.

	Shift point (km/h)
1st → 2nd	20
2nd → 3rd	30
3rd → 4th	40
4th → 5th	50
5th → 6th	60

NOTE:

When shifting down two gears at a time, reduce the speed accordingly (e.g., down to 35 km/h when shifting from 5th to 3rd gear).

Tips for reducing fuel consumption

EAU00424

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Thoroughly warm up the engine.
- Turn the starter (choke) off as soon as possible.
- Shift up swiftly, and avoid high engine speeds during acceleration.
- Do not rev the engine while shifting down, and avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

Engine break-in

EAU01128

There is never a more important period in the life of your engine than the period between 0 and 1,600 km. For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1,600 km. The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

OPERATION AND IMPORTANT RIDING POINTS

0–1,000 km

EAU03172

Avoid prolonged operation above 5,000 r/min.

1,000–1,600 km

Avoid prolonged operation above 6,000 r/min.

EC000052

CAUTION:

After 1,000 km of operation, the engine oil must be changed and the oil filter cartridge replaced.

1,600 km and beyond

The vehicle can now be operated normally.

EC000053

CAUTION:

- Keep the engine speed out of the tachometer red zone.
- If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

NOTE:

During and after the engine break-in period, the exhaust heat may cause discoloration of the exhaust pipe, but this is normal.

Parking

EAU00460

When parking, stop the engine, and then remove the key from the main switch.

EW000058

⚠ WARNING

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them.
- Do not park on a slope or on soft ground, otherwise the motorcycle may overturn.

PERIODIC MAINTENANCE AND MINOR REPAIR

Owner's tool kit	6-1	Checking and lubricating the cables	6-29
Periodic maintenance and lubrication chart.....	6-2	Checking and lubricating the throttle grip and cable	6-29
Removing and installing cowlings and panels	6-5	Lubricating the brake pedal	6-30
Checking the spark plugs	6-7	Checking and lubricating the brake and clutch levers	6-30
Engine oil and oil filter cartridge	6-8	Checking and lubricating the sidestand	6-30
Coolant	6-11	Lubricating the rear suspension	6-31
Cleaning the air filter element	6-15	Checking the front fork	6-31
Adjusting the carburetors	6-17	Checking the steering	6-32
Adjusting the engine idling speed	6-17	Checking the wheel bearings	6-32
Adjusting the throttle cable free play	6-18	Battery	6-33
Adjusting the valve clearance	6-18	Replacing the fuses	6-34
Tires.....	6-19	Replacing the headlight bulb	6-35
Wheels.....	6-22	Replacing the tail/brake light bulb	6-37
Adjusting the clutch lever free play	6-22	Replacing a turn signal light bulb	6-37
Adjusting the brake pedal position	6-23	Supporting the motorcycle	6-38
Adjusting the rear brake light switch	6-24	Front wheel	6-39
Checking the front and rear brake pads	6-24	Rear wheel.....	6-41
Checking the brake fluid level	6-25	Troubleshooting.....	6-42
Changing the brake fluid	6-26	Troubleshooting charts.....	6-43
Drive chain slack.....	6-27		
Lubricating the drive chain	6-28		

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU00462


Safety is an obligation of the owner. Periodic inspection, adjustment and lubrication will keep your vehicle in the safest and most efficient condition possible. The most important points of inspection, adjustment, and lubrication are explained on the following pages. The intervals given in the periodic maintenance and lubrication chart should be simply considered as a general guide under normal riding conditions. However, **DEPENDING ON THE WEATHER, TERRAIN, GEOGRAPHICAL LOCATION, AND INDIVIDUAL USE, THE MAINTENANCE INTERVALS MAY NEED TO BE SHORTENED.**

EAU00464

EW000060

! WARNING

If you are not familiar with motorcycle maintenance work, have a Yamaha dealer do it for you.



1. Owner's tool kit

EAU01575

Owner's tool kit

The tool kit is located inside the storage compartment under the passenger seat. (See page 3-14 for passenger seat removal procedures.)

The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

NOTE:

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EW000063

! WARNING

Modifications not approved by Yamaha may cause loss of performance and render the vehicle unsafe for use. Consult a Yamaha dealer before attempting any changes.

PERIODIC MAINTENANCE AND MINOR REPAIR

EAU00473

Periodic maintenance and lubrication chart

NO.	ITEM	CHECKS AND MAINTENANCE JOBS	Initial 1,000 km	Every	Every	Annual check
				10,000 km	20,000 km	
1	* Fuel line	<ul style="list-style-type: none"> • Check fuel hoses and vacuum hose for cracks or damage. • Replace if necessary. 		√		√
2	* Fuel filter	<ul style="list-style-type: none"> • Check condition. • Replace if necessary. 			√	
3	Spark plugs	<ul style="list-style-type: none"> • Check condition. • Clean, regap or replace if necessary. 		√		
4	* Valves	<ul style="list-style-type: none"> • Check valve clearance. • Adjust if necessary. 	Every 40,000 km			
5	Air filter	<ul style="list-style-type: none"> • Clean or replace if necessary. 		√		
6	Clutch	<ul style="list-style-type: none"> • Check operation. • Adjust or replace cable. 	√	√		
7	* Front brake	<ul style="list-style-type: none"> • Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 6-4.) • Correct accordingly. • Replace brake pads if necessary. 	√	√		√
8	* Rear brake	<ul style="list-style-type: none"> • Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 6-4.) • Correct accordingly. • Replace brake pads if necessary. 	√	√		√
9	* Brake hose	<ul style="list-style-type: none"> • Check for cracks or damage. • Replace if necessary. 		√		√
10	* Wheels	<ul style="list-style-type: none"> • Check balance, runout and for damage. • Rebalance or replace if necessary. 		√		
11	* Tires	<ul style="list-style-type: none"> • Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary. 		√		

PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECKS AND MAINTENANCE JOBS	Initial 1,000 km	Every 10,000 km	Every 20,000 km	Annual check
12	* Wheel bearings	<ul style="list-style-type: none"> • Check bearings for looseness or damage. • Replace if necessary. 		√		
13	* Swingarm	<ul style="list-style-type: none"> • Check swingarm pivoting point for play. • Correct if necessary. • Lubricate with lithium-soap-based grease. 		√		
14	Drive chain	<ul style="list-style-type: none"> • Check chain slack. • Adjust if necessary. Make sure that the rear wheel is properly aligned. • Clean and lubricate. 	Every 1,000 km and after washing the motorcycle or riding in the rain			
15	* Steering bearings	<ul style="list-style-type: none"> • Check bearing play and steering for roughness. • Correct accordingly. 	√	√		
		<ul style="list-style-type: none"> • Lubricate with lithium-soap-based grease. 	Every 24,000 km			
16	* Chassis fasteners	<ul style="list-style-type: none"> • Make sure that all nuts, bolts and screws are properly tightened. • Tighten if necessary. 		√		√
17	Sidestand	<ul style="list-style-type: none"> • Check operation. • Lubricate and repair if necessary. 		√		√
18	* Sidestand switch	<ul style="list-style-type: none"> • Check operation. • Replace if necessary. 	√	√		√
19	* Front fork	<ul style="list-style-type: none"> • Check operation and for oil leakage. • Correct accordingly. 		√		
20	* Rear shock absorber assembly	<ul style="list-style-type: none"> • Check operation and shock absorber for oil leakage. • Replace shock absorber assembly if necessary. 		√		
21	* Rear suspension relay arm and connecting arm pivoting points	<ul style="list-style-type: none"> • Check operation. • Correct if necessary. 		√		
22	* Carburetors	<ul style="list-style-type: none"> • Check engine idling speed, synchronization and starter operation. • Adjust if necessary. 	√	√		√
23	Engine oil	<ul style="list-style-type: none"> • Check oil level and vehicle for oil leakage. • Correct if necessary. • Change. (Warm engine before draining.) 	√	√		√

PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECKS AND MAINTENANCE JOBS	Initial 1,000 km	Every	Every	Annual check
				10,000 km	20,000 km	
24	Engine oil filter cartridge	• Replace.	√		√	
25	* Cooling system	• Check coolant level and vehicle for coolant leakage. • Correct if necessary.		√		√
		• Change coolant.			√	
26	* Front and rear brake switches	• Check operation. • Correct accordingly.	√	√		√
27	Moving parts and cables	• Lubricate if necessary.		√		√
28	* Air induction system	• Check the air cut valve and reed valve for damage. • Replace the entire air induction system if necessary.		√		
29	* Muffler and exhaust pipe	• Check the screw clamp for looseness. • Tighten if necessary.	√	√		
30	* Lights, signals and switches	• Check operation. • Correct if necessary. • Adjust headlight beam if necessary.	√	√		√


* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

EAU03126


NOTE:

- The annual checks must be performed once a year, regardless of the mileage traveled.
- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinder and caliper, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Cowling A
2. Cowling B
3. Panel A



1. Quick fastener screw (× 4)
2. Screw



1. Quick fastener screw (× 4)
2. Screw

Removing and installing cowlings and panels

The cowlings and panels shown above need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a cowling or panel needs to be removed and installed.

EAU01139

Cowling A

To remove the cowling


Loosen the quick fastener screws and remove the screws, and then take the cowling off.

EAU01254

To install the cowling

Place the cowling in the original position, and then tighten the quick fastener screws and install the screws.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Screw
2. Quick fastener screw

EAU01255


Panel A

To remove the panel

Loosen the quick fastener screw and remove the screw, and then take the panel off.

To install the panel

Place the panel in the original position, and then tighten the quick fastener screw and install the screw.




1. Lead connector (× 2)
2. Quick fastener screw (× 2)
3. Screw

EAU01259

Cowling B

To remove the cowling

1. Remove cowling A and panel A.
2. Disconnect the turn signal light lead connectors.
3. Remove the screw, loosen the quick fastener screws, remove the quick fastener at the front of the cowling, and then take the cowling off.





1. Quick fastener

NOTE:

The quick fastener is removed by pushing the center pin in with a screwdriver, then pulling the fastener out.

PERIODIC MAINTENANCE AND MINOR REPAIR



a. Spark plug gap

the engine should have the same color. If any spark plug shows a distinctly different color, the engine could be defective. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the motorcycle. If a spark plug shows signs of electrode erosion and excessive carbon or other deposits, it should be replaced.

To install the cowling

1. Connect the turn signal light lead connectors.
2. Place the cowling in the original position.
3. Install the screw, tighten the quick fastener screws, and then install the quick fastener.

NOTE:

To install the quick fastener, push the center pin out so that it will protrude from the fastener head, insert the fastener into the cowling, and then push the protruding pin in until it is flush with the fastener head.

4. Install the cowling and the panel.

Checking the spark plugs

EAU01880

The spark plugs are important engine components, which should be checked periodically, preferably by a Yamaha dealer. Since heat and deposits will cause any spark plug to slowly erode, they should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.

The porcelain insulator around the center electrode of each spark plug should be a medium-to-light tan (the ideal color when the motorcycle is ridden normally), and all spark plugs installed in

Specified spark plug:
CR9E (NGK) or
U27ESR-N (DENSO)

Before installing a spark plug, the spark plug gap should be measured with a wire thickness gauge and, if necessary, adjusted to specification.

Spark plug gap:
0.7–0.8 mm

PERIODIC MAINTENANCE AND MINOR REPAIR


Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.

Tightening torque:

Spark plug:
12.5 Nm (1.25 m·kg)

NOTE:

If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.



1. Oil level check window
2. Maximum level mark
3. Minimum level mark

EAU01765

Engine oil and oil filter cartridge

The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter cartridge replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

1. Place the motorcycle on a level surface and hold it in an upright position.

NOTE:

Make sure that the motorcycle is positioned straight up when checking the oil level. A slight tilt to the side can result in a false reading.


2. Start the engine, warm it up for several minutes, and then turn it off.
3. Wait a few minutes until the oil settles, and then check the oil level through the check window located at the bottom-right side of the crankcase.

NOTE:

The engine oil should be between the minimum and maximum level marks.

4. If the engine oil is below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Engine oil filler cap

To change the engine oil (with or without oil filter cartridge replacement)


1. Remove cowling A. (See page 6-5 for cowling removal and installation procedures.)



1. Engine oil drain bolt

2. Remove the cowling stay by removing the bolt.
3. Start the engine, warm it up for several minutes, and then turn it off.
4. Place an oil pan under the engine to collect the used oil.
5. Remove the engine oil filler cap and drain bolt to drain the oil from the crankcase.

NOTE: _____
Skip steps 6–8 if the oil filter cartridge is not being replaced.




1. Oil filter wrench
2. Oil filter cartridge

6. Remove the oil filter cartridge with an oil filter wrench.

NOTE: _____
An oil filter wrench is available at a Yamaha dealer.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. O-ring

7. Apply a thin coat of engine oil to the O-ring of the new oil filter cartridge.

NOTE: _____
Make sure that the O-ring is properly seated.



1. Torque wrench

8. Install the new oil filter cartridge, and then tighten it to the specified torque with a torque wrench.

Tightening torque:
Oil filter cartridge:
17 Nm (1.7 m·kg)

9. Install the engine oil drain bolt, and then tighten it to the specified torque.

Tightening torque:
Engine oil drain bolt:
43 Nm (4.3 m·kg)

10. Add the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 8-1.

Oil quantity:

Without oil filter cartridge
replacement:

2.7 L

With oil filter cartridge
replacement:

2.9 L

Total amount (dry engine):

3.6 L

PERIODIC MAINTENANCE AND MINOR REPAIR

EC000072

CAUTION:

- In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives with the oil or use oils of a higher grade than "CD". In addition, do not use oils labeled "ENERGY CONSERVING II" or higher.
- Make sure that no foreign material enters the crankcase.

11. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

NOTE:


After the engine is started, the engine oil level warning light should go off if the oil level is sufficient.

EC000067

CAUTION:

If the oil level warning light flickers or remains on, immediately turn the engine off and have a Yamaha dealer check the vehicle.

12. Turn the engine off, and then check the oil level and correct it if necessary.
13. Install the cowl stay by installing the bolt.
14. Install the cowl.



1. Maximum level mark
2. Minimum level mark

EAU03161

Coolant

To check the coolant level

1. Place the motorcycle on a level surface and hold it in an upright position.

NOTE:

- The coolant level must be checked on a cold engine since the level varies with engine temperature.
- Make sure that the motorcycle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.

PERIODIC MAINTENANCE AND MINOR REPAIR

2. Check the coolant level in the coolant reservoir.

NOTE:

The coolant should be between the minimum and maximum level marks.

3. If the coolant is at or below the minimum level mark, open the reservoir cap, add coolant to the maximum level mark, and then close the reservoir cap.

Coolant reservoir capacity:
0.45 L

EC000080


CAUTION:

- If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine.
- If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the engine may not be sufficiently cooled and the cooling system will not be protected against frost and corrosion.
- If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced.


NOTE:

- The radiator fan is automatically switched on or off according to the coolant temperature in the radiator.
- When the engine is idling with the starter (choke) turned on, the radiator fan will automatically be switched on and off regardless of the coolant temperature, but this does not indicate a malfunction.
- If the engine overheats, see page 6-44 for further instructions.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Coolant reservoir cap
2. Radiator cap



1. Bolt (× 2)
2. Clutch cable holder bolt
4. Remove the radiator cap and coolant reservoir cap.



1. Coolant drain bolt
7. Remove the coolant drain bolt to drain the cooling system.

To change the coolant

EAU01577

1. Place the motorcycle on a level surface and let the engine cool if necessary.
2. Remove cowlings A and B, and panel A. (See pages 6-5 and 6-6 for cowlings and panel removal and installation procedures.)
3. Place a container under the engine to collect the used coolant.

EW000067


WARNING

Never attempt to remove the radiator cap when the engine is hot.

5. Remove the coolant reservoir bolts and the clutch cable holder bolt, and then turn the coolant reservoir upside-down to empty it.
6. Install the coolant reservoir and the clutch cable holder by installing the bolts.

PERIODIC MAINTENANCE AND MINOR REPAIR

EC000080



1. Hose clamp

8. Loosen the radiator hose clamp screw located at the left side of the engine, and then pull off the hose to drain the radiator.
9. After the coolant is completely drained, thoroughly flush the cooling system with clean tap water.
10. Install the coolant drain bolt, and then tighten it to the specified torque.

NOTE:

Check the washer for damage and replace it if necessary.

Tightening torque:

Coolant drain bolt:
7 Nm (0.7 m·kg)

11. Connect the radiator hose, and then tighten the clamp screw.
12. Pour the specified amount of recommended coolant into the radiator and reservoir.

Antifreeze/water mixture ratio:
1:1

Recommended antifreeze:

High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines

Coolant quantity:

Total amount:
2.55 L

Coolant reservoir capacity:
0.45 L


CAUTION:

- If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine.
- If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the engine may not be sufficiently cooled and the cooling system will not be protected against frost and corrosion.
- If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced.

13. Install the radiator cap, start the engine, let it idle for several minutes, and then turn it off.

PERIODIC MAINTENANCE AND MINOR REPAIR

14. Remove the radiator cap to check the coolant level in the radiator. If necessary, add sufficient coolant until it reaches the top of the radiator, and then install the radiator cap.
15. Check the coolant level in the reservoir. If necessary, remove the coolant reservoir cap, add coolant to the maximum level mark, and then install the cap.
16. Start the engine, and then check the vehicle for coolant leakage. If coolant is leaking, have a Yamaha dealer check the cooling system.
17. Install the cowlings and the panel.



1. Bolt (front)
2. Bolt (rear)

EAU03162


Cleaning the air filter element

The air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Clean the air filter element more frequently if you are riding in unusually wet or dusty areas.

1. Remove the rider seat. (See page 3-14 for rider seat removal and installation procedures.)
2. Remove the bolt at the front of the fuel tank and loosen the bolt at the rear.

3. Lift the front of the fuel tank, and then tilt it back and away from the air filter case. (Do not disconnect the fuel hoses!)

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Bolt
2. Screw (× 8)
3. Air filter case cover

EW000071

WARNING

- Make sure that the fuel tank is well supported.
- Do not tilt or pull the fuel tank too much, otherwise the fuel hoses may come loose, which could cause fuel leakage.

4. Remove the air filter case cover by removing the screws and bolt.



5. Pull the air filter element out.
6. Lightly tap the air filter element to remove most of the dust and dirt, and then blow the remaining dirt out with compressed air as shown. If the air filter element is damaged, replace it.
7. Insert the air filter element into the air filter case.

CAUTION:

- Make sure that the air filter element is properly seated in the air filter case.
- The engine should never be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.

8. Install the air filter case cover by installing the screws and bolt.
9. Place the fuel tank in the original position, and then install the bolt at the front and tighten the bolt at the rear.

PERIODIC MAINTENANCE AND MINOR REPAIR

WARNING

EW000072

- Before installing the fuel tank, make sure that the fuel hoses are not damaged. If any fuel hose is damaged, do not start the engine but have a Yamaha dealer replace the hose, otherwise fuel may leak.
- Make sure that the fuel hoses are properly connected and routed, and not pinched.

Adjusting the carburetors

EAU00630

The carburetors are important parts of the engine and require very sophisticated adjustment. Therefore, most carburetor adjustments should be left to a Yamaha dealer, who has the necessary professional knowledge and experience. The adjustment described in the following section, however, may be serviced by the owner as part of routine maintenance.

EC000095

CAUTION:

The carburetors have been set and extensively tested at the Yamaha factory. Changing these settings without sufficient technical knowledge may result in poor performance of or damage to the engine.

Adjusting the engine idling speed

EAU00632


The engine idling speed must be checked and, if necessary, adjusted as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Start the engine and warm it up for several minutes at 1,000–2,000 r/min while occasionally revving it to 4,000–5,000 r/min.

NOTE:

The engine is warm when it quickly responds to the throttle.

PERIODIC MAINTENANCE AND MINOR REPAIR




1. Throttle stop screw

2. Check the engine idling speed and, if necessary, adjust it to specification by turning the throttle stop screw. To increase the engine idling speed, turn the screw in direction (a). To decrease the engine idling speed, turn the screw in direction (b).

Engine idling speed:
1,000–1,100 r/min

NOTE:

If the specified idling speed cannot be obtained as described above, have a Yamaha dealer make the adjustment.



a. Throttle cable free play

Adjusting the throttle cable free play

The throttle cable free play should measure 3–5 mm at the throttle grip. Periodically check the throttle cable free play and, if necessary, have a Yamaha dealer adjust it.

Adjusting the valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

PERIODIC MAINTENANCE AND MINOR REPAIR

Tires

EAU00658

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EW000082

WARNING

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

Tire air pressure (measured on cold tires)		
Load*	Front	Rear
Up to 90 kg*	250 kPa 2.50 kg/cm ² 2.50 bar	250 kPa 2.50 kg/cm ² 2.50 bar
90 kg– maximum*	250 kPa 2.50 kg/cm ² 2.50 bar	290 kPa 2.90 kg/cm ² 2.90 bar
High-speed riding	250 kPa 2.50 kg/cm ² 2.50 bar	250 kPa 2.50 kg/cm ² 2.50 bar

Maximum load*	201 kg
---------------	--------

* Total weight of rider, passenger, cargo and accessories

EWA00012

WARNING


Because loading has an enormous impact on the handling, braking, performance and safety characteristics of your motorcycle, you should keep the following precautions in mind.

- **NEVER OVERLOAD THE MOTORCYCLE!** Operation of an overloaded motorcycle may result in tire damage, loss of control, or severe injury. Make sure

that the total weight of rider, passenger, cargo, and accessories does not exceed the specified maximum load for the vehicle.

- Do not carry along loosely packed items, which can shift during a ride.
- Securely pack the heaviest items close to the center of the motorcycle and distribute the weight evenly on both sides.
- Adjust the suspension and tire air pressure with regard to the load.
- Check the tire condition and air pressure before each ride.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Sidewall
a. Tire tread depth

Tire inspection

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

Minimum tire tread depth (front and rear)	1.6 mm
--	--------


NOTE:

The tire tread depth limits may differ from country to country. Always comply with the local regulations.

EW000079

WARNING

- Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the motorcycle with excessively worn tires decreases riding stability and can lead to loss of control.
- The replacement of all wheel- and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.



1. Tire air valve
2. Valve core
3. Valve cap with seal

Tire information

This motorcycle is equipped with cast wheels and tubeless tires with valves.

PERIODIC MAINTENANCE AND MINOR REPAIR

EW000080

WARNING

- The front and rear tires should be of the same make and design, otherwise the handling characteristics of the motorcycle cannot be guaranteed.
- After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.
- Always make sure that the valve caps are securely installed to prevent air pressure leakage.
- Use only the tire valves and valve cores listed below to avoid tire deflation during a high-speed ride.

FRONT

Manufacturer	Size	Type
Metzeler	120/70 ZR17 (58W)	MEZ3Y Front
Dunlop	120/70 ZR17 (58W)	D207FQ

REAR

Manufacturer	Size	Type
Metzeler	190/50 ZR17 (73W)	MEZ3Y
Dunlop	190/50 ZR17 (73W)	D207N

FRONT & REAR	
Tire air valve	TR412
Valve core	#9000A (original)

EAU00684

WARNING

This motorcycle is fitted with super-high-speed tires. Note the following points in order to make the most efficient use of these tires.

- Use only the specified replacement tires. Other tires may run the danger of bursting at super high speeds.
- Brand-new tires can have a relatively poor grip on certain road surfaces until they have been “broken in”. Therefore, it is advisable before doing any high-speed riding to ride conservatively for approximately 100 km after installing a new tire.
- The tires must be warmed up before a high-speed run.
- Always adjust the tire air pressure according to the operating conditions.


PERIODIC MAINTENANCE AND MINOR REPAIR

Wheels

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends or warpage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.

EAU00687



1. Adjusting bolt
c. Clutch lever free play

EAU01356

Adjusting the clutch lever free play

The clutch lever free play should measure 10–15 mm as shown. Periodically check the clutch lever free play and, if necessary, adjust it as follows.


To increase the clutch lever free play, turn the adjusting bolt at the clutch lever in direction ①. To decrease the clutch lever free play, turn the adjusting bolt in direction ②.

NOTE:


If the specified clutch lever free play cannot be obtained as described above, proceed as follows.

1. Fully turn the adjusting bolt at the clutch lever in direction ① to loosen the clutch cable.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Locknut
2. Adjusting nut



- a. Distance between brake pedal and footrest bracket

Adjusting the brake pedal position


The top of the brake pedal should be positioned approximately 35–40 mm below the bottom of the footrest bracket as shown. Periodically check the brake pedal position and, if necessary, have a Yamaha dealer adjust it.

EAU01357

⚠ WARNING

A soft or spongy feeling in the brake pedal can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Brake light switch
2. Adjusting nut


Adjusting the rear brake light switch

The rear brake light switch, which is activated by the brake pedal, is properly adjusted when the brake light comes on just before braking takes effect. If necessary, adjust the brake light switch as follows.

Turn the adjusting nut while holding the rear brake light switch in place. To make the brake light come on earlier, turn the adjusting nut in direction ①. To make the brake light come on later, turn the adjusting nut in direction ②.

Checking the front and rear brake pads

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.




1. Wear indicator groove


Front brake pads

Each front brake pad is provided with a wear indicator groove, which allows you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator groove. If a brake pad has worn to the point that the wear indicator groove has almost disappeared, have a Yamaha dealer replace the brake pads as a set.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Caliper bolt (× 2)



a. Lining thickness



1. Minimum level mark

Rear brake pads

EAU01248

1. Remove the rear brake caliper by removing the bolts.

2. Check each rear brake pad for damage and measure the lining thickness. If a brake pad is damaged or if the lining thickness is less than 0.5 mm, have a Yamaha dealer replace the brake pads as a set.
3. Install the rear brake caliper by installing the bolts, then tightening them to the specified torque.

Tightening torque:
Brake caliper bolt:
40 Nm (4.0 m·kg)


EAU00731

Checking the brake fluid level

Insufficient brake fluid may allow air to enter the brake system, possibly causing it to become ineffective.

Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake level is low, be sure to check the brake pads for wear and the brake system for leakage.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Minimum level mark

Observe these precautions:

- When checking the fluid level, make sure that the top of the master cylinder is level by turning the handlebars.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking performance.

Recommended brake fluid: DOT 4

- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.

- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.


Changing the brake fluid

EAU00742

Have a Yamaha dealer change the brake fluid at the intervals specified in the periodic maintenance and lubrication chart. In addition, have the oil seals of the brake master cylinders and calipers as well as the brake hoses replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake hoses: Replace every four years.

PERIODIC MAINTENANCE AND MINOR REPAIR



a. Drive chain slack

EAU00744

Drive chain slack

The drive chain slack should be checked before each ride and adjusted if necessary.

To check the drive chain slack

1. Place the motorcycle on a level surface and hold it in an upright position.


NOTE:

When checking and adjusting the drive chain slack, the motorcycle should be positioned straight up and there should be no weight on it.

2. Shift the transmission into the neutral position.
3. Move the rear wheel by pushing the motorcycle to locate the tightest portion of the drive chain, and then measure the drive chain slack as shown.

Drive chain slack:
40–50 mm

4. If the drive chain slack is incorrect, adjust it as follows.



1. Axle nut
2. Adjusting bolt
3. Locknut
4. Alignment marks

EAU01251

To adjust the drive chain slack

1. Loosen the axle nut and the chain puller locknut on each side of the swingarm.
2. To tighten the drive chain, turn the adjusting bolt on each side of the swingarm in direction ①. To loosen the drive chain, turn the adjusting bolt on each side of the swingarm in direction ②, and then push the rear wheel forward.

PERIODIC MAINTENANCE AND MINOR REPAIR

NOTE:

Using the alignment marks on each side of the swingarm, make sure that both chain pullers are in the same position for proper wheel alignment.

EC000096

CAUTION:

Improper drive chain slack will overload the engine as well as other vital parts of the motorcycle and can lead to chain slippage or breakage. To prevent this from occurring, keep the drive chain slack within the specified limits.

3. Tighten the locknuts, and then tighten the axle nut to the specified torque.

Tightening torque:

Axle nut:

150 Nm (15 m·kg)

Lubricating the drive chain

EAU03006

The drive chain must be cleaned and lubricated at the intervals specified in the periodic maintenance and lubrication chart, otherwise it will quickly wear out, especially when riding in dusty or wet areas. Service the drive chain as follows.

EC000097

CAUTION:

The drive chain must be lubricated after washing the motorcycle or riding in the rain.

1. Clean the drive chain with kerosene and a small soft brush.

ECA00053

CAUTION:

To prevent damaging the O-rings, do not clean the drive chain with steam cleaners, high-pressure washers or inappropriate solvents.

2. Wipe the drive chain dry.
3. Thoroughly lubricate the drive chain with a special O-ring chain lubricant.

CAUTION:

Do not use engine oil or any other lubricants for the drive chain, as they may contain substances that could damage the O-rings.

PERIODIC MAINTENANCE AND MINOR REPAIR

Checking and lubricating the cables

EAU02962

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it.

Recommended lubricant:
Engine oil

EW000112

WARNING

Damage to the outer sheath may interfere with proper cable operation and will cause the inner cable to rust. Replace a damaged cable as soon as possible to prevent unsafe conditions.

Checking and lubricating the throttle grip and cable

EAU00773

The operation of the throttle grip and the condition of the throttle cable should be checked before each ride, and the cable should be lubricated or replaced if necessary.

NOTE:

Since the throttle grip must be removed to access the throttle cable end, the throttle grip and the cable should always be lubricated at the same time.

Recommended lubricant:

Throttle cable:


Engine oil

Throttle grip housing and grip:

Lithium-soap-based grease

1. Remove the throttle grip by removing the screws.
2. Disconnect the throttle cable, hold it up, and then apply several drops of oil to the cable end, allowing it to trickle into the sheath.
3. Connect the throttle cable, and then grease the inside of the throttle grip housing.
4. Grease the metal-to-metal contact surface of the throttle grip, and then install the grip by installing the screws.

PERIODIC MAINTENANCE AND MINOR REPAIR




EAU03163

Lubricating the brake pedal

The operation of the brake pedal should be checked before each ride, and the pedal pivot should be lubricated if necessary.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)




EAU03164

Checking and lubricating the brake and clutch levers

The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)



EAU03165

Checking and lubricating the sidestand

The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

EW000113

⚠ WARNING

If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

PERIODIC MAINTENANCE AND MINOR REPAIR

Lubricating the rear suspension

EAU03166

The pivoting points of the rear suspension must be lubricated at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:
Lithium-soap-based grease
(all-purpose grease)

Checking the front fork

EAU02939

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.


To check the condition

EW000115

WARNING

Securely support the motorcycle so that there is no danger of it falling over.

Check the inner tubes for scratches, damage and excessive oil leakage.



To check the operation


1. Place the motorcycle on a level surface and hold it in an upright position.
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.

EC000098

CAUTION:

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.

PERIODIC MAINTENANCE AND MINOR REPAIR



EAU00794

Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place a stand under the engine to raise the front wheel off the ground.

EW000115

! WARNING

Securely support the motorcycle so that there is no danger of it falling over.

2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.

EAU01144

Checking the wheel bearings

The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

PERIODIC MAINTENANCE AND MINOR REPAIR

Battery

EAU01291

EW000116

This motorcycle is equipped with a sealed-type (MF) battery, which does not require any maintenance. There is no need to check the electrolyte or to add distilled water.

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the motorcycle is equipped with optional electrical accessories.

WARNING

- **Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.**
 - **EXTERNAL:** Flush with plenty of water.
 - **INTERNAL:** Drink large quantities of water or milk and immediately call a physician.
 - **EYES:** Flush with water for 15 minutes and seek prompt medical attention.
- **Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.**

- **KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.**

To store the battery


1. If the motorcycle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.
2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
3. Fully charge the battery before installation.
4. After installation, make sure that the battery leads are properly connected to the battery terminals.

PERIODIC MAINTENANCE AND MINOR REPAIR


EC000102

CAUTION:

- Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.
- To charge a sealed-type (MF) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery. If you do not have access to a sealed-type (MF) battery charger, have a Yamaha dealer charge your battery.



1. Headlight fuse
2. Radiator fan fuse
3. Ignition fuse
4. Signaling system fuse
5. Odometer fuse
6. Spare fuse (× 3)



1. Main fuse
2. Spare main fuse

Specified fuses:

Main fuse:	30 A
Headlight fuse:	20 A
Signaling system fuse:	20 A
Radiator fan fuse:	10 A
Ignition fuse:	15 A
Odometer fuse:	10 A

Replacing the fuses

EAU01754

The fuse box is located under the rider seat. (See page 3-14 for rider seat removal and installation procedures.)

If a fuse is blown, replace it as follows.

1. Turn the key to "OFF" and turn off the electrical circuit in question.
2. Remove the blown fuse, and then install a new fuse of the specified amperage.


PERIODIC MAINTENANCE AND MINOR REPAIR

CAUTION:

Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.

3. Turn the key to "ON" and turn on the electrical circuit in question to check if the device operates.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

EC000103




1. Coupler
2. Headlight bulb cover

EAU00826

Replacing the headlight bulb


This motorcycle is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace it as follows.

1. Disconnect the headlight coupler, and then remove the headlight bulb cover.



1. Headlight bulb holder
2. Unhook the headlight bulb holder, and then remove the defective bulb.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Don't touch

EW000119

EC000104

CAUTION:

Take care not to damage the following parts:

- **Headlight bulb**
Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.
- **Headlight lens**
 - Do not affix any type of tinted film or stickers to the headlight lens.
 - Do not use a headlight bulb of a wattage higher than specified.


WARNING

Headlight bulbs get very hot. Therefore, keep flammable products away from a lit headlight bulb, and do not touch the bulb until it has cooled down.


3. Place a new bulb into position, and then secure it with the bulb holder.

4. Install the bulb cover, and then connect the coupler.
5. Have a Yamaha dealer adjust the headlight beam if necessary.


PERIODIC MAINTENANCE AND MINOR REPAIR



1. Tail/brake light bulb cover



1. Socket



1. Screw

Replacing the tail/brake light bulb

EAU01358

1. Remove the passenger seat. (See page 3-14 for passenger seat removal and installation procedures.)
2. Remove the tail/brake light bulb cover.

3. Remove the socket (together with the bulb) by turning it counter-clockwise.
4. Remove the defective bulb by pushing it in and turning it counter-clockwise.
5. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
6. Install the socket (together with the bulb) by turning it clockwise.
7. Install the bulb cover.
8. Install the passenger seat.

Replacing a turn signal light bulb

EAU01095

1. Remove the turn signal light lens by removing the screw.
2. Remove the defective bulb by pushing it in and turning it counter-clockwise.
3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screw.

PERIODIC MAINTENANCE AND MINOR REPAIR

Supporting the motorcycle

EAU01579

Since this model is not equipped with a centerstand, follow these precautions when removing the front and rear wheel or performing other maintenance requiring the motorcycle to stand upright. Check that the motorcycle is in a stable and level position before starting any maintenance. A strong wooden box can be placed under the engine for added stability.

To service the front wheel

1. Stabilize the rear of the motorcycle by using a motorcycle stand or, if an additional motorcycle stand is not available, by placing a jack under the frame in front of the rear wheel.
2. Raise the front wheel off the ground by using a motorcycle stand.

To service the rear wheel

Raise the rear wheel off the ground by using a motorcycle stand or, if a motorcycle stand is not available, by placing a jack either under each side of the frame in front of the rear wheel or under each side of the swingarm.

PERIODIC MAINTENANCE AND MINOR REPAIR

Front wheel

To remove the front wheel


EAU03167

EW000122

WARNING


- It is advisable to have a Yamaha dealer service the wheel.
- Securely support the motorcycle so that there is no danger of it falling over.

1. Remove cowling A. (See page 6-5 for cowling removal and installation procedures.)



1. Wheel axle
2. Pinch bolt

2. Loosen the front wheel axle pinch bolt, then the wheel axle and the brake caliper bolts.
3. Lift the front wheel off the ground according to the procedure on page 6-38.



1. Brake hose holder bolt
2. Caliper bolt (× 2)

4. Remove the brake hose holders on each side by removing the bolts.
5. Remove the brake caliper on each side by removing the bolts.
6. Pull the wheel axle out, and then remove the wheel.

ECA00046

CAUTION:

Do not apply the brake after the brake calipers have been removed, otherwise the brake pads will be forced shut.

PERIODIC MAINTENANCE AND MINOR REPAIR

To install the front wheel

EAU01249

1. Lift the wheel up between the fork legs.
2. Insert the wheel axle.
3. Lower the front wheel so that it is on the ground.
4. Push down hard on the handlebar several times to check for proper fork operation.
5. Install the brake calipers by installing the bolts.

NOTE:

Make sure that there is enough space between the brake pads before installing the brake calipers onto the brake discs.

Tightening torques:

Wheel axle:

72 Nm (7.2 m·kg)

Front wheel axle pinch bolt:

23 Nm (2.3 m·kg)


Brake caliper bolt:

40 Nm (4.0 m·kg)

8. Install the cowling.

6. Install the brake hose holders by installing the bolts.
7. Install the front wheel axle pinch bolt, and then tighten the wheel axle, pinch bolt and brake caliper bolts to the specified torques.

PERIODIC MAINTENANCE AND MINOR REPAIR



1. Axle nut
2. Drive chain adjusting bolt
3. Locknut

EAU01247

Rear wheel


To remove the rear wheel

EW000122


WARNING

- It is advisable to have a Yamaha dealer service the wheel.
- Securely support the motorcycle so that there is no danger of it falling over.

1. Loosen the axle nut and the brake caliper bolts.
2. Lift the rear wheel off the ground according to the procedure on page 6-38.



1. Bolt (× 2)
3. Remove the axle nut and the brake caliper by removing the bolts.
4. Loosen the locknut on each side of the swingarm.
5. Turn the drive chain adjusting bolts fully in direction @.



6. Push the wheel forward, and then remove the drive chain from the rear sprocket.

NOTE:

The drive chain does not need to be disassembled in order to remove and install the rear wheel.

7. Pull the wheel axle out, and then remove the wheel.

ECA00048

CAUTION:

Do not apply the brake after the wheel has been removed together with the brake disc, otherwise the brake pads will be forced shut.

PERIODIC MAINTENANCE AND MINOR REPAIR

To install the rear wheel

EAU01246

1. Install the wheel by inserting the wheel axle.
2. Install the drive chain onto the rear sprocket, and then adjust the drive chain slack. (See page 6-27 for drive chain slack adjustment procedures.)
3. Install the axle nut, and then lower the rear wheel so that it is on the ground.
4. Install the brake caliper by installing the bolts.

NOTE:

Make sure that there is enough space between the brake pads before installing the brake caliper onto the brake disc.

5. Tighten the axle nut and brake caliper bolts to the specified torques.

Tightening torques:

Axle nut:

150 Nm (15.0 m·kg)

Brake caliper bolt:

40 Nm (4.0 m·kg)

Troubleshooting

EAU03087

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

PERIODIC MAINTENANCE AND MINOR REPAIR

Troubleshooting charts

Starting problems or poor engine performance


EAU02990

EW000125


⚠ WARNING

Keep away open flames and do not smoke while checking or working on the fuel system.


1. Fuel




2. Compression



3. Ignition



4. Battery




PERIODIC MAINTENANCE AND MINOR REPAIR

Engine overheating

EW000070


! WARNING

- Do not remove the radiator cap when the engine and radiator are hot. Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.
- After removing the radiator cap retaining bolt, place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.



NOTE:

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.



MOTORCYCLE CARE AND STORAGE

Care	7-1
Storage	7-4

MOTORCYCLE CARE AND STORAGE

EAU03168

Care

While the open design of a motorcycle reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a motorcycle. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your motorcycle looking good, extend its life and optimize its performance.

Before cleaning

1. Cover the muffler outlet with a plastic bag after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug caps, are tightly installed.
3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets, sprockets, the drive chain and wheel axles. Always rinse the dirt and degreaser off with water.

Cleaning

ECA00056

CAUTION:

- **Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.**
- **Improper cleaning can damage windshields, cowlings, panels, other plastic parts, and the muffler. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic. However, if the muffler cannot be thoroughly cleaned with mild detergent, alkaline products and a soft brush may be used.**

MOTORCYCLE CARE AND STORAGE

- Do not use any harsh chemical products on plastic parts or the muffler. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swing-arm bearings, fork and brakes), storage compartments, electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.

- For motorcycles equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

NOTE: Salt sprayed on roads in the winter may remain well into spring.

1. Clean the motorcycle with cold water and a mild detergent, after the engine has cooled down.

ECA00012

CAUTION: Do not use warm water since it increases the corrosive action of the salt.

2. After drying the motorcycle, apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces (except the titanium muffler) to prevent corrosion.

MOTORCYCLE CARE AND STORAGE

Cleaning the titanium muffler

This model is equipped with a titanium muffler, which requires the following special care.

- Use only a soft, clean cloth or sponge with mild detergent and water to clean the titanium muffler. However, if the muffler cannot be thoroughly cleaned with mild detergent, alkaline products and a soft brush may be used.
- Never use compounds or other special treatments to clean the titanium muffler, as they will remove the finish on the outer surface of the muffler.
- Even the smallest amounts of oil, such as from oily towels or fingerprints, will leave stains on the titanium muffler, which can be removed with a mild detergent.
- Note that the thermally induced discoloring of the portion of the exhaust pipe leading into the titanium muffler is normal and cannot be removed.

After cleaning

1. Dry the motorcycle with a chamois or an absorbing cloth.
2. Immediately dry the drive chain and lubricate it to prevent it from rusting.
3. Use a chrome polish to shine chrome, aluminum and stainless-steel parts.
4. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
5. Use spray oil as a universal cleaner to remove any remaining dirt.
6. Touch up minor paint damage caused by stones, etc.
7. Wax all painted surfaces.
8. Let the motorcycle dry completely before storing or covering it.

WARNING

- **Make sure that there is no oil or wax on the brakes or tires.**
- **If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent. Before riding at higher speeds, test the motorcycle's braking performance and cornering behavior.**

EWA00031

MOTORCYCLE CARE AND STORAGE

ECA00013

CAUTION:

- Apply spray oil and wax sparingly and make sure to wipe off any excess.
- Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.
- Avoid using abrasive polishing compounds as they will wear away the paint.

NOTE:

Consult a Yamaha dealer for advice on what products to use.

Storage

Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover.

ECA00014

CAUTION:

- Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.
- To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.

Long-term

Before storing your motorcycle for several months:

1. Follow all the instructions in the "Care" section of this chapter.
2. Drain the carburetor float chambers by loosening the drain bolts; this will prevent fuel deposits from building up. Pour the drained fuel into the fuel tank.
3. For motorcycles equipped with a fuel cock that has an "OFF" position: Turn the fuel cock lever to "OFF".
4. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
5. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion.

MOTORCYCLE CARE AND STORAGE

- a. Remove the spark plug caps and spark plugs.
- b. Pour a teaspoonful of engine oil into each spark plug bore.
- c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
- d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.)
- e. Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.
6. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
7. Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
8. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
9. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place (less than 0 °C or more than 30 °C). For more information on storing the battery, see page 6-33.

NOTE: _____
Make any necessary repairs before storing the motorcycle.

WARNING

To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

EWA00003

SPECIFICATIONS

Specifications	8-1
Conversion table	8-5

SPECIFICATIONS


EAU01038

Specifications

Model	YZF-R1
Dimensions	
Overall length	2,035 mm
Overall width	695 mm
Overall height	1,105 mm
Seat height	815 mm
Wheelbase	1,395 mm
Ground clearance	140 mm
Minimum turning radius	3,400 mm
Basic weight (with oil and full fuel tank)	194 kg
Engine	
Engine type	Liquid-cooled 4-stroke, DOHC
Cylinder arrangement	Forward-inclined parallel 4-cylinder
Displacement	998 cm ³
Bore × stroke	74 × 58 mm
Compression ratio	11.8:1
Starting system	Electric starter
Lubrication system	Wet sump

Engine oil

Type



Recommended engine oil classification

API Service SE, SF, SG or higher

CAUTION:

Be sure to use motor oils that do not contain anti-friction modifiers. Passenger car motor oils (often labeled "Energy Conserving") contain anti-friction additives which will cause clutch and/or starter clutch slippage, resulting in reduced component life and poor engine performance.

Quantity

Without oil filter cartridge replacement	2.7 L
With oil filter cartridge replacement	2.9 L
Total amount (dry engine)	3.6 L

SPECIFICATIONS

Cooling system capacity (total amount)

2.55 L

Air filter

Dry type element

Fuel

Type	Regular unleaded gasoline
Fuel tank capacity	18 L
Fuel reserve amount	3.8 L

Carburetor

Manufacturer	MIKUNI
Model × quantity	BDSR40 × 4

Spark plug

Manufacturer/model	NGK / CR9E or DENSO / U27ESR-N
--------------------	-----------------------------------

Gap	0.7–0.8 mm
-----	------------

Clutch type

Wet, multiple-disc

Transmission

Primary reduction system	Spur gear
Primary reduction ratio	1.581
Secondary reduction system	Chain drive
Secondary reduction ratio	2.688
Number of drive chain sprocket teeth (rear/front)	16/43
Transmission type	Constant mesh 6-speed
Operation	Left foot

Gear ratio

1st	2.500
2nd	1.842
3rd	1.500
4th	1.333
5th	1.200
6th	1.115

Chassis

Frame type	Diamond
Caster angle	24°
Trail	92 mm

Tires

Front

Type	Tubeless
Size	120/70 ZR17 (58 W)
Manufacturer/ model	Metzeler / MEZ3Y Front Dunlop / D207FQ

Rear

Type	Tubeless
Size	190/50 ZR17 (73 W)
Manufacturer/ model	Metzeler / MEZ3Y Dunlop / D207N

SPECIFICATIONS

Maximum load*	201 kg
Tire air pressure (measured on cold tires)	
Up to 90 kg*	
Front	250 kPa (2.50 kg/cm ² , 2.50 bar)
Rear	250 kPa (2.50 kg/cm ² , 2.50 bar)
90 kg–maximum*	
Front	250 kPa (2.50 kg/cm ² , 2.50 bar)
Rear	290 kPa (2.90 kg/cm ² , 2.90 bar)
High-speed riding	
Front	250 kPa (2.50 kg/cm ² , 2.50 bar)
Rear	250 kPa (2.50 kg/cm ² , 2.50 bar)
* Total weight of rider, passenger, cargo and accessories	
Wheels	
Front	
Type	Cast
Size	17 × MT 3.50
Rear	
Type	Cast
Size	17 × MT 6.00
Brakes	
Front	
Type	Dual disc brake
Operation	Right hand
Fluid	DOT 4

Rear	
Type	Single disc brake
Operation	Right foot
Fluid	DOT 4
Suspension	
Front	
Type	Telescopic fork
Rear	
Type	Swingarm (link suspension)
Spring/shock absorber	
Front	Coil spring / oil damper
Rear	Coil spring / gas-oil damper
Wheel travel	
Front	135 mm
Rear	130 mm
Electrical system	
Ignition system	T.C.I. (digital)
Charging system	
Type	A.C. magneto
Standard output	14 V, 365 W@ 5,000 r/min
Battery	
Model	GT12B-4
Voltage, capacity	12 V, 10 Ah
Headlight type	Quartz bulb (halogen)

SPECIFICATIONS

Bulb voltage, wattage × quantity

Headlight	12 V, 60/55 W × 2
Tail/brake light	12 V, 5/21 W × 2
Turn signal light	12 V, 21 W × 4
Auxiliary light	12 V, 5 W × 2
Neutral indicator light	LED
High beam indicator light	LED
Turn signal indicator light	LED
Fuel level warning light	LED
Oil level warning light	LED

Fuses

Main fuse	30 A
Headlight fuse	20 A
Signaling system fuse	20 A
Radiator fan fuse	10 A
Ignition fuse	15 A
Odometer fuse	10 A

SPECIFICATIONS

EAU01064

Conversion table

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Example

METRIC		MULTIPLIER		IMPERIAL
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in

Conversion table

METRIC TO IMPERIAL			
	Metric unit	Multiplier	Imperial unit
Torque	m·kg	7.233	ft·lb
	m·kg	86.794	in·lb
	cm·kg	0.0723	ft·lb
	cm·kg	0.8679	in·lb
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/h	0.6214	mi/h
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume, Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu-in
	L (liter)	0.8799	qt (IMP liq.)
	L (liter)	0.2199	gal (IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade (°C)	9/5 + 32	Fahrenheit (°F)

CONSUMER INFORMATION

Identification numbers	9-1
Key identification number	9-1
Vehicle identification number.....	9-1
Model label	9-2

CONSUMER INFORMATION

EAU01039

Identification numbers


EAU02944

Record the key identification number, vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.

1. KEY IDENTIFICATION NUMBER:

2. VEHICLE IDENTIFICATION NUMBER:

3. MODEL LABEL INFORMATION:




1. Key identification number

EAU01041

Key identification number

The key identification number is stamped into the key tag. Record this number in the space provided and use it for reference when ordering a new key.



1. Vehicle identification number

EAU01043


Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

NOTE:

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.

CONSUMER INFORMATION



1. Model label

EAU03171

Model label

The model label is affixed to the frame under the passenger seat. (See page 3-14 for seat removal and installation procedures.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

INDEX

A

Air filter element, cleaning 6-15
Anti-theft alarm (optional) 3-8

B

Battery 6-33
Brake and clutch levers, checking and lubricating 6-30
Brake fluid, changing 6-26
Brake fluid level, checking 6-25
Brake lever 3-11
Brake pedal 3-11
Brake pedal, lubricating 6-30
Brake pedal position, adjusting 6-23

C

Cables, checking and lubricating 6-29
Carburetors, adjusting 6-17
Care 7-1
Clutch lever 3-10
Clutch lever free play, adjusting 6-22
Controls and instruments 2-3
Conversion table 8-5
Coolant 6-11
 Changing 6-13
 Checking 6-11
Cowlings and panels, removing and installing 6-5

D

Drive chain, lubricating 6-28
Drive chain slack 6-27
 Adjusting 6-27
 Checking 6-27

E

Engine break-in 5-4
Engine idling speed 6-17
Engine oil and oil filter cartridge 6-8
Engine, starting a cold 5-1
Engine, starting a warm 5-3
EXUP system 3-22

F

Front and rear brake pads, checking 6-24
Front and rear suspension settings 3-21
Front fork, adjusting 3-16
Front fork, checking 6-31
Front wheel 6-39
 Installing 6-40
 Removing 6-39
Fuel 3-12
Fuel consumption, tips for reducing 5-4
Fuel tank breather hose 3-13
Fuel tank cap 3-11
Fuses, replacing 6-34

H

Handlebar switches 3-9
 Dimmer switch 3-9
 Engine stop switch 3-9
 Horn switch 3-9
 Light switch 3-9
 Pass switch 3-9
 Start switch 3-10
 Turn signal switch 3-9
Headlight bulb, replacing 6-35
Helmet holders 3-15

I

Identification numbers 9-1
Ignition circuit cut-off system 3-23
Indicator lights 3-2
 Coolant temperature warning light 3-3
 Fuel level warning light 3-2
 High beam indicator light 3-2
 Neutral indicator light 3-2
 Oil level warning light 3-3
 Turn signal indicator light 3-2

K

Key identification number 9-1

L

Left view 2-1
Luggage strap holders 3-22

M

Main switch/steering lock 3-1
Model label 9-2
Motorcycle, supporting 6-38

O

Owner's tool kit 6-1

P

Parking 5-5
Periodic maintenance and lubrication chart 6-2
Pre-operation check list 4-1

INDEX

R

- Rear brake light switch, adjusting 6-24
- Rear suspension, lubricating..... 6-31
- Rear wheel 6-41
 - Installing..... 6-42
 - Removing..... 6-41
- Recommended shift points
(for Switzerland only)..... 5-4
- Right view 2-2

S

- Seats..... 3-14
- Self-diagnosis devices 3-7
- Shifting 5-3
- Shift pedal 3-10
- Shock absorber assembly, adjusting 3-18
- Sidestand 3-23
- Sidestand, checking and lubricating..... 6-30
- Spark plugs, checking 6-7
- Specifications 8-1
- Speedometer unit 3-6
- Starter (choke) lever 3-13
- Steering, checking 6-32
- Storage..... 7-4
- Storage compartment 3-16

T

- Tachometer 3-7
- Tail/brake light bulb, replacing 6-37
- Throttle cable free play, adjusting 6-18
- Throttle grip and cable, checking and
lubricating..... 6-29
- Tires 6-19
- Troubleshooting..... 6-42


- Troubleshooting charts..... 6-43
- Turn signal light bulb, replacing 6-37

V

- Valve clearance, adjusting 6-18
- Vehicle identification number..... 9-1

W

- Wheel bearings, checking 6-32
- Wheels..... 6-22





PRINTED ON RECYCLED PAPER

PRINTED IN JAPAN
99 · 12 - 1.6 × 1 CR
(E)