



7. Apply the sealers and anti-corrosion materials to the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#) .
8. Paint the repair area. Refer to [Basecoat/Clearcoat Paint Systems](#) .
9. Install the windshield. Refer to [Windshield Replacement](#) .
10. Install the liftgate. Refer to [Liftgate Replacement](#) .
11. Install all related panels and components.
12. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
13. Enable the SIR system. Refer to [SIR Disabling and Enabling](#) .