



Horns System Description and Operation

System Description

The horn system consists of the following components:

- F51UA 15A fuse
- Underhood fuse block (contains a non-serviceable PCB Horn relay)
- Horn switch
- Horn
- Body control module (BCM)

System Operation

- The vehicle horn is activated whenever the horn switch is depressed.
- The BCM commands the horns ON under any of the following conditions:
 - When the content theft deterrent system detects a vehicle intrusion—For further information refer to [Content Theft Deterrent \(CTD\) Description and Operation](#) .
 - When the keyless entry system is used to lock the vehicle, a horn chirp may sound to notify the driver that the vehicle has been locked. The notification feature may be enabled or disabled through personalization. For further information refer to [Keyless Entry System Description and Operation](#) .

Circuit Operation

The BCM controls the horn operation, when the horn switch is pressed, it closes a switch pulling the horn signal circuit low. When the BCM detects the drop in voltage in the horn switch signal circuit, it energizes the PCB Horn relay which provides B+ voltage to the horn control circuit, sounding the horn.

When the vehicle is in the Off Power Mode the BCM will attempt to detect a stuck or continuously activated horn switch. When enabled, activation of the horn will be limited to 10 seconds to protect the horn from excessive use.

