


Notice: Refer to [Fastener Notice](#) in the Preface section.



3. Install the rear door trim screws.

Tighten

Tighten the rear door trim screws to 3 N·m (27 lb in).

4. Install the rear door handle cover.
5. Raise the rear window.