



1. Install the rear door frame applique.

Notice: Refer to [Fastener Notice](#) in the Preface section.



2. Install the screws to the rear door frame applique.

Tighten
Tighten the rear door frame applique screws to 1.3 N·m (12 lb in).



3. Install the rear door upper trim panel.