



- 2. Install the plastic trim.
- 3. Install the glass and the frame to the housing.
- 4. Install the shade.
- 5. Install the glass stops.
- 6. Install the shade stops.
- 7. Install the drain nozzles.
- 8. Install the rubber end caps.

Notice: Refer to [Fastener Notice](#) in Cautions and Notices.



- 9. Install the housing to the roof of the vehicle with the bolts.

Tighten
Tighten the sunroof housing bolts to 10 N·m (89 lb in).



- 10. Install the motor control module.
- 11. Install the motor with the screws.

Tighten
Tighten the sunroof motor screws to 3 N·m (27 lb in).

- 12. Connect the electrical connectors.