

Windshield Replacement

Tools Required


- [J 24402-A](#) Glass Sealant Cold Knife Remover
- [J 39032](#) Stationary Glass Removal Tool
- Urethane Adhesive Kit GM P/N 12346392 or Equivalent
- Isopropyl Alcohol or Equivalent
- Cartridge-type Caulking Gun
- Commercial-type Utility Knife
- Razor Blade Scraper
- Suction Cups
- Plastic Paddle

Removal Procedure

Important: Before cutting out a stationary window, apply a double layer of masking tape around the perimeter of the painted surfaces and the interior trim.


1. Open the hood.
2. Remove the windshield wiper arms and blades. Refer to [Wiper Arm Replacement](#) .
3. Remove the air inlet grille. Refer to [Air Inlet Grille Panel Replacement](#) .
4. Remove the interior windshield pillar garnish moldings. Refer to [Windshield Garnish Molding Replacement](#) .
5. Remove the rearview mirror. Refer to [Rearview Mirror Replacement](#) .

Caution: Refer to [Defroster Outlet Caution](#) in Cautions and Notices.



6. Cover the following parts to protect from broken glass:
 - Upper dash pad
 - Defroster outlets and A/C outlets
 - Seats and carpeting

Caution: Refer to [Glass and Sheet Metal Handling Caution](#) in Cautions and Notices.



7. Using a utility knife, carefully cut the exposed reveal molding (1) from the sides and the top edge of the windshield to access the urethane adhesive bead.