


3. Install the upper fascia screws and retainers.


**Tighten**

Tighten the rear upper fascia screws to 2 N·m (18 lb in).

4. Install the tail lamps. Refer to [Tail Lamp Replacement](#)



5. Install the lower fascia retainers.



6. Install the bolts on the rear wheelhouse liner.

**Tighten**

Tighten the rear wheelhouse liner bolts to 4 N·m (36 lb in).