


Rear Door Frame Applique Replacement (C100/Long Body)


Removal Procedure



1. Reposition the weatherstrip in order to access the screws.
2. Remove the screws and the rear side door window frame applique.

Installation Procedure

Notice: Refer to [Fastener Notice](#) in the Preface section.



1. Install the screws and the reart side door window frame applique.

Tighten

Tighten the rear side door window frame applique screws to 1.3 N·m (12 lb in).

2. Install the weatherstrip to its original position.