



Front Bumper Fascia Replacement (C 105/Short Body)

Removal Procedure


Caution: Refer to [Battery Disconnect Caution](#) in the Preface section.



1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Remove the bolts and the retainers from the left and right front wheel well splash shields.



3. Remove the engine shield. Refer to [Engine Shield Replacement](#) .
4. Remove the bolts on the bottom of the left and right front wheel well splash shields.



5. Remove the radiator cover (2).
6. Remove the headlamps (1). Refer to [Headlamp Replacement](#) .
7. Disconnect the connector of the front object sensor wiring harness, if equipped.