



6. Raise the steering column and install the nuts and bolts. Refer to [Steering Column Replacement](#) .
7. Install the bolts securing the left and right sides of the instrument panel.

Tighten

Tighten the bolts on the left and right sides of the instrument panel to 10 N·m (89 lb in).



8. Install the left and right upper instrument panel bolt covers.
9. Install the body control module. Refer to [Body Control Module Replacement](#) .



10. Install the knee bolster. Refer to [Knee Bolster Replacement](#) .
11. Install the instrument panel lower left trim. Refer to [Instrument Panel Lower Trim Panel Replacement - Left Side](#) .
12. Connect the necessary instrument compartment electrical connectors.
13. Install the kick panels.
14. Install the instrument cluster. Refer to [Instrument Cluster Replacement](#) .
15. Install the automatic temperature controls assembly. Refer to [Heater and Air Conditioning Control Replacement](#) .