




20. Cut the applicator nozzle in order to provide a minimum urethane bead of 8 mm (0.31 in) wide and 14 mm (0.55 in) high.



21. Use a cartridge-type caulking gun in order to apply a smooth, continuous bead of urethane adhesive.



22. Use the edge of the window or the inside edge of the reveal molding as a guide for the nozzle in order to apply the urethane adhesive (1) to the inner surface of the window (3).



23. With the aid of an assistant (2), place the window (1) in the opening.