


- 13. Install the instrument panel bolts below the windshield.

**Tighten**

Tighten the instrument panel bolts below the windshield to 23 N·m (17 lb ft).

- 14. Install the A-pillar trim.




- 15. Raise the steering column.
- 16. Connect the steering column electrical connector.
- 17. Install the bolts securing the steering column.

**Tighten**

Tighten the steering column bolts to 22 N·m (16 lb ft).

- 18. Install the headlamp switch. Refer to [Headlamp Switch Replacement](#) .
- 19. Install the wiper/washer switch. Refer to [Windshield Wiper and Washer Switch Replacement](#) .
- 20. Install the steering wheel. Refer to [Steering Wheel Replacement](#) .



- 21. Install the body control module. Refer to [Body Control Module Replacement](#) .
- 22. Install the instrument panel side covers.