



8. Install the front fascia to its original position.
9. Install the bolts securing the front fascia to the fender.

Tighten

Tighten the front fascia-to-fender bolts to 2.5 N·m (22 lb in).

10. Install the front fender liner. Refer to [Fender Liner Replacement](#) .