



- 2. Install the handle by placing into position and sliding rearward ensuring to engage the outside door handle cap.
- 3. Install the outside door handle cap.

Notice: Refer to [Fastener Notice](#) in the Preface section.

- 4. Install the outside door handle screw through door shut face.

Tighten

Tighten the outside door handle screws to 4.5 N·m (40 lb in).

- 5. Install the outside door handle screw cap.
- 6. Install the door water deflector. Refer to [Door Water Deflector Replacement](#) .