


Door Window Guide Replacement (Rear C 100/Long Body)


Removal Procedure



1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Remove the rear door glass. Refer to [Rear Side Door Window Replacement](#) .
3. Remove the power window regulator. Refer to [Door Window Regulator Replacement](#) .
4. Remove the rear door upper trim.
5. Remove the bolt and the nut, rear window guide.

Installation Procedure

Notice: Refer to [Fastener Notice](#) in the Preface section.



1. Install the rear window guide with the bolt and the nut.

Tighten

Tighten the rear windowguide bolt and nut to 10 N·m (89 lb in)

2. Install the rear door upper trim.
3. Install the power window regulator. Refer to [Door Window Regulator Replacement](#) .
4. Install the rear door glass. Refer to [Rear Side Door Window Replacement](#) .
5. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .