



- 13. Install the drain hoses.
- 14. Install the headliner. Refer to [Headlining Trim Panel Replacement](#) .
- 15. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .