



Rear Window Washer Nozzle Replacement

Removal Procedure



1. Remove the liftgate upper applique. Refer to [Liftgate Upper Applique Replacement](#) .
2. Remove the rear wiper nozzle.

Installation Procedure



1. Install the rear wiper nozzle.
2. Install the liftgate upper applique. Refer to [Liftgate Upper Applique Replacement](#) .