



Front Side Door Window Weatherstrip Replacement

Removal Procedure



- 1. Remove the outside rearview mirror. Refer to [Mirror Replacement](#) .
- 2. Remove the front door window weatherstrip.

Installation Procedure



- 1. Install the front door window weatherstrip.
- 2. Install the outside rearview mirror. Refer to [Mirror Replacement](#) .