



- 3. Install the front door trim screws.

Tighten

Tighten the front door trim screws to 3 N·m (27 lb in).

- 4. Install the front door handle cover.
- 5. Raise the front window.