



Sunroof Switch Replacement (C 105/Short Body)

Removal Procedure



1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Pry off the map lamp lens by inserting a taped flat-bladed tool into the recess along the edge of the lens.
3. Remove the screws and the map lamp housing from the headliner.
4. Disconnect the electrical connector.
5. Remove the power sunroof control switch.

Installation Procedure



1. Install the power sunroof control switch.

Notice: Refer to [Fastener Notice](#) in the Preface section.

2. Connect the electrical connector.
3. Install the map lamp housing to the headliner with the screws.

Tighten

Tighten the map lamp housing screw 2 N·m (18 lb in).

4. Press the map lamp lens onto the housing.
5. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .