


# Front Door Opening Weatherstrip Replacement


## Removal Procedure

1. Remove the front door sill plate. Refer to [Front Side Door Sill Plate Replacement](#) .



2. Remove the front door opening weather strip.

## Installation Procedure



1. Install the front door opening weather strip.
2. Install the front door sill plate. Refer to [Front Side Door Sill Plate Replacement](#) .