


11. Install the front fascia to its original position.



12. install the screw (1) securing the front fascia to the fender.

Tighten

Tighten the front fascia-to-fender screw to 2.5 N·m (22 lb in).



13. Install the two fender liner screws.