



# Headlining Trim Panel Replacement (C105/Short Body)

## Removal Procedure




1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Remove the sunroof molding, if equipped.
3. Remove the passenger assist handles. Refer to [Assist Handle Replacement](#) .
4. Remove the dome lamp. Refer to [Dome Lamp Replacement](#) .
5. Remove the sun visors. Refer to [Sunshade Replacement](#) .
6. Remove the power sunroof control switch, if equipped. Refer to [Sunroof Switch Replacement](#) .
7. Remove the windshield garnish molding. Refer to [Windshield Garnish Molding Replacement](#) .
8. Remove the center pillar upper garnish molding. Refer to [Center Pillar Upper Garnish Molding Replacement](#) .
9. Remove the quarter window garnish molding. Refer to [Body Side Window Rear Garnish Molding Replacement](#) .



10. Remove the plastic retainers in the headliner.
11. Recline both front seats.
12. Remove the headliner through a rear door.

## Installation Procedure



1. Recline both front seats.