


2. Install the bolt at the base of the A-pillar.

Tighten

Tighten the A-pillar fender bolt to 10 N·m (89 lb in).



3. Install the bolts at the base of the fender.


Tighten

Tighten the lower fender bolts to 10 N·m (89 lb in).

4. Install the rocker panel molding. Refer to [Rocker Panel Molding Replacement](#) .
5. Install the front fender bolts behind the front fascia.

Tighten

Tighten the front fender bolts to 10 N·m (89 lb in).



6. Install the fender bolts.

Tighten

Tighten the front fender bolts to 10 N·m (89 lb in).

7. Install the fender center molding.