


1. Install the heating mat switch with the screws.

Tighten

Tighten the heating mat switch screws to 2 N·m (18 lb in).

2. Connect the connector and install the rear console cover.

Notice: Refer to [Fastener Notice](#) in Cautions and Notices.



3. Install the rear console box with the screws.

Tighten

Tighten the rear console deposit box screws to 2 N·m (18 lb in).

4. Connect the negative battery cable.