



# Front Side Door Lock Replacement (C100/Long Body)

## Removal Procedure



1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Remove the water deflector. Refer to [Door Water Deflector Replacement](#) .
3. Remove the screws and the front door lock.
4. Disconnect the lock rods.
5. Disconnect the electrical connector.

## Installation Procedure



1. Connect the electrical connector.
2. Connect the lock rods.

**Notice:** Refer to [Fastener Notice](#) in the Preface section.

3. Install the front door lock with the screws.

### Tighten

Tighten the front door lock bolt to 8 N·m (71 lb in).

4. Install the water deflector. Refer to [Door Water Deflector Replacement](#) .
5. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .