



# Instrument Panel Upper Trim Panel Replacement

## Removal Procedure



1. Remove the bolts from the left and right sides of the instrument panel upper I/P trim panel.
2. Remove the upper I/P trim panel from the instrument panel.

## Installation Procedure



1. Position the upper I/P trim panel to the instrument panel .

**Notice:** Refer to [Fastener Notice](#) in Cautions and Notices.

2. Install the bolts securing the sides of the upper I/P trim panel to the instrument panel.

### Tighten

Tighten the upper I/P trim panel bolts to 2 N·m (18 lb in).