


5. Install the lower fascia bolts.

**Tighten**

Tighten the lower fascia bolts to 10 N·m (7 lb ft).

6. Connect the fog lamp electrical connector.  
7. Install the headlamps. Refer to [Headlamp Replacement](#) .



8. Install the bolts on the front wheel well splash shields.

**Tighten**

Tighten the splash shield bolts to 4 N·m (35 lb in).

9. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .