

8. Install the instrument panel left and right side screws (1).


Tighten

Tighten the left and right side instrument panel screws to 2 N·m (18 lb in).

9. Install the instrument panel bolt (2).

Tighten


Tighten the instrument panel bolt to 10 N·m (89 lb in).



10. Install the screws (1) securing the instrument panel center.

Tighten

Tighten the instrument panel center screws to 2 N·m (18 lb in).



11. Install the instrument panel screws (1).

Tighten

Tighten the instrument panel screws to 10 N·m (89 lb in).

12. Install the instrument panel retaining bolt (2).

Tighten

Tighten the instrument panel retaining bolt to 10 N·m (89 lb in).