



Rear Compartment Sill Trim Plate Replacement

Removal Procedure



Remove the floor panel rear extension.

Installation Procedure



Install the floor panel rear extension.