



- 2. Install the handle by placing into position and sliding rearward ensuring to engage the outside door handle.

**Notice:** Refer to [Fastener Notice](#) in the Preface section.

- 3. Install the outside door handle screws.

**Tighten**  
Tighten the outside door handle screws to 4.5 N·m (40 lb in).

- 4. Install the door water deflector. Refer to [Door Water Deflector Replacement](#) .