


Instrument Panel Lower Compartment Replacement

Removal Procedure


1. Remove the instrument panel center trim bezel. Refer to [Instrument Panel Accessory Bezel Replacement](#) .
2. Remove the driver information center bezel. Refer to [Driver Information Display Bezel Replacement](#) .



3. Remove the screws and the instrument panel lower compartment.

Installation Procedure

Notice: Refer to [Fastener Notice](#) in Cautions and Notices.



1. Install the instrument lower compartment with the screws.

Tighten
Tighten the instrument lower compartment with the screws to 2 N·m (18 lb in).

2. Install the instrument panel driver information center bezel. Refer to [Driver Information Display Bezel Replacement](#) .
3. Install the instrument panel center trim bezel. Refer to [Instrument Panel Accessory Bezel Replacement](#) .