


6. Install the bolts at the base of the fender.

Tighten

Tighten the lower fender bolts to 10 N·m (89 lb in).


7. Install the rocker panel molding. Refer to [Rocker Panel Molding Replacement](#) .



8. Install the two fender bolts (1) behind the front fascia.

Tighten

Tighten the two fender bolts to 10 N·m (89 lb in).



9. Reposition the front fascia (3) and install the front fascia to fender bracket (2) to the fender.
10. Install the front fascia to fender bracket bolt (1).

Tighten

Tighten the front fascia bracket to fender bolt to 10 N·m (89 lb in).