


Inside Rearview Mirror Replacement


Removal Procedure

1. Open the door.



2. Using a small flat-bladed tool, remove the rearview mirror from the rearview mirror support and slide it back.

Installation Procedure



1. Install the rearview mirror into the rearview mirror support.

Ensure that the mirror is fully seated.

2. Close the door.