



Steering Column Trim Covers Replacement (C105/Short Body)

Removal Procedure




1. Remove the lower steering column cover panel screw.
2. Turn the steering wheel in order to expose the upper steering column cover panel screws.
3. Remove the upper steering column cover panel screws.
4. Remove the upper steering column cover panel.



5. Remove the lower steering column cover panel from the cluster bezel.

Installation Procedure



1. Install the lower steering column cover panel to the cluster bezel.
2. Install the upper steering column cover panel.