



Rear Side Door Window Weatherstrip Replacement

Removal Procedure



1. Open Door.
2. Remove the rear door window weatherstrip.

Installation Procedure



1. Install the rear door window weatherstrip.
2. Close Door.