



Front Side Door Lock Replacement (C105/Short Body)

Removal Procedure



1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
2. Remove the water deflector. Refer to [Door Water Deflector Replacement](#) .
3. Remove the screws and the front door lock.
4. Disconnect the lock rods.
5. Disconnect the electrical connector.

Installation Procedure



1. Connect the electrical connector.
2. Connect the lock rods.

Notice: Refer to [Fastener Notice](#) in the Preface section.

3. Install the front door lock with the screws.

Tighten

Tighten the front door lock bolt to 8 N·m (71 lb in).

4. Install the water deflector. Refer to [Door Water Deflector Replacement](#) .
5. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .