



1. Secure the front muffler to the rubber hangers.

Notice: Refer to [Fastener Notice](#) in Cautions and Notices.



2. Install the nuts and the gaskets to the both rear muffler pipe flange.

Tighten
Tighten the front muffler-to-rear muffler nuts to 40 N·m (30 lb ft).



3. Install the nuts and gasket to the front muffler pipe-to-UCC.

Tighten
Tighten the front muffler-to-underbody catalytic converter nuts to 30 N·m (22 lb ft).