



- 7. Connect the connector of the rear object sensor, if equipped.
- 8. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .