


# Door Check Link Replacement (C 100/Long Body)


## Removal Procedure

1. Remove the door water deflector. Refer to [Door Water Deflector Replacement](#) .



2. Remove the bolts on the door and on the body.
3. Remove the door hold-open link.

## Installation Procedure



1. Install the door hold-open link to the door and the body with the bolts.

### Tighten

- Tighten the door hold-open link-to-body bolt to 20 N·m (15 lb ft).
- Tighten the door hold-open link-to-door bolts to 9 N·m (80 lb in).

Install the door water deflector. Refer to [Door Water Deflector Replacement](#) .