



Door Weatherstrip Replacement

Removal Procedure




1. Remove the door hold-open link-to-body bolt and the door hold-open link.



2. Remove the door weather strip.

Installation Procedure



1. Install the door weather strip.

Notice: Refer to [Fastener Notice](#) in Cautions and Notices.