


Door Check Link Replacement (C 105/Short Body)

Removal Procedure


1. Remove the door water deflector. Refer to [Door Water Deflector Replacement](#) .



2. Remove the bolts on the door and on the body.
3. Remove the door hold-open link.

Installation Procedure

Notice: Refer to [Fastener Notice](#) in the Preface section.



1. Install the door hold-open link to the door and the body with the bolts.

Tighten

- Tighten the door hold-open link-to-body bolt to 20 N·m (15 lb ft).
 - Tighten the door hold-open link-to-door bolts to 7 N·m (62 lb in).
2. Install the door water deflector. Refer to [Door Water Deflector Replacement](#) .