



3. Install the I/P center trim panel.
4. Connect the negative battery cable.

