



Important: Use care when applying glass prep clear #1 on the window. This primer dries almost instantly, and may stain the viewing area of the window if not applied evenly.

15. Use a new dauber in order to apply glass prep clear #1 to the area approximately 18 mm (0.71 in) around the entire perimeter of the window inner surface.

Immediately wipe the glass primed area using a clean, lint-free cloth.



16. Apply a second coat of the glass prep clear #1 to the same area of the glass.



Important: The glass primer black #2 is effective up to 8 hours after applying it to the glass. The primed surface of the glass must be kept clean.

17. Shake the glass primer black #2 for at least 1 minute.
18. Use a new dauber in order to apply the glass primer black #2 to the same areas (2) that glass prep clear #1 was applied.
19. Allow the glass primer to dry for approximately 10 minutes.