


2. Install the control arm to cradle rear bolts and nuts.
-

Tighten

Tighten the rear bolts and nuts to 70 N·m (52 lb ft).



3. Install the control arm ball joint to the knuckle.
4. Install the nut to the ball joint stud.

Tighten

Tighten the control arm ball joint nut to 10 N·m (89 lb in).

5. Install the cotter pin.
6. Install the front tire and wheel assembly. Refer to [Tire and Wheel Removal and Installation](#) .
7. Lower the vehicle.
-